THE SIMON85 PROJECT

PRINTER85

Pocket Guide

Printer and hardcopy extension for HP-85 BASIC

Option ROM 0241 (octal)
Source: printer85_rom.asm, v0.03b RC1c

An independent HP-85 extension reference

Contents

1 Getting Started 2

2 Commands 2

3 Keyboard Panel 5

Getting Started

PRINTER85 drives external printers and optionally replaces the HP-85's internal COPY and PAPER ADVANCE keys. The ROM does not take over these keys automatically. **EBTKS** Copy the built PRINTER85 option-ROM image (ROM 0241 octal) to the SD-card ROM directory and enable it in CONFIG.TXT. Reboot to load. Connect your printer on HP-IB and use its selected device address in `PRTSET`. **Drivers** Driver 1: HP ThinkJet 2225A in HP control-sequence mode (switch 5 DOWN). Driver 2: SII IFD501/CAPD345A thermal printer. For SII paper cutting, enable the printer's autocutter using its persistent printer configuration software. **First test**

```
PVER
PRTSET 701,2,1,0
PRTSCREEN 701,2,1,0
PRTKEYS 1
```

Replace 701 with the output device code for your own HP-IB printer. Verify the correct HP BASIC device code in your configuration before printing.

Commands

PVER

`PVER`

Displays the installed PRINTER85 version string.

`PVER`

PRTSCREEN

```
PRTSCREEN device,driver[,zoom[,orientation]]
```

Prints the current HP-85 CRT image using the specified device and printer driver. One-shot operation; does not change the stored COPY profile.

```
PRTSCREEN 701,2,1,0
```

PRTSET

```
PRTSET device,driver[,zoom[,orientation]]
```

Stores the printer/device, driver, hardcopy zoom and orientation used by physical COPY/PAPER and text-style controls.

```
PRTSET 701,1,2,0
```

PRTKEYS

```
PRTKEYS mode
```

With 1, enables the replacement COPY/PAPER keys and native K1–K8 printer panel. With 0, restores the previous keyboard handling and key labels.

```
PRTKEYS 1
```

PRTPITCH

```
PRTPITCH pitch
```

Sets text pitch: 0 normal, 1 expanded, 2 compressed, 3 expanded-compressed. Requires a configured printer profile.

```
PRTPITCH 2
```

PRTLPI

```
PRTLPI lines
```

Sets vertical text spacing to 6 or 8 lines per inch on the configured printer.

```
PRTLPI 8
```

PRTBOLD

```
PRTBOLD mode
```

Enables (1) or disables (0) bold text on the configured printer.

```
PRTBOLD 1
```

PRTUNDER

```
PRTUNDER mode
```

Enables (1) or disables (0) underlined text.

```
PRTUNDER 1
```

PRTNORM

```
PRTNORM
```

Resets common text styles: normal pitch, 6 lines per inch, bold and underline off.

```
PRTNORM
```

PRTZOOM

```
PRTZOOM zoom
```

Changes the stored COPY enlargement. Values 1 or 2 for supported printers, and 4 where supported by ThinkJet.

```
PRTZOOM 2
```

PRTORIENT

```
PRTORIENT orientation
```

Sets stored COPY orientation: 0 portrait, 1 clockwise landscape, subject to driver capability.

```
PRTORIENT 0
```

Keyboard Panel

After `PRTSET` and `PRTKEYS 1`, COPY sends a text or graphics hardcopy based on the current screen mode. PAPER ADVANCE feeds paper.

K1	Text pitch
K2	Bold
K3	COPY zoom
K4	Previous panel
K5	Lines per inch
K6	Underline
K7	COPY orientation
K8	Next panel

On the SII autocutter-equipped printer, **SHIFT+PAPER ADVANCE** performs a cut when the device autocutter is enabled. On ThinkJet it performs form feed.

PRTKEYS and CPM85 both need keyboard ownership; use PRTKEYS 0 before entering CPM85 keyboard mode.