EU Data Act

List of Continuous Data

Date: 24.07.2026
Version: 1.0.6

Summary of changes:

Version	*Date:*	*Description*
1.0.0	*11.09.2025*	*Initial Version*
1.0.6	*24.07.2026*	*Updated Data*

About this document

This document helps users understand the continuous data available through the EU Data Act portal.
- Each data point is identified by a “Key”, which serves as its unique identifier
- The “Data Point Name” is the descriptive name of the data point. It may appear multiple times in the Data Dictionary
- The “Description” explains what the data point represents
- The “Measurement Unit” specifies how the data point is measured
- The “Data Type” indicates the format or type of data used for the data point
- The "Data Cluster" comprises data points that are closely related thematically or contextually

How to read this document

This document is an extract from different systems and may therefore contain duplicates in the "Data Point Name" column.

Key	Data Point Name	Description	Measurement Unit	Tech. Data Type	Data Cluster
97b0bc0f-e29d-3530-976f-1e2c26ccd4ee	rearRow1SystemActivationSwitch	current state of rear system activation		string	Infotainment Related Data
19ec0834-f150-3c73-b8c4-7069e2f79df1	remainingChargeTimeComplete	estimated time of charging to reach the 100% SOC (EV vehicle must be connected to charger)	min	int	Charging
cf28f7d9-6201-30b8-82e5-a461968d30dc	remaining_charging_time	Charging time left	min	int	All Data, Charging
8a188a0b-24ea-34a9-9d6b-ed089547a128	remaining_charging_time_target_soc	Charging time left to reach target state of charge	'-	String	All Data, Charging
a70fa341-4097-3e93-8500-b802a292bb0b	remaining_climate_time	how long the AC will started. Normally AC will 30 minutes started but it could be different value depend of target temperature, inside temperature, energy, ... IMPORTANT-> There is not countdown in STK. The information will provide after starting AC		string	All Data, Climatisation and Heating

0f3fab0c-afdd-366c-8128-4fa9ac7363e0	remaining_climate_time	how long the AC will started. Normally AC will 30 minutes started but it could be different value depend of target temperature, inside temperature, energy, ... IMPORTANT-> There is not countdown in STK. The information will provide after starting AC		string	All Data, Climatisation and Heating
3c19831c-38b8-3dc5-9ead-bb333616d925	remaining_climate_time	how long the AC will started. Normally AC will 30 minutes started but it could be different value depend of target temperature, inside temperature, energy, ... IMPORTANT-> There is not countdown in STK. The information will provide after starting AC		string	All Data, Climatisation and Heating
1c62bf0a-8088-332c-9399-3b8cb0573099	remaining_climatisation_time	Remaining time for which climatisations will run	min	int	All Data, Climatisation and Heating

6f7f6a6d-b459-3930-bec5-7ac450dab69d	remaining_time_finished.remaining_time_finished_unit	Unit of remaining time finished. Possible values: TIME_UNIT_UNDEFINED, TIME_UNIT_MILLISECONDS, TIME_UNIT_SECONDS, TIME_UNIT_MINUTES, TIME_UNIT_HOURS, TIME_UNIT_DAYS, TIME_UNIT_MONTHS, TIME_UNIT_YEARS		enum	All Data
0901e6d5-9c06-39a2-bfab-dd9338c60352	remaining_time_finished.remaining_time_finished_value	Value of remaining time finished		int	All Data
399637c2-b835-3b09-b0ab-0e80b5c4dcc7	report_type	The enum value of "report type"		enum	All Data
d52106b4-84aa-39da-8e13-124f07d1204d	report_type	The enum value of "report type"		enum	All Data
76bcb7e5-f11e-363c-aa6c-f30212c7ec2c	report_type	The enum value of "report type"		enum	All Data
af3b7b12-f0bc-343e-8bdb-55ad510281c1	report_type	The enum value of "report type"		enum	All Data
12a65441-a5a5-3a5f-a854-0a9b23abb622	report_type	The enum value of "report type"		enum	All Data
90abf54e-39cd-3faf-b695-e3d7520c427e	report_type	The enum value of "report type"		enum	All Data
3dc12462-4854-3c9e-8428-a61d7c1c3297	report_type	The enum value of "report type"		enum	All Data
c2997ad6-04cb-3c80-880c-f13d518448ca	report_type	The enum value of "report type"		enum	All Data

50f3e0ce-42c0-30cc-becd-fa6f4fe00a25	report_type	The enum value of "report type"		enum	All Data
23380833-5427-3e28-ad47-e7597f3cd047	report_type	The enum value of "report type"		enum	All Data
eca5d171-d3d3-3a73-936d-0c6b51997062	report_type	The enum value of "report type"		enum	All Data
4cf0ff03-1290-3e50-afd9-027970915a67	report_type	The enum value of "report type"		enum	All Data
929a4fa9-08b0-38c7-866d-65b9b150bfc8	report_type	The enum value of "report type"		enum	All Data
481ad2e2-4de7-3352-a2ee-bcfbf22aefc8	report_type	The enum value of "report type"		enum	All Data
43f1360c-94ca-3c19-966f-f241f558acf2	residualEnergyInPercent	information about residual energy	(%)	int	Charging
6b92ffc9-aa49-339f-b27c-c408128a6ea3	result_app	The enum value of "result app"		enum	All Data
5ae09324-0a14-37e7-8506-2e93c6a882b1	result_master	The enum value of "result master"		enum	All Data
d13c7380-2f04-3892-8daa-cc6e18364267	safe	Safe status		boolean	All Data
96dbae8b-1ab7-32f5-9a9b-229c45d4b43f	safe	Safe status		boolean	All Data
940aad2a-eb21-3e5c-b0c6-8ff4b395f917	safe_state_front_engine_bonnet	Indicates the state of the engine bonnet is unsupported (0) or invalid(1) or unsafe (3)	'-	int	All Data, Vehicle Access
3611b9e7-c6f3-39ef-b700-1f650dde7979	safe_state_front_right_door	Indicates the state of the front right door unsupported (0) or invalid(1) or safe (2) or unsafe (3)	'-	int	All Data, Vehicle Access

d5e199c6-cdd5-31c3-b3d1-915c78662521	safe_state_rear_left_door	Indicates the state of the rear left door unsupported (0) or invalid(1) or safe (2) or unsafe (3)	'-	int	All Data, Vehicle Access
1416247c-df11-3685-b839-65d87cf97bcb	safe_state_rear_right_door	Indicates the state of the rear right door unsupported (0) or invalid(1) or safe (2) or unsafe (3)	'-	int	All Data, Vehicle Access
92346806-a547-3014-b291-476c90558e53	safe_state_tailgate	Indicates the state of the tailgate unsupported (0) or invalid(1) or unsafe (3)	'-	int	All Data, Vehicle Access
dab203bd-75b3-3fe0-9be1-b401611e493d	save_to_package_frequency	The int value of "save to package frequency"		int	All Data
3c691e30-8c0e-3d8a-be41-7d2b770aeada	scope_potential_total	This TSS-ID is only interpreted byÂ zFDIÂ for vehicles ofÂ PPEÂ platform!	'-	'-	All Data, Dashboard Measurements
f17c58f9-8763-3cd3-9cc6-c34e74482308	scr_number_of_engine_starts	Number of engine starts for the vehicle <=13 number of restarts, ==14 driveability, ==15 no_driveability	'-	int	All Data
b43ff74c-2505-3a38-bf98-78c817fbaf96	scr_range	Range for SCR (Selective Catalytic Reduction) in km	km	int	All Data, Dashboard Measurements
e350912d-df4d-3b25-923e-97ca8534493c	second_active_consumer_	This TSS-ID is only interpreted by zFDI for vehicles of PPE platform!	'-	'-	All Data, Dashboard Measurements

ce16f6c8-f565-3f9a-bddd-4acd12a41741	secondaryEngineBatteryStateOfChargeIndication	secondary engine battery state of charge	%	int	Charging
9fd85a95-d058-37f8-a072-7876690c529d	secondaryEnginePowermeterIndication	relative expression of the current electric power including charge/recuperation information	kW	int	Vehicle Status
7263649c-a967-39f7-97fd-54f718d97ec5	second_energy_saving_hints_amount_	This TSS-ID is only interpreted by zFDI for vehicles of PPE platform!	'-	'-	All Data, Dashboard Measurements
6b8815d7-5e36-3584-93cb-9ca6cdc34052	send_package_frequency	The int value of "send package frequency"		int	All Data
6f1ce7e0-63a2-3ad8-a88c-35619db67c20	send_package_frequency	The int value of "send package frequency"		int	All Data
0b091342-e54a-3231-9306-5e9906cb1146	send_package_frequency	The int value of "send package frequency"		int	All Data
4b200d44-18ec-33f4-9829-4d88ae0da929	service_key_data	The string value of "service key data"		string	All Data
532d5bbe-e4bf-3066-b418-9dc23cba9edc	service_key_data	The string value of "service key data"		string	All Data
7962e708-7036-39e2-9858-39bf79952a1c	service_key_data_state	Possible states of the ServiceKey VALID = 0; OUTDATED = 1; INVALID = 2;		enum	All Data
bbc05645-e6b9-3478-b1da-193506a42bb8	service_key_data_state	The enum value of "service key data state"		enum	All Data

6d8ee5c9-f895-3c0a-946b-1247f03554b5	service_level.[*]	The values of: "service level.[0]". Note that [*] in the key is replaced by a number.. The values of: "service level.[0]". Note that [*] in the key is replaced by a number.		string	All Data
dd051740-a8a4-3a17-b5d3-eecc2fcc4b51	service_level.[*]	The values of: "service level.[0]". Note that [*] in the key is replaced by a number.. The values of: "service level.[0]". Note that [*] in the key is replaced by a number.		string	All Data
26bfafa1-4494-384b-a3f8-8f294ad041fa	service_maintenances.[*].due_in_distance.current_value	The values of: "service maintenances" & "due in distance.current value". Note that [*] in the key is replaced by a number.. The values of: "service maintenances" & "due in distance.current value". Note that [*] in the key is replaced by a number.		int	All Data, Maintenance Related Information

4fe86875-6953-3114-aadc-b0f1db501b97	service_maintenances.[*].due_in_distance.current_value	Contains the current active value. Additional properties defining this property are contained in this resource. Definition for values referenced from the properties "dueInDistance" or "dueInTime": - Positive values shall be used for the distance or time UNTIL the vehicle maintenance due-date. - Negative values shall be used for the distance or time FOR the vehicle maintenance duedate.. The values of: "service maintenances" & "due in distance.current value". Note that [*] in the key is replaced by a number.		int	All Data, Maintenance Related Information

50aef9c4-e776-36fb-93f4-9a518be5ebd9	service_maintenances.[*].due_in_distance.max_value	The values of: "service maintenances" & "due in distance.max value". Note that [*] in the key is replaced by a number.. The values of: "service maintenances" & "due in distance.max value". Note that [*] in the key is replaced by a number.		int	All Data, Maintenance Related Information
6267706b-a3f7-39fb-ab7d-ecd6365270f7	service_maintenances.[*].due_in_distance.min_value	The values of: "service maintenances" & "due in distance.min value". Note that [*] in the key is replaced by a number.. The values of: "service maintenances" & "due in distance.min value". Note that [*] in the key is replaced by a number.		int	All Data, Maintenance Related Information

e9a7ffa8-fc7f-3381-8b78-bee347fd9723	service_maintenances.[*].due_in_distance.resolution	The values of: "service maintenances" & "due in distance.resolution". Note that [*] in the key is replaced by a number.. The values of: "service maintenances" & "due in distance.resolution". Note that [*] in the key is replaced by a number.		int	All Data, Maintenance Related Information
a16581ad-ec06-3a6a-a385-5675dfff569c	service_maintenances.[*].due_in_distance.restriction_reason	The values of: "service maintenances" & "due in distance.restriction reason". Note that [*] in the key is replaced by a number.. The values of: "service maintenances" & "due in distance.restriction reason". Note that [*] in the key is replaced by a number.		enum	All Data, Maintenance Related Information

d6c12995-1481-3f84-9c47-8a6e9426f7b8	service_maintenances.[*].due_in_distance.state	Possible values: INVALID, VALID, UNSUPPORTED, ERROR. The values of: "service maintenances" & "due in distance.state". Note that [*] in the key is replaced by a number.		enum	All Data, Maintenance Related Information
8fd81f9d-4341-3f55-aeff-7179b2feefe8	service_maintenances.[*].due_in_distance.unit	The values of: "service maintenances" & "due in distance.unit". Note that [*] in the key is replaced by a number.. The values of: "service maintenances" & "due in distance.unit". Note that [*] in the key is replaced by a number.		enum	All Data, Maintenance Related Information
161e93ac-1fc3-363f-a679-d90454ec8fb2	service_maintenances.[*].due_in_distance.unit	Possible values: UNIT_INVALID = 0; UNIT_TIME_DAY = 0; UNIT_DISTANCE_KM = 1; UNIT_DISTANCE_MILES = 2;. The values of: "service maintenances" & "due in distance.unit". Note that [*] in the key is replaced by a number.		enum	All Data, Maintenance Related Information

c6dcfb6c-cd04-3ff7-bfbb-d2f7c6b7ecd9	service_maintenances.[*].due_in_distance.universal_unique_id	The values of: "service maintenances" & "due in distance.universal unique ID". Note that [*] in the key is replaced by a number.. The values of: "service maintenances" & "due in distance.universal unique ID". Note that [*] in the key is replaced by a number.		string	All Data, Maintenance Related Information
d08c771e-0beb-3daf-8d24-49a5bb56e93c	service_maintenances.[*].due_in_time.current_value	The values of: "service maintenances" & "due in time.current value". Note that [*] in the key is replaced by a number.. The values of: "service maintenances" & "due in time.current value". Note that [*] in the key is replaced by a number.		int	All Data, Maintenance Related Information

9d2ccdae-d0b7-32f8-a5ca-011dfb6fccb3	service_maintenances.[*].due_in_time.current_value	Contains the current active value. Additional properties defining this property are contained in this resource. Definition for values referenced from the properties "dueInDistance" or "dueInTime": - Positive values shall be used for the distance or time UNTIL the vehicle maintenance due-date. - Negative values shall be used for the distance or time FOR the vehicle maintenance duedate.. The values of: "service maintenances" & "due in time.current value". Note that [*] in the key is replaced by a number.		int	All Data, Maintenance Related Information

bc9abfe6-c2c4-38c3-8baf-7eb3a98b1d48	service_maintenances.[*].due_in_time.max_value	The values of: "service maintenances" & "due in time.max value". Note that [*] in the key is replaced by a number.. The values of: "service maintenances" & "due in time.max value". Note that [*] in the key is replaced by a number.		int	All Data, Maintenance Related Information
8cb292eb-837a-3f55-b52f-395b2ee3f840	service_maintenances.[*].due_in_time.min_value	The values of: "service maintenances" & "due in time.min value". Note that [*] in the key is replaced by a number.. The values of: "service maintenances" & "due in time.min value". Note that [*] in the key is replaced by a number.		int	All Data, Maintenance Related Information
6acddf3f-022d-3fbb-a57f-59f6c3c100b2	service_maintenances.[*].due_in_time.resolution	The values of: "service maintenances" & "due in time.resolution". Note that [*] in the key is replaced by a number.. The values of: "service maintenances" & "due in time.resolution". Note that [*] in the key is replaced by a number.		int	All Data, Maintenance Related Information

051b79de-e25f-37ee-b4ae-8a40c447542b	service_maintenances.[*].due_in_time.restriction_reason	The values of: "service maintenances" & "due in time.restriction reason". Note that [*] in the key is replaced by a number.. The values of: "service maintenances" & "due in time.restriction reason". Note that [*] in the key is replaced by a number.		enum	All Data, Maintenance Related Information
46f7512d-02df-39e2-bde4-34b22dc682f2	service_maintenances.[*].due_in_time.state	Possible values: INVALID, VALID, UNSUPPORTED, ERROR. The values of: "service maintenances" & "due in time.state". Note that [*] in the key is replaced by a number.		enum	All Data, Maintenance Related Information
13f500a4-6eda-3e4e-83c1-a601845888a0	service_maintenances.[*].due_in_time.unit	The values of: "service maintenances" & "due in time.unit". Note that [*] in the key is replaced by a number.. The values of: "service maintenances" & "due in time.unit". Note that [*] in the key is replaced by a number.		enum	All Data, Maintenance Related Information

d40230e3-5627-313f-b6b3-d7274e63f3bc	service_maintenances.[*].due_in_time.unit	Possible values: UNIT_INVALID = 0; UNIT_TIME_DAY = 0; UNIT_DISTANCE_KM = 1; UNIT_DISTANCE_MILES = 2;. The values of: "service maintenances" & "due in time.unit". Note that [*] in the key is replaced by a number.		enum	All Data, Maintenance Related Information
7dde9d79-9085-395a-b51f-97b4248fa792	service_maintenances.[*].due_in_time.universal_unique_id	The values of: "service maintenances" & "due in time.universal unique ID". Note that [*] in the key is replaced by a number.. The values of: "service maintenances" & "due in time.universal unique ID". Note that [*] in the key is replaced by a number.		string	All Data, Maintenance Related Information
57a100c5-94b2-385b-a82d-d30e57e01c5b	service_maintenances.[*].service_type	The values of: "service maintenances" & "service type". Note that [*] in the key is replaced by a number.. The values of: "service maintenances" & "service type". Note that [*] in the key is replaced by a number.		enum	All Data, Maintenance Related Information

d61f9690-3d27-3865-8b8f-025093cdc640	service_maintenances.[*].service_type	Contains the type of vehicle service. Unique identifier of the element. SERVICE_TYPE_INSPECTION = 0; SERVICE_TYPE_OIL = 1;. The values of: "service maintenances" & "service type". Note that [*] in the key is replaced by a number.		enum	All Data, Maintenance Related Information
63867bab-f3a4-3065-be67-009066c25572	setting.bcam_activation	Possible values: BCAM_ACTIVATION_INVALID, BCAM_ACTIVATION_ACTIVATED, BCAM_ACTIVATION_DEACTIVATED		enum	All Data
5a0b50dc-7e9d-3507-a1c3-d74a066fbf2c	setting.bcam_activation	Possible values: BCAM_ACTIVATION_INVALID, BCAM_ACTIVATION_ACTIVATED, BCAM_ACTIVATION_DEACTIVATED		enum	All Data
90bf5833-6b80-3517-8b6b-6eee0abc1076	setting_climatisation_at_unlock	Is short conditioning enabled	'-	String	All Data, Climatisation and Heating
4fd43a40-7cb4-32c4-bb6b-9b59a2a82975	setting_mirror_heating_enabled	Is glass surface heating active at the moment	'-	String	All Data, Climatisation and Heating

2d7b0796-dc72-343d-b69f-4789bc0fcff2	settings.auto_unlock_ac	AUTO_UNLOCK_AC_INVALID, AUTO_UNLOCK_AC_OFF, AUTO_UNLOCK_AC_PERMANENT, AUTO_UNLOCK_AC_ONCE		enum	All Data
02c331b7-9264-31bf-8e96-5f9da0571f5e	settings.auto_unlock_ac	AUTO_UNLOCK_AC_INVALID, AUTO_UNLOCK_AC_OFF, AUTO_UNLOCK_AC_PERMANENT, AUTO_UNLOCK_AC_ONCE		enum	All Data
1b8eac85-e1ec-3580-b258-a73eec076582	settings.auto_unlock_ac	AUTO_UNLOCK_AC_INVALID, AUTO_UNLOCK_AC_OFF, AUTO_UNLOCK_AC_PERMANENT, AUTO_UNLOCK_AC_ONCE		enum	All Data
329a9e8a-2b8b-3efa-b03e-2d97c73f6db2	settings.auto_unlock_ac	AUTO_UNLOCK_AC_INVALID, AUTO_UNLOCK_AC_OFF, AUTO_UNLOCK_AC_PERMANENT, AUTO_UNLOCK_AC_ONCE		enum	All Data

53975124-320c-3a72-813a-8564f594850e	settings.charge_mode_selection	CHARGE_MODE_SELECTION_INVALID, CHARGE_MODE_SELECTION_TIMERCHARGING, CHARGE_MODE_SELECTION_IMMEDIATECHARGING, CHARGE_MODE_SELECTION_TIMER_CHARGING_CLIMATIZATION, CHARGE_MODE_SELECTION_PREFERRED_CHARGING_TIMES,CHARGE_MODE_SELECTION_ONLY_OWN_CURRENT, CHARGE_MODE_SELECTION_IMMEDIATE_DISCHARGING, CHARGE_MODE_SELECTION_HOME_STORAGE_CHARGING		enum	All Data

9905c311-6620-31ae-9b36-24e1c14edb6f	settings.charge_mode_selection	CHARGE_MODE_SELECTION_INVALID, CHARGE_MODE_SELECTION_TIMERCHARGING, CHARGE_MODE_SELECTION_IMMEDIATECHARGING, CHARGE_MODE_SELECTION_TIMER_CHARGING_CLIMATIZATION, CHARGE_MODE_SELECTION_PREFERRED_CHARGING_TIMES,CHARGE_MODE_SELECTION_ONLY_OWN_CURRENT, CHARGE_MODE_SELECTION_IMMEDIATE_DISCHARGING, CHARGE_MODE_SELECTION_HOME_STORAGE_CHARGING		enum	All Data

c02b446e-32c8-35b0-a9e3-976e0c3fde77	settings.charge_mode_selection	CHARGE_MODE_SELECTION_INVALID, CHARGE_MODE_SELECTION_TIMERCHARGING, CHARGE_MODE_SELECTION_IMMEDIATECHARGING, CHARGE_MODE_SELECTION_TIMER_CHARGING_CLIMATIZATION, CHARGE_MODE_SELECTION_PREFERRED_CHARGING_TIMES,CHARGE_MODE_SELECTION_ONLY_OWN_CURRENT, CHARGE_MODE_SELECTION_IMMEDIATE_DISCHARGING, CHARGE_MODE_SELECTION_HOME_STORAGE_CHARGING		enum	All Data

faffdf9f-7d7b-3624-b50e-8c68ea84f147	settings.charge_mode_selection	CHARGE_MODE_SELECTION_INVALID, CHARGE_MODE_SELECTION_TIMERCHARGING, CHARGE_MODE_SELECTION_IMMEDIATECHARGING, CHARGE_MODE_SELECTION_TIMER_CHARGING_CLIMATIZATION, CHARGE_MODE_SELECTION_PREFERRED_CHARGING_TIMES,CHARGE_MODE_SELECTION_ONLY_OWN_CURRENT, CHARGE_MODE_SELECTION_IMMEDIATE_DISCHARGING, CHARGE_MODE_SELECTION_HOME_STORAGE_CHARGING		enum	All Data
0387de65-ce87-3750-b9d7-906687095200	settings.max_charge_current_ac	MAX_CHARGE_CURRENT_INVALID, MAX_CHARGE_CURRENT_REDUCED, MAX_CHARGE_CURRENT_MAXIMUM		enum	All Data

63e08d24-de2e-39a1-9d43-0c55117fcbfd	settings.max_charge_current_ac	MAX_CHARGE_CURRENT_INVALID, MAX_CHARGE_CURRENT_REDUCED, MAX_CHARGE_CURRENT_MAXIMUM		enum	All Data
6720ab6e-7cda-3e2e-91d0-c7c31938186e	settings.max_charge_current_ac	MAX_CHARGE_CURRENT_INVALID, MAX_CHARGE_CURRENT_REDUCED, MAX_CHARGE_CURRENT_MAXIMUM		enum	All Data
9ddba49e-265b-31c9-935a-67df986229a4	settings.max_charge_current_ac	MAX_CHARGE_CURRENT_INVALID, MAX_CHARGE_CURRENT_REDUCED, MAX_CHARGE_CURRENT_MAXIMUM		enum	All Data
d6758408-804a-3b5f-a727-cc15e8c8c9c9	settings.target_range	The charging will be completed in the defined range. Range from 0 to 1500 Km		int	All Data
4cbb8675-98df-3810-a8ec-041161cbd56c	settings.target_range	The charging will be completed in the defined range. Range from 0 to 1500 Km		int	All Data
c9d71993-64ae-3dea-b8c5-00636c4cc23f	settings.target_range	The charging will be completed in the defined range. Range from 0 to 1500 Km		int	All Data

186e848c-af47-31d1-83a4-217784702454	settings.target_range	The charging will be completed in the defined range. Range from 0 to 1500 Km		int	All Data
b3b04f31-b10e-38aa-b8ad-c0da7c06caea	settings.target_soc	Possible values in SCMC 10-100. The charging will be completed in the defined SOC		int	All Data
e21d4d25-98bc-3016-a234-1ad061cc313b	settings.target_soc	Possible values in SCMC 10-100. The charging will be completed in the defined SOC		int	All Data
86140011-db48-30c8-8172-30a90b39006e	settings.target_soc	Possible values in SCMC 10-100. The charging will be completed in the defined SOC		int	All Data
76acaa98-37ef-3466-b013-21c77ed343ae	settings.target_soc	Possible values in SCMC 10-100. The charging will be completed in the defined SOC		int	All Data
769ec6f6-6223-3419-b3b8-8d0a935d771f	setting_zone_enabled_front_left	Is extended conditioning in front left zone enabled	'-	String	All Data, Climatisation and Heating
68a2bfc3-a7e1-31ed-ac95-5fde7fc6f79b	setting_zone_enabled_front_right	Is extended conditioning in front right zone enabled	'-	String	All Data, Climatisation and Heating
839dbd86-e206-3804-a686-59bb6c7f6f4a	setting_zone_enabled_rear_left	Is extended conditioning in rear left zone enabled	'-	String	All Data, Climatisation and Heating
58c9fa82-6d02-3cdc-b90d-eefa91080427	setting_zone_enabled_rear_left_second_	Is extended conditioning in rear left second zone enabled	'-	String	All Data, Climatisation and Heating

8e2da8f0-18e7-3e58-98fc-ab4571d9deca	setting_zone_enabled_rear_right	Is extended conditioning in rear right zone enabled	'-	String	All Data, Climatisation and Heating
1f11c002-f307-323c-9745-f909ff6eaba7	setting_zone_enabled_rear_right_second	Is extended conditioning in rear right second zone enabled	'-	String	All Data, Climatisation and Heating
bc5bacac-cea7-347e-9c1e-831026a3d996	short_term_data_average_aux_consumer_consumption	Average Auxiliary Consumer Consumption during short term trip	kwH/1000km	int	All Data, Trip Statistics
3b1bdf91-8e59-333a-93ed-f8e5a980bc96	short_term_data_average_electr_engine_consumption	Average Electric Engine Consumption during short term trip	kwH/1000km	int	All Data, Trip Statistics
a0ee824b-9a53-34ee-8107-3ed94684efa7	short_term_data_average_fuel_consumption	Average Fuel Consumption during short term trip	l/1000km	int	All Data, Trip Statistics
bdf31409-b799-3969-8199-e305082aabf2	short_term_data_average_gas_consumption	Average gas Consumption during short term trip	kg/1000km	int	All Data, Trip Statistics
8bad11dc-3a56-33ad-a4e9-23fdf117a88b	short_term_data_average_recuperation	Average recuperation during short term trip	kwH/1000km	int	All Data, Trip Statistics
9f55581a-4fa2-3570-9c9e-b80d210b9a42	short_term_data_mileage	Overall Mileage for short term trips	km	int	All Data, Trip Statistics
06e25fe1-794b-378d-b1d1-eefd5324dbcf	short_term_data_range_gain_distance	Gained range distance in [0.1 km] during short term trip	100m	int	All Data, Trip Statistics
ecd266dd-f536-39c2-a575-352216b87f39	short_term_data_start_mileage	Mileage when trip started	km	int	All Data, Trip Statistics
f0890c07-e62e-32dc-ab3b-80431f070b13	short_term_data_travel_time	Time of trip with vehicle ready for driving	min	int	All Data, Trip Statistics
df069cac-4bec-3894-afa4-bd344d3cd21c	short_term_data_zero_emission_distance	Distance driven without emission in [0,1km] during short term trip	100m	int	All Data

09cb4860-2965-3915-a9a1-7b1ebc1c34f4	short_trip.reset_timestamp	The string value of "short trip reset timestamp" - DPS - Remote Trip Statistics		string	All Data, Trip Statistics
45df4e5a-c2e3-3588-b917-e572ef5ac213	slope_consumption_values.ascent_slope_consumption.physical_value	The float value of "slope consumption values ascent slope consumption physical value"		float	All Data
a0d94ba4-7674-3934-b542-5c6b76aad876	slope_consumption_values.ascent_slope_consumption.value_type	Indicates whether the field physical_value contains a valid value.		enum	All Data
8fbb198f-872a-33b2-8c2f-84a3185f1b3a	slope_consumption_values.descent_slope_consumption.physical_value	The float value of "slope consumption values descent slope consumption physical value"		float	All Data
30066859-2b5b-31db-86bf-c1a504a296af	slope_consumption_values.descent_slope_consumption.value_type	Indicates whether the field physical_value contains a valid value.		enum	All Data
cc52518e-328a-3f09-8767-af04ac8c86f5	speed.[*].mileage_with_unit.mileage_state	The values of: "speed" & "mileage with unit.mileage state". Note that [*] in the key is replaced by a number.. The values of: "speed" & "mileage with unit.mileage state". Note that [*] in the key is replaced by a number.		enum	All Data

0ae5cc5f-7260-38af-a354-afa4e5399d75	speed.[*].mileage_with_unit.mileage_state	The values of: "speed" & "mileage with unit.mileage state". Note that [*] in the key is replaced by a number.. The values of: "speed" & "mileage with unit.mileage state". Note that [*] in the key is replaced by a number.		enum	All Data
c1fe04b9-568e-3dd0-809d-b249bd08683c	start_exceeding	The string value of "start exceeding"		string	All Data
4ae5b58c-46e2-3ec2-bf00-f6a05ef498d2	start_stop_action	Indicates the action related to charging	'-	String	All Data
6b720620-2e64-3e49-aab5-80858d8e05fd	start_stop_modification	Contains the detail realted to start stop modification	'-	String	All Data
85fbdac0-35e4-374e-b89f-a2520215a355	state	State of the information (valid/invalid);		enum	All Data
c600e6a7-1799-31b3-9cee-1af018705e8a	state	State of the information (valid/invalid); type ï¿½Stateï¿½ defined in ï¿½TTRVS_types_v1ï¿½		enum	All Data
dcec2039-3329-3448-8029-de14fef26f11	state	The enum value of "state"		enum	All Data
460d9194-3ae8-3df5-bec9-fd963e48ce96	state	The enum value of "state"		enum	All Data
e0a4b262-2c9e-3a40-a9f4-495fe5c59060	state	The enum value of "state"		enum	All Data
1f44781f-0021-3d0c-b38f-6eaac5db3eee	state	State of the information (valid/invalid); type ï¿½Stateï¿½ defined in ï¿½TTRVS_types_v1ï¿½		enum	All Data

0718582b-7259-3c9a-818a-ea848a7365a8	state	State of the information (valid/invalid); type ï¿½Stateï¿½ defined in ï¿½TTRVS_types_v1ï¿½		enum	All Data
ac19dde4-0a7c-335d-bb73-43d1dff3cc06	state	The enum value of "state"		enum	All Data
8e0ee7f6-8069-3821-abd8-5cf2fb926d8d	state	The enum value of "state"		enum	All Data
f0124371-ad79-3855-b49f-413b3982cd3f	state	State of the information . Possible values: INVALID, VALID, UNSUPPORTED, ERROR		enum	All Data
67a4b496-5bb1-39aa-b85f-6bef783ade01	state	State of the information . Possible values: INVALID, VALID, UNSUPPORTED, ERROR		enum	All Data
416ad6d5-30ed-303f-81fb-0775cbd5bfb8	state	The enum value of "state"		enum	All Data
7de61e97-63fc-377d-9bbd-c1e3610fd477	state_ext_cond_available_front_left	Is extended conditioning zone front left available in the vehicle	'-	String	All Data
9fe7d23e-5382-3f2c-be59-d3a00c390d1b	state_ext_cond_available_front_right	Is extended conditioning zone front right available in the vehicle	'-	String	All Data
06393f33-948c-33b7-8509-90de26acd841	state_ext_cond_available_rear_left	Is extended conditioning zone rear left available in the vehicle	'-	String	All Data
df36184f-51ae-3bea-8704-363bc20c295f	state_ext_cond_available_rear_left_second	State of ext cond availability at rear left second	'-	String	All Data
d225b44e-a996-30d0-9b00-3b0128f30806	state_ext_cond_available_rear_right	Is extended conditioning zone rear right available in the vehicle	'-	String	All Data

5b0059c8-6c7e-3c0a-8465-591e406e07e5	state_ext_cond_available_rear_right_second	State of ext cond availability at rear right second	'-	String	All Data
60a4f436-5534-32f4-b4cc-b5a88a9d4b91	state_front_left_door_window_lifter	Indicates the state of the front left door window lifter is unsupported (0) or invalid (1) or open (2) or closed (3)	'-	int	All Data
5fcf7d27-6b76-3de0-9ce9-f207370cdaff	state_front_right_door_window_lifter	Indicates the state of the front right door window lifter is unsupported (0) or invalid (1) or open (2) or closed (3)	'-	int	All Data
c0fa0a66-bdeb-3a02-b51f-631182ef2b5e	state_mirror_heating_active	Is glass surface heating active at the moment	'-	String	All Data
ae0294b4-1286-3e98-a818-1485b8d88430	state_of_charge	State of charge for vehicles with an electric battery in percentage	%	int	All Data
d48ccd21-a39f-33eb-989b-d81bd23fa766	state_of_hood	Indicates the state of the car hood unsupported (0) or invalid(1) or open (2) or closed (3)	'-	int	All Data
5fb120bb-ab59-38fc-8e03-9ae197c7a1ae	state_rear_left_door_window_lifter	Indicates the state of the rear left door window lifter is unsupported (0) or invalid (1) or open (2) or closed (3)	'-	int	All Data
3ef13c1d-7e08-3cf4-b501-a8bda80cff78	state_rear_right_door_window_lifter	Indicates the state of the rear right door window lifter is unsupported (0) or invalid (1) or open (2) or closed (3)	'-	int	All Data

b38e35e9-b2e9-38ce-9b14-27e6066ab888	state_service_hatch	Indicates the state of the service hatch unsupported (0) or invalid(1) or open (2) or closed (3)	'-	int	All Data
6d90f88e-b7bf-3b1e-a306-c0e1c0c29c6e	state_spoiler	Indicates the state of the spoiler unsupported (0) or invalid(1) or open (2) or closed (3)	'-	int	All Data
cff28415-8084-34e0-ad91-db191e5ff3b6	state_sunroof_motor_hood_1	Indicates the state of the sunroof motor hood 1 unsupported (0) or invalid(1) or open (2) or closed (3)	'-	int	All Data
a8bd75f4-e8d2-3c8b-973d-b2d15d9a1d46	state_sunroof_motor_hood_3	Indicates the state of the sunroof motor hood 3 unsupported (0) or invalid(1) or open (2) or closed (3)	'-	int	All Data
7aef23c8-40f2-3dc3-afdb-684d8133a4df	state_zone_active_front_left	Status of extended conditioning in zone front left	'-	String	All Data
1b51e1bc-0db9-3c5d-b124-1ea7d672da99	state_zone_active_front_right	Status of extended conditioning in zone front right	'-	String	All Data
cf2340ad-a815-3de9-bea4-6bc839bb4194	state_zone_active_rear_left	Status of extended conditioning in zone rear left	'-	String	All Data
9e1f59dc-f564-35b4-bf85-257bd0a09746	state_zone_active_rear_left_second_	Depicts whether rear left second zone is active or not	'-	String	All Data

269de32d-64fe-31ee-b903-d55f68072728	state_zone_active_rear_right	Status of extended conditioning in zone rear right	'-	String	All Data
b110d41f-5b9b-3deb-be3f-6b5361013239	state_zone_active_rear_right_second_	Depicts whether rear right second zone is active or not	'-	String	All Data
415ed50d-77d7-33c6-a927-f92f6fdfa05f	status	The enum value of "status"		enum	All Data
19cf1318-b263-36e3-abba-59c3e714f82c	sunrooffront.is_set	The boolean value of "sunrooffront is set"		boolean	All Data
3d219e22-1311-3112-a9cc-f8db86a69a9f	sunrooffront.open	The boolean value of "sunrooffront open"		boolean	All Data
17da8056-ab43-39ab-bab5-128c57881c9b	sunrooffront.percent_open	The int value of "sunrooffront percent open"		int	All Data
709444ae-fa00-34b5-b61c-8957a99a1a6e	sunrooffront.state	The enum value of "sunrooffront state"		enum	All Data
672acc16-0302-398c-818e-499674a3758b	tank_accuracy	Accuracy of the fuel level with 0 or 1	'-	int	All Data, Dashboard Measurements
3ba7c870-d2a7-3383-8a17-e4048a57a583	tank_current_level	Current fuel level in percentage	%	int	All Data, Dashboard Measurements
6e10c0f1-09fa-32a2-b821-4c177ba1f61f	third_active_consumer_	This TSS-ID is only interpreted by zFDI for vehicles of PPE platform!	'-	'-	All Data, Dashboard Measurements
cfe87070-685f-3f42-a94f-cf4ce0aa7747	third_energy_saving_hints_amount_	This TSS-ID is only interpreted by zFDI for vehicles of PPE platform!	'-	'-	All Data, Dashboard Measurements

18a0cdb2-d690-334b-9208-42a17e63b0dc	timers.[*].activation_state	If the timer is activated/deactivated. The values of: "timers" & "activation state". Note that [*] in the key is replaced by a number.		boolean	All Data
c299ad4d-fc34-3662-9c33-6f4aa436db46	timers.[*].activation_state	The values of: "timers" & "activation state". Note that [*] in the key is replaced by a number.. The values of: "timers" & "activation state". Note that [*] in the key is replaced by a number.		boolean	All Data
89112005-2e95-34ed-9eb1-1b6521b7a39b	timers.[*].single.departure_date_time	The timer will be programmed for the corresponding date and time. STK provides the YEAR, MONTH, DAY, HOUR, MINUTE (reference instrument_cluster_time/ Zeitmaster (time master)) but java will forward this date and time in UTC. The values of: "timers" & "single.departure date time". Note that [*] in the key is replaced by a number.		string	All Data

138b23ca-85ea-314a-af52-6962148e366f	timers.[*].single.departure_date_time	The values of: "timers" & "single.departure date time". Note that [*] in the key is replaced by a number.. The values of: "timers" & "single.departure date time". Note that [*] in the key is replaced by a number.		string	All Data
d2fc3ad9-5cba-39e7-847f-99ef232bdbd0	timers.[*].timer_id	1 or 2. Identify the timer. The values of: "timers" & "timer ID". Note that [*] in the key is replaced by a number.		int	All Data
3bee8e35-a977-35c6-8edc-e42a15ed5151	timers.[*].timer_id	The values of: "timers" & "timer ID". Note that [*] in the key is replaced by a number.. The values of: "timers" & "timer ID". Note that [*] in the key is replaced by a number.		int	All Data

b2099e28-7c8a-31eb-9c98-c133563af210	timestamp	Timestamp of the reported vehicle information<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Vehicle Health Report		string	All Data
beafe64e-9076-3034-aaae-bda0d1bbc3be	timestamp	Timestamp of the mileage report - DPS - Vehicle Health Report		string	All Data

493476b5-3aea-30b7-a937-256d862adf25	timestamp	The string value of "timestamp"<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Vehicle Health Report		string	All Data

c7ffb8a5-0dc3-3dca-bacf-153f0d3fd4fa	timestamp	Timestamp of the reported aggregated driver notification<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Vehicle Health Report		string	All Data
bfb33d47-84a1-3c69-97bf-a82663ec1b3c	timestamp	System time of the vehicle in UTC - DPS - Remote Vehicle Status		string	All Data

0a13125b-5c5b-36e8-8d30-e69ea5e51f8d	timestamp	The string value of "timestamp" <span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Remote Vehicle Status		string	All Data
8040d6f6-7fe1-3d81-983e-271584e4177d	timestamp	System time of the vehicle in UTC - DPS - Remote Vehicle Status		string	All Data

97cbee65-ad27-3e26-9937-94b64a2d03c3	timestamp	The string value of "timestamp" <span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Remote Vehicle Status		string	All Data
6afb2dbc-69f7-3e32-9474-a28023bd1341	timestamp	System time of the vehicle in UTC - DPS - Remote Vehicle Status		string	All Data
3fd9969f-8a49-3099-be59-0fb23c9c4a94	timestamp	System time of the vehicle in UTC - DPS - Remote Vehicle Status		string	All Data

fce14539-bb80-31c5-8e4e-cb06a73a611b	timestamp	The string value of "timestamp" <span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Remote Vehicle Status		string	All Data

a9a60224-654b-373e-82ee-4031c9dd83a7	timestamp	The string value of "timestamp" <span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Remote Vehicle Status		string	All Data
b66a49f0-481d-3ca9-a22f-66c4b797bfeb	timestamp	System time of the vehicle in UTC - DPS - Remote Vehicle Status		string	All Data
67d015ee-c2c0-383d-ab67-33ac674c0129	timestamp	System time of the vehicle in UTC - DPS - Remote Vehicle Status		string	All Data
e7a241de-ed81-3df4-b28c-92032d21c4dd	timestamp	System time of the vehicle in UTC - DPS - Remote Vehicle Status		string	All Data

067f539c-85fe-3067-9c29-d63e177e3712	timestamp	System time of the vehicle in UTC - DPS - Remote Vehicle Status		string	All Data
3f5a294b-b672-3963-83d8-bfb54e5b943d	timestamp	System time of the vehicle in UTC - DPS - Remote Vehicle Status		string	All Data
8c8d2e90-bffe-3739-939d-bfee302dc185	timestamp	The string value of "timestamp" <span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Remote Vehicle Status		string	All Data
cb453de8-9e87-34a4-9a70-dd5f48f715a5	timestamp	System time of the vehicle in UTC - DPS - Remote Vehicle Status		string	All Data

26037a21-e81e-3ebf-adcc-877916647cbf	timestamp	The string value of "timestamp" <span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Remote Vehicle Status		string	All Data
d58a20aa-3e62-38b7-b77c-9db367b4ee36	timestamp	System time of the vehicle in UTC - DPS - Remote Vehicle Status		string	All Data
bfd88f68-a91a-35f7-8041-e2003d883472	timestamp	System time of the vehicle in UTC - DPS - Remote Vehicle Status		string	All Data
9d78eef2-c500-345c-ac9e-bed85fbc5a22	timestamp	System time of the vehicle in UTC - DPS - Remote Vehicle Status		string	All Data

554be87f-539f-3f6c-9622-bcbbd5a55cb7	timestamp	System time of the vehicle in UTC - DPS - Remote Vehicle Status		string	All Data
d8bc5d37-5c01-37fa-ae6d-c54405eb5f3f	timestamp	System time of the vehicle in UTC - DPS - Remote Vehicle Status		string	All Data
b2d70b1f-dc81-3af7-a21e-45c9cd00daaa	timestamp	The string value of "timestamp"<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Remote Lock Unlock		string	All Data

f2f5726d-7ab4-3145-923b-0527c51bd78c	timestamp	The string value of "timestamp"<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Remote Honk & Flash		string	All Data

ebab3977-bd99-3a87-842c-0c9d426fb998	timestamp	The string value of "timestamp"<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Location and Speed Service		string	All Data

311ab02f-b10c-3cbd-abe1-bc0fac84c734	timestamp	The string value of "timestamp"<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Location and Speed Service		string	All Data

da52455a-0c22-3419-8c9a-02b11bcaef6c	timestamp	The string value of "timestamp"<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Location and Speed Service		string	All Data

540ad128-649e-309f-bb55-72baf7105166	timestamp	The string value of "timestamp"<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Location and Speed Service		string	All Data

a1c6961f-3f38-3ec9-bdf9-bdb6415111ea	timestamp	The string value of "timestamp"<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Location and Speed Service		string	All Data

b79d9ad3-85cf-3798-9cb1-a7567e5b0a95	timestamp	The string value of "timestamp"<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Location and Speed Service		string	All Data

e1247e1b-ca63-3849-b098-e37427a8c8fc	timestamp	The string value of "timestamp"<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Location and Speed Service		string	All Data
7b76a2c8-162c-3438-814b-0768f6cc6649	timestamp	The string value of "timestamp" - DPS - Identification Authentication Authorization		string	All Data
978a3724-f6aa-3e6b-8b54-700261d65d39	timestamp	The string value of "timestamp" - DPS - Identification Authentication Authorization		string	All Data

d88548ed-1aa4-3e97-9ed9-6549085a689e	timestamp	The string value of "timestamp"<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - DWA - Anti-Theft Alert Push		string	All Data

a8a7e1e8-e6d7-3b96-bc29-83e46c6ac06f	timestamp	The string value of "timestamp"<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

b131586a-3d3d-3eb1-b210-b333bb828b34	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

e38de2e0-9515-3861-a124-81f6bf761257	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

75184561-67be-36ed-a951-d2b398cc256f	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

f044b3d8-f912-3f11-8625-1dada41bc887	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

37923e4a-3fb1-3be7-9fa4-c774ea4d2eea	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

cab54365-ef43-3631-a0e4-530ddb81b25f	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

49274b4c-a6ec-3519-945a-9c6f29981591	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

504e0a48-25fb-3a37-81ba-785b5d77274f	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

c909c8ab-ffce-31ce-a252-0037b5768fa0	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

6587dc55-ba3c-3566-ad8c-2bedbde37806	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

ff8a8153-447b-3636-a36c-046e9f437a4f	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

7090e5dd-fa6c-388c-8e3e-ab1f33cfe376	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

1690b76c-f671-370b-8242-97239d4473ce	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

0201f541-3efc-34d9-b183-417e4a059c21	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

8427fd45-cd45-3bfd-8347-71cc29c87b0f	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

4c7d3de6-e2bc-3fbb-bbc1-08d9f1c20cbc	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

31a9b927-f32f-3fb7-8ef1-dca19c372002	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

7085b9d6-2dc4-3378-aadc-42e15448314c	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

f6301d52-5c96-3e26-9461-565f2af06043	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

1c135f51-1db8-36df-bc3c-6a983efe784f	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

e2de248b-f852-3557-971f-7154ce2334e1	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

e31f4599-429d-3a79-8a10-bd2f2af11c05	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

7b0bb11e-9f36-3397-9248-88bb09195afe	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

55ae6aa8-f485-3eb2-8f13-58391f46d7e5	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

6cb250b1-05d8-3022-979c-93292072a50b	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data

49027c33-e045-36c5-bbaf-9a068631d8e9	timestamp	UTC Time<span style="background-color: rgb(255,255,255);font-family: 'Inter Variable' , 'Open Sans Variable' , 'Helvetica Neue' , Helvetica , Arial , sans-serif;font-weight: 400;font-size: 14.0px;white-space: pre-wrap;">Â - DPS - Ecall		string	All Data
e285202c-6ec8-3532-bd78-8be7290c2749	acknowledge.is_set	The boolean value of "acknowledge is set"		boolean	All Data
968057df-7916-3079-b2f8-01c35da6da7f	active_target_soc	Active Target SOC	'-	String	All Data, Charging

e61ced87-231e-3697-8a0f-ca8d524203be	active_warnings_in_instrument_cluster_0001	Information about the warning lights being actived in the instrument cluster (001)	Hex (Interpreted)	int	All Data, Breakdown, Maintenance Related Information, Dashboard Measurements, Vehicle Warning Lights
513906e6-3ba8-3802-887a-2b159e61095f	active_warnings_in_instrument_cluster_0001_filtered	Information about the warning lights being actived in the instrument cluster filtered (001)	Hex (Interpreted)	String	All Data, Breakdown, Maintenance Related Information, Dashboard Measurements, Vehicle Warning Lights
6c980d05-90d5-3948-8f35-2bd94fe9d1a2	active_warnings_in_instrument_cluster_feff_filtered	Information about the warning lights being actived in the instrument cluster filtered (FEFF)	Hex (Interpreted)	dateTime	All Data, Breakdown, Maintenance Related Information, Dashboard Measurements, Vehicle Warning Lights

80e4fc45-1bf3-35eb-99b0-e956fd5ae5f0	active_warnings_in_instrument_cluster_fff	Information about the warning lights being actived in the instrument cluster filtered (FFF)	Hex (Interpreted)	int	All Data, Breakdown, Maintenance Related Information, Dashboard Measurements, Vehicle Warning Lights
370c2092-d983-38e4-861f-91482b7cff54	actual_charge_rate	Indicates actual charge rate	'-	int	All Data, Charging
5fbb197a-751e-3e36-a48a-398327cc1cac	actuation_s	The enum value of "actuation s"		enum	All Data
39a2407f-3225-3bed-a618-f3582816a2ca	actuation_s	The enum value of "actuation s"		enum	All Data
2524f98a-78af-3f02-9580-6e665c625570	actuation_s	The enum value of "actuation s"		enum	All Data
ce093d36-7814-3038-93c1-09e117fc114a	actuationS	The enum value of "actuationS"		enum	All Data
eef8e710-69d3-30dc-9da6-ccc1852eaef3	additional_consumptions.additional_comfort_consumption	Additional comfort consumption for a given driving mode (comfort-related).		float	All Data
cd8ae411-97d3-3f2a-aef5-4a10eaef9020	additional_consumptions.additional_comfort_consumption	Additional comfort consumption for a given driving mode (comfort-related).		float	All Data
a3f0ee5e-e2c6-351d-96f3-7e4434738e0f	additional_consumptions.additional_comfort_consumption	Additional comfort consumption for a given driving mode (comfort-related).		float	All Data

490802b9-3636-3737-a106-167c91716b09	additional_consumptions.additional_comfort_consumption	Additional comfort consumption for a given driving mode (comfort-related).		float	All Data
e3ec4dfb-0c3b-33dc-b8cd-3b9a18fda057	additional_consumptions.battery_climatization_consumption	Energy consumption for battery climtization for a given driving mode (non-comfortrelated).		float	All Data, Climatisation and Heating
482e54c4-a38a-33ff-9769-2a34243ca704	additional_consumptions.battery_climatization_consumption	Energy consumption for battery climtization for a given driving mode (non-comfortrelated).		float	All Data, Climatisation and Heating
d4636c00-10ba-31ba-a4c8-b7b3cde6dbb3	additional_consumptions.battery_climatization_consumption	Energy consumption for battery climtization for a given driving mode (non-comfortrelated).		float	All Data, Climatisation and Heating
5e3d43d5-5ec5-31ae-96d3-9439ff941e62	additional_consumptions.battery_climatization_consumption	Energy consumption for battery climtization for a given driving mode (non-comfortrelated).		float	All Data, Climatisation and Heating
f5ec0055-1e94-3b1f-8064-4cae5d947e8e	additional_consumptions.interior_climatization_consumption	Interior climatization consumption for a given driving mode (comfort-related).		float	All Data, Climatisation and Heating
f4c8b37d-6f1f-3e24-94de-d7741f0fd17e	additional_consumptions.interior_climatization_consumption	Interior climatization consumption for a given driving mode (comfort-related).		float	All Data, Climatisation and Heating
52b18582-0ee4-3353-9aa5-ab50ba533c8a	additional_consumptions.interior_climatization_consumption	Interior climatization consumption for a given driving mode (comfort-related).		float	All Data, Climatisation and Heating

bc5027b4-a92e-32ca-a2a6-ef7f9bc96309	additional_consumptions.interior_climatization_consumption	Interior climatization consumption for a given driving mode (comfort-related).		float	All Data, Climatisation and Heating
dabd99e5-ff5d-3555-b234-2b52be48f75f	additional_consumptions.residual_consumption	Energy consumption for residual car network components for a given driving mode (non-comfort-related).		float	All Data
c05673ec-3328-3c66-994a-bffd5beeb402	additional_consumptions.residual_consumption	Energy consumption for residual car network components for a given driving mode (non-comfort-related).		float	All Data
711385c5-9868-37df-8296-c5b20caf1ac3	additional_consumptions.residual_consumption	Energy consumption for residual car network components for a given driving mode (non-comfort-related).		float	All Data
a53cf95e-0c24-30b0-84d1-d4d618224376	additional_consumptions.residual_consumption	Energy consumption for residual car network components for a given driving mode (non-comfort-related).		float	All Data
acb35f9e-c65e-3076-a760-7b75fdafa521	array_size	The int value of "array size"		int	All Data
8b4d778f-bd46-3b1e-b0a5-3188f5571378	array_size	The int value of "array size"		int	All Data
d509b35a-96c7-3e7b-9be0-7f6a72f2f49c	array_size	The int value of "array size"		int	All Data

223143dc-ee1a-33be-bbfe-4eb052793ae2	battery_care_mode.bcam_notification	Possible values: BCAM_NOTIFICATION_INVALID, IMMEDIATE_CHARGING_SOC_RESET_IN_NEXT_CHARGING_PROCESS, IMMEDIATE_CHARGING_NOTIFY_BCAM_IS_OFF, EXTENDED_CHARGING_SOC_RESET_IN_NEXT_CHARGING_PROCESS, EXTENDED_CHARGING_NOTIFY_BCAM_IS_OFF, BCAM_SCORE_VALUE_WARNING, BCAM_SCORE_VALUE_REACHED		enum	All Data, Charging
d3df7f3d-b7cf-3793-bc2b-2fbed2ef859c	battery_care_mode.bcam_score	Score value indicates the use of the battery charging care mode		float	All Data, Charging
2a12f8e6-614f-3899-bbe9-4826d93ec08b	battery_care_mode.bcam_score_threshold	Threshold up to which the battery charging care mode was used in an exemplary manner		float	All Data, Charging
9185af4f-0ef9-3e85-a533-340303acb264	battery_care_mode.charge_bcam_threshold	Charge threshold of battery charging care mode where the targetSoc is set to in case the BCCM is activated		int	All Data, Charging

081f3121-0f89-3553-b7a2-f79bd5537479	battery_charging_status_soc	Indicates the current charging status for the battery	%	int	All Data, Charging
db2263a6-bac6-3da1-870c-04f4c8aa8005	battery_level_HV.battery_level_HV.state	The enum value of "battery level HV battery level HV state"		enum	All Data, Charging
162c2a75-edf4-3990-b8ed-7c600b3dbc40	battery_level_HV.battery_level_HV.value	The float value of "battery level HV battery level HV value"		float	All Data, Charging
d97bceed-dbfc-3282-87da-9b3551988822	battery_level_HV.is_set	The boolean value of "battery level HV is set"		boolean	All Data, Charging
2a9de7f7-a846-3d18-9883-650de9c4e4e1	battery_level_HV.state	The enum value of "battery level HV state"		enum	All Data, Charging
ac1108b1-b8cc-3db9-a663-03d387e42223	battery_level_HV.value	The float value of "battery level HV value"		float	All Data, Charging
d29e6189-6ff1-3a48-8d20-c9462ab033da	battery_state_report.charge_bulk_threshold	Charging is slower after threshold		int	All Data, Charging
eb523ec1-4e8d-3712-8a95-a17bbc1a311a	battery_state_report.charge_bulk_threshold	Charging is slower after threshold		int	All Data, Charging
b9e3fd5e-4346-3e94-8c67-d4a0f5d61d5a	battery_state_report.charge_bulk_threshold	The int value of "battery state report charge bulk threshold"		int	All Data, Charging
9a7c5d79-7b61-3028-bcc9-67c23ef812ca	battery_state_report.charge_bulk_threshold	Charging is slower after threshold		int	All Data, Charging
0026a089-3dd3-3026-8e74-0505a0b73c01	battery_state_report.charge_energy	Informs about the charged energy in kWh with a range between 0 and 1000kWh		float	All Data, Charging
082de9b8-46aa-3b64-9235-01baee4f3131	battery_state_report.charge_energy	Informs about the charged energy in kWh with a range between 0 and 1000kWh		float	All Data, Charging

e532aed3-190a-3ff0-bfa4-2e05c61c929e	battery_state_report.charge_energy	The float value of "battery state report charge energy"		float	All Data, Charging
c3e6a888-39a6-376b-8f20-ebda00e02cb5	battery_state_report.charge_energy	Informs about the charged energy in kWh with a range between 0 and 1000kWh		float	All Data, Charging
44ed0d61-98c4-36df-b860-b077929a5797	battery_state_report.charge_power	Informs about the actual charge power to the hv battery kW range between 0 and 500 with a resolution of 0,1 kW possible restrictionReason invalid		float	All Data, Charging
8087d3b7-03bd-350a-95ef-bd8cb3ba20fa	battery_state_report.charge_power	Informs about the actual charge power to the hv battery kW range between 0 and 500 with a resolution of 0,1 kW possible restrictionReason invalid		float	All Data, Charging
c8cb205f-01c6-3c81-bda1-059b99ae6515	battery_state_report.charge_power	The float value of "battery state report charge power"		float	All Data, Charging
885d1abd-799d-344a-bf02-0d07c6d6eebf	battery_state_report.charge_power	Informs about the actual charge power to the hv battery kW range between 0 and 500 with a resolution of 0,1 kW possible restrictionReason invalid		float	All Data, Charging

9e366e14-a8ce-30b4-a204-b573596d1dbf	battery_state_report.charge_rate	Informs about the actual rate of the charging process based on the average energy comsumption for driving range between 0 and 3000 with a resolution of 0,1 possible restrictionReason- invalid possible speedUnitskm per min km per hour,miles per min,miles per hour		float	All Data, Charging
0c60a14f-116d-3ccd-b551-940a0814364e	battery_state_report.charge_rate	Informs about the actual rate of the charging process based on the average energy comsumption for driving range between 0 and 3000 with a resolution of 0,1 possible restrictionReason- invalid possible speedUnitskm per min km per hour,miles per min,miles per hour		float	All Data, Charging
1efb6000-6b54-366a-9233-d320699687cf	battery_state_report.charge_rate	The float value of "battery state report charge rate"		float	All Data, Charging

1edd4c7f-90b3-3ca4-a748-3b78132aab1d	battery_state_report.charge_rate	Informs about the actual rate of the charging process based on the average energy comsumption for driving range between 0 and 3000 with a resolution of 0,1 possible restrictionReason- invalid possible speedUnitskm per min km per hour,miles per min,miles per hour		float	All Data, Charging
f01dccee-9a1a-3db6-8a99-4e483c604b4c	battery_state_report.charge_rate_unit	CHARGE_RATE_UNIT_INVALID, CHARGE_RATE_UNIT_KM_PER_H, CHARGE_RATE_UNIT_KM_PER_MIN, CHARGE_RATE_UNIT_MILES_PER_H, CHARGE_RATE_UNIT_MILES_PER_MIN		enum	All Data, Charging

9ca09c8a-0b43-323c-8ce1-d757480c928c	battery_state_report.charge_rate_unit	CHARGE_RATE_UNIT_INVALID, CHARGE_RATE_UNIT_KM_PER_H, CHARGE_RATE_UNIT_KM_PER_MIN, CHARGE_RATE_UNIT_MILES_PER_H, CHARGE_RATE_UNIT_MILES_PER_MIN		enum	All Data, Charging
9c83ccaa-5288-38da-9d38-81ef8db469b3	battery_state_report.charge_rate_unit	The enum value of "battery state report charge rate unit"		enum	All Data, Charging
1f9c6e86-b4d5-3eb9-8bb2-886298c24a06	battery_state_report.charge_rate_unit	CHARGE_RATE_UNIT_INVALID, CHARGE_RATE_UNIT_KM_PER_H, CHARGE_RATE_UNIT_KM_PER_MIN, CHARGE_RATE_UNIT_MILES_PER_H, CHARGE_RATE_UNIT_MILES_PER_MIN		enum	All Data, Charging
5acaca8a-7eb4-382e-9e0f-c16debd34e7c	battery_state_report.charge_target_time	Estimated end time/date of current charge process. The car provides time and date in customerTime but backend will obtain UTC		string	All Data, Charging

0efd1746-3e73-325f-97ce-a3da5cb09e69	battery_state_report.charge_target_time	Estimated end time/date of current charge process. The car provides time and date in customerTime but backend will obtain UTC		string	All Data, Charging
aaee532f-090f-3848-a8bb-5ee972f7f74e	battery_state_report.charge_target_time	The string value of "battery state report charge target time"		string	All Data, Charging
2d49e8ad-043e-365e-b280-454e0233b64e	battery_state_report.charge_target_time	Estimated end time/date of current charge process. The car provides time and date in customerTime but backend will obtain UTC		string	All Data, Charging

c9203a5b-0fac-3423-a438-973cf67dc901	battery_state_report.cruising_ranges.[*].engine_type	ENGINE_TYPE_INVALID, ENGINE_TYPE_GAS_CNG, ENGINE_TYPE_GAS_LPG, ENGINE_TYPE_PETROL_DIESEL, ENGINE_TYPE_PETROL_GASOLINE, ENGINE_TYPE_TYPE_IS_ELECTRIC, ENGINE_TYPE_TYPE_IS_GAS, ENGINE_TYPE_TYPE_IS_PETROL, ENGINE_TYPE_UNSUPPORTED. The values of: "battery state report.cruising ranges" & "engine type". Note that [*] in the key is replaced by a number.		enum	All Data, Charging

c92f946c-3dea-317f-88c7-620e4c15fe1c	battery_state_report.cruising_ranges.[*].engine_type	ENGINE_TYPE_INVALID, ENGINE_TYPE_GAS_CNG, ENGINE_TYPE_GAS_LPG, ENGINE_TYPE_PETROL_DIESEL, ENGINE_TYPE_PETROL_GASOLINE, ENGINE_TYPE_TYPE_IS_ELECTRIC, ENGINE_TYPE_TYPE_IS_GAS, ENGINE_TYPE_TYPE_IS_PETROL, ENGINE_TYPE_UNSUPPORTED. The values of: "battery state report.cruising ranges" & "engine type". Note that [*] in the key is replaced by a number.		enum	All Data, Charging

33430216-bd7b-3410-b3f1-7f8a14a5ab3b	battery_state_report.cruising_ranges.[*].engine_type	The values of: "battery state report.cruising ranges" & "engine type". Note that [*] in the key is replaced by a number.. The values of: "battery state report.cruising ranges" & "engine type". Note that [*] in the key is replaced by a number.		enum	All Data, Charging

d9d15909-a5cd-3085-87a7-fd4b6c87640c	battery_state_report.cruising_ranges.[*].engine_type	ENGINE_TYPE_INVALID, ENGINE_TYPE_GAS_CNG, ENGINE_TYPE_GAS_LPG, ENGINE_TYPE_PETROL_DIESEL, ENGINE_TYPE_PETROL_GASOLINE, ENGINE_TYPE_TYPE_IS_ELECTRIC, ENGINE_TYPE_TYPE_IS_GAS, ENGINE_TYPE_TYPE_IS_PETROL, ENGINE_TYPE_UNSUPPORTED. The values of: "battery state report.cruising ranges" & "engine type". Note that [*] in the key is replaced by a number.		enum	All Data, Charging
70b701be-b1df-334b-9759-a2a49c48785e	battery_state_report.cruising_ranges.[*].range	Range for the corresponding engine. The values of: "battery state report.cruising ranges" & "range". Note that [*] in the key is replaced by a number.		int	All Data, Charging

c2b3bc79-bede-3fce-b36e-d1e2678ced8a	battery_state_report.cruising_ranges.[*].range	Range for the corresponding engine. The values of: "battery state report.cruising ranges" & "range". Note that [*] in the key is replaced by a number.		int	All Data, Charging
c7e31dd1-01f1-312b-b3ae-757f3ec8fd75	battery_state_report.cruising_ranges.[*].range	The values of: "battery state report.cruising ranges" & "range". Note that [*] in the key is replaced by a number.. The values of: "battery state report.cruising ranges" & "range". Note that [*] in the key is replaced by a number.		int	All Data, Charging
0a14579b-cf62-39b6-9bba-e333abcde58b	battery_state_report.cruising_ranges.[*].range	Range for the corresponding engine. The values of: "battery state report.cruising ranges" & "range". Note that [*] in the key is replaced by a number.		int	All Data, Charging
59f4681b-6df3-30b1-99e0-2d959d60fdfd	battery_state_report.cruising_ranges.[*].unit	Range unit. The values of: "battery state report.cruising ranges" & "unit". Note that [*] in the key is replaced by a number.		enum	All Data, Charging

fc36a60e-1d31-3e3b-9d81-1e38a08a44c6	battery_state_report.cruising_ranges.[*].unit	Range unit. The values of: "battery state report.cruising ranges" & "unit". Note that [*] in the key is replaced by a number.		enum	All Data, Charging
f7a357e8-d31f-353b-9ea9-6dbbf4992e54	battery_state_report.cruising_ranges.[*].unit	The values of: "battery state report.cruising ranges" & "unit". Note that [*] in the key is replaced by a number.. The values of: "battery state report.cruising ranges" & "unit". Note that [*] in the key is replaced by a number.		enum	All Data, Charging
6eea6340-29ae-3424-a4e6-91838d3d9369	battery_state_report.cruising_ranges.[*].unit	Range unit. The values of: "battery state report.cruising ranges" & "unit". Note that [*] in the key is replaced by a number.		enum	All Data, Charging
7bd2f74f-5677-3695-9b95-a4db8d581d81	battery_state_report.energy_amount_max_soc	Amount of Energy necessary to charge to the maxSoc		int	All Data, Charging
51d41cfc-bda9-3412-8b81-d4ad176dbc3d	battery_state_report.energy_amount_max_soc	Amount of Energy necessary to charge to the maxSoc		int	All Data, Charging

582f5f4a-f021-3485-8cac-9ed6ee25d218	battery_state_report.energy_amount_min_soc	Amount of Energy necessary to charge to minSoc of profile (ChargingManagementExtended.chargingProfiles[].minSoc)		int	All Data, Charging
fd2a0951-f22e-339c-a195-f0d580fc03a5	battery_state_report.energy_amount_min_soc	Amount of Energy necessary to charge to minSoc of profile (ChargingManagementExtended.chargingProfiles[].minSoc)		int	All Data, Charging
ec6dd57a-3fe3-32b7-a8dd-0ed5d2f1fe36	battery_state_report.energy_amount_target_soc	Amount of Energy necessary to charge to the current targetSoc		int	All Data, Charging
3948a86f-fb50-3b7f-aeef-7fb70f1a632f	battery_state_report.energy_amount_target_soc	Amount of Energy necessary to charge to the current targetSoc		int	All Data, Charging
f4920d99-5887-34f4-92dc-7582cdbe637c	battery_state_report.remaining_charging_time_bulk	How many time left to reach charging bulk (For example: 80 % SOC)		string	All Data, Charging
7892c419-573f-34d8-8c7b-526cd3d10958	battery_state_report.remaining_charging_time_bulk	How many time left to reach charging bulk (For example: 80 % SOC)		string	All Data, Charging
2725401e-75cf-3c11-96a1-e926c9871fd3	battery_state_report.remaining_charging_time_bulk	The string value of "battery state report remaining charging time bulk"		string	All Data, Charging
273ea434-fd5a-34e0-8975-b1da857af83c	battery_state_report.remaining_charging_time_bulk	How many time left to reach charging bulk (For example: 80 % SOC)		string	All Data, Charging

cad65f6f-17c5-377b-b030-821ffaf27dd5	battery_state_report.remaining_charging_time_complete	How much time left to reach charging completed		string	All Data, Charging
7b149fa0-1cae-35e3-9f81-49656d2393b8	battery_state_report.remaining_charging_time_complete	How much time left to reach charging completed		string	All Data, Charging
7405c11f-4d20-36d2-8381-18364aa1f444	battery_state_report.remaining_charging_time_complete	The string value of "battery state report remaining charging time complete"		string	All Data, Charging
c32ae9c8-b3c1-3334-865e-ddce83159935	battery_state_report.remaining_charging_time_complete	How much time left to reach charging completed		string	All Data, Charging
93b55324-6628-36df-8f76-8eba797fc59c	battery_state_report.soc	State of Charging when charging is started		int	All Data, Charging
7bddd5e7-43a4-3878-bd63-9502782f77a5	battery_state_report.soc	State of Charging when charging is started		int	All Data, Charging
506cb83e-f99f-3af3-bbeb-0429b69a78d9	battery_state_report.soc	The int value of "battery state report soc"		int	All Data, Charging
bd4b6d50-b574-31e6-8141-8787ca5fec8c	battery_state_report.soc	State of Charging when charging is started		int	All Data, Charging
180b6446-c574-3b80-8c0e-0b33960d35d0	time_to_live	The int value of "time to live"		int	All Data
3ac98b4d-94a5-3c79-829c-90d09a9c2715	time_to_live	The int value of "time to live"		int	All Data
cf1d4ccd-9bfc-3b6e-a137-baf8eeb0abda	inspectionTime	time to next inspection	(days)	int	Maintenance Related Information
0ce1adb6-4776-31a1-9dd0-31a5695655f4	inspectionOilTime	time to next oil inspection	(days)	int	Maintenance Related Information

a2fd3e73-dea1-30c7-8d0d-154764667990	tires.[*].actual_pressure	The values of: "tires" & "actual pressure". Note that [*] in the key is replaced by a number.. The values of: "tires" & "actual pressure". Note that [*] in the key is replaced by a number.		float	All Data
15fa9d07-81ab-354e-98aa-398ae2b968fc	tires.[*].actual_pressure	The values of: "tires" & "actual pressure". Note that [*] in the key is replaced by a number.. The values of: "tires" & "actual pressure". Note that [*] in the key is replaced by a number.		float	All Data
6a437b5d-f18a-3128-8311-32d747dd9898	tires.[*].is_set	The values of: "tires" & "is set". Note that [*] in the key is replaced by a number.. The values of: "tires" & "is set". Note that [*] in the key is replaced by a number.		boolean	All Data

4d0eba78-b603-3f5e-a63e-1bcb52fe87fb	tires.[*].position	The values of: "tires" & "position". Note that [*] in the key is replaced by a number.. The values of: "tires" & "position". Note that [*] in the key is replaced by a number.		enum	All Data
b0fa23c5-e91e-30b6-bd99-10ef302fd4da	tires.[*].position	The values of: "tires" & "position". Note that [*] in the key is replaced by a number.. The values of: "tires" & "position". Note that [*] in the key is replaced by a number.		enum	All Data
bd5a8375-a327-359e-aad4-20d137eb1ade	tires.[*].required_pressure	The values of: "tires" & "required pressure". Note that [*] in the key is replaced by a number.. The values of: "tires" & "required pressure". Note that [*] in the key is replaced by a number.		float	All Data

a10c17c5-01ad-3ff0-830d-31970fa4cb52	tires.[*].required_pressure	The values of: "tires" & "required pressure". Note that [*] in the key is replaced by a number.. The values of: "tires" & "required pressure". Note that [*] in the key is replaced by a number.		float	All Data
0398554c-411d-3c7b-ae15-568b09bbf1f9	tires.[*].state	The values of: "tires" & "state". Note that [*] in the key is replaced by a number.. The values of: "tires" & "state". Note that [*] in the key is replaced by a number.		enum	All Data
60c580df-b760-3468-af3c-390c7f1a5fd4	tires.[*].state	The values of: "tires" & "state". Note that [*] in the key is replaced by a number.. The values of: "tires" & "state". Note that [*] in the key is replaced by a number.		enum	All Data
b2786818-d5ad-380d-81b0-1075d6e4a6b5	tires.[*].unit	The values of: "tires" & "unit". Note that [*] in the key is replaced by a number.. The values of: "tires" & "unit". Note that [*] in the key is replaced by a number.		enum	All Data

c200f5e7-6174-345a-b88b-8c9d538dcfe6	tires.[*].unit	The values of: "tires" & "unit". Note that [*] in the key is replaced by a number.. The values of: "tires" & "unit". Note that [*] in the key is replaced by a number.		enum	All Data
0d16f887-074b-3867-9f4f-d5201a9237e7	tracking_id	The string value of "tracking ID"		string	All Data
c151b90a-d3fa-3400-afd6-2817ee8af2f7	tracking_id	The string value of "tracking ID"		string	All Data
e76569a2-ca91-39ce-9eae-a1ec7a6737e7	tracking_id	The string value of "tracking ID"		string	All Data
d047fa33-ae82-3526-859a-afcb529dd592	tracking_id	The string value of "tracking ID"		string	All Data
4ef20dfc-24e4-3a37-bde3-4c79ce9e7c40	tracking_id	The string value of "tracking ID"		string	All Data
3beb85bc-243d-3da0-ac90-6ba8c6d28eee	tracking_id	The string value of "tracking ID"		string	All Data
fab3ee49-5266-3055-8b73-7e57332f680e	tracking_mode	The enum value of "tracking mode"		enum	All Data
ddbd7032-9e6d-3618-92cc-d13943d9c0b2	tracking_mode	The enum value of "tracking mode"		enum	All Data
21484b35-0ef1-370e-9c81-bb0203e42726	tracking_mode	The enum value of "tracking mode"		enum	All Data
a05b0228-a4fc-3787-878b-5cce5a302298	trailer_consumption_offset_value	Consumption influence of the trailer. Vehicle always lets this field empty.		float	All Data

ea50ff51-4978-3d21-b6c0-21ce5ac4ac0b	trailer_consumption_offset_value	Consumption influence of the trailer. Vehicle always lets this field empty.		float	All Data
8958570e-6962-32b8-8ee7-3dd7567db6c4	trailer_consumption_offset_value	Consumption influence of the trailer. Vehicle always lets this field empty.		float	All Data
38b01fd9-7a04-3d26-b35b-f05a8a4a7e71	trailer_consumption_offset_value	Consumption influence of the trailer. Vehicle always lets this field empty.		float	All Data
41a6d82b-e06b-372c-ba29-ba93d75cfddf	trailer_consumption_offset_value	Consumption influence of the trailer. Vehicle always lets this field empty.		float	All Data
09a5f8b9-29a4-3341-9b1e-c87a17e1cf6f	trailer_consumption_offset_value	Consumption influence of the trailer. Vehicle always lets this field empty.		float	All Data
adcd1a55-3b9a-365b-8790-18975eefe26b	trailer_consumption_offset_value	Consumption influence of the trailer. Vehicle always lets this field empty.		float	All Data
81b6bfa3-e52b-33cf-9ef8-c41f610c05cb	trailer_consumption_offset_value	Consumption influence of the trailer. Vehicle always lets this field empty.		float	All Data
a4c2755f-21ad-3ff4-ae90-5c0d243fa0fc	trailer_found.state	State of the information . Possible values: INVALID, VALID, UNSUPPORTED, ERROR		enum	All Data

3961ac28-2e83-3468-b1f6-54ca9c4c2696	trailer_found.value	Value of the trailer_found information		boolean	All Data
8c82037b-9569-31a6-8e9e-cb9298fd58f2	trailer_state	Specifies the trailer state. Vehicle always sets this field to TRAILER_STATE_UNKNOWN. Possible values: , TRAILER_STATE_UNKNOWN , TRAILER_STATE_ACTIVE , TRAILER_STATE_DEACTIVE		enum	All Data
ebd60952-74dc-39ee-a7bd-5beaa9b06d3c	trailer_state	Specifies the trailer state. Vehicle always sets this field to TRAILER_STATE_UNKNOWN. Possible values: , TRAILER_STATE_UNKNOWN , TRAILER_STATE_ACTIVE , TRAILER_STATE_DEACTIVE		enum	All Data
5d4e6bcd-b3cf-3fbc-86f0-0010e4062124	trailer_state	Specifies the trailer state. Vehicle always sets this field to TRAILER_STATE_UNKNOWN. Possible values: , TRAILER_STATE_UNKNOWN , TRAILER_STATE_ACTIVE , TRAILER_STATE_DEACTIVE		enum	All Data

823f5f94-5713-30a0-b8ff-ba4361e70bd7	trailer_state	Specifies the trailer state. Vehicle always sets this field to TRAILER_STATE_UNKNOWN. Possible values: , TRAILER_STATE_UNKNOWN , TRAILER_STATE_ACTIVE , TRAILER_STATE_DEACTIVE		enum	All Data
7a8670ad-10c0-3fd0-a3d7-ac2e479165fe	trailer_state	Specifies the trailer state. Vehicle always sets this field to TRAILER_STATE_UNKNOWN. Possible values: , TRAILER_STATE_UNKNOWN , TRAILER_STATE_ACTIVE , TRAILER_STATE_DEACTIVE		enum	All Data
cb87ea1e-6c1b-375f-b0be-abbd388eacaf	trailer_state	Specifies the trailer state. Vehicle always sets this field to TRAILER_STATE_UNKNOWN. Possible values: , TRAILER_STATE_UNKNOWN , TRAILER_STATE_ACTIVE , TRAILER_STATE_DEACTIVE		enum	All Data

8cf1fada-a815-3c0d-b53b-f0c4853b10fc	trailer_state	Specifies the trailer state. Vehicle always sets this field to TRAILER_STATE_UNKNOWN. Possible values: , TRAILER_STATE_UNKNOWN , TRAILER_STATE_ACTIVE , TRAILER_STATE_DEACTIVE		enum	All Data
f8784873-1494-3066-bbf8-68505d3fb7a1	trailer_state	Specifies the trailer state. Vehicle always sets this field to TRAILER_STATE_UNKNOWN. Possible values: , TRAILER_STATE_UNKNOWN , TRAILER_STATE_ACTIVE , TRAILER_STATE_DEACTIVE		enum	All Data
1bfb3d7b-fbbc-345a-9ee4-ef91cc9e2665	trigger_type	The string value of "trigger type"		string	All Data
fc96fd28-d5b6-37c6-9e65-a716a288439e	trigger_type	The string value of "trigger type"		string	All Data
b0761759-fe46-35b4-90cb-f5fb665125c5	trigger_type	The string value of "trigger type"		string	All Data
b52563ed-8be6-37e1-a61b-61e91798a7b4	trigger_type	Trigger of the call service. (ROA, ROA_HK, ROA_SK, ICL, ICL_HK, ICL_SK, USM, ROA_REMOTE, ICL_REMOTE)		string	All Data

32cc717b-b632-3191-953c-653c1fb8eaef	trigger_type	Trigger of the call service. (ROA, ICL, USM, ICL_REMOTE, ROA_REMOTE)		string	All Data
eabc207e-9548-3319-8e89-487102f300f0	trigger_type	Trigger of the call service. (ROA, ICL, USM, ICL_REMOTE, ROA_REMOTE)		string	All Data
4c364670-03ed-35eb-83f8-7b517b8807cd	trigger_type	Trigger of the call service. (ROA, ICL, USM, ICL_REMOTE, ROA_REMOTE)		string	All Data
2e227fdd-9aec-3745-87df-5931c1b2dd69	trigger_type	Trigger of the call service. (ROA, ICL, USM, ICL_REMOTE, ROA_REMOTE)		string	All Data
200bb4a2-a0b4-368e-be30-ce7ef22551d4	trigger_type	Trigger of the call service. (ROA, ICL, USM, ICL_REMOTE, ROA_REMOTE)		string	All Data
a77763b9-b0d3-3fc3-8a60-9a52f17cbecf	trigger_type	Trigger of the call service. (ROA, ROA_HK, ROA_SK, ICL, ICL_HK, ICL_SK, USM, ROA_REMOTE, ICL_REMOTE)		string	All Data
b56f7d21-9665-3ba4-959a-bd718e75abbb	trigger_type	Trigger of the call service. (ROA, ICL, USM, ICL_REMOTE, ROA_REMOTE)		string	All Data

afaf3e17-8d75-3465-a907-ad4c9bff61ca	trigger_type	Trigger of the call service. (ROA, ICL, USM, ICL_REMOTE, ROA_REMOTE)		string	All Data
668ecdba-aa47-3522-8edf-5f297b5918ee	trigger_type	Trigger of the call service. (ROA, ICL, USM, ICL_REMOTE, ROA_REMOTE)		string	All Data
c11c26b1-40d4-35e9-839d-3801508eca94	trigger_type	Trigger of the call service. (ROA, ICL, USM, ICL_REMOTE, ROA_REMOTE)		string	All Data
e8b8da87-6f73-3fa1-8267-9659f634c36d	trigger_type	Trigger of the call service. (ROA, ICL, USM, ICL_REMOTE, ROA_REMOTE)		string	All Data
cd55a1fe-b7ee-31f7-a1d3-f6298f1103bb	trigger_type	Trigger of the call service. (ROA, ICL, USM, ICL_REMOTE, ROA_REMOTE)		string	All Data
a3634814-4911-38f8-902a-bd08f6c85354	trigger_type	Trigger of the call service. (ROA, ICL, USM, ICL_REMOTE, ROA_REMOTE)		string	All Data
6d4e6a95-4661-3886-8ac0-77b243d19b09	trigger_type	Trigger of the call service. (ROA, ICL, USM, ICL_REMOTE, ROA_REMOTE)		string	All Data
be7bfad9-c610-344a-8cb4-f7ba048473a5	trigger_type	Trigger of the call service. (ROA, ICL, USM, ICL_REMOTE, ROA_REMOTE)		string	All Data

5b13bc8d-4bd7-3947-8e90-188595d1c9a8	trigger_type	Trigger of the call service. (ROA, ICL, USM, ICL_REMOTE, ROA_REMOTE)		string	All Data
ac7e9ed2-6dfd-346b-b029-385a9c9c17d6	trigger_type	Trigger of the call service. (ROA, ICL, USM, ICL_REMOTE, ROA_REMOTE)		string	All Data
c860261c-4f19-3697-bcbf-eb272723aab2	trigger_type	Trigger of the call service. (ROA, ICL, USM, ICL_REMOTE, ROA_REMOTE)		string	All Data
e537aaa8-db42-33b2-b58e-494392b0c756	trigger_type	Trigger of the call service. (ROA, ICL, USM, ICL_REMOTE, ROA_REMOTE)		string	All Data
9ee96f87-ad89-399a-a2a1-c2ffb064b471	trigger_type	Trigger of the call service. (ROA, ICL, USM, ICL_REMOTE, ROA_REMOTE)		string	All Data
173589ce-e437-3c6e-a0ec-6df704586fd7	trueness	fair, good, none, weak	'-	String	All Data, Breakdown, Parking Data, Vehicle Location Tracking
c044a70f-90d8-3e4e-83ef-d5672f60bf87	trunk.is_set	The boolean value of "trunk is set"		boolean	All Data
25eaa230-0d3c-3df3-aac5-6b8b1890b9f9	trunk.locked	The boolean value of "trunk locked"		boolean	All Data
25ed3407-82de-353e-9f3e-f37952731932	trunk.open	The boolean value of "trunk open"		boolean	All Data

e6e155d0-a917-30bb-a5de-4990d8d51bf7	trunk.safe	The boolean value of "trunk safe"		boolean	All Data
6bd44e4b-e580-3577-a704-1e2b6b092ef5	trunk.state	The enum value of "trunk state"		enum	All Data
c4a26fd6-c08f-3921-bb8c-23fab6751c54	tyre_pressure_actual_front_left	Indicates if the actual front left tyre pressure is unsupported (0) or invalid (1) or valid (int)	10kPA / Bar / PSI/ kPA	float	All Data
be03dca4-16fb-3072-82bd-17064bd423b9	tyre_pressure_actual_front_right	Indicates if the actual front right tyre pressure is unsupported (0) or invalid (1) or valid (int)	10kPA / Bar / PSI/ kPA	float	All Data
33d2c35b-8aac-3509-bb88-807682055b1b	tyre_pressure_actual_rear_left	Indicates if the actual rear left tyre pressure is unsupported (0) or invalid (1) or valid (int)	10kPA / Bar / PSI/ kPA	float	All Data
5f913493-351d-3aa8-a1c5-20506d9d7f9a	tyre_pressure_actual_rear_right	Indicates if the actual rear left tyre pressure is unsupported (0) or invalid (1) or valid (int)	10kPA / Bar / PSI/ kPA	float	All Data
1403559a-d939-3ec2-96c6-c2e8e6d0bd13	tyre_pressure_actual_spare_tyre	Indicates if the actual spare tyre pressure is unsupported (0) or invalid (1) or valid (int)	10kPA / Bar / PSI/ kPA	float	All Data
69729e19-7b1a-3189-8e11-b4b31ab7601a	tyre_pressure_differential_front_left	Indicates if the differential front left tyre pressure is unsupported (0) or invalid (1) or valid (int)	10kPA / Bar / PSI/ kPA	float	All Data

a86e735b-5f04-336a-8dc7-8fb189d02cd2	tyre_pressure_differential_front_right	Indicates if the differential front right tyre pressure is unsupported (0) or invalid (1) or valid (int)	10kPA / Bar / PSI/ kPA	float	All Data
a59fa6dd-c0e8-35af-afc0-1f411c33c78c	tyre_pressure_differential_rear_left	Indicates if the differential rear left tyre pressure is unsupported (0) or invalid (1) or valid (int)	10kPA / Bar / PSI/ kPA	float	All Data
d7d35c0a-706c-3f28-a61a-c3b002116a25	tyre_pressure_differential_rear_right	Indicates if the differential rear right tyre pressure is unsupported (0) or invalid (1) or valid (int)	10kPA / Bar / PSI/ kPA	float	All Data
351e9e10-b831-391e-9fc4-ccacc8cd3eba	tyre_pressure_differential_spare_tyre	Indicates if the differential spare tyre pressure is unsupported (0) or invalid (1) or valid (int)	10kPA / Bar / PSI/ kPA	float	All Data
1e4d13b5-ce70-3429-a545-796f40775f92	tyre_pressure_required_front_left	Indicates if the required front left tyre pressure is unsupported (0) or invalid (1) or valid (int)	10kPA / Bar / PSI/ kPA	float	All Data
8ab83a99-d382-3ce1-9470-d98612e85066	tyre_pressure_required_front_right	Indicates if the required front right tyre pressure is unsupported (0) or invalid (1) or valid (int)	10kPA / Bar / PSI/ kPA	float	All Data
5497c6f9-d22e-3bfc-886e-d1279a6be410	tyre_pressure_required_rear_left	Indicates if the required rear left tyre pressure is unsupported (0) or invalid (1) or valid (int)	10kPA / Bar / PSI/ kPA	float	All Data

fcbbc9c5-d302-3019-a293-07a0123e3f53	tyre_pressure_required_rear_right	Indicates if the required rear left tyre pressure is unsupported (0) or invalid (1) or valid (int)	10kPA / Bar / PSI/ kPA	float	All Data
c046a189-1068-3f8a-b00b-8bc4b9b4c6e0	tyre_pressure_required_spare_tyre	Indicates if the required spare tyre pressure is unsupported (0) or invalid (1) or valid (int)	10kPA / Bar / PSI/ kPA	float	All Data
93b991ae-8025-3a77-bfcf-7163c20cb44c	unit	The enum value of "unit"		enum	All Data
3f4da2da-196f-3a9a-b109-0ea0d5f5a264	unit	The enum value of "unit"		enum	All Data
e7545b76-e6c5-3279-a1ec-6bf148688014	unit	The enum value of "unit"		enum	All Data
8d508462-17e7-3027-8980-cbbbc86d9496	unit	Unit of the value; type ï¿½DistanceUnitï¿½ defined in ï¿½TTRVS_types_v1ï¿½		enum	All Data
770793a8-6cc8-37ee-b395-162b5fa094d4	update_reason	The reason why the report has been sent to the backend. Possible values: UPDATE_REASON_INVALID, UPDATE_REASON_CHARGING, UPDATE_REASON_CLAMP15_OFF, UPDATE_REASON_CLAMP15_ON, UPDATE_REASON_CLIMATISATION, UPDATE_REASON_OTHER		enum	All Data

0a56b510-44b9-3ee9-9274-7988c60bd87d	update_reason	The reason why the report has been sent to the backend. Possible values: UPDATE_REASON_INVALID, UPDATE_REASON_CHARGING, UPDATE_REASON_CLAMP15_OFF, UPDATE_REASON_CLAMP15_ON, UPDATE_REASON_CLIMATISATION, UPDATE_REASON_OTHER		enum	All Data
25096bfe-96e0-3bcc-8c78-5ed5b72d5399	update_reason	The enum value of "update reason"		enum	All Data

76ef7fdd-77c8-3559-901c-1c62370528fe	update_reason	The reason why the report has been sent to the backend. Possible values: UPDATE_REASON_INVALID, UPDATE_REASON_CHARGING, UPDATE_REASON_CLAMP15_OFF, UPDATE_REASON_CLAMP15_ON, UPDATE_REASON_CLIMATISATION, UPDATE_REASON_OTHER		enum	All Data
3ae4b499-6b81-3a6b-9a04-bd014de76e1d	user_id	The string value of "user ID"		string	All Data
c98af658-9d4b-30e8-a933-307d93108aef	user_id	The string value of "user ID"		string	All Data
3d2f200a-4025-3e0a-a424-c5e776dad26a	user_id	The string value of "user ID"		string	All Data
66a821ca-d34f-35ee-b510-d23b33499f53	value	The int value of "value"		int	All Data
8891d6c6-7fae-3b78-b2fa-0247226e49ed	value	The int value of "value"		int	All Data
57b433c8-3dcc-3fbf-9b38-74f8f6480682	value	The int value of "value"		int	All Data
0ca40e18-0564-3eda-bcc0-7aee9ef44f04	value	Value of the primary range		int	All Data
0010398f-5fda-39af-9e7a-25db8c2e623a	vehicleIsStandingStill	current motion state of vehicle		boolean	Parking Data
f9f8a854-c623-366e-be10-d4b379cbb757	verification_uri_complete	The string value of "verification uri complete"		string	All Data

8dba6f8d-d3ff-3ed8-8e59-032944e21127	volumeLvl	current volume level		int	Infotainment Related Data
e53059af-fad5-3a5e-9933-eb3c5afcb605	window_heating_error_code	The int value of "window heating error code"		int	All Data
fc0a66cd-9921-3835-8360-88bcd686a7c3	window_heating_error_code	the state represents an aborted situation, which avoid start AC. The customer must not be informed with a popup/notification in this situation		int	All Data
5853f734-d629-39a4-8d66-ba1d5e359daf	window_heating_error_code	the state represents an aborted situation, which avoid start AC. The customer must not be informed with a popup/notification in this situation		int	All Data
f5a56a87-0b03-3593-b66b-044f9006aea5	window_heating_error_code	Error code will be set here in case of an error with window heating	'-	int	All Data, Climatisation and Heating
a894455d-2917-33cf-a9bd-d05846a14cfe	window_heating_state	The enum value of "window heating state"		enum	All Data
e2abc97e-17fa-39bd-b40d-6ee12b358cbd	window_heating_state	Possible values: WINDOW_HEATING_STATE_INVALID, WINDOW_HEATING_STATE_OFF, WINDOW_HEATING_STATE_ON		enum	All Data

e761b218-2337-3a74-a211-ed6f72d864ef	window_heating_state	Possible values: WINDOW_HEATING_STATE_INVALID, WINDOW_HEATING_STATE_OFF, WINDOW_HEATING_STATE_ON		enum	All Data
14c7e318-fcea-3ed5-8284-a0309dc7527d	window_heating_state_front	State of front window heating	'-	String	All Data, Climatisation and Heating
920f460c-123e-3088-8d36-ba349b11f399	window_heating_state_rear	State of rear window heating	'-	String	All Data, Climatisation and Heating
fbc258c9-7905-3ee4-95eb-485e91146153	windows.[*].is_set	The values of: "windows" & "is set". Note that [*] in the key is replaced by a number.. The values of: "windows" & "is set". Note that [*] in the key is replaced by a number.		boolean	All Data, Vehicle Access, Vehicle Status
4b127ed5-8bca-3152-8def-60037e3278a5	windows.[*].open	Opening status of the window. The values of: "windows" & "open". Note that [*] in the key is replaced by a number.		boolean	All Data, Vehicle Access, Vehicle Status

f75ba52d-259e-3c0b-b0f8-3925866e280d	windows.[*].open	The values of: "windows" & "open". Note that [*] in the key is replaced by a number.. The values of: "windows" & "open". Note that [*] in the key is replaced by a number.		boolean	All Data, Vehicle Access, Vehicle Status
702c60f0-ab4a-397a-b848-424cdd2732e6	windows.[*].percent_open	Opening status of the window. The values of: "windows" & "percent open". Note that [*] in the key is replaced by a number.		boolean	All Data, Vehicle Access, Vehicle Status
4dfb991d-ef83-3c2a-a18d-9d02561d617d	windows.[*].percent_open	The values of: "windows" & "percent open". Note that [*] in the key is replaced by a number.. The values of: "windows" & "percent open". Note that [*] in the key is replaced by a number.		int	All Data, Vehicle Access, Vehicle Status
b932e36f-5017-3001-94fa-69e23d85db9a	windows.[*].position	Identifies the window, type ï¿½Positionï¿½ defined in ï¿½TTRVS_types_v1ï¿½. The values of: "windows" & "position". Note that [*] in the key is replaced by a number.		enum	All Data, Vehicle Access, Vehicle Status

cf0d0cef-00b2-3a59-944d-ce677f960bff	windows.[*].position	The values of: "windows" & "position". Note that [*] in the key is replaced by a number.. The values of: "windows" & "position". Note that [*] in the key is replaced by a number.		enum	All Data, Vehicle Access, Vehicle Status
73cc6e4b-2dd8-3c41-9985-87b125b4e71e	windows.[*].state	State of the information (valid/invalid); type ï¿½Stateï¿½ defined in ï¿½TTRVS_types_v1ï¿½. The values of: "windows" & "state". Note that [*] in the key is replaced by a number.		enum	All Data, Vehicle Access, Vehicle Status
03c99068-2df2-3e8e-9355-f08e304b2656	windows.[*].state	The values of: "windows" & "state". Note that [*] in the key is replaced by a number.. The values of: "windows" & "state". Note that [*] in the key is replaced by a number.		enum	All Data, Vehicle Access, Vehicle Status
ca862431-6954-3737-93af-4c1ae896b2cf	wireless_charging_error_code	Error code for wireless charging	'-	int	All Data, Charging
3e4785ab-a12f-3a68-a79e-8d37ece4b719	wireless_charging_mode	Mode of wireless charging	'-	String	All Data, Charging
ac2c540f-5345-3b27-8d9b-d3f3ca4ecf1c	wireless_charging_state	State of wireless charging	'-	String	All Data, Charging
9d4670a2-2142-3100-b277-cae6578a9e5b	wireless_connection_state	State of wireless connection	'-	String	All Data, Charging

07f4bc25-712f-355b-be74-a21eb51e3e8e	wireless_error_state_z_mover	Indicates error state of Z mover	'-	String	All Data, Charging
768a121e-8c41-3aec-b6e0-770edc749775	wireless_led_color	Indicates color of wireless LED	'-	String	All Data, Charging
bcba15b9-7842-389c-a8a4-22abd9c8fb50	wireless_led_state	State of wireless LED	'-	String	All Data, Charging
1b686e84-511e-3100-8b4f-63edc2eed932	wireless_panel_state	State of wireless panel	'-	String	All Data, Charging
9ef2605a-36eb-3378-95e1-bc851255a827	bem_alert_time	Delay after activation of the BEM2 pre-warning (12v battery BEM -level 2)	'-	int	All Data, Charging
053496dc-0a8e-3e0c-93fd-055e622d3f99	bem_level	BEM (Battery Energy Management) Level for auxiliary battery	%	int	All Data, Charging
ac6fa085-f5f7-391b-a5c9-ac7edcbc604b	bidirectional_charging_mode.amount_of_energy	Amount of used energy in bidirectional charging mode		float	All Data, Charging
5c313e9b-8b73-363b-9dc7-22aa86b43fed	bidirectional_charging_mode.amount_of_energy_threshold	Amount of used energy in bidirectional charging mode threshold		float	All Data, Charging
062aebad-665c-3880-a794-fd6535b17a91	bidirectional_charging_mode.bidi_max_Soc	Additional SOC range for bidirectional charging from maxSoc to greater than maxSoc. Setting is profile independet		int	All Data, Charging
afb326fb-e97b-3008-b870-5f8bbe636494	bidirectional_charging_mode.bidi_min_Soc	Additional SOC range for bidirectional charging from less than minSoc to minSoc. Setting is profile independet.		int	All Data, Charging

d614786f-de0b-3f79-b375-98ec4cfd75a8	bidirectional_charging_mode.charging_mode	Possible values: CHARGING_MODE_INVALID, CHARGING_MODE_HOMESTORAGECHARGING, CHARGING_MODE_EMERGENCY_SUPPLY, CHARGING_MODE_OFF_GRID_OPERATION		enum	All Data, Charging

b2278ea5-b5b5-3cf6-bee8-dab5dda97b68	bidirectional_charging_mode.mode_information	Possible values: INFORMATION_INVALID, INFORMATION_DISCHARGING_ACTIVE, INFORMATION_DISCHARGING_STOPPED, INFORMATION_HOME_STORAGE_CHARGING_ACTIVE, INFORMATION_HOME_STORAGE_CHARGING_STOPPED, INFORMATION_EMERGENCY_SUPPLY_ACTIVE, INFORMATION_EMERGENCY_SUPPLY_STOPPED, INFORMATION_OFF_GRID_OPERATION_ACTIVE, INFORMATION_OFF_GRID_OPERATION_STOPPED, INFORMATION_DISCHARGING_FINISHED_MIN_SOC, INFORMATION_BIDI_AVAILABLE_NO_PROFILE, INFORMATION_BIDI_NOT_POSSIBLE_MINSOC, INFORMATION_BIDI_NOT_POSSIBLE_GENERAL		enum	All Data, Charging
e0524804-fc3d-3260-b60f-c17de7c8f1c4	bidirectional_charging_mode.numbers_of_cycles	Bidirectional charging cycles		int	All Data, Charging

33b4be4a-8cb8-3ee0-8e53-7d559939702a	bidirectional_charging_mode.numbers_of_cycles_threshold	Bidirectional charging cycles threshold		int	All Data, Charging
f4507f8c-c554-3fa5-9ce0-a153ffc5dd4a	bidirectional_charging_mode.operating_hours	Operating hours counter		float	All Data, Charging
90f6d4c8-9c58-341d-94cd-e97bc1899931	bidirectional_charging_mode.operating_hours_threshold	Operating hours counter threshold		float	All Data, Charging
b8850eb7-e7d3-337c-838b-1788a532bc5e	bidirectional_charging_mode.quota	Bidirectional charging quota		float	All Data, Charging
93ea210c-e850-3231-a0c6-23b6567f9876	bidirectional_charging_mode.quota_Threshold	Bidirectional charging quota threshold		float	All Data, Charging
c5b624db-6a07-3957-9127-98cee0be6c98	boardnetBatteryVoltageIndication	current boardnet battery voltage	(V)	int	Vehicle Status
99de9ff3-cb15-3fda-b363-734b4282dfb6	calibration_activation	The enum value of "calibration activation"		enum	All Data
efb68454-6835-3ae7-b71c-2c3df0af26c3	calibration_failure	The enum value of "calibration failure"		enum	All Data
5c2fe31d-f7fd-3be7-929a-39cd3ab3c13e	calibration_failure_reason	The enum value of "calibration failure reason"		enum	All Data
cde4ae0d-de39-31e8-8a1a-3c2a853416d1	calibration_need_detected	The enum value of "calibration need detected"		enum	All Data

ccb6b60c-3984-319f-9c51-60aa33578035	calibration_request_method	Notifiaction: User can select one of the given calibration methods. Possible values: CALIBRATION_REQ_METHOD_UNDEFINED, CALIBRATION_REQ_METHOD_NONE, CALIBRATION_REQ_METHOD_FULL_CHARGE_RELAX, CALIBRATION_REQ_METHOD_FULL_CHARGE_AC60, CALIBRATION_REQ_METHOD_FULL_CHARGE_AC95		enum	All Data
d9a7c2d5-43d9-3010-b3da-646581ae8687	calibration_requests.calibration_request_escalation_1	Notification: First escalation request for a battery calibration. Possible values: Possible values: CALIBRATION_REQUEST_UNDEFINED, CALIBRATION_REQUEST_NONE, CALIBRATION_REQUEST_ACTIVE, CALIBRATION_REQUEST_ACK, CALIBRATION_REQUEST_REJECT		enum	All Data

1c968dcd-9c85-3554-83b0-5ddeddf6cb02	calibration_requests.calibration_request_escalation_2	Notification: Second escalation request for a battery calibration. Possible values: Possible values: CALIBRATION_REQUEST_UNDEFINED, CALIBRATION_REQUEST_NONE, CALIBRATION_REQUEST_ACTIVE, CALIBRATION_REQUEST_ACK, CALIBRATION_REQUEST_REJECT		enum	All Data
31c34f58-019d-3681-b447-c1adeacfb009	calibration_requests.calibration_request_initial	Notification: Initial request for a battery calibration. Possible values: Possible values: CALIBRATION_REQUEST_UNDEFINED, CALIBRATION_REQUEST_NONE, CALIBRATION_REQUEST_ACTIVE, CALIBRATION_REQUEST_ACK, CALIBRATION_REQUEST_REJECT		enum	All Data
c9e547fa-7efb-3670-8733-5bcfc6c0a16e	calibration_state	The enum value of "calibration state"		enum	All Data

7592e22a-e38f-3bac-ac14-d60557650fcb	capacity_measurement_data	Indicates the tank capacity in percentage	%	int	All Data, Dashboard Measurements
228a34f4-23c7-36e8-a9cf-977caa442759	car_captured_time	times and date (UTC) when the report has been sent to the backend		string	All Data
e3295e62-2ffb-3fc3-a7ce-7ccb43efebbf	car_captured_time	The string value of "car captured time"		string	All Data
2b60ce28-ee9b-327b-80bb-4d4b0d4a5bc3	car_captured_time	The string value of "car captured time"		string	All Data
a4041a54-c604-3e72-b182-158271ff4e7d	car_captured_time	The string value of "car captured time"		string	All Data
a6b9cb56-3538-3b6c-ac3d-338309c857fd	car_captured_time	The string value of "car captured time"		string	All Data
e86632ec-b96f-3232-9bf9-ebe27e990afb	car_captured_time	The string value of "car captured time"		string	All Data
785c7ccc-76e4-36d4-ba27-8c9ed664e6c7	car_captured_time	The string value of "car captured time"		string	All Data
45db10d7-e757-31bc-b3cb-cc3f26c03333	car_captured_time	The string value of "car captured time"		string	All Data
2b33b7f0-738f-328d-b6c8-bee45e803a47	car_captured_time	times and date (UTC) when the report has been sent to the backend		string	All Data
88714bc5-5c84-35e0-a0ce-d8fd54ad4633	car_captured_time	times and date (UTC) when the report has been sent to the backend		string	All Data
bad0afe1-23a4-39c7-b233-6dab350fa26c	car_captured_time	The string value of "car captured time"		string	All Data
4ee56d80-061b-385a-ab8c-5b30ac7649b1	car_captured_time	timestamp when RPC (Java-ICAS1)has sent the report to the backend		string	All Data

8883bf69-2d6a-322f-a910-be34ec77a2a4	car_captured_time	The string value of "car captured time"		string	All Data
e332925d-fdef-3f14-89f4-76b841f005b8	car_captured_time	times and date (UTC) when the report has been sent to the backend		string	All Data
9f69b287-0df9-374c-aec1-32f09a81f07b	car_captured_time	The string value of "car captured time"		string	All Data
8754cf24-0741-3f45-ac17-764ba960139f	car_captured_time	timestamp when RPC (Java-ICAS1)has sent the report to the backend		string	All Data
f9e0f13e-be8c-359c-a00b-7418a34b3420	car_captured_time	The string value of "car captured time"		string	All Data
45e8d399-9030-3853-87db-6b8b4d48309a	car_captured_time	The string value of "car captured time"		string	All Data
ee9423a8-f1eb-3142-880e-88c12a52d1c5	car_captured_time	The string value of "car captured time"		string	All Data
42986641-9117-3669-89eb-430e8c415ca7	car_captured_time	timestamp when RPC (Java-ICAS1)has sent the report to the backend		string	All Data
47015e31-2d7f-3cda-a6c3-0dfa3123b925	car_captured_time	times and date (UTC) when the report has been sent to the backend		string	All Data
9e1dc4b0-7c24-35b9-9986-2c939bd44c3f	car_captured_time	times and date (UTC) when the report has been sent to the backend		string	All Data
ae3569a4-3e3e-350b-9dd4-0b675132918d	car_captured_time	The string value of "car captured time"		string	All Data
831cb207-047c-3d7d-b6ed-5433bfe1cbe7	car_captured_time	The string value of "car captured time"		string	All Data

1acad4b1-8026-357f-acf7-a5c18fe23f3f	car_captured_time	The timestamp when the ICAS1 (Java service in the car) has sent the report to the --> OCU --> DP		string	All Data
4ac05f4e-e67d-34e5-b306-ecf2cbea0deb	car_captured_time	The string value of "car captured time"		string	All Data
607783dd-f37e-3890-8b6e-34b4798a1b14	car_captured_time	The timestamp when the ICAS1 (Java service in the car) has sent the report to the --> OCU --> DP		string	All Data
f25e91bb-c5f3-3e35-b54b-4bcccbdc4cb9	car_captured_time	The timestamp when the ICAS1 (Java service in the car) has sent the report to the --> OCU --> DP		string	All Data
49483a41-6452-3438-ac80-2087775c4fe5	car_captured_time	Timestamp when the ICAS1 (Java service in the car) has sent the report to the --> OCU --> DP		string	All Data
2496cd73-8a68-318c-a159-200ecfd0e47d	car_captured_time	Timestamp when the ICAS1 (Java service in the car) has sent the report to the --> OCU --> DP		string	All Data
f122e87c-f121-37de-bffd-7ca663e597c7	car_captured_time	The string value of "car captured time"		string	All Data

89a55664-59a4-3a91-9f6e-83668467ac0c	car_captured_time	The timestamp when the ICAS1 (Java service in the car) has sent the report to the --> OCU --> DP		string	All Data
df0ec81d-ce2e-397d-9301-e42fedb203c1	car_captured_time	The string value of "car captured time"		string	All Data
72e1ae0b-580f-371a-b3b7-730a66df681e	car_captured_time	The string value of "car captured time"		string	All Data
c8901fd0-07cb-3578-814c-e47d14b51a69	car_captured_time	The timestamp when the ICAS1 (Java service in the car) has sent the report to the --> OCU --> DP		string	All Data
87c0286f-a663-3082-ba14-86685054ad9d	car_captured_time	The string value of "car captured time"		string	All Data
90dc52b2-e0ab-3a86-941a-e9aead718222	car_captured_time	Timestamp when the ICAS1 (Java service in the car) has sent the report to the --> OCU --> DP		string	All Data
c7cdaf19-c935-3e3b-84b9-ed173519765c	car_captured_time	Timestamp when the ICAS1 (Java service in the car) has sent the report to the --> OCU --> DP		string	All Data
89f70f79-0bc0-345d-aba3-5a8d2140e7d4	car_captured_time	The string value of "car captured time"		string	All Data
7c8ec93e-74ce-3761-985d-5580f0f4bf26	car_captured_time	Times and date (UTC) when the report has been sent to the backend		string	All Data

bc85e77a-7d12-3d08-89e3-7505c752dc37	car_captured_time	The string value of "car captured time"		string	All Data
95cb1f03-d6f5-3f52-8954-61139bdb99d6	car_captured_time	The string value of "car captured time"		string	All Data
29e50a87-82cc-3d99-aebb-b890052d1feb	car_captured_time	The timestamp when the ICAS1 (Java service in the car) has sent the report to the --> OCU --> DP		string	All Data
fce3b0f3-6206-3d8c-bf1c-905b5a2e1fb0	car_captured_time	Timestamp when the ICAS1 (Java service in the car) has sent the report to the --> OCU --> DP		string	All Data
c797bbd6-cb02-3be2-8d4e-9fdc083d7343	car_captured_time	The string value of "car captured time"		string	All Data
77f91d75-860e-3691-a408-9dab060f89ee	car_captured_time	Timestamp when the ICAS1 (Java service in the car) has sent the report to the --> OCU --> DP		string	All Data
9d044be1-53c1-3e2f-b532-b00e6d505783	car_captured_utc_timestamp	Date and time when the report has been created, represented by the number of seconds that have elapsed since 00:00:00 Thursday, 1 January 1970. - DPS - Range Management		string	All Data

295187a1-3fbc-3f65-aba6-ce2f31285ef4	car_captured_utc_timestamp	Date and time when the report has been created, represented by the number of seconds that have elapsed since 00:00:00 Thursday, 1 January 1970. - DPS - Range Management		string	All Data
9b377d04-c63b-3eda-a84a-4e2de581f1e3	car_captured_utc_timestamp	Date and time when the report has been created, represented by the number of seconds that have elapsed since 00:00:00 Thursday, 1 January 1970. - DPS - Range Management		string	All Data
2e0ca17a-962a-3c73-b532-0d60c21020fc	car_captured_utc_timestamp	Date and time when the report has been created, represented by the number of seconds that have elapsed since 00:00:00 Thursday, 1 January 1970. - DPS - Range Management		string	All Data
262b34e4-831f-37ef-af20-7a13da5706dc	car_captured_utc_timestamp	Date and time when the report has been created, represented by the number of seconds that have elapsed since 00:00:00 Thursday, 1 January 1970. - DPS - Range Management		string	All Data

b6578915-a5d6-329d-8949-c0e567400cb1	car_captured_utc_timestamp	Date and time when the report has been created, represented by the number of seconds that have elapsed since 00:00:00 Thursday, 1 January 1970. - DPS - Range Management		string	All Data
dd27c928-9a72-3fc8-935a-6e328d080977	car_captured_utc_timestamp	Date and time when the report has been created, represented by the number of seconds that have elapsed since 00:00:00 Thursday, 1 January 1970. - DPS - Range Management		string	All Data
a7537a9c-a269-307a-a15c-2bc59454c25b	car_captured_utc_timestamp	Date and time when the report has been created, represented by the number of seconds that have elapsed since 00:00:00 Thursday, 1 January 1970. - DPS - Range Management		string	All Data
12c88f08-e0f5-3798-9b69-ab3d38ccbad8	car_captured_utc_timestamp	Date and time when the report has been created, represented by the number of seconds that have elapsed since 00:00:00 Thursday, 1 January 1970. - DPS - Range Management		string	All Data

a56dfff2-0f8f-3c72-be78-e1adcc4c2931	car_captured_utc_timestamp	Date and time when the report has been created, represented by the number of seconds that have elapsed since 00:00:00 Thursday, 1 January 1970. - DPS - Range Management		string	All Data
5768ad07-5ef9-3d6f-9526-978980d7e40a	car_captured_utc_timestamp	Date and time when the report has been created, represented by the number of seconds that have elapsed since 00:00:00 Thursday, 1 January 1970. - DPS - Range Management		string	All Data
0140e2ae-3ca2-3991-a97b-ba07bf139bd7	car_captured_utc_timestamp	Date and time when the report has been created, represented by the number of seconds that have elapsed since 00:00:00 Thursday, 1 January 1970. - DPS - Range Management		string	All Data
6ce43709-73fc-3024-806f-068aad8ca9d2	car_captured_utc_timestamp	Date and time when the report has been created, represented by the number of seconds that have elapsed since 00:00:00 Thursday, 1 January 1970. - DPS - Range Management		string	All Data

72effed7-4ee6-33d6-922a-0876c6e17056	car_captured_utc_timestamp	Date and time when the report has been created, represented by the number of seconds that have elapsed since 00:00:00 Thursday, 1 January 1970. - DPS - Range Management		string	All Data
ca741a57-d547-3fe2-b994-b9e59465ce0e	amsSource	information about current Active media source in vehicle		string	Infotainment Related Data
d70aa566-c751-31b4-b039-0504d6947122	charged_energy	Charged energy 143 -> 14.3 kWh	kWh	int	All Data, Charging
6b6bb06e-2a14-39d6-b72b-a56955bdfbc5	chargeEnergy	charging energy (EV vehicle must be connected to charger)	kWh	int	Charging
b4d5d426-faea-37fd-8274-8fd4a386e535	charge_mode	Indicates mode of charging	'-	String	All Data, Charging
ac47bec5-b25f-3287-aa83-02fe0bcb2494	charge_mode_selection_options.home_storage_charging	The boolean value of "charge mode selection options home storage charging"		boolean	All Data, Charging
c75fddcf-cdb1-3921-9570-3d08017ea277	charge_mode_selection_options.immediate_charging	The boolean value of "charge mode selection options immediate charging"		boolean	All Data, Charging
1763a4fe-d8a6-3b8c-b095-70081f3e61c7	charge_mode_selection_options.immediate_discharging	The boolean value of "charge mode selection options immediate discharging"		boolean	All Data, Charging

89049f0f-9481-3c8e-bfd4-16c2935963ae	charge_mode_selection_options.only_own_current	The boolean value of "charge mode selection options only own current"		boolean	All Data
d0fea44d-fe29-3dd8-969c-d687f3f0cb77	charge_mode_selection_options.preferred_charging_times	The boolean value of "charge mode selection options preferred charging times"		boolean	All Data, Charging
5c291f94-f7fb-35ce-89dd-90dd7ee31b1a	charge_mode_selection_options.timer_charging	The boolean value of "charge mode selection options timer charging"		boolean	All Data, Charging
cdd68160-2c48-3181-af84-79d0a4109d32	charge_mode_selection_options.timer_charging_climatization	The boolean value of "charge mode selection options timer charging climatization"		boolean	All Data, Climatisation and Heating
63e4ad8b-c556-34bd-8185-618d5c34f9b2	chargePower	actual charge power to the hv battery (EV vehicle must be connected to charger)the charger	kWh	string	Charging
732b602c-ec3a-3f77-805f-77ec03bf0e5a	chargeRate	actual rate of the charging process based on the average energy comsumption for driving range (EV vehicle must be connected to charger)	kmPerHour	int	Charging
f4cca318-8c7d-3a5e-a2af-04559e298e68	charge_rate_unit	Unit of charge rate	'-	String	All Data, Charging
cf5f35d3-e569-3b38-b0cf-b09c0e99aebd	charge_target_time	Target time for charging in Day,hour,minute,month,offset,year with # as delimeter	'-	String	All Data, Charging

ea79c4db-5ef3-3090-be19-0649474a16b8	chargeTargetTime	estimated end time of current charge process (EV vehicle must be connected to charger)	(min)	int	Charging
0f387b6d-ded5-34d5-b3c4-d7e48659915b	chargeTargetTimeOffset	difference between target time and estimated end of remaining charge time (EV vehicle must be connected to charger)	(min)	int	Charging
8a1a81d1-eddc-31ee-94b1-36f8228193fb	charge_time_display	Indicates details of remaining charge time	'-	String	All Data, Charging
86df6747-e512-39b2-9de3-6b2458be62fb	chargeType	information about charge type the car is connected to and used for charging (EV vehicle must be connected to charger)		string	Charging
b6e7ee32-4306-3969-bfda-780a8ce07256	chargingBatteryEnergy	information about the amount of energy charged in battery	kWh	int	Charging
97c7b448-13e7-3266-a6be-7487caf1a354	charging_mode	Mode of charging	'-	String	All Data, Charging
37d8c0c0-9677-3823-8b32-d0a5001cb0d0	charging_plug1_connectionstate	Conection state of charging plug1	'-	String	All Data, Charging
eb33ae12-1481-36e5-b228-c74fa5478eb5	charging_plug1_flap_lock_state	State of charging plug1 flap lock	'-	String	All Data, Charging
33bf521d-b194-3b38-97c3-1b63727676d1	charging_plug1_flap_state	State of the infra related to charging plug1 flap	'-	String	All Data, Charging
2efcd0ec-6188-3fbc-a455-8dabe4df3b2b	charging_plug1_infrastructure_state	State of the infra related to charging plug1	'-	String	All Data, Charging

9f020a2c-f4d8-380f-8afb-77ee9fc9e4d3	charging_plug1_lock_state	State of charging plug1 lock	'-	String	All Data, Charging
d3ada06c-3910-34f5-bb98-3e5813bbe8da	charging_plug2_connectionstate	Conection state of charging plug2	'-	String	All Data, Charging
cd4aec42-7620-38bc-a285-92626ca7cc91	charging_plug2_flap_lock_state	State of charging plug2 flap lock	'-	String	All Data, Charging
7e50ef29-05bc-36c3-8e31-d51ee67f7eb7	charging_plug2_flap_state	State of the infra related to charging plug2 flap	'-	String	All Data, Charging
2e6b0c49-6e9c-33ae-b83b-a9920c48c0b3	charging_plug2_infrastructure_state	State of the infra related to charging plug2	'-	String	All Data, Charging
db1eb937-aac2-305f-a43a-f35d61033b67	charging_plug2_lock_state	State of charging plug2 lock	'-	String	All Data, Charging
978be4ed-2f7f-32c0-8644-18e7b0dde741	charging_power	Power of charging	'-	int	All Data, Charging
61118afe-a4e4-3750-b1ad-2b38ff1d349b	charging_reason_trigger	Trigger for charging	'-	String	All Data, Charging
1920d136-854f-3a0c-905a-1dcbdfc955bd	charging_scenario	Indicates Charging Scenario	'-	String	All Data, Charging
9da735bb-c5d5-39f8-bf53-0fa2a367aa8f	charging_state	Indicates the state of charging with invalid, unsupported, off, charching, completed, error, conservationCharging	'-	String	All Data, Charging
4c81b70a-b304-3df3-bb25-53cbc10e7236	charging_state_error_code	Error code will be set here in case of an error with charging state	'-	int	All Data, Charging

d6d9e458-88c5-38b7-95b6-247b1a5063b2	charging_state_report.charge_mode	Informs about the charge mode. Possible values: CHARGE_MODE_INVALID, CHARGE_MODE_IMMEDIATELY_STOPPED, CHARGE_MODE_IMMEDIATELY_DEFAULT, CHARGE_MODE_IMMEDIATELY_PROFILE, CHARGE_MODE_EXTENDED_PROFILE, CHARGE_MODE_EXTENDED_STOPPED		enum	All Data, Charging
b695b7e8-0fe4-3aad-b2b2-a624746f0344	charging_state_report.charge_mode	Informs about the charge mode. Possible values: CHARGE_MODE_INVALID, CHARGE_MODE_IMMEDIATELY_STOPPED, CHARGE_MODE_IMMEDIATELY_DEFAULT, CHARGE_MODE_IMMEDIATELY_PROFILE, CHARGE_MODE_EXTENDED_PROFILE, CHARGE_MODE_EXTENDED_STOPPED		enum	All Data, Charging
45410f9e-b068-3dc7-9afb-238a2ef7454e	charging_state_report.charge_mode	The enum value of "charging state report charge mode"		enum	All Data, Charging

c5a4b6cd-9f8c-32aa-8871-4653362318ad	charging_state_report.charge_mode	Informs about the charge mode. Possible values: CHARGE_MODE_INVALID, CHARGE_MODE_IMMEDIATELY_STOPPED, CHARGE_MODE_IMMEDIATELY_DEFAULT, CHARGE_MODE_IMMEDIATELY_PROFILE, CHARGE_MODE_EXTENDED_PROFILE, CHARGE_MODE_EXTENDED_STOPPED		enum	All Data, Charging
f994c025-a69f-39ae-8860-9cb9a2ea9ed8	charging_state_report.charge_type	Informs about the charge type the car is connected to and used for charging. Possible values: CHARGE_TYPE_INVALID, CHARGE_TYPE_OFF, CHARGE_TYPE_AC, CHARGE_TYPE_DC		enum	All Data, Charging
b942e990-6a4e-351b-81ce-84e27d13d97a	charging_state_report.charge_type	Informs about the charge type the car is connected to and used for charging. Possible values: CHARGE_TYPE_INVALID, CHARGE_TYPE_OFF, CHARGE_TYPE_AC, CHARGE_TYPE_DC		enum	All Data, Charging

a5fa0f82-e717-36ec-a1d7-ed05b47295f8	charging_state_report.charge_type	The enum value of "charging state report charge type"		enum	All Data, Charging
33bb1490-adbb-3a14-9abf-e68417d46f0b	charging_state_report.charge_type	Informs about the charge type the car is connected to and used for charging. Possible values: CHARGE_TYPE_INVALID, CHARGE_TYPE_OFF, CHARGE_TYPE_AC, CHARGE_TYPE_DC		enum	All Data, Charging

abf1baf4-86e6-35e5-9936-df515fd1743c	charging_state_report.charging_scenario	Informs about the actual charging scenario. States are also used for brand specific configurations at charging LED. Possible values: CHARGING_SCENARIO_INVALID, CHARGING_SCENARIO_OFF, CHARGING_SCENARIO_CHARGING_TO_DEPARTURE_TIME_FINISHED, CHARGING_SCENARIO_IMMEDIATELY_CHARGING_FINISHED, CHARGING_SCENARIO_OPTIMISED_CHARGING_FINISHED, CHARGING_SCENARIO_CHARGING_TO_DEPARTURE_TIME_ACTIVE, CHARGING_SCENARIO_IMMEDIATELY_CHARGING_ACTIVE, CHARGING_SCENARIO_OPTIMISED_CHARGING_		enum	All Data, Charging

c7aa1c25-7c32-3b9a-a732-1d9fd786bbfe	charging_state_report.charging_scenario	Informs about the actual charging scenario. States are also used for brand specific configurations at charging LED. Possible values: CHARGING_SCENARIO_INVALID, CHARGING_SCENARIO_OFF, CHARGING_SCENARIO_CHARGING_TO_DEPARTURE_TIME_FINISHED, CHARGING_SCENARIO_IMMEDIATELY_CHARGING_FINISHED, CHARGING_SCENARIO_OPTIMISED_CHARGING_FINISHED, CHARGING_SCENARIO_CHARGING_TO_DEPARTURE_TIME_ACTIVE, CHARGING_SCENARIO_IMMEDIATELY_CHARGING_ACTIVE, CHARGING_SCENARIO_OPTIMISED_CHARGING_ACTIVE		enum	All Data, Charging
a8b48aad-8cd4-3534-b64d-6c8abd600972	charging_state_report.charging_scenario	The enum value of "charging state report charging scenario"		enum	All Data, Charging

0ba7abe4-14d5-3541-adec-31be0ecdfcc9	charging_state_report.charging_scenario	Informs about the actual charging scenario. States are also used for brand specific configurations at charging LED. Possible values: CHARGING_SCENARIO_INVALID, CHARGING_SCENARIO_OFF, CHARGING_SCENARIO_CHARGING_TO_DEPARTURE_TIME_FINISHED, CHARGING_SCENARIO_IMMEDIATELY_CHARGING_FINISHED, CHARGING_SCENARIO_OPTIMISED_CHARGING_FINISHED, CHARGING_SCENARIO_CHARGING_TO_DEPARTURE_TIME_ACTIVE, CHARGING_SCENARIO_IMMEDIATELY_CHARGING_ACTIVE, CHARGING_SCENARIO_OPTIMISED_CHARGING_		enum	All Data, Charging

96c211b4-f8fb-3f40-b7cf-6a1cd12cce6d	charging_state_report.current_charge_state	Possible values: CHARGE_STATE_INVALID, CHARGE_STATE_NOT_READY_FOR_CHARGING, CHARGE_STATE_READY_FOR_CHARGING, CHARGE_STATE_CHARGING_HV_BATTERY, CHARGE_STATE_DISCHARGING, CHARGE_STATE_CHARGE_PURPOSE_REACHED_AND_NOT_CONSERVATION_CHARGING, CHARGE_STATE_CHARGE_PURPOSE_REACHED_AND_CONSERVATION, CHARGE_STATE_CONSERVATION_CHARGING, CHARGE_STATE_CHARGING_ERROR		enum	All Data, Charging

3581f1e0-580b-3f18-aa73-6fbf037b841e	charging_state_report.current_charge_state	Possible values: CHARGE_STATE_INVALID, CHARGE_STATE_NOT_READY_FOR_CHARGING, CHARGE_STATE_READY_FOR_CHARGING, CHARGE_STATE_CHARGING_HV_BATTERY, CHARGE_STATE_DISCHARGING, CHARGE_STATE_CHARGE_PURPOSE_REACHED_AND_NOT_CONSERVATION_CHARGING, CHARGE_STATE_CHARGE_PURPOSE_REACHED_AND_CONSERVATION, CHARGE_STATE_CONSERVATION_CHARGING, CHARGE_STATE_CHARGING_ERROR		enum	All Data, Charging
a08cca2b-ed42-37bc-b160-d015ce205d3d	charging_state_report.current_charge_state	The enum value of "charging state report current charge state"		enum	All Data, Charging

0811aa96-26d8-3d5f-8bd7-77be06612d85	charging_state_report.current_charge_state	Possible values: CHARGE_STATE_INVALID, CHARGE_STATE_NOT_READY_FOR_CHARGING, CHARGE_STATE_READY_FOR_CHARGING, CHARGE_STATE_CHARGING_HV_BATTERY, CHARGE_STATE_DISCHARGING, CHARGE_STATE_CHARGE_PURPOSE_REACHED_AND_NOT_CONSERVATION_CHARGING, CHARGE_STATE_CHARGE_PURPOSE_REACHED_AND_CONSERVATION, CHARGE_STATE_CONSERVATION_CHARGING, CHARGE_STATE_CHARGING_ERROR		enum	All Data, Charging
914924d0-5a46-3867-8e07-542170a56c05	charging_state_report.error_code	The car is an state which avoid start charging although the customer must not be inform with a popup/notification. For example: battery low		int	All Data, Charging

cc22c5ea-f4bd-35df-8da6-da8d62fe2cb5	charging_state_report.error_code	The car is an state which avoid start charging although the customer must not be inform with a popup/notification. For example: battery low		int	All Data, Charging
d726c45d-3772-39be-80c1-0e82d448aa95	charging_state_report.error_code	The int value of "charging state report error code"		int	All Data, Charging
da36f14f-a040-3a1d-b040-6e2499085eca	charging_state_report.error_code	The car is an state which avoid start charging although the customer must not be inform with a popup/notification. For example: battery low		int	All Data, Charging

cd818487-0687-3a3f-9044-26d1f22860ba	charging_state_report.immediate_action_state	IMMEDIATE_ACTION_STATE_INVALID, IMMEDIATE_ACTION_STATE_IMMEDIATE_ACTION_TIME, IMMEDIATE_ACTION_STATE_IMMEDIATE_CHARGING, IMMEDIATE_ACTION_STATE_IMMEDIATE_ACTION_STOPPED, IMMEDIATE_ACTION_STATE_IMMEDIATE_ACTION_RANGE, IMMEDIATE_ACTION_STATE_IMMEDIATE_ACTION_SOC, IMMEDIATE_ACTION_STATE_CHARGE_MODE_SELECTION		enum	All Data, Charging

1581d30c-e516-3cfe-8f54-f4142122a6a7	charging_state_report.immediate_action_state	IMMEDIATE_ACTION_STATE_INVALID, IMMEDIATE_ACTION_STATE_IMMEDIATE_ACTION_TIME, IMMEDIATE_ACTION_STATE_IMMEDIATE_CHARGING, IMMEDIATE_ACTION_STATE_IMMEDIATE_ACTION_STOPPED, IMMEDIATE_ACTION_STATE_IMMEDIATE_ACTION_RANGE, IMMEDIATE_ACTION_STATE_IMMEDIATE_ACTION_SOC, IMMEDIATE_ACTION_STATE_CHARGE_MODE_SELECTION		enum	All Data, Charging
4c4f3038-d18b-3d3c-87fd-335cbfa4b364	charging_state_report.immediate_action_state	The enum value of "charging state report immediate action state"		enum	All Data, Charging

defd7ed1-c1aa-318a-9324-bd91a9c52246	charging_state_report.immediate_action_state	IMMEDIATE_ACTION_STATE_INVALID, IMMEDIATE_ACTION_STATE_IMMEDIATE_ACTION_TIME, IMMEDIATE_ACTION_STATE_IMMEDIATE_CHARGING, IMMEDIATE_ACTION_STATE_IMMEDIATE_ACTION_STOPPED, IMMEDIATE_ACTION_STATE_IMMEDIATE_ACTION_RANGE, IMMEDIATE_ACTION_STATE_IMMEDIATE_ACTION_SOC, IMMEDIATE_ACTION_STATE_CHARGE_MODE_SELECTION		enum	All Data, Charging

d654c183-4fd3-3f1f-b41d-e464798d6078	charging_state_report.profile_charge_reason	The property informs about the specific reason why the charging process ist currently running when a profile is active. An profile is active when chargeMode is "immediatly profile" or "extended profile. Possible values: PROFILE_CHARGE_REASON_INVALID, PROFILE_CHARGE_REASON_MIN_SOC, PROFILE_CHARGE_REASON_MAX_SOC, PROFILE_CHARGE_REASON_OWN_CURRENT, PROFILE_CHARGE_REASON_SMART_CHARGING, PROFILE_CHARGE_REASON_LOW_COST		enum	All Data, Charging

1e12abd7-4ef5-334a-b380-3118e45f7fd4	charging_state_report.profile_charge_reason	The property informs about the specific reason why the charging process ist currently running when a profile is active. An profile is active when chargeMode is "immediatly profile" or "extended profile. Possible values: PROFILE_CHARGE_REASON_INVALID, PROFILE_CHARGE_REASON_MIN_SOC, PROFILE_CHARGE_REASON_MAX_SOC, PROFILE_CHARGE_REASON_OWN_CURRENT, PROFILE_CHARGE_REASON_SMART_CHARGING, PROFILE_CHARGE_REASON_LOW_COST		enum	All Data, Charging
b7c1c672-4c96-3088-aaac-bd8899e486f5	charging_state_report.profile_charge_reason	The enum value of "charging state report profile charge reason"		enum	All Data, Charging

6ff34f11-ba35-3afe-b360-7cdd24f53442	charging_state_report.profile_charge_reason	The property informs about the specific reason why the charging process ist currently running when a profile is active. An profile is active when chargeMode is "immediatly profile" or "extended profile. Possible values: PROFILE_CHARGE_REASON_INVALID, PROFILE_CHARGE_REASON_MIN_SOC, PROFILE_CHARGE_REASON_MAX_SOC, PROFILE_CHARGE_REASON_OWN_CURRENT, PROFILE_CHARGE_REASON_SMART_CHARGING, PROFILE_CHARGE_REASON_LOW_COST		enum	All Data, Charging
a0efe9e2-7633-3dea-a948-4c0b4a358c2b	climate_error_code	the state represents an aborted situation, which avoid start AC. The customer must not be informed with a popup/notification in this situation		int	All Data, Climatisation and Heating

5c863513-7a6c-399d-989b-c84bb4a33df8	climate_error_code	the state represents an aborted situation, which avoid start AC. The customer must not be informed with a popup/notification in this situation		int	All Data, Climatisation and Heating
7c426272-4ccc-3368-bacb-ac1278d26337	climate_error_code	the state represents an aborted situation, which avoid start AC. The customer must not be informed with a popup/notification in this situation		int	All Data, Climatisation and Heating
c129d05d-de28-3490-a74a-27811b5e8e2e	cng_gas_level	Gas level in percentage	%	int	All Data, Dashboard Measurements
153e8c40-4c6c-3c17-a11b-0ecc35d55b81	cruising_range_combined	Combined available range for primary and secondary engine in kilometer	km	int	All Data, Breakdown
55e0d40b-38ed-3cb5-9dcd-6193df6fc493	cruising_range_primary_engine	Available range for primary engine in kilometer	km	int	All Data, Breakdown
3dedefab-8ded-3f5a-907f-d5e9970720bf	cruising_range_secondary_engine	Available range for secondary engine in kilometer	km	int	All Data, Breakdown
707ad8ef-a307-333b-ab80-124af20af3bd	currentChargeState	information about the State of Charging process of the vehicle (EV vehicle must be connected to charger)		string	Charging

5aafef2b-f697-3e21-b8b3-012808011c6f	data	Container that carries the raw data. TLV Encoded		string	All Data
91adf535-a36b-3b73-aa18-99c59f647886	data	Container that carries the raw data. TLV Encoded		string	All Data
bc176347-fb8c-3dea-9cb9-62fb0b42ad36	data_filter_hash	Unique hash for identifying latest datafilter configuration in the backend		string	All Data
310b07f2-55f6-30d1-bfde-80b87a14ef57	data_filter_hash	Unique hash for identifying latest datafilter configuration in the backend		string	All Data
c1465986-2f76-3b4f-8e52-9819481a8e60	distance.state	The enum value of "distance state"		enum	All Data
ea58e713-ef44-3150-9303-edfc519dcdc1	inspectionDistance	distance to next inspection	(km)	int	Maintenance Related Information
b06b7c81-2de5-3aa3-847c-4ee16a56233b	inspectionOilDistance	distance to next oil inspection	(km)	int	Maintenance Related Information
4af0f776-5487-32b8-a054-b352ac1d6692	distance.unit	The enum value of "distance unit"		enum	All Data
938f759e-fd4c-3274-9f3d-c78d4aab4f76	distance.value	The int value of "distance value"		int	All Data

b60079d3-67da-3ac2-a471-5e755ccb15be	doors.[*].is_set	The values of: "doors" & "is set". Note that [*] in the key is replaced by a number.. The values of: "doors" & "is set". Note that [*] in the key is replaced by a number.		boolean	All Data, Vehicle Access, Vehicle Status
56b6ef8f-4af8-3b41-95bf-8db17527f12d	doors.[*].locked	The values of: "doors" & "locked". Note that [*] in the key is replaced by a number.. The values of: "doors" & "locked". Note that [*] in the key is replaced by a number.		boolean	All Data, Vehicle Access, Vehicle Status
b525e89d-1032-3e98-aae7-a138efcb2aa0	doors.[*].locked	Lock status. The values of: "doors" & "locked". Note that [*] in the key is replaced by a number.		boolean	All Data, Vehicle Access, Vehicle Status
a873b8c3-0f56-3ab6-a846-4574749ac795	doors.[*].open	The values of: "doors" & "open". Note that [*] in the key is replaced by a number.. The values of: "doors" & "open". Note that [*] in the key is replaced by a number.		boolean	All Data, Vehicle Access, Vehicle Status

a1eb9722-4b70-3f57-88e6-a549e0480f56	doors.[*].open	Openig status. The values of: "doors" & "open". Note that [*] in the key is replaced by a number.		boolean	All Data, Vehicle Access, Vehicle Status
341b8505-e00b-3935-8999-e381016d11f2	doors.[*].position	The values of: "doors" & "position". Note that [*] in the key is replaced by a number.. The values of: "doors" & "position". Note that [*] in the key is replaced by a number.		enum	All Data, Vehicle Access, Vehicle Status
bfdb7061-4630-3db1-87cc-a478675780d0	doors.[*].position	Identifies the door, type ï¿½Positionï¿½ defined in ï¿½TTRVS_types_v1ï¿½. The values of: "doors" & "position". Note that [*] in the key is replaced by a number.		enum	All Data, Vehicle Access, Vehicle Status
29ce5685-6ff1-380c-8c85-6dca496f6f7e	doors.[*].safe	The values of: "doors" & "safe". Note that [*] in the key is replaced by a number.. The values of: "doors" & "safe". Note that [*] in the key is replaced by a number.		boolean	All Data, Vehicle Access, Vehicle Status
e6a097af-c04e-3cd9-8ecf-3f892f312a7d	doors.[*].safe	Safe status. The values of: "doors" & "safe". Note that [*] in the key is replaced by a number.		boolean	All Data, Vehicle Access, Vehicle Status

50cd8e22-72ec-3266-96a7-268ce5d1771b	doors.[*].state	The values of: "doors" & "state". Note that [*] in the key is replaced by a number.. The values of: "doors" & "state". Note that [*] in the key is replaced by a number.		enum	All Data, Vehicle Access, Vehicle Status
b1fa453b-1e5b-391e-a535-a1082f4db926	doors.[*].state	State of the information (valid/invalid); type ï¿½Stateï¿½ defined in ï¿½TTRVS_types_v1ï¿½. The values of: "doors" & "state". Note that [*] in the key is replaced by a number.		enum	All Data, Vehicle Access, Vehicle Status
65c10552-ff56-3db9-a827-93f19b23705d	doorTrunkStateIndication	current state of trunk door		string	Vehicle Status
e12ccb68-ba91-3839-a334-cb190916242e	dwa_active_state	The enum value of "dwa active state"		enum	All Data
326c7a78-b71a-3648-b3da-e64464e6d0c4	dwa_alarm_reason	The enum value of "dwa alarm reason"		enum	All Data
c85a4804-f7e5-36b1-ac03-66dc36fe847e	dwa_alarm_state	The enum value of "dwa alarm state"		enum	All Data
0f43f2e7-3556-36a9-8271-a60bc54afad8	echo	TSS always creates a fixed value of echo every time a report is received	'-	String	All Data
84e64812-6eaa-3477-b587-0c5b02d8446f	energy_contents.current_energy_content.physical_value	The float value of "energy contents current energy content physical value"		float	All Data

fbe8bab2-344e-34c8-8ac4-4b18156128cf	energy_contents.current_energy_content.value_type	The enum value of "energy contents current energy content value type"		enum	All Data
09ed1319-7b17-31c6-ba74-817ce91a4c1d	energy_contents.maximal_energy_content.physical_value	The float value of "energy contents maximal energy content physical value"		float	All Data
9c171290-fe3d-3304-890e-b9a52fbc5ef5	energy_contents.maximal_energy_content.value_type	The enum value of "energy contents maximal energy content value type"		enum	All Data
769f98fd-b821-367e-8434-e2c92fc5c52e	energy_flow	Flow of energy	'-	String	All Data, Charging
c83bab6f-02df-36c1-8c59-af4ae2e3a808	enginehood.is_set	The boolean value of "enginehood is set"		boolean	All Data
7cb3f0c6-ad8e-3f60-be61-c0772cb65421	enginehood.locked	The boolean value of "enginehood locked"		boolean	All Data
8540dd41-556c-3e41-aea9-3e28f8d80a2a	enginehood.open	The boolean value of "enginehood open"		boolean	All Data
b7dc3d7a-ae0e-3047-b070-d5392349e627	enginehood.safe	The boolean value of "enginehood safe"		boolean	All Data
4db99550-91ab-3cef-94cb-488dd971d26a	enginehood.state	The enum value of "enginehood state"		enum	All Data
7b567b84-b1e1-3542-b074-49e03e87a0c9	engineState	The enum value of "engineState"		enum	All Data
eb9af4c0-5f9e-3245-995c-c3d9f635c852	engine_status	The enum value of "engine status"		enum	All Data
6c396e50-06a9-3e86-a533-a367ce67e800	engine_status	The enum value of "engine status"		enum	All Data
a6f7d8c1-f46e-3616-8e7c-ad44864944c8	engine_status	The enum value of "engine status"		enum	All Data

27860466-37c1-3777-9bd0-93b4896fe436	engine_type	The enum value of "engine type"		enum	All Data
94ea744b-6ad1-3495-9c23-70fc17b23fa4	engine_type	The enum value of "engine type"		enum	All Data
6132f36f-a856-3467-a976-639559a1370b	error_code	error=1 if one parameter has invalid/unknown value (for example: temperature=3000ï¿½C in the car). error=2 time out in the car (for example: service temperature is not available)		int	All Data
b24b8c24-662b-3540-9bf3-6ea953e5303e	error_code	ï¿½#0ï¿½ = No Error =; ï¿½#1ï¿½= PNL Missing; ï¿½#2ï¿½= Validation Error		string	All Data
e578b7c1-0b5f-3d40-81e8-0b817d709cb6	error_description	The string value of "error description"		string	All Data
91f9847c-b70b-3675-96e8-2bf8b4f799df	error_description	The string value of "error description"		string	All Data
8378d999-acdc-3917-bd25-1e6bfc3eeb17	error_description	The string value of "error description"		string	All Data
4c3dc7f9-c655-3015-8994-ab7d6056c257	error_description	The string value of "error description"		string	All Data
3005f457-a9e8-35d7-aa8b-3d5ff88b2c2d	error_description	The string value of "error description"		string	All Data
a4ccd92d-e128-3f10-96c7-8c1f411de2e7	error_description	The string value of "error description"		string	All Data
52bbc970-45cb-3eb5-bdf1-a7e628079585	error_description	The string value of "error description"		string	All Data

41c473bb-a9c6-3941-aa9d-df9c7bbbd361	error_description	The string value of "error description"		string	All Data
8ba41fd8-d897-3ff3-96c1-f9be8f56bd85	error_description	The string value of "error description"		string	All Data
cbf03111-d63e-3eea-9c47-c476b55e4854	error_description	The string value of "error description"		string	All Data
580746cb-91f7-308e-a36b-f34a89aa15a2	error_description	The string value of "error description"		string	All Data
fade91a6-e94b-3d37-bf4e-fee59833752c	error_description	The string value of "error description"		string	All Data
34992c8b-af8f-3ba3-b07d-33825456474f	error_description	The string value of "error description"		string	All Data
0eb38b25-8f84-3a02-97c5-34da5d3655aa	error_description	The string value of "error description"		string	All Data
916c8cda-5e1e-3949-a586-46c72775e668	error_description	The string value of "error description"		string	All Data
79db4238-389b-396c-9d2f-cd3de9b4f375	error_description	The string value of "error description"		string	All Data
4745a601-90fe-3faa-a251-3efa1848da1b	error_description	The string value of "error description"		string	All Data
0a7ecca3-e96a-3745-9bf8-2bac574dfe9d	error_description	The string value of "error description"		string	All Data
6e4ff717-51e5-37e4-964c-d0075b371e60	error_description	The string value of "error description"		string	All Data
79e8b280-0678-3944-aabf-ea99faf6d265	error_number	The int value of "error number"		int	All Data
983d7ce9-31a4-3558-ba0d-5074c8e4fabd	error_number	The int value of "error number"		int	All Data
4d51cec0-2a92-3fc6-9156-eb6c25b1ffcf	error_number	The int value of "error number"		int	All Data
e21af734-2372-31d0-8ac3-aff4f61a7916	error_number	The int value of "error number"		int	All Data

1e29dde1-84db-382d-9278-4ca4fd3ae5f7	error_number	The int value of "error number"		int	All Data
23de3045-3bb5-31ba-a1df-bc42210cd9b0	error_number	The int value of "error number"		int	All Data
04474da8-9410-3d1d-94ee-20ba152ff177	error_number	The int value of "error number"		int	All Data
d59b0a45-03f6-378e-b485-363b3f0a1377	error_number	The int value of "error number"		int	All Data
80bb2581-938d-3987-85e3-b74f7394ada9	error_number	The int value of "error number"		int	All Data
7b905e23-d1a9-36d1-a2f8-fcfbb45dba4a	error_number	The int value of "error number"		int	All Data
1876a3f7-9426-3a13-951e-d9401f5a5c0a	error_number	The int value of "error number"		int	All Data
d010f674-4645-30c6-81f0-3453c8efa6bf	error_number	The int value of "error number"		int	All Data
a6f5b7a1-b425-3e82-bd9c-cf86ab2f0d19	error_number	The int value of "error number"		int	All Data
78c89bc2-c7d7-34af-a361-02bc675f97fb	error_number	The int value of "error number"		int	All Data
86e43005-5262-3a23-8d74-912108bdad2a	error_number	The int value of "error number"		int	All Data
39c6d912-10f2-336b-b4b8-638359178d2a	error_number	The int value of "error number"		int	All Data
12df7672-e0b5-3372-b78b-82588746d5b3	error_number	The int value of "error number"		int	All Data
639f00ab-3d10-3918-b318-e2de7484358c	error_number	The int value of "error number"		int	All Data
9958cd8d-efd3-3988-abcf-040eb6f0948a	error_number	The int value of "error number"		int	All Data
b477dd84-740f-3511-8261-16e84f1b4983	ErrorReason	The int value of "ErrorReason"		int	All Data

84e9229e-ecb1-35df-86b7-ca8d4ea1559e	estimatedcruisingrangeprimary.is_set	The boolean value of "estimatedcruisingrangeprimary is set"		boolean	All Data
fd3c9e8d-cbc3-3483-8545-39267f47bfd5	estimatedcruisingrangeprimary.state	The enum value of "estimatedcruisingrangeprimary state"		enum	All Data
a270f8d2-266d-378b-b7e7-b41d77f1dcc7	estimatedcruisingrangeprimary.unit	The enum value of "estimatedcruisingrangeprimary unit"		enum	All Data
b9c90aa6-9495-362c-99c2-1963f8bcfe7b	estimatedcruisingrangeprimary.value	The int value of "estimatedcruisingrangeprimary value"		int	All Data
d001eea9-f495-3c23-b284-92bbafac8908	estimatedcruisingrangesecondary.is_set	The boolean value of "estimatedcruisingrangesecondary is set"		boolean	All Data
b3d321d3-ad38-3f9b-8278-a745a2df7fba	estimatedcruisingrangesecondary.state	The enum value of "estimatedcruisingrangesecondary state"		enum	All Data
67611e1d-f363-3ebc-a473-6cf00c70daae	estimatedcruisingrangesecondary.unit	The enum value of "estimatedcruisingrangesecondary unit"		enum	All Data
1b98f8f7-fd80-323f-bdc6-8971e7da7fdb	estimatedcruisingrangesecondary.value	The int value of "estimatedcruisingrangesecondary value"		int	All Data
63b2777d-5ada-32ac-8b80-2cbc78623928	estimatedRangeWithCurrentCharge	estimated range that is possible to go with the actual state of charge	km	int	Charging
f7d5abb7-2d85-314c-80f7-aa28bced9f6d	expires_in	The int value of "expires in"		int	All Data
a56a4e27-7d8d-3434-a746-4736c3b5a496	external_power_supply_state	State of external power supply	'-	String	All Data, Charging

375b3b08-426d-3a3a-aefe-7b4d2710ba28	first_active_consumer_	This TSS-ID is only interpreted by zFDI for vehicles of PPE platform!	'-	'-	All Data
42c4a3cf-d6d8-39f4-ac6e-a5747129ae24	flap_error_state	Contains details of flap error state	'-	String	All Data, Vehicle Access
68a41ffa-311b-35d0-94fe-e5e10e72c1a8	flap_lock_state	Indicates state of flap lock	'-	String	All Data, Vehicle Access
a0736cf5-584b-36ef-b2f7-eec3644c0493	flap_state	Indicates state of tank flap	'-	String	All Data, Vehicle Access
15de9d82-0995-334a-a37a-d3d1d9060da3	fogLightFrontIndication	current state of front fog light		string	Vehicle Status
7419b035-e03f-30b7-aa9a-a60b1d8ad98d	fogLightRearIndication	current state of rear fog light		string	Vehicle Status
81e21dd8-0397-3fc1-8778-9e40afb1589f	fuel_level	Value of the fuel level in percent		int	All Data
4d984161-147b-3297-8175-d87f2e991af9	fuelLevel	current fuel level	(%)	int	Vehicle Status
7e35b2a4-8f31-30a7-848d-3af7bb1c5e55	fuel_level__accuracy	Indicates if fuel level is measured (0) or calculated (1)	'-	int	All Data, Dashboard Measurements
1503760b-5570-3001-8ffc-1bb6f464948e	fuel_level_current_level	Fuel level in percentage	%	int	All Data, Dashboard Measurements
49f92d8e-1651-3f14-9e94-d1f1af96e8b7	fuel_level.fuel_level	The int value of "fuel level fuel level"		int	All Data
fbf4a9c0-48ff-39c0-8f0d-fb801138eb1f	fuel_level.is_set	The boolean value of "fuel level is set"		boolean	All Data
2518cfe1-a80a-3131-b14d-4a932192215a	fuel_level.state	The enum value of "fuel level state"		enum	All Data
804af313-f570-3fb3-88cf-f92a8bd31751	fuel_level.value	Value of the fuel level in percent		int	All Data
f18bd205-0a2b-39f3-8e35-2e34ed23f4c4	highBeamFrontIndication	current state of high beam front		string	Vehicle Status

d948da3a-f330-3221-a5fc-2d1eba69a955	history_active_warnings_in_instrument_cluster_0001	Historical information about the warning lights being actived in the instrument cluster (001)	Hex (Interpreted)	Boolean	All Data, Breakdown, Maintenance Related Information, Dashboard Measurements, Vehicle Warning Lights
19fca6af-7eb7-3d7b-88ed-0f2415cdd7c3	history_active_warnings_in_instrument_cluster_fff	Historical information about the warning lights being actived in the instrument cluster (FFF)	Hex (Interpreted)	int	All Data, Breakdown, Maintenance Related Information, Dashboard Measurements, Vehicle Warning Lights
9941ce18-6be8-308f-9c19-91a998f3ee9a	hvbatterytemperature.is_set	The boolean value of "hvbatterytemperature is set"		boolean	All Data, Charging
0bb38c06-6c78-3675-88d4-de93d2c36008	hvbatterytemperature.max_temperature	The float value of "hvbatterytemperature max temperature"		float	All Data, Charging
45df000d-f24c-33a7-a564-c67cbcbb1f23	hvbatterytemperature.min_temperature	The float value of "hvbatterytemperature min temperature"		float	All Data, Charging

41c0805c-43e5-313e-9dfb-356cb8d20f7c	mileage	Mileage of the vehicle as W3C/#unsignedInt	'-	unsignedInt	All Data, Trip Statistics, Breakdown, Maintenance Related Information, Vehicle Status, Vehicle Location Tracking, Dashboard Measurements
13d34349-0d76-3bd1-8765-fa7a6b307bc0	mileage.is_set	The boolean value of "mileage is set"		boolean	All Data
fc78c9ac-afa8-3ae0-b92d-890af9b0bb1a	mileage.state			enum	All Data
86824bea-ed3f-37c0-ad3d-19a601d6adf4	mileage.state	The enum value of "mileage state"		enum	All Data
a04d086d-70bb-30c2-8361-68da66b4fd97	mileage.state	State of the information (valid/invalid); type ï¿½Stateï¿½ defined in ï¿½TTRVS_types_v1ï¿½		enum	All Data
aefcb497-c0eb-39d0-8a91-2b728fcb2b47	mileage.unit	The unit of the distance provided by the property current_value. 0 = km. 1 = miles		enum	All Data
37fcab93-1d16-329f-b13c-844d244faa04	mileage.unit	The enum value of "mileage unit"		enum	All Data
bafabdff-671e-331f-825d-d193cd397c5d	mileage.unit	Unit of the value; type ï¿½DistanceUnitï¿½ defined in ï¿½TTRVS_types_v1ï¿½		enum	All Data
75d65f00-5fa8-334a-826d-e73e91fe5c8d	mileage.value	The value of the corresponding distance.		int	All Data

69d437d3-7baa-38bc-b842-f5baf99ddade	mileage.value	The int value of "mileage value"		int	All Data
30cc36fd-71ca-3c09-9296-e94ebd47bd2b	mileage.value	Value of the mileage		int	All Data
374014c4-2fd5-3d73-ac75-7c949e726f00	min_temperature	Current temperature value of the battery module with the lowest temperature in ï¿½C.		float	All Data
fea4b596-b0e8-3bf8-8520-452ef9502bde	min_temperature	The float value of "min temperature"		float	All Data
f13bf5a2-f460-3e52-9f8e-6ae9e402207b	notification_type	The enum value of "notification type"		enum	All Data
2db43f62-6bd9-3ffc-865d-aa033329aaeb	oilLvl	current oil level	%	int	Vehicle Status, Maintenance Related Information
a3368611-8c63-3b7d-9d19-148a464c7a7b	oil_level_actual_level	Amount of current motoroil level in percentage	%	float	All Data, Maintenance Related Information, Vehicle Status
78e92351-cf56-3c15-96d3-9b63d62ca618	oil_level_additional_oil_level	Fix for a known vehicle issue, used to overwrite the actual level in case of failure	%	float	All Data, Maintenance Related Information, Vehicle Status
78fdf808-7917-335f-a44b-f4ad582f98bc	oil_level_dipstick_indicator_function	Indicates if off (0) or active (1)	'-	int	All Data, Maintenance Related Information, Vehicle Status

db768a8b-7aed-3851-801a-fe9e0c13e372	oil_level_min_warning	Indicates the minimum level of motoroil as 0 if current oil level still enough, 1 if warning	'-	int	All Data, Maintenance Related Information, Breakdown, Dashboard Measurements, Vehicle Warning Lights
a105604b-c44c-30da-b1c9-14bb9c48c714	oil_level_status	Indicates if the oil level is valid (1), invalid (0) or unsupported (2)	'-	int	All Data, Maintenance Related Information, Vehicle Status
8d4cb2b4-a4f5-3285-9cc4-fc6709ada6fd	oil_level_total_max	Amount of motoroil level in liter	l	float	All Data, Maintenance Related Information, Vehicle Status
c0bb1348-5d0d-3140-9a51-06881db06490	open	Openig status		boolean	All Data
f5fa6f61-ea56-3be8-97e6-acc8543cc49e	open	Opening status of the sun roof		boolean	All Data
d5dc7c87-5051-34db-ae99-0bd2cf987c45	open	Openig status		boolean	All Data
e1c6d420-b439-3de6-a5b7-d0b474cc2752	open_state_front_engine_bonnet	Indicates if the engine bonnet is unsupported (0) or invalid (1) or open (2) or closed (3)	'-	int	All Data, Vehicle Access
bc9bbc65-8461-30eb-88db-f94148552a20	open_state_front_left_door	Indicates if the front left door is open (2) or closed (3)	'-	int	All Data, Vehicle Access

0bb971a6-12ef-3382-9b99-5ed0a52f18e9	open_state_front_right_door	Indicates if the front right door is locked (2) or unlocked (3)	'-	int	All Data, Vehicle Access
bf62dd10-b184-3425-a64c-c50b09420bc3	open_state_rear_left_door	Indicates if the rear left door is open(2) or closed (3)	'-	int	All Data, Vehicle Access
60c81e02-4825-3aab-8da8-b8b07f251623	open_state_rear_right_door	Indicates if the rear right door is locked (2) or unlocked (3)	'-	int	All Data, Vehicle Access
dbb8f3b1-2bc9-3afc-a1d5-61f1eb04d1c4	open_state_tailgate	Indicates if the tailgate is unsupported (0) or invalid (1) or open (2) or closed (3)	'-	int	All Data, Vehicle Access
b6ea5ae8-53ff-386d-8415-1baa0602bbb6	outdoor_temperature	Current outdoor temperature in ï¿½C		float	All Data
45fd0a36-7dcd-3ca1-aaa5-3670eab45fd8	outdoor_temperature.is_set	The boolean value of "outdoor temperature is set"		boolean	All Data
1a84c328-d69f-370b-8021-a26e77e1933d	outdoor_temperature.measurement_state	Possible values: MEASUREMENT_STATE_INVALID, MEASUREMENT_STATE_UNSUPPORTED, MEASUREMENT_STATE_VALID		enum	All Data
6b77a5fe-76f3-362c-9b6c-1a9f114f8ce8	outdoor_temperature.outdoor_temperature	The float value of "outdoor temperature outdoor temperature"		float	All Data

f2e30577-7407-3875-972d-9493ef12efcb	outdoor_temperature.temperature	the value of the corresponding temperature. Resolution=0.1ï¿½C 0(-46ï¿½C)->1460(100ï¿½C)/ Resolution=0.25ï¿½F 1461(-51ï¿½F)->2513ï¿½F(212ï¿½F)		int	All Data
6810b781-e54a-35e8-af98-fcdefb54bac6	outside_temperature	Temperature outside the vehicle in deci-Kelvin	dK	int	All Data, Climatisation and Heating, Vehicle Status, Vehicle Location Tracking
b871c390-5325-377d-a91f-ea09bc0eff92	outsideTemperatureIndication	current outside air temperature	(Â°C)	int	Climatisation and Heating
4a022fc2-3999-3e97-837f-dda7e71b7fa3	parkBrakeStatus	current state of park brake		string	Parking Data
d8e0307c-f31b-3896-a9e8-001949a52d11	parking_brake	Status of the parking brake		boolean	All Data, Parking Data
f8bbe94d-06e1-3311-bf8f-c0c99cc67d48	parking_brake	Indicates if the parking brake is inactive (0) or active (1)	'-	int	All Data, Parking Data
b8a73b17-98c0-3b1d-8875-8e365d1c5cbb	parkingBrakeIndication	current state of park brake		object	Driving Behaviour, Vehicle Status
015e697d-a920-31f6-ba1c-cad8205011bc	parking_brake.is_set	The boolean value of "parking brake is set"		boolean	All Data, Parking Data
9c257af4-d7b3-3b2f-8490-7be732a06cae	parking_brake.parking_brake	The boolean value of "parking brake parking brake"		boolean	All Data, Parking Data

c7828009-144b-36e9-af38-2c35e7356c34	parking_light_left	Status of the left parking light		boolean	All Data, Parking Data
0fa69b72-8432-3ef4-a312-cbb2f7861dfc	parking_light_right	Status of the right parking light		boolean	All Data, Parking Data
c17ead4f-09b8-357f-ac2b-38c448ab88c4	parking_lights	Indicates if parking lights are unsupported (0), invalid (1), off (2), left (3), right (4) or both (5)	'-	int	All Data, Parking Data
c8708024-f284-3b5d-ba60-8242b9f8a76d	parkinglightstate.is_set	The boolean value of "parkinglightstate is set"		boolean	All Data, Parking Data
d36a6660-23ef-3a73-97db-42607fde981d	parkinglightstate.parking_light_left	The boolean value of "parkinglightstate parking light left"		boolean	All Data, Parking Data
acca76c4-3d59-3e7e-bb8b-4a9e177d8e7e	parkinglightstate.parking_light_right	The boolean value of "parkinglightstate parking light right"		boolean	All Data, Parking Data
6ff851e4-e94f-3f22-8287-3fa547798afa	percent_open	Opening status of the sun roof		boolean	All Data
6b61d861-e8c2-3600-a9ba-2f5da9ac3410	plug_connection_state	Indicates the state of plug connection	'-	String	All Data, Charging
973e67d7-9b08-3d24-9e16-a99f9231af58	plugConnectionState	information about the current plug connection state		string	Charging
44534a85-8757-381d-96ba-51be8272dd8c	plug_lock_state	Describes the plug lock state	'-	String	All Data, Charging
167aef98-3f19-3036-94f4-579b0eb7b0b0	plugPosition	information about the plug position on the vehicle		string	Trip Statistics
c111830c-f959-30d2-859a-ea996190d864	plug_state	Indicates state of the charge plug	'-	String	All Data, Charging

a8462bf0-ec85-3f93-a6f3-83ad31681e5f	plug_states.[*].flap_lock_state	FLAP_LOCK_STATE_INVALID, FLAP_LOCK_STATE_LOCKED, FLAP_LOCK_STATE_UNLOCKED, FLAP_LOCK_STATE_ERROR. The values of: "plug states" & "flap lock state". Note that [*] in the key is replaced by a number.		enum	All Data
aa703eda-569c-3790-93cd-8bf57c2c0337	plug_states.[*].infrastructure_state	INFRASTRUCTURE_STATE_INVALID, INFRASTRUCTURE_STATE_UNAVAILABLE, INFRASTRUCTURE_STATE_READY, INFRASTRUCTURE_STATE_ACTIVE. The values of: "plug states" & "infrastructure state". Note that [*] in the key is replaced by a number.		enum	All Data

1a3c205d-d9ea-3b5e-aab4-9b448ebbb486	plug_states.[*].lock_state	PLUG_LOCK_STATE_INVALID, PLUG_LOCK_STATE_UNLOCKED, PLUG_LOCK_STATE_LOCKED, PLUG_LOCK_STATE_ERROR. The values of: "plug states" & "lock state". Note that [*] in the key is replaced by a number.		enum	All Data
aa839791-9aaa-3d6f-8a73-f7d32f649e9c	plug_states.[*].plug_connection_state	PLUG_CONNECTION_STATE_INVALID, PLUG_CONNECTION_STATE_CONNECTED, PLUG_CONNECTION_STATE_DISCONNECTED. The values of: "plug states" & "plug connection state". Note that [*] in the key is replaced by a number.		enum	All Data

a44dc807-404a-33a9-8719-b1014c96cff3	plug_states.[*].plug_position	PLUGPOSITION_INVALID, PLUGPOSITION_FRONTLEFT1, PLUGPOSITION_FRONTLEFT2, PLUGPOSITION_FRONTRIGHT1, PLUGPOSITION_FRONTRIGHT2, PLUGPOSITION_REARLEFT1, PLUGPOSITION_REARLEFT2, PLUGPOSITION_REARRIGHT1, PLUGPOSITION_REARRIGHT2, PLUGPOSITION_FRONT. The values of: "plug states" & "plug position". Note that [*] in the key is replaced by a number.		enum	All Data
e5434e51-73e6-3a16-be78-e1b39b9a316c	plugType	information about the vehicles type of plug		string	Charging
60fddd42-f4fe-3382-ba31-f04ce52d2ab4	position_front_left_door_window_lifter	Indicates the position of the front left door window lifter is open in percentage or closed (0)	%	int	All Data, Vehicle Access

57cb3a0e-e9f1-32d1-bf19-dd5970230699	position_front_right_door_window_lifter	Indicates if the position of the front right door window lifter is open in percentage or closed (0)	%	int	All Data, Vehicle Access
7a803b50-2501-328c-9579-ee6bba235c1b	position_of_hood	Indicates the position of the car hood in percentage and (0) for closed	%	int	All Data, Vehicle Access
0543e58f-cd49-3e63-9e00-3b2d27043a25	position_rear_left_door_window_lifter	Indicates if the position of the rear left door window lifter is open in percentage or closed (0)	%	int	All Data, Vehicle Access
0bf3d84a-9164-3d1c-8191-ca6dbce848a7	position_rear_right_door_window_lifter	Indicates if the position of the rear right door window lifter is open in percentage or closed (0)	%	int	All Data, Vehicle Access
36e1e80f-aa67-3c22-bb4b-a8dd65cf4ef8	position_service_hatch	Indicates the position of the service hatch in percentage and (0) for closed	%	int	All Data, Vehicle Access
395be049-b48e-3498-b287-aa60554f2f58	position_spoiler	Indicates the position of the spoiler in percentage and (0) for closed	%	int	All Data, Vehicle Access
2d10f834-6e6e-3be0-9292-8c8cb9e09581	position_sunroof_motor_hood_1	Indicates the position of the sunroof motor hood 1 in percentage and (0) for closed	%	int	All Data, Vehicle Access
8ce79e79-1f3b-3d1e-85e4-426db863a8d8	position_sunroof_motor_hood_3	Indicates the position of the sunroof motor hood 3 in percentage and (0) for closed	%	int	All Data, Vehicle Access

303493e7-320b-3976-8fc5-34bed9e1f1cc	primaryEngineAbsChargingAirPressureIndication	the absolute charging air pressure	(bar)	int	Vehicle Status
95d06331-ef55-3218-9869-a409922b6279	primaryEngineFuelLevelSensorStateIndication	current state of primary engine fuel level sensor		int	Vehicle Status
dc6b767b-fc82-379f-90bf-457cf2fea03a	primaryEngineMaxChargingAirPressureIndication	maximum charging air pressure	(bar)	int	Vehicle Status
4fc7c455-6423-32c2-b5cd-09db4fce33d5	primaryEngineMaxOutputPowerIndication	maximum power output of the engine	(kW)	int	Vehicle Status
7b1864d1-f519-3df4-b031-4b8d4e2d7614	primaryEngineOilTemperatureIndication	current oil temperature	(Â°C)	int	Vehicle Status
e21eb49e-bf4a-3b00-b10a-9a1fb19646ec	primaryEngineRelChargingAirPressureIndication	relative charging air pressure	(%)	int	Vehicle Status
dff10788-0863-3c8b-9dcc-148a506e57cc	primaryEngineSpeedIndication	engine speed	(1/min)	int	Vehicle Status
9ea413f5-ee6c-3f28-b7a3-65ed6d9757ef	profile_charge_reason	Indicates Charging Reason assicoated with Profile	'-	String	All Data, Charging
cf6a20aa-8ffe-3241-adbe-aadd97e091cf	profile_state_report.car_captured_time	times and date (UTC) when the report has been sent to the backend		string	All Data
2e6ddd5d-0475-384a-a4b4-8fdf7e96d7f0	profile_state_report.car_captured_time	times and date (UTC) when the report has been sent to the backend		string	All Data
03ad2fc6-8caa-33b7-9992-9fb288f876c1	profile_state_report.car_captured_time	times and date (UTC) when the report has been sent to the backend		string	All Data
a4d00a7b-6108-3c7a-807d-49b5f8a7b2d0	profile_state_report.car_captured_time	times and date (UTC) when the report has been sent to the backend		string	All Data

9ccc6b06-fb4a-3ed9-b377-72a35c7f8f16	profile_state_report.instrument_cluster_time	Format for the DP (mqtt publish)-> 2009-01-01T12:00:00+01:00 (without miliseconds. Java service must use 00 seconds, if SCME doesnï¿½t provide the seconds. Java must compare UTC time with instrument_cluster_time, if SCME has not provide timezone. Java must send the timezone in the ICT). The instrument_cluster_time (time adjusted in the car) = customeTime in the Service_Time. The frontends can use this time to represent the timers and preferredcharging in the time zone, which the car is using.		string	All Data

42ea1549-2286-3c73-8778-3b7349e98048	profile_state_report.instrument_cluster_time	Format for the DP (mqtt publish)-> 2009-01-01T12:00:00+01:00 (without miliseconds. Java service must use 00 seconds, if SCME doesnï¿½t provide the seconds. Java must compare UTC time with instrument_cluster_time, if SCME has not provide timezone. Java must send the timezone in the ICT). The instrument_cluster_time (time adjusted in the car) = customeTime in the Service_Time. The frontends can use this time to represent the timers and preferredcharging in the time zone, which the car is using.		string	All Data

f295ae23-0485-3ccb-830b-58c644a04f2e	profile_state_report.instrument_cluster_time	Format for the DP (mqtt publish)-> 2009-01-01T12:00:00+01:00 (without miliseconds. Java service must use 00 seconds, if SCME doesnï¿½t provide the seconds. Java must compare UTC time with instrument_cluster_time, if SCME has not provide timezone. Java must send the timezone in the ICT). The instrument_cluster_time (time adjusted in the car) = customeTime in the Service_Time. The frontends can use this time to represent the timers and preferredcharging in the time zone, which the car is using.		string	All Data

fd6897c0-6d7c-3efe-b875-27b24aa668fd	profile_state_report.instrument_cluster_time	Format for the DP (mqtt publish)-> 2009-01-01T12:00:00+01:00 (without miliseconds. Java service must use 00 seconds, if SCME doesnï¿½t provide the seconds. Java must compare UTC time with instrument_cluster_time, if SCME has not provide timezone. Java must send the timezone in the ICT). The instrument_cluster_time (time adjusted in the car) = customeTime in the Service_Time. The frontends can use this time to represent the timers and preferredcharging in the time zone, which the car is using.		string	All Data
1d217545-0720-3d44-9c67-5aeb006d30fe	profile_state_report.next_charging_timer_information.estimated_finish_time	expectation when the timer will be finished. The SCME uses customerTime (Service Time-> customeTime) but java service must send in UTC time		string	All Data, Charging

fd287eb9-3733-32b6-be50-0bebabd5497e	profile_state_report.next_charging_timer_information.estimated_finish_time	expectation when the timer will be finished. The SCME uses customerTime (Service Time-> customeTime) but java service must send in UTC time		string	All Data, Charging
e3258c86-d04c-3c17-a00c-ce500ddead21	profile_state_report.next_charging_timer_information.estimated_finish_time	expectation when the timer will be finished. The SCME uses customerTime (Service Time-> customeTime) but java service must send in UTC time		string	All Data, Charging
e80b43ba-acf3-3610-8a17-2020038f4faf	profile_state_report.next_charging_timer_information.estimated_finish_time	expectation when the timer will be finished. The SCME uses customerTime (Service Time-> customeTime) but java service must send in UTC time		string	All Data, Charging
a9591043-0d98-3fa5-8c41-38b935c2b7fb	profile_state_report.next_charging_timer_information.estimated_start_time	expectation when the timer will be started. The SCME uses customerTime (Service Time-> customeTime) but java service must send in UTC time		string	All Data, Charging

12622e8a-71ef-381e-94db-4529c730e33e	profile_state_report.next_charging_timer_information.estimated_start_time	expectation when the timer will be started. The SCME uses customerTime (Service Time-> customeTime) but java service must send in UTC time		string	All Data, Charging
9fe68597-df48-30c2-9c84-46c49e955957	profile_state_report.next_charging_timer_information.estimated_start_time	expectation when the timer will be started. The SCME uses customerTime (Service Time-> customeTime) but java service must send in UTC time		string	All Data, Charging
c7cb6984-1d8a-33b2-8f5c-5206b348d52a	profile_state_report.next_charging_timer_information.estimated_start_time	expectation when the timer will be started. The SCME uses customerTime (Service Time-> customeTime) but java service must send in UTC time		string	All Data, Charging
8fb48a35-e3bd-36ac-9d6e-afac33720052	profile_state_report.next_charging_timer_information.nextChargingTimer	which timer is the nextChargingTimer (Profile1: 1,2,3 ..... Profile5: 13,14,15) Date-Time customeTime		int	All Data, Charging
ceb84bca-c7c1-3cb5-b947-b2b30a463722	profile_state_report.next_charging_timer_information.nextChargingTimer	which timer is the nextChargingTimer (Profile1: 1,2,3 ..... Profile5: 13,14,15) Date-Time customeTime		int	All Data, Charging

3c8b91a6-6d4f-3069-8681-30eaa9350cb9	profile_state_report.next_charging_timer_information.nextChargingTimer	which timer is the nextChargingTimer (Profile1: 1,2,3 ..... Profile5: 13,14,15) Date-Time customeTime		int	All Data, Charging
fc500e8a-746a-3d58-a5ea-a37c6eabcbbf	profile_state_report.next_charging_timer_information.nextChargingTimer	which timer is the nextChargingTimer (Profile1: 1,2,3 ..... Profile5: 13,14,15) Date-Time customeTime		int	All Data, Charging
222dd7bd-fc3b-3bfd-866c-56605a5f02e0	profile_state_report.next_charging_timer_information.target_reachability	Possible values: TARGET_REACHABILITY_INVALID , TARGET_REACHABILITY_CALCULATING , TARGET_REACHABILITY_REACHABLE , TARGET_REACHABILITY_NOT_REACHABLE ,		enum	All Data, Charging
11e77b4d-97f8-31bb-873b-c19dc1793f18	profile_state_report.next_charging_timer_information.target_reachability	Possible values: TARGET_REACHABILITY_INVALID , TARGET_REACHABILITY_CALCULATING , TARGET_REACHABILITY_REACHABLE , TARGET_REACHABILITY_NOT_REACHABLE ,		enum	All Data, Charging

1b022ff0-eb13-3595-b7a2-e90ce8e500de	profile_state_report.next_charging_timer_information.target_reachability	Possible values: TARGET_REACHABILITY_INVALID , TARGET_REACHABILITY_CALCULATING , TARGET_REACHABILITY_REACHABLE , TARGET_REACHABILITY_NOT_REACHABLE ,		enum	All Data, Charging
44ce3d59-0afc-3241-97b8-1a596d59c8a5	profile_state_report.next_charging_timer_information.target_reachability	Possible values: TARGET_REACHABILITY_INVALID , TARGET_REACHABILITY_CALCULATING , TARGET_REACHABILITY_REACHABLE , TARGET_REACHABILITY_NOT_REACHABLE ,		enum	All Data, Charging

3cac5072-b69c-322c-9ed9-b058328d8fcf	profile_state_report.profiles.[*].max_charge_current	maxCurrent. Charge with low current or high current. This maxcurrent will be used when charging is started by timer and only by the timers under this profile. Possible values: MAX_CHARGE_CURRENT_INVALID , MAX_CHARGE_CURRENT_MAX , MAX_CHARGE_CURRENT_REDUCED ,. The values of: "profile state report.profiles" & "max charge current". Note that [*] in the key is replaced by a number.		enum	All Data

c0c92327-c1b1-317d-b55e-c823db67002f	profile_state_report.profiles.[*].max_charge_current	maxCurrent. Charge with low current or high current. This maxcurrent will be used when charging is started by timer and only by the timers under this profile. Possible values: MAX_CHARGE_CURRENT_INVALID , MAX_CHARGE_CURRENT_MAX , MAX_CHARGE_CURRENT_REDUCED ,. The values of: "profile state report.profiles" & "max charge current". Note that [*] in the key is replaced by a number.		enum	All Data

4aa7149c-be98-3976-8cc0-a36779779d40	profile_state_report.profiles.[*].max_charge_current	maxCurrent. Charge with low current or high current. This maxcurrent will be used when charging is started by timer and only by the timers under this profile. Possible values: MAX_CHARGE_CURRENT_INVALID , MAX_CHARGE_CURRENT_MAX , MAX_CHARGE_CURRENT_REDUCED ,. The values of: "profile state report.profiles" & "max charge current". Note that [*] in the key is replaced by a number.		enum	All Data

2957784a-da3c-3b30-9b82-031316c471c3	profile_state_report.profiles.[*].max_charge_current	maxCurrent. Charge with low current or high current. This maxcurrent will be used when charging is started by timer and only by the timers under this profile. Possible values: MAX_CHARGE_CURRENT_INVALID , MAX_CHARGE_CURRENT_MAX , MAX_CHARGE_CURRENT_REDUCED ,. The values of: "profile state report.profiles" & "max charge current". Note that [*] in the key is replaced by a number.		enum	All Data
efd0f66c-0a0a-385f-95b7-9c6e13a8602d	profile_state_report.profiles.[*].minimum_soc	minimun_soc. The min. charge level, which the customer want, that the battery reach. 0-10-20-30-40-50. The values of: "profile state report.profiles" & "minimum soc". Note that [*] in the key is replaced by a number.		int	All Data

90f2aad3-ee8f-3bd7-8713-9364fc7f0fa7	profile_state_report.profiles.[*].minimum_soc	minimun_soc. The min. charge level, which the customer want, that the battery reach. 0-10-20-30-40-50. The values of: "profile state report.profiles" & "minimum soc". Note that [*] in the key is replaced by a number.		int	All Data
e747685e-4e50-3815-816a-03483364bd92	profile_state_report.profiles.[*].minimum_soc	minimun_soc. The min. charge level, which the customer want, that the battery reach. 0-10-20-30-40-50. The values of: "profile state report.profiles" & "minimum soc". Note that [*] in the key is replaced by a number.		int	All Data
03fc6a1a-29a9-3ec5-af18-40b4fdc4eb9b	profile_state_report.profiles.[*].minimum_soc	minimun_soc. The min. charge level, which the customer want, that the battery reach. 0-10-20-30-40-50. The values of: "profile state report.profiles" & "minimum soc". Note that [*] in the key is replaced by a number.		int	All Data

ba44770a-dcb6-3d4f-8846-dbe01b844a86	profile_state_report.profiles.[*].preferred_charging_times.[*].end_time	to set the end time - from 00:00 to 00:00/24:00 (For example: 00:00). SCME uses 01:00:30+00:00 format (read viwi definition for time) and customerTime reference but java service must send in UTC and without seconds 00:00 and timezone(intrumentClusterTime has the timezone, if the frontends need the timezone). The values of: "profile state report.profiles" & "preferred charging times" & "end time". Note that [*] in the key is replaced by a number.		string	All Data, Charging

3ad09928-265a-38c5-8136-afc025cdce22	profile_state_report.profiles.[*].preferred_charging_times.[*].end_time	to set the end time - from 00:00 to 00:00/24:00 (For example: 00:00). SCME uses 01:00:30+00:00 format (read viwi definition for time) and customerTime reference but java service must send in UTC and without seconds 00:00 and timezone(intrumentClusterTime has the timezone, if the frontends need the timezone). The values of: "profile state report.profiles" & "preferred charging times" & "end time". Note that [*] in the key is replaced by a number.		string	All Data, Charging

5aaefb7d-18d1-3c7b-b830-109d93d76aa9	profile_state_report.profiles.[*].preferred_charging_times.[*].end_time	to set the end time - from 00:00 to 00:00/24:00 (For example: 00:00). SCME uses 01:00:30+00:00 format (read viwi definition for time) and customerTime reference but java service must send in UTC and without seconds 00:00 and timezone(intrumentClusterTime has the timezone, if the frontends need the timezone). The values of: "profile state report.profiles" & "preferred charging times" & "end time". Note that [*] in the key is replaced by a number.		string	All Data, Charging

b10e1c34-da10-33b6-aca6-a433bc18970d	profile_state_report.profiles.[*].preferred_charging_times.[*].end_time	to set the end time - from 00:00 to 00:00/24:00 (For example: 00:00). SCME uses 01:00:30+00:00 format (read viwi definition for time) and customerTime reference but java service must send in UTC and without seconds 00:00 and timezone(intrumentClusterTime has the timezone, if the frontends need the timezone). The values of: "profile state report.profiles" & "preferred charging times" & "end time". Note that [*] in the key is replaced by a number.		string	All Data, Charging

098a8055-4fcc-3119-8974-7bb42faa2e36	profile_state_report.profiles.[*].preferred_charging_times.[*].id	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "preferred charging times" & "ID". Note that [*] in the key is replaced by a number.		int	All Data, Charging
a79a14f8-74de-3269-9b7e-248463584ef0	profile_state_report.profiles.[*].preferred_charging_times.[*].id	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "preferred charging times" & "ID". Note that [*] in the key is replaced by a number.		int	All Data, Charging

8c77e5c6-06d9-3718-bd2d-29312b17d3a0	profile_state_report.profiles.[*].preferred_charging_times.[*].id	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "preferred charging times" & "ID". Note that [*] in the key is replaced by a number.		int	All Data, Charging
2361babf-1d31-351a-9711-5e19ec32a9c0	profile_state_report.profiles.[*].preferred_charging_times.[*].id	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "preferred charging times" & "ID". Note that [*] in the key is replaced by a number.		int	All Data, Charging

196a3794-7634-3f70-9da5-59cb7b75d7a5	profile_state_report.profiles.[*].preferred_charging_times.[*].is_activated	to activate o deactivate the corresponding preferred_charging_time. The values of: "profile state report.profiles" & "preferred charging times" & "is activated". Note that [*] in the key is replaced by a number.		boolean	All Data, Charging
08499e8c-bb6d-3098-b4b4-a25c25ef4a15	profile_state_report.profiles.[*].preferred_charging_times.[*].is_activated	to activate o deactivate the corresponding preferred_charging_time. The values of: "profile state report.profiles" & "preferred charging times" & "is activated". Note that [*] in the key is replaced by a number.		boolean	All Data, Charging
664588c9-c954-3513-ad61-34f78b895b49	profile_state_report.profiles.[*].preferred_charging_times.[*].is_activated	to activate o deactivate the corresponding preferred_charging_time. The values of: "profile state report.profiles" & "preferred charging times" & "is activated". Note that [*] in the key is replaced by a number.		boolean	All Data, Charging

60d4f304-037b-35e5-b8ef-b8cf439b46ba	profile_state_report.profiles.[*].preferred_charging_times.[*].is_activated	to activate o deactivate the corresponding preferred_charging_time. The values of: "profile state report.profiles" & "preferred charging times" & "is activated". Note that [*] in the key is replaced by a number.		boolean	All Data, Charging
f3c33b3d-5e71-309b-a36e-6f65e9567b6e	profile_state_report.profiles.[*].preferred_charging_times.[*].start_time	to set the start time - from 00:00 to 00:00/24:00 UTC (For example: 00:00). SCME uses 01:00:30+00:00 format (read viwi definition for time) and customerTime reference but java service must send in UTC and without seconds 00:00 and timezone(intrumentClusterTime has the timezone, if the frontends need the timezone). The values of: "profile state report.profiles" & "preferred charging times" & "start time". Note that [*] in the key is replaced by a number.		string	All Data, Charging

e73621e5-05bf-3e8f-8fe2-c830a6359768	profile_state_report.profiles.[*].preferred_charging_times.[*].start_time	to set the start time - from 00:00 to 00:00/24:00 UTC (For example: 00:00). SCME uses 01:00:30+00:00 format (read viwi definition for time) and customerTime reference but java service must send in UTC and without seconds 00:00 and timezone(intrumentClusterTime has the timezone, if the frontends need the timezone). The values of: "profile state report.profiles" & "preferred charging times" & "start time". Note that [*] in the key is replaced by a number.		string	All Data, Charging

478de476-1471-3f5a-a9de-58dc87e32e1b	profile_state_report.profiles.[*].preferred_charging_times.[*].start_time	to set the start time - from 00:00 to 00:00/24:00 UTC (For example: 00:00). SCME uses 01:00:30+00:00 format (read viwi definition for time) and customerTime reference but java service must send in UTC and without seconds 00:00 and timezone(intrumentClusterTime has the timezone, if the frontends need the timezone). The values of: "profile state report.profiles" & "preferred charging times" & "start time". Note that [*] in the key is replaced by a number.		string	All Data, Charging

38153e97-d33d-3a4b-b290-e715a1aafe2a	profile_state_report.profiles.[*].preferred_charging_times.[*].start_time	to set the start time - from 00:00 to 00:00/24:00 UTC (For example: 00:00). SCME uses 01:00:30+00:00 format (read viwi definition for time) and customerTime reference but java service must send in UTC and without seconds 00:00 and timezone(intrumentClusterTime has the timezone, if the frontends need the timezone). The values of: "profile state report.profiles" & "preferred charging times" & "start time". Note that [*] in the key is replaced by a number.		string	All Data, Charging
33f06cba-5e0f-3c54-ac38-6c1918e0dffb	profile_state_report.profiles.[*].profile_id	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "profile ID". Note that [*] in the key is replaced by a number.		int	All Data

a9468174-23e7-30d2-8bc2-51e8c52a58af	profile_state_report.profiles.[*].profile_id	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "profile ID". Note that [*] in the key is replaced by a number.		int	All Data
8c4b43a9-b78b-380a-ad65-064d829ab1f9	profile_state_report.profiles.[*].profile_id	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "profile ID". Note that [*] in the key is replaced by a number.		int	All Data
cbb5de64-5fa6-3cd2-825d-aaa2d8a784ad	profile_state_report.profiles.[*].profile_id	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "profile ID". Note that [*] in the key is replaced by a number.		int	All Data

ef9df1d9-de38-32f6-8d11-699777a7e9ef	profile_state_report.profiles.[*].profile_name	the name of the corresponding profile. For example: "House_charging_SOC_100" "PetrolStation". The values of: "profile state report.profiles" & "profile name". Note that [*] in the key is replaced by a number.		string	All Data
ce5ec1df-41f4-31b4-89a6-dde5ae052879	profile_state_report.profiles.[*].profile_name	the name of the corresponding profile. For example: "House_charging_SOC_100" "PetrolStation". The values of: "profile state report.profiles" & "profile name". Note that [*] in the key is replaced by a number.		string	All Data
73f7a767-15d3-3f74-8d3e-a60e32b61303	profile_state_report.profiles.[*].profile_name	the name of the corresponding profile. For example: "House_charging_SOC_100" "PetrolStation". The values of: "profile state report.profiles" & "profile name". Note that [*] in the key is replaced by a number.		string	All Data

81ce5ffd-a993-3ff7-a8e8-4c8c67ad993c	profile_state_report.profiles.[*].profile_name	the name of the corresponding profile. For example: "House_charging_SOC_100" "PetrolStation". The values of: "profile state report.profiles" & "profile name". Note that [*] in the key is replaced by a number.		string	All Data
0065e7c4-1f7e-3cf0-beca-657e61c72fb3	profile_state_report.profiles.[*].profile_options.auto_unlock_ac	Possible values: AUTO_UNLOCK_AC_INVALID , AUTO_UNLOCK_AC_OFF , AUTO_UNLOCK_AC_PERMANENT , AUTO_UNLOCK_AC_ONCE. The values of: "profile state report.profiles" & "profile options.auto unlock ac". Note that [*] in the key is replaced by a number.		enum	All Data

fafb9920-0623-3e8a-8385-a74499920ae2	profile_state_report.profiles.[*].profile_options.auto_unlock_ac	Possible values: AUTO_UNLOCK_AC_INVALID , AUTO_UNLOCK_AC_OFF , AUTO_UNLOCK_AC_PERMANENT , AUTO_UNLOCK_AC_ONCE. The values of: "profile state report.profiles" & "profile options.auto unlock ac". Note that [*] in the key is replaced by a number.		enum	All Data
403bcbf6-d681-330a-897a-21122c042a6f	profile_state_report.profiles.[*].profile_options.auto_unlock_ac	Possible values: AUTO_UNLOCK_AC_INVALID , AUTO_UNLOCK_AC_OFF , AUTO_UNLOCK_AC_PERMANENT , AUTO_UNLOCK_AC_ONCE. The values of: "profile state report.profiles" & "profile options.auto unlock ac". Note that [*] in the key is replaced by a number.		enum	All Data

38e85a4d-e3b1-3731-aa8d-f96270f19461	profile_state_report.profiles.[*].profile_options.auto_unlock_ac	Possible values: AUTO_UNLOCK_AC_INVALID , AUTO_UNLOCK_AC_OFF , AUTO_UNLOCK_AC_PERMANENT , AUTO_UNLOCK_AC_ONCE. The values of: "profile state report.profiles" & "profile options.auto unlock ac". Note that [*] in the key is replaced by a number.		enum	All Data
6fcf3c60-6f5a-379d-9268-cca61e866a8d	profile_state_report.profiles.[*].profile_options.preferred_charging_enabled	if the preferred charging timers for the corresponding profile are activated/deactivated. For the timers of the corresponding profiles. The values of: "profile state report.profiles" & "profile options.preferred charging enabled". Note that [*] in the key is replaced by a number.		boolean	All Data, Charging

6fd54e57-b280-3040-af55-5e801c319f95	profile_state_report.profiles.[*].profile_options.preferred_charging_enabled	if the preferred charging timers for the corresponding profile are activated/deactivated. For the timers of the corresponding profiles. The values of: "profile state report.profiles" & "profile options.preferred charging enabled". Note that [*] in the key is replaced by a number.		boolean	All Data, Charging
f054c087-0fd0-3092-9206-3b7d7b4400ed	profile_state_report.profiles.[*].profile_options.preferred_charging_enabled	if the preferred charging timers for the corresponding profile are activated/deactivated. For the timers of the corresponding profiles. The values of: "profile state report.profiles" & "profile options.preferred charging enabled". Note that [*] in the key is replaced by a number.		boolean	All Data, Charging

cffb3cdc-e6f4-3048-b130-888e86ceffa9	profile_state_report.profiles.[*].profile_options.preferred_charging_enabled	if the preferred charging timers for the corresponding profile are activated/deactivated. For the timers of the corresponding profiles. The values of: "profile state report.profiles" & "profile options.preferred charging enabled". Note that [*] in the key is replaced by a number.		boolean	All Data, Charging
39bf5980-16ce-3e05-aafa-3e4c28362d30	profile_state_report.profiles.[*].profile_options.smart_charging_enabled	battery will be charged and controlled in a more intelligent way depend of the tarif. The values of: "profile state report.profiles" & "profile options.smart charging enabled". Note that [*] in the key is replaced by a number.		boolean	All Data, Charging

211782bb-948c-38f6-8ef1-9498082f306c	profile_state_report.profiles.[*].profile_options.smart_charging_enabled	battery will be charged and controlled in a more intelligent way depend of the tarif. The values of: "profile state report.profiles" & "profile options.smart charging enabled". Note that [*] in the key is replaced by a number.		boolean	All Data, Charging
cec1f420-b462-37b0-8ef4-3270c2ebffad	profile_state_report.profiles.[*].profile_options.smart_charging_enabled	battery will be charged and controlled in a more intelligent way depend of the tarif. The values of: "profile state report.profiles" & "profile options.smart charging enabled". Note that [*] in the key is replaced by a number.		boolean	All Data, Charging
ea237dea-a049-389b-8f39-baade44fe5ff	profile_state_report.profiles.[*].profile_options.smart_charging_enabled	battery will be charged and controlled in a more intelligent way depend of the tarif. The values of: "profile state report.profiles" & "profile options.smart charging enabled". Note that [*] in the key is replaced by a number.		boolean	All Data, Charging

aff9daac-7b5e-33e2-ab6d-39f4e2d2aa81	profile_state_report.profiles.[*].profile_options.use_external_service	In use in case customer can use the PV system or similar supplies. The values of: "profile state report.profiles" & "profile options.use external service". Note that [*] in the key is replaced by a number.		boolean	All Data
035f57f0-fe06-3bb0-a17d-7028b2cf8f08	profile_state_report.profiles.[*].profile_options.use_external_service	In use in case customer can use the PV system or similar supplies. The values of: "profile state report.profiles" & "profile options.use external service". Note that [*] in the key is replaced by a number.		boolean	All Data
dcd669c2-b90b-32af-819e-d8dd6bb391f9	profile_state_report.profiles.[*].profile_options.use_external_service	In use in case customer can use the PV system or similar supplies. The values of: "profile state report.profiles" & "profile options.use external service". Note that [*] in the key is replaced by a number.		boolean	All Data

38d97fc9-0a74-3464-ab63-a6c051aa32c2	profile_state_report.profiles.[*].profile_options.use_external_service	In use in case customer can use the PV system or similar supplies. The values of: "profile state report.profiles" & "profile options.use external service". Note that [*] in the key is replaced by a number.		boolean	All Data
588e3c88-170e-381e-822a-2781f1c71535	profile_state_report.profiles.[*].profile_options.use_private_current_enabled	the parameter will be foward to the backend with a value but SCME ignores the parameter (the customer will not see effects in the car) although the parameter is adjustable in SCME. The values of: "profile state report.profiles" & "profile options.use private current enabled". Note that [*] in the key is replaced by a number.		boolean	All Data

ffd76981-f2a8-3f1a-8752-10d3693cc4fc	profile_state_report.profiles.[*].profile_options.use_private_current_enabled	the parameter will be foward to the backend with a value but SCME ignores the parameter (the customer will not see effects in the car) although the parameter is adjustable in SCME. The values of: "profile state report.profiles" & "profile options.use private current enabled". Note that [*] in the key is replaced by a number.		boolean	All Data
105416e2-4788-32de-a64a-c62f36cd0da2	profile_state_report.profiles.[*].profile_options.use_private_current_enabled	the parameter will be foward to the backend with a value but SCME ignores the parameter (the customer will not see effects in the car) although the parameter is adjustable in SCME. The values of: "profile state report.profiles" & "profile options.use private current enabled". Note that [*] in the key is replaced by a number.		boolean	All Data

421f9b94-997b-3723-bdcc-b60fc6d02928	profile_state_report.profiles.[*].profile_options.use_private_current_enabled	the parameter will be foward to the backend with a value but SCME ignores the parameter (the customer will not see effects in the car) although the parameter is adjustable in SCME. The values of: "profile state report.profiles" & "profile options.use private current enabled". Note that [*] in the key is replaced by a number.		boolean	All Data
104c0c80-bb9c-34bd-b921-720248ad7ded	profile_state_report.profiles.[*].profile_type	Possible values: PROFILE_TYPE_INVALID , PROFILE_TYPE_LOCATION_INDEPENDENT , PROFILE_TYPE_LOCATION_BASED , PROFILE_TYPE_NAVIGATION_BASED. The values of: "profile state report.profiles" & "profile type". Note that [*] in the key is replaced by a number.		enum	All Data

a04f8d07-8d4e-350b-a26a-d3d1341b7375	profile_state_report.profiles.[*].profile_type	Possible values: PROFILE_TYPE_INVALID , PROFILE_TYPE_LOCATION_INDEPENDENT , PROFILE_TYPE_LOCATION_BASED , PROFILE_TYPE_NAVIGATION_BASED. The values of: "profile state report.profiles" & "profile type". Note that [*] in the key is replaced by a number.		enum	All Data
5fe0b323-85b8-3b58-8d44-23ae0a1be65b	profile_state_report.profiles.[*].profile_type	Possible values: PROFILE_TYPE_INVALID , PROFILE_TYPE_LOCATION_INDEPENDENT , PROFILE_TYPE_LOCATION_BASED , PROFILE_TYPE_NAVIGATION_BASED. The values of: "profile state report.profiles" & "profile type". Note that [*] in the key is replaced by a number.		enum	All Data

7d2ccf11-f4fd-324f-89bc-1487fe7d4dee	profile_state_report.profiles.[*].profile_type	Possible values: PROFILE_TYPE_INVALID , PROFILE_TYPE_LOCATION_INDEPENDENT , PROFILE_TYPE_LOCATION_BASED , PROFILE_TYPE_NAVIGATION_BASED. The values of: "profile state report.profiles" & "profile type". Note that [*] in the key is replaced by a number.		enum	All Data
cb09acec-c53a-3829-ac02-d120b4c41f20	profile_state_report.profiles.[*].profile_uuid	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "profile uuid". Note that [*] in the key is replaced by a number.		string	All Data

187b8bad-fd61-3f4e-83d6-1be6a0777753	profile_state_report.profiles.[*].profile_uuid	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "profile uuid". Note that [*] in the key is replaced by a number.		string	All Data
88bde5d4-a823-35b6-aa5b-828cea5ca8fd	profile_state_report.profiles.[*].profile_uuid	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "profile uuid". Note that [*] in the key is replaced by a number.		string	All Data
6291f7a6-2b09-38eb-88af-545b66cfec69	profile_state_report.profiles.[*].profile_uuid	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "profile uuid". Note that [*] in the key is replaced by a number.		string	All Data

3974d399-7d2c-35f6-b050-10cf4471980a	profile_state_report.profiles.[*].target_soc	the desired SOC that the client wants to reach. Options: 50-60-70-80-90-100. The values of: "profile state report.profiles" & "target soc". Note that [*] in the key is replaced by a number.		int	All Data
ec71179b-066f-38cf-b83e-0350bfa2096b	profile_state_report.profiles.[*].target_soc	the desired SOC that the client wants to reach. Options: 50-60-70-80-90-100. The values of: "profile state report.profiles" & "target soc". Note that [*] in the key is replaced by a number.		int	All Data
98006dd3-a38c-3a7a-8f76-242678d180d1	profile_state_report.profiles.[*].target_soc	the desired SOC that the client wants to reach. Options: 50-60-70-80-90-100. The values of: "profile state report.profiles" & "target soc". Note that [*] in the key is replaced by a number.		int	All Data

a63f0405-424a-39f0-bdbe-709565190c3e	profile_state_report.profiles.[*].target_soc	the desired SOC that the client wants to reach. Options: 50-60-70-80-90-100. The values of: "profile state report.profiles" & "target soc". Note that [*] in the key is replaced by a number.		int	All Data
0806db0b-8df8-35b0-a6c6-bd38c7e0d191	profile_state_report.profiles.[*].timers.[*].activation_state	to activacte or deactivate the corresponding timer. The values of: "profile state report.profiles" & "timers" & "activation state". Note that [*] in the key is replaced by a number.		boolean	All Data
5a62ef40-27d2-3dd7-a251-a1b8c498db9d	profile_state_report.profiles.[*].timers.[*].activation_state	to activacte or deactivate the corresponding timer. The values of: "profile state report.profiles" & "timers" & "activation state". Note that [*] in the key is replaced by a number.		boolean	All Data

12e0f6f8-5928-3a3d-b295-6b8a67b9aa9f	profile_state_report.profiles.[*].timers.[*].activation_state	to activacte or deactivate the corresponding timer. The values of: "profile state report.profiles" & "timers" & "activation state". Note that [*] in the key is replaced by a number.		boolean	All Data
6d9b412b-a8f5-3954-ad6c-62a89f442b8a	profile_state_report.profiles.[*].timers.[*].activation_state	to activacte or deactivate the corresponding timer. The values of: "profile state report.profiles" & "timers" & "activation state". Note that [*] in the key is replaced by a number.		boolean	All Data
4707cdfc-6e85-30f9-b213-265315b7ca21	profile_state_report.profiles.[*].timers.[*].charge_option	if the parameter is true, the timer is programmed for charging. The values of: "profile state report.profiles" & "timers" & "charge option". Note that [*] in the key is replaced by a number.		boolean	All Data

d641b228-b8fb-379c-97ef-f9181bdcfe9b	profile_state_report.profiles.[*].timers.[*].charge_option	if the parameter is true, the timer is programmed for charging. The values of: "profile state report.profiles" & "timers" & "charge option". Note that [*] in the key is replaced by a number.		boolean	All Data
fe99f266-837f-301f-9295-3837efc471c5	profile_state_report.profiles.[*].timers.[*].charge_option	if the parameter is true, the timer is programmed for charging. The values of: "profile state report.profiles" & "timers" & "charge option". Note that [*] in the key is replaced by a number.		boolean	All Data
10ccf810-7738-3976-ad9e-9866068f7aa3	profile_state_report.profiles.[*].timers.[*].charge_option	if the parameter is true, the timer is programmed for charging. The values of: "profile state report.profiles" & "timers" & "charge option". Note that [*] in the key is replaced by a number.		boolean	All Data

995fedf1-68ac-300c-9fa8-8e5127414706	profile_state_report.profiles.[*].timers.[*].clima_option	if the parameter is true, the timer is programmed for AC and WindowHeating+Mirrors (WindowHeating+Mirrors, If the customer has bought FoD features / package 2 AND is_mirror_heating_enabled=true). The values of: "profile state report.profiles" & "timers" & "clima option". Note that [*] in the key is replaced by a number.		boolean	All Data, Climatisation and Heating
2cad090b-df21-36e9-8d4b-29fde7c0730f	profile_state_report.profiles.[*].timers.[*].clima_option	if the parameter is true, the timer is programmed for AC and WindowHeating+Mirrors (WindowHeating+Mirrors, If the customer has bought FoD features / package 2 AND is_mirror_heating_enabled=true). The values of: "profile state report.profiles" & "timers" & "clima option". Note that [*] in the key is replaced by a number.		boolean	All Data, Climatisation and Heating

964701ba-880d-3586-9fbe-883a0367f6d4	profile_state_report.profiles.[*].timers.[*].clima_option	if the parameter is true, the timer is programmed for AC and WindowHeating+Mirrors (WindowHeating+Mirrors, If the customer has bought FoD features / package 2 AND is_mirror_heating_enabled=true). The values of: "profile state report.profiles" & "timers" & "clima option". Note that [*] in the key is replaced by a number.		boolean	All Data, Climatisation and Heating
fd9d2123-7b50-3c65-9b53-2f5c596ba217	profile_state_report.profiles.[*].timers.[*].clima_option	if the parameter is true, the timer is programmed for AC and WindowHeating+Mirrors (WindowHeating+Mirrors, If the customer has bought FoD features / package 2 AND is_mirror_heating_enabled=true). The values of: "profile state report.profiles" & "timers" & "clima option". Note that [*] in the key is replaced by a number.		boolean	All Data, Climatisation and Heating

855a8fd1-2971-3652-85da-3f76da76619c	profile_state_report.profiles.[*].timers.[*].single.departure_date_time	The timer will be programmed for the corresponding date and time. SCME provides the time (departureDate>Example: 2005-11-12) and date (departureTime: 00:00:00+00:00) but java will forward this date-time in UTC. The values of: "profile state report.profiles" & "timers" & "single.departure date time". Note that [*] in the key is replaced by a number.		string	All Data

7004d1b2-11ed-3fac-930c-46be92ebe26a	profile_state_report.profiles.[*].timers.[*].single.departure_date_time	The timer will be programmed for the corresponding date and time. SCME provides the time (departureDate>Example: 2005-11-12) and date (departureTime: 00:00:00+00:00) but java will forward this date-time in UTC. The values of: "profile state report.profiles" & "timers" & "single.departure date time". Note that [*] in the key is replaced by a number.		string	All Data

5e85b868-d63f-39b8-afe8-d1a1e33473e6	profile_state_report.profiles.[*].timers.[*].single.departure_date_time	The timer will be programmed for the corresponding date and time. SCME provides the time (departureDate>Example: 2005-11-12) and date (departureTime: 00:00:00+00:00) but java will forward this date-time in UTC. The values of: "profile state report.profiles" & "timers" & "single.departure date time". Note that [*] in the key is replaced by a number.		string	All Data

17798dd9-823f-3118-98e6-b9f384c84783	profile_state_report.profiles.[*].timers.[*].single.departure_date_time	The timer will be programmed for the corresponding date and time. SCME provides the time (departureDate>Example: 2005-11-12) and date (departureTime: 00:00:00+00:00) but java will forward this date-time in UTC. The values of: "profile state report.profiles" & "timers" & "single.departure date time". Note that [*] in the key is replaced by a number.		string	All Data
79e5e077-5931-3447-b41f-389dac3b1cce	profile_state_report.profiles.[*].timers.[*].timer_id	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "timers" & "timer ID". Note that [*] in the key is replaced by a number.		int	All Data

9f3019a5-0e17-323c-be0e-ac73bcd6ab6b	profile_state_report.profiles.[*].timers.[*].timer_id	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "timers" & "timer ID". Note that [*] in the key is replaced by a number.		int	All Data
6a68ac19-8fd5-3603-9ce7-b93d337d0cc3	profile_state_report.profiles.[*].timers.[*].timer_id	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "timers" & "timer ID". Note that [*] in the key is replaced by a number.		int	All Data

600598b8-8331-37fd-9542-eca4f99d7de2	profile_state_report.profiles.[*].timers.[*].timer_id	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "timers" & "timer ID". Note that [*] in the key is replaced by a number.		int	All Data
31697503-5924-3fdb-b13a-c19b79da9936	profile_state_report.profiles.[*].timers.[*].timer_uuid	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "timers" & "timer uuid". Note that [*] in the key is replaced by a number.		string	All Data

ed97b88f-aa5c-3dc7-90cb-c986370de07e	profile_state_report.profiles.[*].timers.[*].timer_uuid	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "timers" & "timer uuid". Note that [*] in the key is replaced by a number.		string	All Data
e8bab46e-b409-3de0-a8e8-9fd8c7958f7f	profile_state_report.profiles.[*].timers.[*].timer_uuid	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "timers" & "timer uuid". Note that [*] in the key is replaced by a number.		string	All Data

b2360256-8da4-3213-a50a-1a556f7a8e64	profile_state_report.profiles.[*].timers.[*].timer_uuid	identification number for the preferred_charging_time. (Profile1: 1,2,3,4 ..... Profile5: 17,18,19,20). The values of: "profile state report.profiles" & "timers" & "timer uuid". Note that [*] in the key is replaced by a number.		string	All Data
dff014a3-fb9f-30ce-9194-5ca59c0c26fc	amsAlbum	information about music played in vehicle (Name of album)		string	Infotainment Related Data
99a0590e-ad3a-3743-9d5a-11801722d2cd	amsArtist	information about music played in vehicle (Artist)		string	Infotainment Related Data
f2e639d6-b513-3427-a861-a976259db659	amsSongTitle	information about music played in vehicle (Title of the song)		string	Infotainment Related Data
f89ed652-d104-3fa6-b7e2-ab7543309e7b	hv_soc	Indicates the state of charge for the high voltage battery	%	int	All Data, Vehicle Status, Charging
274e6453-8889-352d-a47d-b4f1a50b8e5a	idp_idt	The string value of "idp IDt"		string	All Data
3c217477-7218-34be-b791-86df4a41f4c8	in_cabin_temperature.measurement_state	Possible values: MEASUREMENT_STATE_INVALID, MEASUREMENT_STATE_UNSUPPORTED, MEASUREMENT_STATE_VALID		enum	All Data

74039fb6-281b-33d8-aba5-d7fb58b53525	in_cabin_temperature.temperature	the value of the corresponding temperature. Resolution=0.1ï¿½C 0(-46ï¿½C)->1460(100ï¿½C)/ Resolution=0.25ï¿½F 1461(-51ï¿½F)->2513ï¿½F(212ï¿½F)		int	All Data

5feaf5db-29c9-3e59-9f5d-68d19a562a80	instrument_cluster_time	Format for the DP (mqtt publish)-> 2009-01-01T12:00:00+01:00 (without miliseconds. Java service must use 00 seconds, if SCME doesnï¿½t provide the seconds. Java must compare UTC time with instrument_cluster_time, if SCME has not provide timezone. Java must send the timezone in the ICT). The instrument_cluster_time (time adjusted in the car) = customeTime in the Service_Time. The frontends can use this time to represent the timers and preferredcharging in the time zone, which the car is using		string	All Data
d8d3e58b-b527-39b6-8d71-c3da9c7e2816	instrument_cluster_time	The string value of "instrument cluster time"		string	All Data
de771c0f-c53b-3c3a-ad10-aa1ee58ebb22	is_actuationS_activated	The boolean value of "is actuationS activated"		boolean	All Data
148382ea-0c23-3b16-98f8-24d895024327	is_actuationS_activated	The boolean value of "is actuationS activated"		boolean	All Data
74f33bc7-01e7-316c-ae59-fd679cb6d9d7	is_actuationS_activated	The boolean value of "is actuationS activated"		boolean	All Data

a6403fa6-dcd4-33ce-84b7-2612cad3c45b	is_engine_activated	The boolean value of "is engine activated"		boolean	All Data
d7a8bc27-95c2-30b3-ad81-2df3e7d75e1b	is_enginestate_activated	The boolean value of "is enginestate activated"		boolean	All Data
7bc194a2-8fe8-3894-86c6-252054009045	is_enginestate_activated	The boolean value of "is enginestate activated"		boolean	All Data
4cc09672-e4e7-394d-8e00-d67b55092f43	is_enginestate_activated	The boolean value of "is enginestate activated"		boolean	All Data
120d3d4e-edc9-356a-9a6e-4b3731998ec4	is_mileage_activated	The boolean value of "is mileage activated"		boolean	All Data
1a6838f8-eeda-36b9-b1e6-b661e97d88a6	is_mileage_activated	The boolean value of "is mileage activated"		boolean	All Data
3fac5f9d-7110-3711-bb20-532ff2c488b5	is_mileage_activated	The boolean value of "is mileage activated"		boolean	All Data
c5b49a1b-6d02-3578-94cb-b051cef40e85	is_single_request	The boolean value of "is single request"		boolean	All Data
b04af953-45ae-349a-ab7c-bde7101406a2	is_single_request	The boolean value of "is single request"		boolean	All Data
ea88b25e-3ceb-36a3-94f9-290509911f70	is_single_request	The boolean value of "is single request"		boolean	All Data
f437dc0b-3021-323f-a2c4-e3d3be2f144d	is_single_request	The boolean value of "is single request"		boolean	All Data
bc097f17-2f61-3e69-b900-a9bcc5445b5d	is_single_request	The boolean value of "is single request"		boolean	All Data
3283a9b1-463a-3a36-89bc-543df74e8237	is_single_request	The boolean value of "is single request"		boolean	All Data
acdd25b5-8d20-3dbc-83f7-e5b8436e0362	last_battery_charger_update_trigger	Contains trigger info about last battery charger update	'-	String	All Data, Charging
b6c6d710-53c3-3a5d-a23c-5a5141681d30	led_color	Color of LED	'-	String	All Data, Charging

9c390ebd-cc97-3f18-8e47-82dcc44a514e	led_state	Indicates state of LED (off/blink/pulse etc)	'-	String	All Data, Charging
bd917b58-82bd-3c34-a006-747ca5aec03d	locked	Lock status		boolean	All Data
ad12b2c9-2290-3147-bc72-f5adbf659d9b	locked	Lock status		boolean	All Data
937bf8d6-bd3e-306e-af30-8a8a4cc14644	locked_state_front_engine_bonnet	Indicates if the engine bonnet is unsupported (0) or invalid (1) or locked (2) or unlocked (3)	'-	int	All Data, Vehicle Access
db6919e8-430a-35dc-a930-14d289be6985	locked_state_front_left_door	Indicates if the front left door is locked (2) or unlocked (3)	'-	int	All Data, Vehicle Access
21e084ad-51bf-3461-a521-49a544720c91	locked_state_front_right_door	Indicates if the front right door is locked (2) or unlocked (3)	'-	int	All Data, Vehicle Access
fc0dab76-59ca-31bd-8845-e4b39d485b71	locked_state__rear_left_door	Indicates if the rear left door is locked (2) or unlocked (3)	'-	int	All Data, Vehicle Access
6e36232f-4c55-3688-9948-a3a6ae056db1	locked_state_rear_right_door	Indicates if the rear right door is locked (2) or unlocked (3)	'-	int	All Data, Vehicle Access
95380872-847c-39d7-857f-17cdea1579ce	locked_state_tailgate	Indicates if the tailgate is unsupported (0) or invalid (1) or locked (2) or unlocked (3)	'-	int	All Data, Vehicle Access
60bc0937-f5a7-3809-9535-9a7942e5dd94	lock_state	Describes the lock state	'-	String	All Data, Charging
4549d5ee-f04c-3a26-b351-c27f8003f07f	longTermAverageConsumption	long term fuel consumption	l/100km / kWh/100km	string	Trip Statistics
e88f3118-f6ae-3e30-86ec-830dda2df294	longTermAveragePrimaryEngineConsumptionIndication	long term average primary engine consumption	(l/100km)	int	Trip Statistics

b1bd8934-0618-398f-b675-8ad20d427bd3	longTermAverageSecondaryEngineConsumptionIndication	long term average secondary engine consumption	KWh_per_100km	int	Trip Statistics
21d53d55-28e9-3911-8a23-5eb060c085b6	longTermAverageVehicleSpeedIndication	long term average vehicle speed	(km/h)	int	Trip Statistics
6346419f-810c-3244-8003-b21ddf3f1e8d	long_term_data_average_aux_consumer_consumption	Average Auxiliary Consumer Consumption during long term trip	kwH/1000km	int	All Data, Trip Statistics
79f1709e-028d-3b3a-936e-bbef63b92969	long_term_data_average_electr_engine_consumption	Average Electric Engine Consumption during long term trip	kwH/1000km	int	All Data, Trip Statistics
df531c6f-8897-3236-a760-5975322e7021	long_term_data_average_fuel_consumption	Average Fuel Consumption during long term trip	l/1000km	int	All Data, Trip Statistics
a326ae4c-afe8-3929-bf1a-b95ba7107c2f	long_term_data_average_gas_consumption	Average gas Consumption during long term trip	kg/1000km	int	All Data, Trip Statistics
579128d5-94d8-3548-abcd-341fcf34401b	long_term_data_average_recuperation	Average recuperation during long term trip	kwH/1000km	int	All Data, Trip Statistics
77838f59-786a-36fa-b1d4-47217a9fb40e	long_term_data_average_speed	Average speed	km/h	int	All Data, Trip Statistics
f8eba56b-ee3f-3c48-b852-03c9b956053f	long_term_data_mileage	Overall Mileage for long term trips	km	int	All Data, Trip Statistics
f27da3e3-4130-3444-8203-3023f333d253	long_term_data_range_gain_distance	Gained range distance in [0.1 km] during long term trip	100m	int	All Data, Trip Statistics
2bfaa641-c972-3816-ae7c-73459bcd673d	long_term_data_start_mileage	Mileage when trip started	km	int	All Data, Trip Statistics
d2ad181b-511a-37d0-8109-e676e68c86b2	long_term_data_travel_time	Time of trip with vehicle ready for driving	min	int	All Data, Trip Statistics

10857fe3-8150-3e86-84a9-970648cf55e0	long_term_data_zero_emission_distance	Distance driven without emission in [0,1km] during long term trip	100m	int	All Data, Trip Statistics
ca35a41d-d729-3372-9b80-fdb23c01347c	longTermTimeIndication	long term time	(min)	int	Trip Statistics
487ac023-ec69-32f2-86ca-6af613cd819e	long_trip.average_electric_engine_consumption	The float value of "long trip average electric engine consumption"		float	All Data, Trip Statistics
da1e7b6c-8483-31bf-b4ab-0d809d76278e	long_trip.average_fuel_consumption	The float value of "long trip average fuel consumption"		float	All Data, Trip Statistics
59074036-4c26-388c-b47e-fb48bff41106	long_trip.average_gas_consumption	The float value of "long trip average gas consumption"		float	All Data, Trip Statistics
09d29793-a5ab-3817-af5f-af9375ca0d3e	long_trip.average_speed	The float value of "long trip average speed"		float	All Data, Trip Statistics
2bafe6fa-04c5-3df5-9c07-73e5d4d399f2	long_trip.car_captured_timestamp	The string value of "long trip car captured timestamp" - DPS - Remote Trip Statistics		string	All Data, Trip Statistics
63b87c26-3c18-3883-9e57-d0e62d403fab	long_trip.distance_unit	The enum value of "long trip distance unit"		enum	All Data, Trip Statistics
bda80f94-2a24-3120-ac5a-340110c7c527	long_trip.electric_engine_consumption_unit	The enum value of "long trip electric engine consumption unit"		enum	All Data, Trip Statistics
133e55ae-2931-38e7-822e-8fa723b9d453	long_trip.fuel_consumption_unit	The enum value of "long trip fuel consumption unit"		enum	All Data, Trip Statistics
d3b0e261-3627-3f20-a416-9eec66f669aa	long_trip.gas_consumption_unit	The enum value of "long trip gas consumption unit"		enum	All Data, Trip Statistics

574d786d-68ef-3df2-bd61-47ab19e7c56b	long_trip.message_received_timestamp	The string value of "long trip message received timestamp" - DPS - Remote Trip Statistics		string	All Data, Trip Statistics
045aa17a-d1e6-36ac-b94b-ee719c293824	long_trip.mileage_unit	The enum value of "long trip mileage unit"		enum	All Data, Trip Statistics
65e4eb58-6dae-3207-88fa-756f375d983d	long_trip.overall_mileage	The int value of "long trip overall mileage"		int	All Data, Trip Statistics
5f3ee778-b16d-373c-87d8-e6237292bcc7	long_trip.reset_reason	The enum value of "long trip reset reason"		enum	All Data, Trip Statistics
574aa213-76e4-33a4-a4a1-86409f511f39	long_trip.speed_unit	The enum value of "long trip speed unit"		enum	All Data, Trip Statistics
03d59946-8521-3ce5-80a7-102c2c09a216	long_trip.travel_time	The int value of "long trip travel time"		int	All Data, Trip Statistics
faaa5b4f-9405-33bd-a9d7-44d0d48072cd	long_trip.trip_data.average_electr_engine_consumption	The float value of "long trip trip data average electr engine consumption"		float	All Data, Trip Statistics
779b5173-837d-3d37-9626-724ea5b51c94	long_trip.trip_data.average_electr_engine_consumption_unit	The string value of "long trip trip data average electr engine consumption unit"		string	All Data, Trip Statistics
f0f0d936-7884-32f1-8c75-1dc25fd54fa4	long_trip.trip_data.average_fuel_consumption	The float value of "long trip trip data average fuel consumption"		float	All Data, Trip Statistics
33c3c0c7-3f14-3c01-b407-ae69868d8ab0	long_trip.trip_data.average_fuel_consumption_unit	The string value of "long trip trip data average fuel consumption unit"		string	All Data, Trip Statistics
0236091d-7a95-3496-bcc1-c35c4e0ca959	long_trip.trip_data.average_Speed	The float value of "long trip trip data average Speed"		float	All Data, Trip Statistics

46c41796-c830-3c5e-b4f2-cbc5cdc266ea	long_trip.trip_data.average_Speed_unit	The string value of "long trip trip data average Speed unit"		string	All Data, Trip Statistics
b97195df-ae2c-30d9-8f95-8e20e57de5d6	long_trip.trip_data.travel_time	The int value of "long trip trip data travel time"		int	All Data, Trip Statistics
a293bef7-21b6-325a-bdc9-7795b704611f	long_trip.trip_data.trip_distance	The float value of "long trip trip data trip distance"		float	All Data, Trip Statistics
16aced03-e58d-37d3-be60-562d171e2c2b	long_trip.trip_data.trip_distance_unit	The enum value of "long trip trip data trip distance unit"		enum	All Data, Trip Statistics
480f1d81-44dc-31c0-b405-8ea65144c8c5	long_trip.trip_distance	The float value of "long trip trip distance"		float	All Data, Trip Statistics
531a453f-c9c4-3280-ab13-9b4ab774eadb	long_trip.trip_reset_id	The string value of "long trip trip reset ID"		string	All Data, Trip Statistics
7b00e81a-35c0-360f-9968-6d04cbb80553	long_trip.vehicle_trip_data.overall_Mileage	The int value of "long trip vehicle trip data overall Mileage"		int	All Data, Trip Statistics
a2905058-ee58-3150-a153-7085764d573b	long_trip.vehicle_trip_data.overall_Mileage_unit	The enum value of "long trip vehicle trip data overall Mileage unit"		enum	All Data, Trip Statistics
85a0ba32-76cc-3a1f-94be-bbde20c89442	long_trip.vehicle_trip_data.reason	The enum value of "long trip vehicle trip data reason"		enum	All Data, Trip Statistics
4e80d99f-4592-3a47-9830-51ff50f64243	long_trip.vehicle_trip_data.resetcounter	The int value of "long trip vehicle trip data resetcounter"		int	All Data, Trip Statistics
a1272723-a7c6-35cd-ad80-f4cc3bb71982	long_trip.vehicle_trip_data.timestamp	The string value of "long trip vehicle trip data timestamp" - DPS - Remote Trip Statistics		string	All Data, Trip Statistics

5893e9c7-818c-3762-970d-1a6d36595252	long_trip.vehicle_trip_data.vehicleTripDataType	The enum value of "long trip vehicle trip data vehicleTripDataType"		enum	All Data, Trip Statistics
ac86e00b-7fa1-3a59-b481-aa7cfc49b0d9	maintenance_interval_distance_until_inspection	Indicates the remaining running distance until the next service; if this limit was exceeded, this value indicates the distance that has been driven since then (always in km).	km	int	All Data, Maintenance Related Information
d9f36adc-1840-37da-8ca1-7c2d789bcf9e	maintenance_interval_distance_until_oil_change	Indicates the remaining running distance until the next oil service; if this limit was exceeded, this value indicates the distance that has been driven since then (in each case in kilometers).	km	int	All Data, Maintenance Related Information
97aa3271-7b36-322f-b913-d4bf5ab31633	maintenance_interval_inspection_warning	Indicates if the inspection warning is active in the vehicle	'-	int	All Data, Maintenance Related Information, Breakdown, Dashboard Measurements, Vehicle Warning Lights
d607f5ff-cacb-3460-a8eb-8ca16d4acc08	maintenance_interval_monthly_mileage	Indicates the distance driven monthly in kilometer	km	int	All Data, Maintenance Related Information

0b7f22d9-1703-35f5-94cc-0c58a42fcbb4	maintenance_interval_oil_change_warning	Indicates if the oil change warning is active in the vehicle	'-	int	All Data, Maintenance Related Information, Breakdown, Dashboard Measurements, Vehicle Warning Lights
fd600221-7965-3396-96d7-82a840a2831c	maintenance_interval__time_until_inspection	Indicates the time remaining until the next service; if this limit was exceeded, this value indicates the time that has passed since then.	day	int	All Data, Maintenance Related Information
42b1c47b-e1d1-375f-a76f-32ab0177f03e	maintenance_interval__time_until_oil_change	Indicates the time remaining until the next oil service; if this limit was exceeded, this value indicates the time that has passed since then.	day	int	All Data, Maintenance Related Information
f6d48e16-a95f-30f8-bb50-757ddf528082	maximum_speed	The float value of "maximum speed"		float	All Data
5ab31e3b-fd8d-3686-807f-0de95825d7c3	max_number_users	The int value of "max number users"		int	All Data
b7adff02-c1a4-357c-ba12-731d3e4990af	maxPowerChargingStation	current maximum Charging power that the charger can offer to the car (EV vehicle must be connected to charger)	kW	int	Charging

dc4a4716-2205-352f-802f-8d7d59705c5b	max_temperature	Current temperature value of the battery module with the highest temperature in ï¿½C.		float	All Data
c0f85ba6-01f5-379d-a29d-32d693a85174	max_temperature	The float value of "max temperature"		float	All Data
f312e824-5e2e-3531-afd0-8ed4f66a778d	message_id	Unique ID for reports		string	All Data
5f69f758-b24d-3d4f-a550-628d809879b6	message_id	Unique ID for reports		string	All Data
0db29eee-33a5-35f3-8bec-7a992cf02b22	message_id	Unique ID for reports		string	All Data
50fa4203-fc8a-340a-9784-8d2755c65f3f	message_id	Unique ID for reports		string	All Data
03bfbd83-77dc-3ec8-bef0-deb1591ef9cd	message_id	Unique ID for reports		string	All Data
23310236-8006-3088-a0b2-7b4bd34c5248	message_id	Unique ID for reports		string	All Data
d2ee04a0-451e-3c0e-b4d4-d40746df78b6	message_id	The string value of "message ID"		string	All Data
fd3a9ffa-5da9-3d06-a1a6-e0550910abfe	message_id	Unique ID for reports		string	All Data
e6d9c546-57ab-35aa-b42d-a47d55633a8e	message_id	The string value of "message ID"		string	All Data
cd0c83e9-88aa-32e9-a4ef-7ef7a003f5e5	message_id	Unique ID for reports		string	All Data
5624bf83-9cc4-359e-9adf-c308d970441d	message_id	Unique ID for reports		string	All Data
8b6e4245-967b-34c6-b6e9-72833cfbfb83	message_id	The string value of "message ID"		string	All Data
6ec5e368-f0a9-3688-9a70-cf943ee04f01	message_id	Unique ID for reports		string	All Data
c9b814d9-8dd5-3fba-8b8d-13020dca8352	message_id	Unique ID for reports		string	All Data
8263f809-126f-3067-b450-5383f92ac8dd	message_id	Unique ID for reports		string	All Data
9d945ab1-f68f-3418-b9cc-987cc38122a3	message_id	Unique ID for reports		string	All Data
708df65a-76dc-3f2e-ab75-68dcb6d2078e	message_id	Unique ID for reports		string	All Data
456e9b87-d8cc-3f8c-8415-13d2ddca9ba7	message_id	Unique ID for reports		string	All Data
e7da1fba-3322-3525-b85b-2fc62c9b43f2	message_id	Unique ID for reports		string	All Data
75ccdc7e-6515-327a-8c8c-ca9dc7576981	message_id	Unique ID for reports		string	All Data
fd0c6f14-0922-3868-8b01-8653e26f25c8	message_id	Unique ID for reports		string	All Data
e995d737-62f4-327e-8ee5-857742cfdf62	message_id	The string value of "message ID"		string	All Data

9a3cb9d8-ded5-320f-bcbf-223dcd873bcf	message_id	The string value of "message ID"		string	All Data
cfa19d5e-036a-3d7f-8f3e-745a1b11cc64	message_id	Unique ID for reports		string	All Data
ff301275-23b7-33c2-85e3-eb7657a4a5f0	message_id	Unique ID for reports		string	All Data
4f78c41f-54cf-3723-a3a1-87bd44488624	message_id	Unique ID for reports		string	All Data
a5b167e5-7fa8-3e59-9343-beae8a777908	message_id	Unique ID for reports		string	All Data
775033d3-08df-3721-a287-e4f5611cf164	message_id	Unique ID for reports		string	All Data
eef89cad-bf03-3c34-886a-4c7bc97d948f	message_id	Unique ID for reports		string	All Data
07641f9e-035f-3f9d-b9c6-1d5a61500472	message_id	The string value of "message ID"		string	All Data
5eff7106-6297-352d-a03a-b866c9c05ca1	message_id	Unique ID for report		string	All Data
ea3d1410-6bad-3845-b389-958e4d35d4ce	message_id	Unique ID for reports		string	All Data
ffb51616-04fa-35f3-886a-9b277198298b	message_id	Unique ID for reports		string	All Data
03cf02e2-98e4-3f95-851d-20da2e5938c2	message_id	Unique ID for reports		string	All Data
c2763f0f-847b-3d6f-b5e9-fd76d4a49337	message_id	Unique ID for reports		string	All Data
208bfe91-afcd-3ae3-b9c8-e4a0168d257e	message_id	Unique ID for reports		string	All Data
7ed088f3-7d74-3012-a229-e996e2e639e7	message_id	Unique ID for reports		string	All Data
aa7d5653-4d61-38ed-817f-812bcaa01886	message_id	The string value of "message ID"		string	All Data
1e5b53d9-6718-331c-80ce-a2c0e2e55295	message_id	Unique ID for reports		string	All Data
15fee9e7-739f-3d8a-a6c4-52d37bca21cc	message_id	Unique ID for reports		string	All Data
c8c8307d-5503-3fde-b30a-028785e17717	message_id	Unique ID for reports		string	All Data
1fc8f18d-6f33-3c9b-8bf6-ddb6595e5565	message_id	Unique ID for reports		string	All Data
5b8d0bb9-0155-3648-b444-9281bc025d3f	message_id	Unique ID for reports		string	All Data
e41c0a65-a010-35aa-934d-7822d08aec0d	message_id	Unique ID for reports		string	All Data
422df9c2-99f2-3186-905e-e55bfd8cf16a	message_id	Unique ID for reports		string	All Data
e6ec39f1-8a74-3000-88e6-b3e5f0b36565	message_id	The string value of "message ID"		string	All Data
394f5c6d-a595-30e8-83d8-eaf29622246b	message_id	Unique ID for reports		string	All Data
f0116b03-b11a-3378-b2d9-4d0fcf4cebf3	message_id	Unique ID for reports		string	All Data
889cf7ab-54cd-36d0-8044-004c729a6eba	message_id	Unique ID for reports		string	All Data
51070c94-359c-35ef-bdbf-eb415da7ce3a	message_id	Unique ID for reports		string	All Data

0199b88b-bd69-7380-9f48-c027e3579351	AAG_Anhaenger_erkannt_XIX_Anhaenger_02_XIX_HCP4_CANFD01	Erkennung Anhaenger			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e35793e8	AB_Gurtschloss_FA_XIX_Airbag_02_XIX_E3V_VLAN_Connect	Gurtschlosstatatus Fahrerseite			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e35793d9	AB_Gurtschloss_Reihe2_MI_XIX_Airbag_02_XIX_E3V_VLAN_Connect	Gurtschlossstatus 2. Reihe Mitte, Mehrausstattung			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea7894	ACC_Abbiegewunsch_XIX_ACC_18_XIX_E3V_VLAN_Connect	Identifizierter Abbiegewunsch vom Fahrer			
019a7124-a083-776f-b8ee-3b8ef6ea78a4	ACC_Anzeige_Schwarmregelung_XIX_ACC_19_XIX_E3V_VLAN_Connect	Anzeige der Schwarmregelung vom ACC			
019a7124-a083-776f-b8ee-3b8ef6ea78a1	ACC_Blindheit_erkannt_XIX_ACC_18_XIX_E3V_VLAN_Connect	Blindheitserkennung			
019a61ac-1573-7a44-8b16-0b2939cb1ca6	ACC_FoD_Status_XIX_ACC_18_XIX_E3V_VLAN_Connect	Informiert den TSK und Kombi, ob die ACC-Funktion freigeschaltet ist oder nicht.			
019a7124-a083-776f-b8ee-3b8ef6ea7883	ACC_Statusicon_XIX_ACC_19_XIX_E3V_VLAN_Connect	Statusanzeige der aktiven LÃ¤ngsregelfuntkion (ACC/GRA-Modus)			

019a7124-a083-776f-b8ee-3b8ef6ea78a0	ACC_Typ_RNS_XIX_ACC_19_XIX_E3V_VLAN_Connect	VW: Anzeige der Klasse des rechten Nebenspurobjektes (RNS)			
019a7124-a083-776f-b8ee-3b8ef6ea7886	ACC_Warnung_Verkehrszeichen_1_XIX_ACC_19_XIX_E3V_VLAN_Connect	PACC: Zeigt bei Ãberschreitung der aktuellen HÃ¶chstgeschwindigkeit um 10% einen Hinweis im Kombi an			
0199b88b-c53f-718d-b010-636bf9b22c40	BCM1_Valet_Parking_Taster_XIX_BCM_01_XIX_E3V_VLAN_Connect	Valet Parking Taster			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1c4	BCM_Charisma_Taste2_XIX_BCM_01_XIX_E3V_VLAN_Connect	BetÃ¤tigung der Charisma-Taste 2			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be61	BDM_I_Bereich_dyn_XIX_BDMs_Dyn_XIX_HCP5_LIN01				All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be54	BDM_Spannung_dyn_XIX_BDMs_Dyn_XIX_HCP5_LIN01				All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be69	BDM_Strom_XIX_BDMs_Ruhe_XIX_HCP5_LIN01				All Data, Dynamic Technical Data Campaigns

0199b88a-7c25-7d2b-96f6-64981efcc4c7	BMC_IstZellSpannungMax_Zell_ID_XIX_BMC_HV_08_XIX_HCP5_CANFD01	RTM-Signal: Nummer (ID) der Zelle (innerhalb des Moduls) mit der aktuell hÃ¶chsten Zellspannung			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4a4	BMC_IstZellspannungMax_XIX_BMC_HV_02_XIX_HCP5_CANFD01	Aktuell hÃ¶chste Zellspannung in der Batterie			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4a3	BMC_IstZellspannungMin_XIX_BMC_HV_02_XIX_HCP5_CANFD01	Aktuell niedrigste Zellspannung in der Batterie			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be5f	BMC_Spannung_XIX_BMC_HV_01_XIX_HCP5_CANFD02	actual voltage of the battery / Momentanwert: Batteriespannung			All Data, Dynamic Technical Data Campaigns
0199b88a-a399-76f6-9144-d8e4878e2880	BMS_DC_Ladeprofil_XIX_BMS_26_XIX_E3V_VLAN_Connect	Akuelles DC-Ladeprofil der HV-Batterie			All Data, Dynamic Technical Data Campaigns
0199b88a-a399-76f6-9144-d8e4878e288c	BMS_IstZellspannung_hoechste_XIX_BMS_11_XIX_E3V_VLAN_Connect	hÃ¶chster Wert aller Zellspannungen im BMS			All Data, Dynamic Technical Data Campaigns

019df66c-523e-77a6-b40f-146dd459efd7	BMS_MV_IstStrom_XIX_BMS_MV_01_XIX_HCP5_CANFD02	Momentanwert: Batteriestrom Stromrichtung: ein Ladestrom wird mit positiven, ein Entladestrom mit negativen Werten angegeben			
0199b88a-db0b-76ce-b5c4-746cf1c7ed1c	BMS_Rekuperation_XIX_BMS_05_XIX_E3V_VLAN_Connect	ZÃ¤hler: Anzeigesignal: Energiezufuhr in die HV-Batterie (Reku). Darf nicht durch Laden der Batterie bedatet werden			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f1c4	BMS_SoC_Kalib_Anf_XIX_BMS_34_XIX_E3V_VLAN_Connect	Anforderung Laden auf 100% SOC fÃ¼r SOC-Kalibrierung			All Data, Dynamic Technical Data Campaigns
0199b88a-db0b-76ce-b5c4-746cf1c7ecf4	BMS_Spannung_Zwischenkreis_XIX_BMS_20_XIX_E3V_VLAN_Connect	Aktuelle Spannung an den Batterie-HV-AnschlÃ¼ssen; Abgang der Batterie zum Zwischenkreis / HV-Bordnetz / zur Leistungselektronik.			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f137	BT_FH_S_ManHoch_XIX_TSG_BT_01_XIX_E3V_VLAN_Connect	FH Schalter manuell hoch gedrÃ¼ckt			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f110	BT_SP_Heizung_Status_XIX_TSG_BT_01_XIX_E3V_VLAN_Connect	Status der Spiegelheizung			All Data, Dynamic Technical Data Campaigns

0199b88b-c53f-718d-b010-636bf9b22c35	BT_TIG_betaetigt_XIX_TSG_BT_01_XIX_E3V_VLAN_Connect	TÃ¼rinnengriff			All Data, Dynamic Technical Data Campaigns
0199b88b-b83a-74d1-8d51-ff00e79fefd7	DPM_StTarDrvPosn	P: Antriebsmoment muss abgerampt werden, Parksperre muss eingelegt werden R: Antriebsmoment rÃ¼ckwÃ¤rts darf freigegeben werden, Parksperre muss ausgelegt werden N: Antriebsmoment muss abgerampt werden, Parksperre muss ausgelegt werden D: Antriebsmoment vorwÃ¤rts darf freigegeben werden , Parksperre muss ausgelegt werden			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1aa	DiETa_FAS_Stufe_XIX_DiETa_01_XIX_E3V_VLAN_Connect	Status FAS-Taste			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579426	DiETa_Lock_Unlock_Taste_XIX_DiETa_01_XIX_E3V_VLAN_Connect	Lock-/Unlock-Taste			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f0f7	DiETa_Mode_roh_XIX_DiETa_01_XIX_E3V_VLAN_Connect	Erweitertes SIgnal zur ErfÃ¼llung der OBD-Relevanz fÃ¼r die Funktion Mode auf der DiETa			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0c7	DiETa_PAO_ON_Status_XIX_DiETa_01_XIX_E3V_VLAN_Connect	Istwert fÃ¼r LED "ON" in Anzeige Passenger Airbag On/Off			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea788e	EA_Bremslichtblinken_XIX_EA_02_XIX_E3V_VLAN_Connect	Die Funktion Emergency Alert fordert ein Blinken der Bremsleuchten an.			
019a7124-a083-776f-b8ee-3b8ef6ea7893	EA_Fahrzeughupe_Anf_XIX_EA_02_XIX_E3V_VLAN_Connect	Emergency Assist Anforderung Fahrzeughupe			
0199b88a-3c9f-7e8e-9943-76deb3fbbe42	EBKV_Fahrer_bremst_XIX_EBKV_03_Auth_XIX_E3V_VLAN_Connect	Fahrer will bremsen (Eintreterkennung). Wird benÃ¶tigt, um ACC oder GRA abzuschalten.			All Data, Dynamic Technical Data Campaigns
019a1468-1323-785a-b8fa-3f570f743a73	ELM1_HVK_Fehler_AE	Ausgabe eines Fehlers in der Funktion zur aktive Entladung der elektrischen Antriebseinheit			

019a1468-1323-785a-b8fa-3f570f743a72	ELM1_StCpb	Status der KomponentenverfÃ¼gbarkeit 0x0: Initialisierung 0x1: erweiterte Performance verfÃ¼gbar 0x2: normale Performance verfÃ¼gbar 0x3: geringfÃ¼gige LeistungseinschrÃ¤nkung 0x4: Warnung â erhebliche LeistungseinschrÃ¤nkung 0x5: Fehler - schwerwiegende LeistungseinschrÃ¤nkung			
0199b88b-b83a-74d1-8d51-ff00e79ff028	ELM1_StOpm	Ist-Modus elektrische Antriebseinheit			All Data, Dynamic Technical Data Campaigns
0199b88b-b83a-74d1-8d51-ff00e79ff029	ELM1_TqAct	Ist-Moment (Momentanwert) der elektrischen Antriebseinheit			All Data, Dynamic Technical Data Campaigns

0199c202-d863-7e93-9c3d-93ff74e0f1b6	ESP_Codierung_ADS_XIX_ESP_52_XIX_E3V_VLAN_Connect	ESP gibt fÃ¼r EmpfÃ¤nger im Fahrzeug aus, ob ADS verbaut/nicht verbaut ist. Im MQB wird das Signal nicht unterstÃ¼tzt!			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea789e	ESP_Lenkeingriff_ADS_XIX_ESC_50_XIX_E3V_VLAN_Connect	Im Falle eines fahrzeugstabilisierenden Lenkeingriffs des ADS-Systems soll ACC/GRA deaktiviert werden. Im MQB wird dieses Signal nicht unterstÃ¼tzt!			
019a7124-a083-776f-b8ee-3b8ef6ea789f	ESP_Notbremsanzeige_XIX_ESC_50_XIX_E3V_VLAN_Connect	ABS/ASR oder ESP hat Notbremssituation erkannt. WeiterfÃ¼hrende Informationen im Lastenheft spezifiziert und in der entsprechenden Fachabteilung zu erfragen.			

0199b88a-3c9f-7e8e-9943-76deb3fbbea6	ESP_Querbeschleunigung_XIX_ESC_50_XIX_E3V_VLAN_Connect	Beschleunigungswert in y-Achse MLB: Gemessener Wert 0xFF = Fehler (wie bereits im Wertebereich spezifizert) Bei ESP-Abschaltung durch modellgestÃ¼tzte Ãberwachung wird das Signal weiterhin ausgegeben. Im AU64x und AU57x erfolgt die Bereitstellung der Sensorwerte durch SARA-SG! MQB: Sensorrohwert Querbeschleunigung Bei ESP gemessene GrÃ¶Ãe, bei ABS errechnet (ungenauer Ersatzwert)			All Data, Dynamic Technical Data Campaigns
019ca279-c7e1-706a-97e7-d3587caf4374	ETMTElm1_TqDes_XIX_ETMTElm1_ETMTElm2_01_XIX_HCP1_FlexRay_A	Soll-Moment der elektrischen Antriebseinheit			
0199b88b-c53f-718d-b010-636bf9b22c51	FFB_HDF_Taste_XIX_ZV_02_XIX_E3V_VLAN_Connect	HDF Taste am Funkschluessel			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f0bb	FSH_Taster_XIX_Klima_12_XIX_E3V_VLAN_Connect	TasterbetÃ¤tigung Frontscheibenheizung			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579412	FS_Luftfeuchte_rel_XIX_Klima_Sensor_01_XIX_E3V_VLAN_Connect	gemessene relative Luftfeuchte			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea7863	FS_Push_Tuergriff_XIX_TSG_FT_02_XIX_E3V_VLAN_Connect	Push zum Ausfahren der Flush-Tuergriffe			
019a61ac-1573-7a44-8b16-0b2939cb1ca9	FT_Daemmglas_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	Daemmglas verbaut			
0199b88b-bd69-7380-9f48-c027e357941d	FT_FH_S_AutoHoch_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	FH Schalter automatisch hoch gedrÃ¼ckt			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea786f	FT_IRUE_Taste_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	BetÃ¤tigung IRUE-Taster (InnenraumÃ¼berwachung) MQB: Bei Verbau eines einzelnen Taster zur Deaktivierung von IRUE und NGS wird dieses Signal als Deaktivierungsanforderung beider DWA-Alarmquellen gesendet.			

0199b88b-c540-7457-9d9f-4c3cbac6f0eb	FT_Tueroeffnen_Warnung_XIX_TSG_FT_02_XIX_E3V_VLAN_Connect	Bit wird gesetzt, wenn TÃ¼r wÃ¤hrend der Fahrt geoeffnet werden soll.			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea7868	FT_Zuziehhilfe_aktiv_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	Zuziehhilfe aktiv			
019a61ac-1573-7a44-8b16-0b2939cb1c94	FoD_DTC_RPA_EPH_XIX_IPA_02_XIX_E3V_VLAN_Connect	Function on Demand DTC for RPA from EPH to Function Master			
019a61ac-1573-7a44-8b16-0b2939cb1c95	FoD_DTC_TPA_rTPA_EPH_XIX_IPA_02_XIX_E3V_VLAN_Connect	Function on Demand DTC for TPA and rTPA from EPH to Function Master			
0199bcdc-2d44-7d5f-9522-f4897daf26ef	GRA_Tip_Wiederaufnahme_XIX_GRA_ACC_01_XIX_E3V_VLAN_Connect	Tippschalter Wiederaufnahme			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c8a	HBFS_FH_Bew_hoch_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	HBFS Fenster bewegt sich in Richtung hoch			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0d4	HBFS_Unlock_Taster_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	Betaetigung Unlock Taster			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f09b	HBFS_verriegelt_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	Verriegelungsstatus TÃ¼r			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f164	HFS_FH_S_AutoHoch_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	Betaetigung FH Schalter auto hoch			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1df	HFS_FH_S_ManTief_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	Betaetigung FH Schalter man tief			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0ef	HFS_Lock_Taster_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	BetÃ¤tigung Lock-Taster			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f135	HFS_SAD_Schalter_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	| Ausstelldach MD3 ---------- 0 | nicht_betaetigt 1 | 2 | 3 | 4 | 5 | (m) Auf 6 | (a) Auf 7 | (m) Zu 8 | (a) Zu 13| Schalter nicht verfuegbar 14| Init 15| Fehlerfall			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1d0	HFS_Status_KiSi_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	Status Kindersicherung hinten Fahrerseite			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f166	HFS_Status_eTAG_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	Status des elektrischen Tueraussengriffes Tuer Fahrerseite hinten			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1cb	HFS_TIG_betaetigt_schliessen_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	TÃ¼rinnenbetÃ¤tigung, Taster TÃ¼r schlieÃen.			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c8b	HFS_Tuer_geoeffnet_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	HFS Tuer geoeffnet			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c82	HFS_Tueroeffnen_Warnung_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	Bit wird gesetzt, wenn TÃ¼r wÃ¤hrend der Fahrt geoeffnet werden soll.			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0b7	HFS_Unlock_Taster_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	Betaetigung Unlock Taster			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f09c	HSH_Taster_XIX_Klima_12_XIX_E3V_VLAN_Connect	An-/Abforderung Heckscheibenheizung Ã¼ber spezielles Tastersignal			All Data, Dynamic Technical Data Campaigns
0199b88a-db0b-76ce-b5c4-746cf1c7ed17	HVLE_Temperatur_XIX_IPB_03_XIX_E3V_VLAN_Connect	Isttemperatur SAC			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea78eb	HVLM_CJ_Restladezeit_XIX_HVLM_CJ_01_XIX_E3V_VLAN_Connect	Das Signal zeigt die restliche Ladezeit bis gewuenschte Ladezsutand			

0199b88b-ade0-704f-9ab6-916f1b71be49	HVLM_MaxLadeleistungDcFzg_XIX_HVLM_17_XIX_HCP5_CANFD01	Maximale Ladeleistung die das Fahrzeug aus einer DC-Ladeinfrastruktur entnehmen kann			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea78dc	HVLM_ZahlungsmethodeFzgPlc_XIX_HVLM_PLC_01_XIX_E3V_VLAN_Connect	Verwendete Zahlungsmethode / SelectedPaymentOption (DIN70121 RC_2) 0 = Vertrag / Contract 1 = externe Bezahlung/ ExternalPayment			
0199c202-d863-7e93-9c3d-93ff74e0f0cb	HVLS_IstPosition_Lk1_XIX_HVLS_Ladedose_SG1_XIX_E3V_VLAN_Connect	Ist-Position der Ladeklappe, Ausgabewert des Stellmotors			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f10d	HVLS_IstPosition_Lk2_XIX_HVLS_Ladedose_SG2_XIX_E3V_VLAN_Connect	Ist-Position der Ladeklappe, Ausgabewert des Stellmotors			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f1cf	HVLS_LadedosenVerbaut_SG2_XIX_HVLS_Ladedose_SG2_XIX_E3V_VLAN_Connect	Gibt an welche Ladedosen des angeschlossenen SteuergerÃ¤tes verbaut und ausgewertet werden			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f1a3	HVLS_LdTaster_Spielschutz_LK2_XIX_HVLS_Ladedose_SG2_XIX_E3V_VLAN_Connect	Gibt an ob der Spielschutz des Tasters an der Ladedose bei der Ladeklappe 2 gedrÃ¼ckt wurde			All Data, Dynamic Technical Data Campaigns

0199c202-d863-7e93-9c3d-93ff74e0f134	HVLS_PP_Max_Strom_A_XIX_HVLS_Ladedose_SG1_XIX_E3V_VLAN_Connect	Gibt die maximale Belastbarkeit des angeschlossenen Ladekabels an Ladedose A an			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f0f2	HVLS_PP_Max_Strom_B_XIX_HVLS_Ladedose_SG2_XIX_E3V_VLAN_Connect	Gibt die maximale Belastbarkeit des angeschlossenen Ladekabels an Ladedose B an			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f103	HVLS_SteckerAdapterStatus_XIX_HVLS_Ladedose_SG1_XIX_E3V_VLAN_Connect	Status eines gesteckten Adapters in der Ladedose			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f136	HVLS_SteckerEntriegelungVerbot_A_XIX_HVLS_Ladedose_SG1_XIX_E3V_VLAN_Connect	Verbot zur Ladesteckerentriegelung			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be6b	HVLS_SteckerVeriegelungStatus_A_XIX_HVLS_Ladedose_SG1_XIX_HCP5_CANFD01	Zeigt den Status des Verriegelungsaktors der Ladedose A an			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be63	HVLS_Steckerstatus_SG1_XIX_HVLS_Ladedose_SG1_XIX_HCP5_CANFD01	Stellt den Status eines Ladesteckers am SteuergerÃ¤t hinsichtlich PrÃ¤senz zur VerfÃ¼gung			All Data, Dynamic Technical Data Campaigns
0199b88b-b16d-77a2-8b45-d444aa727519	HVLS_Temp_DC_minus_XIX_HVLS_Ladedose_SG1_XIX_HCP5_CANFD01	aktuelle Temperatur des Pins DC (-) der Ladedose			All Data, Dynamic Technical Data Campaigns

019a7124-a083-776f-b8ee-3b8ef6ea78ef	HVLX_Isond_IstEnergiemengeLsPlc_XIX_ISOND_01_XIX_E3V_VLAN_Connect	Abgerechnete Ladeenergie von der Ladesaeule in kWh			
019a7124-a083-776f-b8ee-3b8ef6ea78e2	HVLX_Isond_LadeartDCComboCorePlc_XIX_ISOND_01_XIX_E3V_VLAN_Connect	Gibt an, ob die PLC-Ladesaeule das DC-Laden nach IEC2196-3 ueber die Core Pins (Steckerausfuehrung EE oder FF) unterstuetzt			
019a7124-a083-776f-b8ee-3b8ef6ea78ee	HVLX_Isond_LadeartDCExtendedPlc_XIX_ISOND_01_XIX_E3V_VLAN_Connect	Gibt an, ob die PLC-Ladesaeule das DC-Laden nach IEC2196-3 ueber die externen Pins (Steckerausfuehrung EE oder FF) unterstuetzt			
019a7124-a083-776f-b8ee-3b8ef6ea7909	HVLX_Isond_ZahlungsmethodeLs_XIX_ISOND_01_XIX_E3V_VLAN_Connect	Verwendete Zahlungsmethode / SelectedPaymentOption (DIN70121 RC_2)			
019a7124-a083-776f-b8ee-3b8ef6ea7903	IPA_PL_Anzeige_links_XIX_IPA_02_XIX_E3V_VLAN_Connect	Zeigt an, ob auf der linken Seite eine ParklÃ¼cke erkannt wurde.			
019a7124-a083-776f-b8ee-3b8ef6ea78f6	IPA_PL_Anzeige_rechts_XIX_IPA_02_XIX_E3V_VLAN_Connect	Zeigt an, ob auf der rechten Seite eine ParklÃ¼cke erkannt wurde.			
0199b88b-bd69-7380-9f48-c027e35793b0	IPA_TPA_Abbruch_XIX_Parken_01_XIX_E3V_VLAN_Connect	Signalisierung eines durch IPA erkannten Abbruchs mit Angabe des Grundes			All Data, Dynamic Technical Data Campaigns

0199b88b-c53f-718d-b010-636bf9b22c7b	ISP_EC_Lichtwert_vorne_XIX_FLA_01_XIX_E3V_VLAN_Connect	Innenspiegel: Lichtwert vorne			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f12a	ISP_EC_aktiv_XIX_FLA_01_XIX_E3V_VLAN_Connect	Status Innenspiegel (EC-Spiegel)			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4db	KL_FSA_Luftfeuchte_rel_XIX_ClimateControl_01_XIX_HCP4_CANFD02	FSA_Luftfeuchte (geroutet)			All Data, Dynamic Technical Data Campaigns
0199cc4f-0634-7c4d-9601-d022c7a9e195	KL_FSH_Soll_XIX_Klima_16_XIX_E3V_VLAN_Connect	Sollstatus der Frontscheibenheizung			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea78da	KL_Klappe_Status_XIX_Klima_16_XIX_E3V_VLAN_Connect	Status Luftklappe			
019a7124-a083-776f-b8ee-3b8ef6ea78c0	KL_LRH_Soll_XIX_Klima_16_XIX_E3V_VLAN_Connect	Sollstatus der Lenkradheizung			
019a7124-a083-776f-b8ee-3b8ef6ea78ec	KL_Mot_Tk_Soll_li_XIX_Klima_EV_04_XIX_E3V_VLAN_Connect	Stellung Temperaturklappe Soll links			
0199b88b-c540-7457-9d9f-4c3cbac6f0c3	KL_SH_Soll_hr_XIX_Klima_03_XIX_E3V_VLAN_Connect	Einstellung Sitzheizung hinten rechts (0...6)			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f13a	KL_SIH_LEH_Verteilung_VL_XIX_Klima_03_XIX_E3V_VLAN_Connect	Vom Kunden eingestellte Aufteilung der Heizleistung auf SitzflÃ¤che und LehneflÃ¤che fÃ¼r Sitz vorne links			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0ea	KL_SIH_LEH_Verteilung_VR_XIX_Klima_03_XIX_E3V_VLAN_Connect	Vom Kunden eingestellte Aufteilung der Heizleistung auf SitzflÃ¤che und LehneflÃ¤che fÃ¼r Sitz vorne rechts			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f168	KL_SIH_LEL_Verteilung_VL_XIX_Klima_03_XIX_E3V_VLAN_Connect	Vom Kunden eingestellte Aufteilung der LÃ¼ftungsleistung auf SitzflÃ¤che und LehnenflÃ¤che fÃ¼r Sitz vorne links			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579457	KL_SIH_LEL_Verteilung_VR_XIX_Klima_03_XIX_E3V_VLAN_Connect	Vom Kunden eingestellte Aufteilung der LÃ¼ftungsleistung auf SitzflÃ¤che und LehnenflÃ¤che fÃ¼r Sitz vorne rechts			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f15e	KL_SIH_Soll_li_XIX_Klima_12_XIX_E3V_VLAN_Connect	Einstellung Sitzheizung Fahrer (0...6)			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1dd	KL_Standklima_Status_03_XIX_Klima_EV_04_XIX_E3V_VLAN_Connect	Standklimatisierung Innenraum			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f1cf	KRH_Soll_re_XIX_Klima_12_XIX_E3V_VLAN_Connect	Ausgabe des Sollwertes fÃ¼r die Kopfraumheizung rechts.			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea78c2	LH_Blinker_HL_akt_XIX_Licht_hinten_01_XIX_E3V_VLAN_Connect	Blinker hinten links			
0199b88b-c540-7457-9d9f-4c3cbac6f204	LH_Nebelschluss_aktiv_XIX_Licht_hinten_01_XIX_E3V_VLAN_Connect	Nebelschlusslicht			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579467	LH_Rueckfahrlicht_aktiv_XIX_Licht_hinten_01_XIX_E3V_VLAN_Connect	Rueckfahrlicht			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1d7	LIM_bCall_Taster_XIX_BCM_Taster_02_XIX_E3V_VLAN_Connect	Statusinformation des Service Call Tasters im Dachmodul			All Data, Dynamic Technical Data Campaigns
0199b88b-b16d-77a2-8b45-d444aa727524	LL_AppliServe1Syste2JavaUDS_ReadDataByIdentMeasuValue_Life_cycle_data_68_0x1AAC	Life_cycle_data_68			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4a0	LL_BatteEnergContrModulUDS_ReadDataByIdentMeasuValue_High_Voltage_Battery_Minimum_Temperature_0x1E0F_1	High_Voltage_Battery_Minimum_Temperature			All Data, Dynamic Technical Data Campaigns
0199b88a-db0b-76ce-b5c4-746cf1c7eceb	LL_BatteEnergContrModulUDS_ReadDataByIdentMeasuValue_Maximum_Cell_Voltage_0x1E33	Maximum_Cell_Voltage			All Data, Dynamic Technical Data Campaigns

0199b88a-7c25-7d2b-96f6-64981efcc4c8	LL_BatteEnergContrModulUDS_ReadDataByIdentMeasuValue_Maximum_Cell_Voltage_0x1E33_1	Maximum_Cell_Voltage			All Data, Dynamic Technical Data Campaigns
0199b88a-db0b-76ce-b5c4-746cf1c7ed0e	LL_BatteEnergContrModulUDS_ReadDataByIdentMeasuValue_Minimum_Cell_Voltage_0x1E34	Minimum_Cell_Voltage			All Data, Dynamic Technical Data Campaigns
019bd9ab-f017-7e58-ab83-0056eae1e580	LL_CentrElectUDS_ReadDataByIdentMeasuValue_Ecc_Non_Correctable_0x1012	Ecc_Non_Correctable			
019c09eb-c61d-7054-a7ab-6f4af2796dcb	LL_CentrElectUDS_ReadDataByIdentMeasuValue_Number_of_unplanned_ECU_resets_coc_0x1023	Number_of_unplanned_ECU_resets_coc			
0199b88b-b16d-77a2-8b45-d444aa72752c	LL_EnginContrModul1UDS_ReadDataByIdentMeasuValue_FAC_TPS_1_SAE_0x11EE	FAC_TPS_1_SAE			All Data, Dynamic Technical Data Campaigns
0199b88a-a399-76f6-9144-d8e4878e2a36	LL_GatewUDS_ReadDataByIdentMeasuValue_Calculated_value_range_display_0x2AB6	Calculated_value_range_display			All Data, Dynamic Technical Data Campaigns
019c7421-8555-722b-8921-aa1c2a4734a0	LL_GatewUDS_ReadDataByIdentMeasuValue_Life_cycle_data_66_0x1AAA	Life_cycle_data_66			

019c7421-8555-722b-8921-aa1c2a473495	LL_HighPerfoCompuPlatfBodySyste1UDS_ReadDataByIdentMeasuValue_Fsm_error_counter_0x1022	Fsm_error_counter			
0199b88b-b16d-77a2-8b45-d444aa72753a	LL_MainUnitPowerChassUDS_ReadDataByIdentMeasuValue_MIL_requester_0xC105	MIL_requester			All Data, Dynamic Technical Data Campaigns
019c7421-8555-722b-8921-aa1c2a47349e	LL_ThermManagUDS_ReadDataByIdentMeasuValue_Wdg_Malive_ASIL_0x1033	Wdg_Malive_ASIL			
0199b88b-b83a-74d1-8d51-ff00e79fef92	LL_TirePressMonit1UDS_ReadDataByIdentMeasuValue_Right rear tire pressure sensor remaining operation time_0x4E97	Right rear tire pressure sensor remaining operation time			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1cba	LS_Helligkeit_FW_XIX_RLS_02_XIX_E3V_VLAN_Connect	Vorfeldhelligkeit			
0199b88a-3c9f-7e8e-9943-76deb3fbbe43	LTM_Beruehrung_XIX_LTMs_01_XIX_E3V_VLAN_Connect	Status fÃ¼r BerÃ¼hrung der Auto-Taste im Lichttastenmodul (LTM)			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c2c	LTM_Nebelschlusslicht_XIX_LTMs_01_XIX_E3V_VLAN_Connect	Status Nebelschlusslicht-Taste			All Data, Dynamic Technical Data Campaigns

0199b88b-ade0-704f-9ab6-916f1b71be55	LVB_Restladezeit_XIX_HVLM_13_XIX_HCP4_CANFD03	Restladezeit des Ladevorgangs bis gewÃ¼nschter Ladezustand erreicht ist.			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579425	LV_Nebelschlusslicht_Anzeige_XIX_Licht_vorne_01_XIX_E3V_VLAN_Connect	Nebelschlusslicht_aktiv			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea786b	MIK_OoP_Meldung_R1_BFS_XIX_MIK_05_XIX_E3V_VLAN_Connect	Signal zur Aktivierung der HMI-Ausgabe bei Erkennung eines Out-of-Position Sitzszenarios fÃ¼r den Beifahrer in der 1. SR			
0199b88b-bd69-7380-9f48-c027e357944e	MRollo_Position_XIX_SAD_01_XIX_E3V_VLAN_Connect	Aktuelle Ãffnungsweite des Dachrollos.			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f189	MTHBFS_M_Taste_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	BetÃ¤tigung M-Taste HBFS			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c6d	OCU_Privacymode_Status_XIX_TM_01_XIX_E3V_VLAN_Connect	Signal zur Ausgabe des Privacymode Status 0 = Init 1 = Privacymode ist nicht aktiv 2 = Privacymode ist aktiv			All Data, Dynamic Technical Data Campaigns

0199b88b-ade0-704f-9ab6-916f1b71be62	OTP_Aussen_Temp_gef_XIX_OTP_01_XIX_HCP4_CANFD01	Gefilterte Aussentemperatur. Es werden hier EinflÃ¼sse durch AbwÃ¤rme ausgefiltert.			All Data, Dynamic Technical Data Campaigns
0199b88b-b16d-77a2-8b45-d444aa72753e	OTP_Aussen_Temp_gef_XIX_OTP_01_XIX_HCP4_CANFD02	Gefilterte Aussentemperatur. Es werden hier EinflÃ¼sse durch AbwÃ¤rme ausgefiltert.			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea78f9	PDC_Tonausgabe_Front_XIX_Parkhilfe_01_XIX_E3V_VLAN_Connect	In AbhÃ¤ngigkeit der SystemaktivitÃ¤ten werden unterschiedliche Tonwarnungen ausgegeben. Kombi spielt entsprechende WAV.-Datei Ã¼ber internen Audiomaster ab. 0 = kein Ton 1 = Intervallton 1 2 = Intervallton 2 3 = Intervallton 3 4 = Intervallton 4 5 = Intervallton 5 6 = Dauerton 7 = Fehlerton 8 = RCTATon 9..15 res			

0199b88b-c540-7457-9d9f-4c3cbac6f0be	PH_Aufschaltursache_XIX_Parkhilfe_04_XIX_E3V_VLAN_Connect	Der Grund fÃ¼r die Aufschaltung der Einparkhilfe wird angegeben, z.B. bei der Aktivierung der Einparkhilfe durch eine andere Funktion, wird diese Funktion als Aktivierungsursache fÃ¼r die Dauer der Aktivierung gemeldet. Das Signal wird den PH_Systemzustand ersetzen, wenn alle Funktionen umgestiegen sind.			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea78ff	PH_Opt_Anzeige_H_ein_XIX_Parkhilfe_01_XIX_E3V_VLAN_Connect	OPS hinten ist im Display aktiv bzw. Anzeigemodule hinten sind eingeschaltet. Funktion nur bei gesicherter RÃ¼ckmeldung vom ASG gegeben.			
019a7124-a083-776f-b8ee-3b8ef6ea78f1	PH_StartStopp_Info_XIX_Parkhilfe_01_XIX_E3V_VLAN_Connect	Stopp-Freigabe und Start-Anforderung an den Start-Stopp-Koordinator			
019a7124-a083-776f-b8ee-3b8ef6ea78de	PH_Ton_Lautstaerke_XIX_Parkhilfe_04_XIX_E3V_VLAN_Connect	WunschlautstÃ¤rke der Tonanforderung beim MIB3 durch die Parkhilfe.			
019add4e-9add-7cac-b101-e8fedadcef65	RS_Schwall_XIX_RLSs_01_XIX_HCP4_LIN01	Schwallereignis			

0199b88b-6db6-7e7d-a158-acde71ef513c	RS_Verglasung_schliessen_XIX_RLS_01_XIX_E3V_VLAN_Connect	Anforderung: Verglasung schliessen			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0dc	SIL_Stufe_LED_re_XIX_BCM_05_XIX_E3V_VLAN_Connect	Statusmeldung SitzlÃ¼ftung rechts			All Data, Dynamic Technical Data Campaigns
0199b88b-6db6-7e7d-a158-acde71ef515a	SLS_Helligkeit_IR_XIX_RLS_01_XIX_E3V_VLAN_Connect	Helligkeitswert des "Smart-Light-Sensor" im Dashboard analog / alternativ zu LS_Helligkeit_IR. Es ist entweder ein RLS_LIN oder ein Smart-LS im FZG verbaut.			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f183	SP_BT_rechts_XIX_Spiegel_01_XIX_E3V_VLAN_Connect	Spiegel BeifahrertÃ¼r nach rechts			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c69	SP_FT_unten_XIX_Spiegel_01_XIX_E3V_VLAN_Connect	Spiegel FahrertÃ¼r nach unten			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1c93	SWA_SDA_Abstand_Spur_L1_XIX_SWA_SDA_01_XIX_E3V_VLAN_Connect	Abstand zum 1. Fahrzeug auf der Linken Spur ausgehend von Ego Spur			
019a61ac-1573-7a44-8b16-0b2939cb1cad	SWA_SDA_Abstand_Spur_L2_XIX_SWA_SDA_01_XIX_E3V_VLAN_Connect	Abstand zum 2. Fahrzeug auf der Linken Spur ausgehend von Ego Fahrzeug.			

019a61ac-1573-7a44-8b16-0b2939cb1cb5	SWA_SDA_Abstand_Spur_R1_XIX_SWA_SDA_01_XIX_E3V_VLAN_Connect	Abstand zum 1. Fahrzeug auf der Rechten Spur ausgehend von Ego Fahrzeug.			
0199b88b-c540-7457-9d9f-4c3cbac6f139	TM_Nur_Hupen_XIX_TM_01_XIX_E3V_VLAN_Connect	Remote Hupen (ohne Blinken) aktiviert			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f14a	TM_Panik_Alarm_XIX_TM_01_XIX_E3V_VLAN_Connect	Remote Hupen und Blinken aktiv			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1e6	TM_Spiegel_Anklappen_XIX_TM_01_XIX_E3V_VLAN_Connect	Anklappen der AuÃenspiegel Ã¼ber Remote MOD Anforderung			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea78be	TPMS_SensTypFrRi_XIX_RDK_11_XIX_E3V_VLAN_Connect	TPM sensor type front right			
019a7124-a083-776f-b8ee-3b8ef6ea78c4	TPMS_Warn1TireFrLe_XIX_RDK_11_XIX_E3V_VLAN_Connect	Stage 1 warning for left front tires			
019a7124-a083-776f-b8ee-3b8ef6ea78c6	TPMS_Warn1TireFrRi_XIX_RDK_11_XIX_E3V_VLAN_Connect	Stage 1 warning for left right tires			
019a7124-a083-776f-b8ee-3b8ef6ea78bc	TPMS_Warn2TireReLe_XIX_RDK_11_XIX_E3V_VLAN_Connect	Stage 2 warning for left rear tires			
019a7124-a083-776f-b8ee-3b8ef6ea78d2	TPMS_Warn4TireFrRi_XIX_RDK_11_XIX_E3V_VLAN_Connect	Stage 4 warning for right front tyres			

019a7124-a083-776f-b8ee-3b8ef6ea78a6	TPMS_Warn4_XIX_RDK_11_XIX_E3V_VLAN_Connect	General Warning Level 4			
019a7124-a083-776f-b8ee-3b8ef6ea78d9	TPMS_WarnAcoCalOk_XIX_RDK_11_XIX_E3V_VLAN_Connect	Acoustic output for correct calibration (only necessary for switch calibration)			
019a7124-a083-776f-b8ee-3b8ef6ea78a9	TPMS_WarnCmftP_XIX_RDK_11_XIX_E3V_VLAN_Connect	Warning when the comfort pressure is active			
019a61ac-1573-7a44-8b16-0b2939cb1cb1	TSK_GRA_FoD_Status_XIX_Motor_54_XIX_E3V_VLAN_Connect	Information, ob die TSK-GRA-Funktion freigeschaltet ist oder nicht.			
0199b88b-b83a-74d1-8d51-ff00e79fefd6	VDSO_AgvYawRateOfsCmp	Formula: IMU_YawRate-VDSO_YawRateOfs=VDSO_YawRateOfsCmp			All Data, Dynamic Technical Data Campaigns
0199b88b-b83a-74d1-8d51-ff00e79fefd3	VDSO_FlgWhlMoveDet_XIX_VDSO_03_XIX_HCP5_CANFD05	Detection of wheelmovement			All Data, Dynamic Technical Data Campaigns
0199b88b-b83a-74d1-8d51-ff00e79fefd2	VDSO_Vx3dGNSS	Longitudinal velocity estimated at the centre of rear axle. including GNSS adaption. Estimation requires 3D IMU.			All Data, Dynamic Technical Data Campaigns

0199b88a-3c9f-7e8e-9943-76deb3fbbf1b	VZE_Akustik_Limitwechsel_Status_XIX_VZE_04_XIX_E3V_VLAN_Connect	Das Signal Ã¼bertrÃ¤gt die Information, ob der Kunde, in den Einstellungen, die akustische Information, bei einem Tempolimitwechsel, ausgewÃ¤hlt hat.			All Data, Dynamic Technical Data Campaigns
0199b88b-b16d-77a2-8b45-d444aa727532	VehicleProtectedEnvironment_D_XIX_OTAMC_D_01_XIX_HCP5_CANFD02	Environment of vehicle in case of Remote Production			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea7881	WBA_Warnblinken_XIX_AWV_02_XIX_E3V_VLAN_Connect	Ansteuerung des Warnblinkers fÃ¼r die Funktion Warnen, Bremsen, Ausweichen			
019abe65-f104-7eb1-a101-d4e8049db7e8	WH_Fahrstufe	Fahrstufenwunsch der SchaltbetÃ¤tigung (berechnet aus Fahreraktion am Bedienelement)			
0199b88b-6db6-7e7d-a158-acde71ef5131	WH_Heckintervall_XIX_SMLS_01_XIX_E3V_VLAN_Connect	Wischerhebel: Stellung Heckintervall			All Data, Dynamic Technical Data Campaigns
0199b88b-6db6-7e7d-a158-acde71ef515b	WH_Tipwischen_lang_XIX_SMLS_01_XIX_E3V_VLAN_Connect	Wischerhebel: Tippwischen lang (dient zur Auswertung fÃ¼r die Unterscheidung Tippwischen oder Serviceposition Wischer)			All Data, Dynamic Technical Data Campaigns

0199b88a-3c9f-7e8e-9943-76deb3fbbeaa	WH_WischerStufe1_XIX_SMLS_01_XIX_E3V_VLAN_Connect	Wischerhebel: Stufe Wischen 1			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9f-7e8e-9943-76deb3fbbee5	WH_WischerStufe2_XIX_SMLS_01_XIX_E3V_VLAN_Connect	Wischerhebel: Stufe Wischen 2			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e35793d3	Wischer_WH_Typ_XIX_Wischer_01_XIX_E3V_VLAN_Connect	Signal beinhaltet Lenkstockschaltertyp fÃ¼r grafische Anzeige im Kombi zur Wischerfunktion			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1c3	Wischer_vorne_Schnell_XIX_Wischer_01_XIX_E3V_VLAN_Connect	Wischer vorne schnell aktiv			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c6a	Wischer_vorne_blockiert_XIX_Wischer_01_XIX_E3V_VLAN_Connect	Blockade Wischer vorne (z.B. durch Schnee)			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1ca4	ZM_Fahrzeugabstellzeit_XIX_ZeitMaster_01_XIX_E3V_VLAN_Connect	Zeit seit letzter Fahrbereitschaft			
019a61ac-1573-7a44-8b16-0b2939cb1cb8	ZM_Standzeit_XIX_ZeitMaster_01_XIX_E3V_VLAN_Connect	Standzeit des Fahrzeugs			
0199b88b-c53f-718d-b010-636bf9b22c6c	ZV_Einzeltuerentriegelung_XIX_ZV_02_XIX_E3V_VLAN_Connect	EinzeltÃ¼rentriegelung ZV			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f0a8	ZV_SAD_auf_XIX_ZV_02_XIX_E3V_VLAN_Connect	KomfortÃ¶ffnen des Schiebeausstelldaches			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9e-7f41-ac22-d009bf607e66	cso_v1_drivingenvironment_time_utc_subscribe	Current UTC time			All Data, Dynamic Technical Data Campaigns
0199b88b-b16d-77a2-8b45-d444aa7274ff	cso_v1_vehicle_body_exterior_lights_highbeam_status_subscribe	indicates if the specified light is on			All Data, Dynamic Technical Data Campaigns
0199b88b-b16d-77a2-8b45-d444aa7274f8	cso_v1_vehicle_body_exterior_lights_lowbeam_status_subscribe	indicates if the specified light is on			All Data, Dynamic Technical Data Campaigns
019a4d13-d54c-7128-b876-41b8062656ee	HVLX_EVSEID	get the charging history for the high voltage battery			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9e-7f41-ac22-d009bf607e5b	viwi_DriverNotification_1.2.0_get_notifications	This resource contains available notifications.			All Data, Dynamic Technical Data Campaigns
0199b88a-a399-76f6-9144-d8e4878e2b22	viwi_DriverNotification_3.0.1_get_notifications	This resource contains all active notifications			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e35793e2	AB_Belegung_VF_XIX_Airbag_01_XIX_E3V_VLAN_Connect	Belegungserkennung vorne Fahrer.			All Data, Dynamic Technical Data Campaigns

0199b88b-bd69-7380-9f48-c027e35793cf	AB_Gurtschloss_BF_XIX_Airbag_02_XIX_E3V_VLAN_Connect	Gurtschlossstatus Beifahrerseite			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e35793af	AB_Gurtschloss_Reihe2_FA_XIX_Airbag_02_XIX_E3V_VLAN_Connect	Gurtschlossstatus 2. Reihe Fahrerseite, Mehrausstattung			All Data, Dynamic Technical Data Campaigns
0199bcdc-2d44-7d5f-9522-f4897daf26f3	ACC_Status_GRA_Modus_XIX_ACC_19_XIX_E3V_VLAN_Connect	Statusinformation zur GRA in Verbindung mit ACC			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea787f	ACC_relev_Nichtverfuegbarkeit_XIX_ACC_18_XIX_E3V_VLAN_Connect	Frontradar-SG erkennt eine temporÃ¤re NichtverfÃ¼gbarkeit, ohne FSP-Eintrag			
019a61ac-1573-7a44-8b16-0b2939cb1c91	AZK_Schluessel_im_Fzg_XIX_AZK_01_XIX_E3V_VLAN_Connect	Signalisierung der Kessy-Meldung "SchlÃ¼ssel im Fahrzeug" vom AZK an ein Anzeigeinstrument (Kombiinstrument, I-ID etc.)			
019a61ac-1573-7a44-8b16-0b2939cb1ca8	AZK_Weiterfahrt_mit_Mobilgeraet_XIX_AZK_01_XIX_E3V_VLAN_Connect	Signalisierung der DKM-Meldung "Weiterfahrt mit MobilgerÃ¤t mÃ¶glich" vom AZK an ein Anzeigeinstrument (Kombiinstrument, I-ID etc.)			

0199b88b-d329-7ca8-a18e-12944e659b1b	BCM1_FStatus_Aussentemp_ungef_XIX_Klima_Sensor_02_MQB_XIX_E3V_VLAN_Connect	Fehlerstatus fÃ¼r Aussentemperatur (Kombianzeige)			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1b5	BCM1_Lenksaeule_aktiv_XIX_BCM_01_XIX_E3V_VLAN_Connect	Lenksaeulenverstellung aktiv			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0a3	BCM1_SRA_aktiv_XIX_Wischer_01_XIX_E3V_VLAN_Connect	Status Scheinwerferreinigungsanlage			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f17d	BCM_FS_Multif_Taster_XIX_BCM_Taster_02_XIX_E3V_VLAN_Connect	Ansteuerungs-Signalisierung der Pneumatik-Funktionen			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be64	BDM_I_Bereich_XIX_BDMs_Ruhe_XIX_HCP5_LIN01				All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4af	BMC_IstTemperaturMin_Sensor_ID_XIX_BMC_HV_08_XIX_HCP5_CANFD01	RTM-Signal: Nummer (ID) des Sensors (innerhalb des Moduls) mit dem aktuell niedrigsten TemperaturmeÃwert			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4bb	BMC_IstZellSpannungMin_Modul_ID_XIX_BMC_HV_08_XIX_HCP5_CANFD01	RTM-Signal: Nummer (ID) des Moduls mit der aktuell niedrigsten Zellspannung			All Data, Dynamic Technical Data Campaigns

0199b88a-7c25-7d2b-96f6-64981efcc49d	BMC_IstZellSpannungMin_Zell_ID_XIX_BMC_HV_08_XIX_HCP5_CANFD01	RTM-Signal: Nummer (ID) der Zelle (innerhalb des Moduls) mit der aktuell niedrigsten Zellspannung			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be5c	BMC_IstZellspannungMax_XIX_BMC_HV_02_XIX_HCP4_CANFD03	Aktuell hÃ¶chste Zellspannung in der Batterie			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4d1	BMC_Spannung_XIX_BMC_HV_01_XIX_HCP5_CANFD01	actual voltage of the battery / Momentanwert: Batteriespannung			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4a8	BMC_Temperatur_hoechste_XIX_BMC_HV_07_XIX_HCP5_CANFD01	aktuell hÃ¶chste Temperatur in der Batterie			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4b4	BMC_Temperatur_niedrigste_XIX_BMC_HV_07_XIX_HCP5_CANFD01	aktuell niedrigsteTemperatur in der Batterie			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea7905	BMS_Batteriediagnose_XIX_BMS_07_XIX_E3V_VLAN_Connect	Anzeige von Textwarnungen			
0199b88a-a399-76f6-9144-d8e4878e2898	BMS_IstTemperatur_hoechste_XIX_BMS_11_XIX_E3V_VLAN_Connect	aktuell hÃ¶chste Temperatur in der Batterie			All Data, Dynamic Technical Data Campaigns

0199b88a-a399-76f6-9144-d8e4878e288b	BMS_IstZellSpannungMax_Zell_ID_XIX_BMS_28_XIX_E3V_VLAN_Connect	RTM-Signal: Nummer (ID) der Zelle (innerhalb des Moduls) mit der aktuell hÃ¶chsten Zellspannung			All Data, Dynamic Technical Data Campaigns
0199b88b-d329-7ca8-a18e-12944e659b14	BMS_KundenWarnung_XIX_BMS_07_XIX_E3V_VLAN_Connect	Kundenwarnung und Ersatzreaktionen aufgrund von Batteriebrandgefahr			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e35793d0	BMS_Ladevorgang_aktiv_XIX_BMS_24_XIX_E3V_VLAN_Connect	Signalisiert aktiven Ladevorgang, LadegerÃ¤t und DC/DC aktiv. Signal bleibt nach Kl.15 ein aktiv, bis ESP_Stillstandsflag gelÃ¶scht. AbhÃ¤ngigkeit zu BMS_Energieinhalt			All Data, Dynamic Technical Data Campaigns

0199b88a-3c9f-7e8e-9943-76deb3fbbe67	BMS_Status_Ventil1_XIX_BMS_25_XIX_E3V_VLAN_Connect	Status Ventil; wassergekÃ¼hltes Batteriesystem. Batteriekreis-Absperrventil. nicht-angesteuert = Batterie im kleinen KÃ¼hlkreislauf, abgetrennt vom restlichen KÃ¼hlsystem angesteuert = Batterie eingeschleift in groÃen KÃ¼hlkreislauf (Niedertemperatur-KÃ¼hlkreis)			All Data, Dynamic Technical Data Campaigns
0199b88a-db0b-76ce-b5c4-746cf1c7ed03	BMS_Verbrauch_XIX_BMS_05_XIX_E3V_VLAN_Connect	ZÃ¤hler: Energieentnahme aus der HV-Batterie			All Data, Dynamic Technical Data Campaigns
0199b88b-6db6-7e7d-a158-acde71ef5163	BM_rechts_XIX_Blinkmodi_02_XIX_E3V_VLAN_Connect	Richtungsblinken rechts			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f106	BT_FH_Oeffnung_XIX_TSG_BT_01_XIX_E3V_VLAN_Connect	Gibt den FensterÃ¶ffnungswert in % an.			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1b9	BT_FH_S_ManTief_XIX_TSG_BT_01_XIX_E3V_VLAN_Connect	FH Schalter manuell tief gedrÃ¼ckt			All Data, Dynamic Technical Data Campaigns

0199b88b-ade0-704f-9ab6-916f1b71be68	CHA_CurProf_XIX_Charisma_20_XIX_HCP4_CANFD03	Ausgabe des aktuell selektierten Charisma Fahrprofils			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be7d	DCA_HMI_com_volkswagenag_assistant_SPEECH_DIALOG_ASR_UseCase_1_0	Assistant			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f13d	DiETa_Mode2_XIX_DiETa_01_XIX_E3V_VLAN_Connect	Status Mode2taste (GTE-Taster im VW380 PHEV)			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579462	DiETa_PAO_OFF_Status_XIX_DiETa_01_XIX_E3V_VLAN_Connect	Istwert fÃ¼r LED "OFF" in Anzeige Passenger Airbag On/Off			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea789c	EA_Innenraumlicht_Anf_XIX_EA_02_XIX_E3V_VLAN_Connect	Anforderung Innenraumbeleuchtung durch den Emergency Assist			
019a1468-1323-785a-b8fa-3f570f743a76	ELM1_UAct	Momentanwert der in der Komponente gemessenen DC-Spannung			
0199b88b-ade0-704f-9ab6-916f1b71be6a	ELM1_WGen	zurÃ¼ckgespeiste elektrische Energie (Überlaufbehaftet)			All Data, Dynamic Technical Data Campaigns
019add4e-9add-7cac-b101-e8fedadcef68	EPS_Warn	Definiert die Warnlampenansteuerung im Kombi			

019a7124-a083-776f-b8ee-3b8ef6ea7890	ESP_Anhaltevorgang_ACC_aktiv_XIX_ESP_21_XIX_E3V_VLAN_Connect	Zeigt an, ob ACC-Anhaltevorgang aktiv			
0199b88b-bd69-7380-9f48-c027e357940c	ESP_FZR_uebersteuern_XIX_ESC_51_Auth_XIX_E3V_VLAN_Connect	Fahrzeug erkennt uebersteuern			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579405	ESP_FZR_untersteuern_XIX_ESC_51_Auth_XIX_E3V_VLAN_Connect	Fahrzeug erkennt untersteuern			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea7880	ESP_HDC_FktLampe_XIX_ESP_24_XIX_E3V_VLAN_Connect	Funktionslampe Bergabfahrassistent. (Sender blinkt mit dem Bit 3,3Hz)			
0199c202-d863-7e93-9c3d-93ff74e0f0d6	ESP_Offroad_Modus_XIX_ESP_52_XIX_E3V_VLAN_Connect	Nur VW526: Bei Offroad-Fahrzeugen kann Ã¼ber einen Schalter ein Offroadmodus gewÃ¤hlt werden, dieser wird hier angezeigt. Bei Offroad Plus- Fahrzeugen wird hier der Offroadmodus indirekt durch das Verteilergetriebe vorgegeben (ALR_Offroad = 1) und eingespiegelt.			All Data, Dynamic Technical Data Campaigns

0199b88a-db0b-76ce-b5c4-746cf1c7ed2e	ESP_v_ref_Fahrtrichtung_XIX_ESC_50_XIX_E3V_VLAN_Connect	Signal stellt die Informationen Ã¼ber die Fahrtrichtung des Fahrzeuges dar. Sie wird als Vorzeichen der Referenzgeschwindigkeit ESP_v_ref interpretiert und basiert auf den Drehrichtungen der RÃ¤der. Detailinformationen zu dem Signal sind dem Lastenheft 'Signalexport - Funktionale Anforderungen an ESP' zu entnehmen - Signal ESP_V_fzg_ref_FR.			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1d6	FFB_Komfortoeffnen_XIX_ZV_02_XIX_E3V_VLAN_Connect	Komfortoeffnen Funk			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c67	FFB_Panik_Taste_XIX_ZV_02_XIX_E3V_VLAN_Connect	Panik Taste Funkschluessel			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f100	FFB_Zu_Taste_XIX_ZV_02_XIX_E3V_VLAN_Connect	Zu-Taste Funkschluessel			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea787b	FLA_Fernlicht_PWM_XIX_FLA_01_XIX_E3V_VLAN_Connect	FLA PWM Vorgabe Fernlicht (20ms Task)			

019a7124-a083-776f-b8ee-3b8ef6ea7865	FS_Status_eTAG_ext_XIX_TSG_FT_02_XIX_E3V_VLAN_Connect	erweitert um den Wert "verfÃ¤hrt"			
0199b88b-bd69-7380-9f48-c027e357945d	FT_FH_S_AutoTief_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	FH Schalter automatisch tief gedrÃ¼ckt			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c55	FT_FH_S_ManHoch_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	FH Schalter manuell hoch gedrÃ¼ckt			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f213	FT_Kisi_Taster_li_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	Linker Kisi Taster betaetigt			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f126	FT_Kisi_Taster_re_02_XIX_TSG_FT_02_XIX_E3V_VLAN_Connect	Der Kindersicherungstaster hinten rechts aktiv.			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c63	FT_Kisi_li_aktiv_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	Aktivierungsstatus der Kindersicherung links			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0b1	FT_TD_Taste_Status_XIX_TSG_FT_02_XIX_E3V_VLAN_Connect	Status Taste fÃ¼r Tankdeckel			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f11f	FT_Unlock_Taster_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	Entriegelungstaster betÃ¤tigt			All Data, Dynamic Technical Data Campaigns

019a61ac-1573-7a44-8b16-0b2939cb1cb9	FoD_DTC_IPA_EPH_XIX_IPA_02_XIX_E3V_VLAN_Connect	Function on Demand DTC for IPA from EPH to Function Master			
0199b88a-db0c-73df-ac62-80cf1ecde52c	GE_Fahrstufe_XIX_Getriebe_11_XIX_E3V_VLAN_Connect	Fahrprogramm des Getriebes Hinweis: Zwischenstellung "0x0" darf nur fÃ¼r Zustandswechsel P/R, R/N, N/D ausgegeben werden, nicht fÃ¼r D/S oder D/Tippgasse wegen Abschaltkriterium GRA/ACC			All Data, Dynamic Technical Data Campaigns
0199bcdc-2d44-7d5f-9522-f4897daf26f4	GRA_Codierung_XIX_GRA_ACC_01_XIX_E3V_VLAN_Connect	Das Signal zeigt an, ob das Sende-SG (SMLS/MFL) auf GRA- oder ACC-Bedienteil codiert ist: 0: kein GRA- oder ACC Bedienteil 1: GRA-Bedienteil 2: ACC-Bedienteil 3: Limiter_Only-Bedienteil			All Data, Dynamic Technical Data Campaigns
0199bcdc-2d44-7d5f-9522-f4897daf26f7	GRA_Limiter_XIX_GRA_ACC_01_XIX_E3V_VLAN_Connect	Stellung des Limiter-Tasters			All Data, Dynamic Technical Data Campaigns

0199bcdc-2d44-7d5f-9522-f4897daf26eb	GRA_PIT_Limiter_XIX_GRA_ACC_01_XIX_E3V_VLAN_Connect	Stellung der Taste PIT-Speed-Limiter			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e357932d	GRA_Tip_Setzen	Tippschalter Set			All Data, Dynamic Technical Data Campaigns
0199bcdc-2d44-7d5f-9522-f4897daf26f1	GRA_Tip_Stufe_2_XIX_GRA_ACC_01_XIX_E3V_VLAN_Connect	Signal zeigt an, dass der zweistufige GRA/ACC-Hebel (8_Positions_Bedienteil) in der 2. Tip-Stufe betÃ¤tigt wird. Das Signal wird nur gleichzeitig mit dem Signal GRA_Tip_Hoch oder GRA_Tip_Runter gesetzt, wobei die Bits GRA_Tip_Hoch bzw. GRA_Tip_Runter die Richtung der HebelbetÃ¤tigung anzeigen und der Status von GRA_Tip_Stufe_2 kennzeichnet, ob die BetÃ¤tigung in der ersten oder zweiten Tip-Stufe erfolgt. 0 = Tip_Stufe_1 oder keine BetÃ¤tigung 1 = Tip_Stufe_2			All Data, Dynamic Technical Data Campaigns

0199bcdc-2d44-7d5f-9522-f4897daf26ed	GRA_TravelAssist_XIX_GRA_ACC_01_XIX_E3V_VLAN_Connect	Taste fÃ¼r TravelAssist			All Data, Dynamic Technical Data Campaigns
0199bcdc-2d44-7d5f-9522-f4897daf26f0	GRA_Typ_Hauptschalter_XIX_GRA_ACC_01_XIX_E3V_VLAN_Connect	Variante des GRA/ACC-Hauptschalters: 0: gerasteter Hauptschalter (bzw. Taster mit Speicherung des Status im SMLS (PAG)) 1: getasteter Hauptschalter, keine Speicherung des Status im SMLS			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c52	HBFS_FH_Bew_tief_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	HBFS Fenster bewegt sich in Richtung tief			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f19c	HBFS_FH_S_HFS_AutoHoch_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	Automatisches Hochfahren der Seitenscheibe HFS			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c54	HBFS_FH_S_ManHoch_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	Betaetigung FH Schalter man hoch			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1cc	HBFS_Lock_Taster_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	Betaetigung Lock-Taster			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f176	HBFS_Tuer_Status_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	TÃ¼rstatus mit Fehler und Initwert			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f149	HBFS_Tuer_geoeffnet_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	HBFS Tuer geoeffnet			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0e8	HFS_FH_Bew_hoch_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	HFS Fenster bewegt sich in Richtung hoch			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579454	HFS_FH_S_HBFS_ManHoch_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	Manuelles Hochfahren der Seitenscheibe HBFS			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f194	HFS_TAG_betaetigt_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	Betaetigung TÃ¼raussengriff			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0d8	HMI_WLC1_Systemzustand_intern_XIX_MainUnit_01_XIX_E3V_VLAN_Connect	Ãbertragung der HMI Einstellung fÃ¼r den WLC1 Systemzustand			All Data, Dynamic Technical Data Campaigns
019a1468-1323-785a-b8fa-3f570f743a75	HVK_ETM_Freigabe_XIX_HVK_03_XIX_HCP5_CANFD01	HV-Freigabe fÃ¼r den Antrieb (ETM - Elektr.TraktionsManager)			
0199b88a-7c25-7d2b-96f6-64981efcc4b0	HVLE_OBG_DC_IstStrom_XIX_OBG_01_XIX_HCP5_CANFD01	aktueller Iststrom des OCC			All Data, Dynamic Technical Data Campaigns

0199b88b-ade0-704f-9ab6-916f1b71be4a	HVLM_Ladeszenario_XIX_HVLM_14_XIX_HCP4_CANFD03	Ãber dieses Signal wird das einzustellende Szenario fÃ¼r die Visualisierung gesendet.			All Data, Dynamic Technical Data Campaigns
0199b88b-b16d-77a2-8b45-d444aa727513	HVLM_Max_Strom_Netz_L1_XIX_HVLM_13_XIX_HCP5_CANFD01	Gibt den maximal zulÃ¤ssigen Aufnahmestrom aus der Infrastruktur auf L1 an.			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea78e8	HVLM_Steckerstatus_A_XIX_HVLM_14_XIX_E3V_VLAN_Connect	Gibt den Steckerstatus aus der Ladedose A an			
0199c202-d863-7e93-9c3d-93ff74e0f0ca	HVLS_LadeklappePosition_Lk2_XIX_HVLS_Ladedose_SG2_XIX_E3V_VLAN_Connect	Gibt die aktuelle, Ã¼ber den Endlagenschalter bestimmte, Position der Ladeklappe 2 an.			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f193	HVLS_LdTaster_Anf_LK1_XIX_HVLS_Ladedose_SG1_XIX_E3V_VLAN_Connect	Gibt an ob der Taster an der Ladedose bei Ladeklappe 1 gedrÃ¼ckt wurde			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f0e2	HVLS_PP_Status_B_XIX_HVLS_Ladedose_SG2_XIX_E3V_VLAN_Connect	Status Plug Present B			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f119	HVLS_Steckerstatus_SG1_XIX_HVLS_Ladedose_SG1_XIX_E3V_VLAN_Connect	Stellt den Status eines Ladesteckers am SteuergerÃ¤t hinsichtlich PrÃ¤senz zur VerfÃ¼gung			All Data, Dynamic Technical Data Campaigns
0199b88b-b16d-77a2-8b45-d444aa727510	HVLS_Temp_AC_B_XIX_HVLS_Ladedose_SG2_XIX_HCP5_CANFD01	aktuelle Temperatur der AC-Ladedose an B			All Data, Dynamic Technical Data Campaigns

019a7124-a083-776f-b8ee-3b8ef6ea78fa	HVLX_Isond_LadeartAC3PCorePlc_XIX_ISOND_01_XIX_E3V_VLAN_Connect	Gibt an, ob die PLC-Ladesaeule das einphasige AC-Laden nach IEC 62196 unterstuetzt			
019a7124-a083-776f-b8ee-3b8ef6ea78e9	HVLX_Isond_LadeartDCUniquePlc_XIX_ISOND_01_XIX_E3V_VLAN_Connect	Gibt an, ob die PLC-Ladesaeule das DC-Laden ueber einen spezifischen Ladestecker unterstuetzt			
019a7124-a083-776f-b8ee-3b8ef6ea7904	HVLX_Isond_ResponseCodeLsPlc_XIX_ISOND_01_XIX_E3V_VLAN_Connect	Gibt den Rueckmeldestatus der Ladesaeule an			
019a7124-a083-776f-b8ee-3b8ef6ea78f0	HVLX_Isond_ZahlererfassungAnfHlc_XIX_ISOND_01_XIX_E3V_VLAN_Connect	Information ob die Ladesaeule nach ISO15118 eine Zaehlererfassung zur Abrechnung anfordert (nur fuer PnC)			
0199b88b-c540-7457-9d9f-4c3cbac6f0e9	IPA_TPA_Remote_Anf_XIX_Parken_01_XIX_E3V_VLAN_Connect	Anforderung fÃ¼r bzw. bei fernbedienten Parkvorgang			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f122	ISP_EC_Lichtwert_hinten_XIX_FLA_01_XIX_E3V_VLAN_Connect	Innenspiegel: Lichtwert hinten			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9f-7e8e-9943-76deb3fbbeb1	KBI_Aussen_Temp_gef_XIX_Temperaturen_01_XIX_E3V_VLAN_Connect				All Data, Dynamic Technical Data Campaigns

0199c202-d863-7e93-9c3d-93ff74e0f189	KL_AirCleaner_aktiv_XIX_Klima_11_XIX_E3V_VLAN_Connect	Status des Zustands der AirCare Funktion (Umluft) im Fahrzeug			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e35793d1	KL_Ausstattung_Klima_XIX_Klima_11_XIX_E3V_VLAN_Connect	Austtattungsart der Klimabedienung			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea7906	KL_BCmE_Livetip_Freigabe_XIX_Klima_03_XIX_E3V_VLAN_Connect	Status der Klimaanlage. Zeigt an, ob der Livetip "Fenster schlieÃen wegen Ineffizienz Klimaanlage" sinvollerweise angezeigt werden soll			
019a7124-a083-776f-b8ee-3b8ef6ea78df	KL_Geblaese_Fond_Status_XIX_Klima_03_XIX_E3V_VLAN_Connect	Status Geblaese			
0199b88a-db0b-76ce-b5c4-746cf1c7ed28	KL_Geblspng_Soll_XIX_Klima_12_XIX_E3V_VLAN_Connect	Ausgabe des Sollwertes fÃ¼r die Spannung des KlimageblÃ¤semotores vorne.			All Data, Dynamic Technical Data Campaigns
0199b88b-9d26-72d4-9750-0952bf2bdc13	KL_IstLeistung_XIX_Klima_EV_06_XIX_E3V_VLAN_Connect	Gesamt-Ist-Leistung fÃ¼r Komfort- und Thermomanagement			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c6b	KL_LRH_Stufe_XIX_Klima_12_XIX_E3V_VLAN_Connect	Eingestellte Temperaturstufe der Lenkradheizung			All Data, Dynamic Technical Data Campaigns

019a7124-a083-776f-b8ee-3b8ef6ea78fb	KL_Mot_Tk_Soll_re_XIX_Klima_EV_04_XIX_E3V_VLAN_Connect	Stellung Temperaturklappe Soll rechts			
0199b88b-c540-7457-9d9f-4c3cbac6f1d5	KL_SH_Soll_hl_XIX_Klima_03_XIX_E3V_VLAN_Connect	Einstellung Sitzheizung hinten links (0...6)			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1d4	KL_SIH_Soll_re_XIX_Klima_12_XIX_E3V_VLAN_Connect	Einstellung Sitzheizung Beifahrer (0...6)			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1f1	KL_SIL_Soll_li_XIX_Klima_12_XIX_E3V_VLAN_Connect	Einstellung SitzlÃ¼ftung Fahrer (0...6)			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f208	KL_Zustand_XIX_Klima_11_XIX_E3V_VLAN_Connect	Beschreibt den Zustand des Klima-/Heizungsbedienteils. (OFF-Mode Bedienteil) PAG (MLB): Beschreibt den Zustand des Kompressors			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c3f	LH_Parklicht_HL_aktiv_XIX_Licht_hinten_01_XIX_E3V_VLAN_Connect	Parklicht hinten links			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1bb	LIM_S_SAD_Vo_XIX_BCM_Taster_02_XIX_E3V_VLAN_Connect	Schalterfeld LIM fÃ¼r SAD vorne			All Data, Dynamic Technical Data Campaigns

0199b88b-bd69-7380-9f48-c027e3579460	LINDa_Touch_Event_XIX_BCM_Taster_02_XIX_E3V_VLAN_Connect	Touch_Events fÃ¼r Informationen einer FunktionsauslÃ¶sung auf dem LINDa, welches dann fÃ¼r bspw. ein akustisches Signal zentral umgesetzt werden kÃ¶nnen.			All Data, Dynamic Technical Data Campaigns
0199b88a-db0b-76ce-b5c4-746cf1c7ecc0	LL_AirCondiUDS_ReadDataByIdentMeasuValue_Humidity_Sensor_Outside_0x27C3	Humidity_Sensor_Outside			All Data, Dynamic Technical Data Campaigns
0199b88b-b16d-77a2-8b45-d444aa727526	LL_AppliServe1Syste2JavaUDS_ReadDataByIdentMeasuValue_Life_cycle_data_66_0x1AAA	Life_cycle_data_66			All Data, Dynamic Technical Data Campaigns
0199b88a-db0b-76ce-b5c4-746cf1c7ed0d	LL_BatteEnergContrModulUDS_ReadDataByIdentMeasuValue_High_Voltage_Battery_Maximum_Temperature_0x1E0E	High_Voltage_Battery_Maximum_Temperature			All Data, Dynamic Technical Data Campaigns
0199b88a-db0b-76ce-b5c4-746cf1c7ed19	LL_BatteEnergContrModulUDS_ReadDataByIdentMeasuValue_High_Voltage_Battery_Minimum_Temperature_0x1E0F	High_Voltage_Battery_Minimum_Temperature			All Data, Dynamic Technical Data Campaigns
0199b88b-b480-74b1-ba03-0e84b0e34a9f	LL_BatteEnergContrModulUDS_ReadDataByIdentMeasuValue_Maximum_Cell_Voltage_0x1E33_2	Maximum_Cell_Voltage			All Data, Dynamic Technical Data Campaigns

019c09eb-c61d-7054-a7ab-6f4af2796dc8	LL_CentrElectUDS_ReadDataByIdentMeasuValue_Fsm_error_counter_coc_0x1025	Fsm_error_counter_coc			
019c7421-8555-722b-8921-aa1c2a47349d	LL_CentrElectUDS_ReadDataByIdentMeasuValue_Fsm_startup_supervision_0x1047	Fsm_startup_supervision			
019bd9ab-f017-7e58-ab83-0056eae1e582	LL_CentrElectUDS_ReadDataByIdentMeasuValue_History_memory_reset_counter_0x1021	History_memory_reset_counter			
019cc16f-2ac4-738e-9c9d-c54d9a6722be	LL_CentrElectUDS_ReadDataByIdentMeasuValue_Virtual_remote_control_key_status_0xEF91	Virtual_remote_control_key_status			
0199b88b-b16d-77a2-8b45-d444aa727538	LL_DashBoardUDS_ReadDataByIdentMeasuValue_Driver_messages_history_buffer_0x22FD	Driver_messages_history_buffer			All Data, Dynamic Technical Data Campaigns
0199b88a-a399-76f6-9144-d8e4878e2916	LL_GatewUDS_ReadDataByIdentMeasuValue_Virtual_remote_control_key_status_0xEF91	Virtual_remote_control_key_status			All Data, Dynamic Technical Data Campaigns
0199b88b-b16d-77a2-8b45-d444aa72753b	LL_MainUnitPowerChassUDS_ReadDataByIdentMeasuValue_MIL_requester_list_0xC106	MIL_requester_list			All Data, Dynamic Technical Data Campaigns
0199b88b-6db6-7e7d-a158-acde71ef5126	LS_Licht_ein_XIX_RLS_02_XIX_E3V_VLAN_Connect	Anfoderung Fahrlicht			All Data, Dynamic Technical Data Campaigns

0199b88b-6db6-7e7d-a158-acde71ef5139	LS_TFL_mit_SL_ein_XIX_RLS_02_XIX_E3V_VLAN_Connect	Anforderung Tagfahrlich mit Schlusslicht			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1c98	LS_Verbau_XIX_RLS_01_XIX_E3V_VLAN_Connect	Verbauinfo Lichtsensor			
0199b88b-c540-7457-9d9f-4c3cbac6f1c1	LTM_Autolicht_XIX_LTMs_01_XIX_E3V_VLAN_Connect	Status Autolicht-Taste			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e357944f	LTM_Nebellicht_XIX_LTMs_01_XIX_E3V_VLAN_Connect	Status Nebellicht-Taste			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e35793f8	LTM_Variante_XIX_LTMs_01_XIX_E3V_VLAN_Connect	LTM_Variante dient zur Unterscheidung, welche Variante des Lichttastenmoduls verbaut ist: 0x00 1-Tasten-Bedienung (LTM mit 1-Hauptlichttaste) 0x01 3-Tasten-Bedienung (LTM mit 3-Hauptlichttasten) 0x02 Variante 3 0x03 Variante 4			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f16e	LV_Abblendlicht_Anzeige_XIX_Licht_vorne_01_XIX_E3V_VLAN_Connect	Abblendlicht aktiv			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f104	LV_FLA_aktiv_Anzeige_XIX_Licht_vorne_01_XIX_E3V_VLAN_Connect	Ansteuerung FLA-Lampe im Kombi (BCM1 Bedienmaster)			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c59	LV_Nebellicht_Anzeige_XIX_Licht_vorne_01_XIX_E3V_VLAN_Connect	Nebellicht_aktiv			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f214	LiSi_Defrost_Taste_XIX_LTMs_01_XIX_E3V_VLAN_Connect	Defrost AN/AUS und Status			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0ed	LiSi_FSH_Taste_XIX_LTMs_01_XIX_E3V_VLAN_Connect	Frontscheibenheizung AN/AUS und Status			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1b7	MD1_Position_XIX_SAD_01_XIX_E3V_VLAN_Connect	Aktuelle Ãffnungsweite Schiebedach.			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea7860	MIK_Gurtverlauf_R1_BFS_XIX_MIK_05_XIX_E3V_VLAN_Connect	Ergebnis der Gurt-Misuse-Erkennung in der MIK			
019a7124-a083-776f-b8ee-3b8ef6ea7867	MIK_Insassenklasse_R1_BFS_XIX_MIK_05_XIX_E3V_VLAN_Connect	Insassenklasse der Person in Reihe 1, Beifahrerseite			
019a7124-a083-776f-b8ee-3b8ef6ea7870	MIK_Insassenklasse_R1_FS_XIX_MIK_05_XIX_E3V_VLAN_Connect	Insassenklasse der Person in Reihe 1, Fahrerseite			
019a7124-a083-776f-b8ee-3b8ef6ea7866	MIK_Insassenpos_R1_FS_XIX_MIK_05_XIX_E3V_VLAN_Connect	Position des Insassen in Reihe 1 Fahrerseite			

019a7124-a083-776f-b8ee-3b8ef6ea786a	MIK_Insassenschutz_Status_GVW_FS_XIX_MIK_05_XIX_E3V_VLAN_Connect	Status der MIK Gurtverlaufserkennung der Funktion "Gurtverlaufswarnung" fÃ¼r den Fahrersitz			
0199c203-06af-76b5-a928-09387ebdcbf2	MMI_SDS_aktiv_XIX_MainUnit_01_XIX_E3V_VLAN_Connect	Signal wird gesetzt, solange die Sprachbedienung aktiv ist.			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c62	MTHFS_Pos1_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	BetÃ¤tigung Postionstaste 1 HFS			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f10a	MTHFS_Pos2_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	BetÃ¤tigung Postionstaste 2 HFS			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e35793ea	MU_Update_Time_XIX_MainUnit_01_XIX_E3V_VLAN_Connect	ErmÃ¶glicht auslesen der Historiendaten, wann ein Update lief			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea78f3	PH_Visualisierung_XIX_Parkhilfe_01_XIX_E3V_VLAN_Connect	Signal zeigt den PartnersteuergerÃ¤ten RearView/TopView/ARA/... den aktuellen Status der Visualisierung des OPS. Die PartnersteuergerÃ¤te kÃ¶nnen dadurch auch ihre Aufschaltung an dieses Signal koppeln.			

019abe65-f104-7eb1-a101-d4e8049db7e7	PaCo_VideoDisplayRequest	Signal is used to trigger instantanous display of Video of VideoParkingSystem in HeadUnit. Signal enums transmit resolution and coding of the video which is transmitted by the VideoParkingSystem.			
0199b88a-db0b-76ce-b5c4-746cf1c7ed30	Parken_aktives_System_02_XIX_IPA_02_XIX_E3V_VLAN_Connect	zeigt an welches parkendes System aktiv ist			All Data, Dynamic Technical Data Campaigns
0199b88b-6db6-7e7d-a158-acde71ef5156	RS_Regenmenge_XIX_RLS_02_XIX_E3V_VLAN_Connect	Regenmenge			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1caa	RS_Schwall_XIX_RLS_02_XIX_E3V_VLAN_Connect	Schwallereignis			
0199b88b-6db6-7e7d-a158-acde71ef5133	SMLS_PTT_XIX_SMLS_01_XIX_E3V_VLAN_Connect	Betaetigung PTT			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0b8	SP_BT_links_XIX_Spiegel_01_XIX_E3V_VLAN_Connect	Spiegel BeifahrertÃ¼r nach links			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f12d	SP_FT_oben_XIX_Spiegel_01_XIX_E3V_VLAN_Connect	Spiegel FahrertÃ¼r nach oben			All Data, Dynamic Technical Data Campaigns

0199b88b-c53f-718d-b010-636bf9b22c57	SP_FT_rechts_XIX_Spiegel_01_XIX_E3V_VLAN_Connect	Spiegel FahrertÃ¼r nach rechts			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f19d	SP_Hzg_Taster_XIX_Spiegel_01_XIX_E3V_VLAN_Connect	Heizungstaster/schalter aktiv			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579409	SWA_Obj_Kurvenradius_XIX_Heckradar_02_XIX_E3V_VLAN_Connect	Kurvenradius ermittelt aus dem zurÃ¼ckgelegten Streckenverlauf in Metern. Die aktuelle Berechnungsgrundlage fÃ¼r die kurvenbereinigte PositionY der ausgegebenen Objekte.			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c31	TM_Door_Lock_XIX_TM_01_XIX_E3V_VLAN_Connect	Remote Door lock angefordert: ZV zu/verriegeln			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea78b9	TPMS_PDeReLe_XIX_RDK_11_XIX_E3V_VLAN_Connect	Pressure deviation between actual and set pressure rear left, normalized to 20Â°C			
019a7124-a083-776f-b8ee-3b8ef6ea78d5	TPMS_PDeReRi_XIX_RDK_11_XIX_E3V_VLAN_Connect	Pressure deviation between actual and set pressure rear right, normalized to 20Â°C			

019a7124-a083-776f-b8ee-3b8ef6ea78ae	TPMS_SensPReLe_XIX_RDK_11_XIX_E3V_VLAN_Connect	Sensor measured pressure (tire pressure uncompensated) rear left			
019a7124-a083-776f-b8ee-3b8ef6ea78bd	TPMS_TarPTmpDepFrRi_XIX_RDK_11_XIX_E3V_VLAN_Connect	Temperature dependent target pressure front right			
019a7124-a083-776f-b8ee-3b8ef6ea78bf	TPMS_Warn1TireReRi_XIX_RDK_11_XIX_E3V_VLAN_Connect	Stage 1 warning for right front tires			
019a7124-a083-776f-b8ee-3b8ef6ea78b6	TPMS_Warn2TireFrRi_XIX_RDK_11_XIX_E3V_VLAN_Connect	Stage 2 warning for right front tires			
019a7124-a083-776f-b8ee-3b8ef6ea78c7	TPMS_Warn2TireReRi_XIX_RDK_11_XIX_E3V_VLAN_Connect	Stage 2 warning for right rear tires			
019a7124-a083-776f-b8ee-3b8ef6ea78c3	TPMS_Warn3_XIX_RDK_11_XIX_E3V_VLAN_Connect	General Warning Level 3			
019a7124-a083-776f-b8ee-3b8ef6ea78a7	TPMS_Warn4TireFrLe_XIX_RDK_11_XIX_E3V_VLAN_Connect	Stage 4 warning for left front tyres			
019a7124-a083-776f-b8ee-3b8ef6ea78d8	TPMS_Warn4TireReRi_XIX_RDK_11_XIX_E3V_VLAN_Connect	Stage 4 warning for right rear tyres			
019a7124-a083-776f-b8ee-3b8ef6ea78cd	TPMS_WarnTmpFlt_XIX_RDK_11_XIX_E3V_VLAN_Connect	Warning when the TPMS has a temporary fault			
019a7124-a083-776f-b8ee-3b8ef6ea78aa	TPMS_WhlChgDetReRi_XIX_RDK_11_XIX_E3V_VLAN_Connect	Wheel change rear right detected			

0199b88b-c540-7457-9d9f-4c3cbac6f1a8	TSG_FS_Spiegel_angeklappt_XIX_TSG_FT_02_XIX_E3V_VLAN_Connect	FunktionsrÃ¼ckmeldung TSG_FS Ã¼ber Spiegelstellung angeklappt			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1c90	TSK_ACC_FoD_Status_XIX_Motor_54_XIX_E3V_VLAN_Connect	Information, ob die TSK-ACC-Funktion freigeschaltet ist oder nicht.			
019a7124-a083-776f-b8ee-3b8ef6ea78a3	TSK_Ueberstimmt_vMax_FahrerInfo_XIX_Motor_41_XIX_E3V_VLAN_Connect	Information ueber den Zustand wann die vMax-Limitierung vom Fahrer ueberstimmt wird.			
019a7124-a083-776f-b8ee-3b8ef6ea7885	TSK_Wunschgeschw_XIX_Motor_53_XIX_E3V_VLAN_Connect	Zur Anzeige der Wunschgeschwindigkeit von GRA/Speedlimiter im Kombiinstrument			
0199b88b-c540-7457-9d9f-4c3cbac6f161	Tuerkontakt_Innenlicht_Taste_XIX_BCM_Taster_02_XIX_E3V_VLAN_Connect	Taste zum Ändern des TÃ¼rkontakt-Lichtfunktionszustandes.			All Data, Dynamic Technical Data Campaigns
0199b88b-b83a-74d1-8d51-ff00e79fefd0	VDSO_AgReWhlStgAxl	Steering angle of rear axle.			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be4b	VDSO_DKmtg_XIX_VDSO_09_XIX_HCP4_CANFD01	Vehicle lifetime traveled distance			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9f-7e8e-9943-76deb3fbbef7	VZE_Akustik_Limitwechsel_XIX_VZE_04_XIX_E3V_VLAN_Connect	Anforderung eines Signaltons bei Tempolimitwechsel.			All Data, Dynamic Technical Data Campaigns

0199b88a-3c9f-7e8e-9943-76deb3fbbf0b	VZE_FoD_Status_XIX_VZE_04_XIX_E3V_VLAN_Connect	Status der VZE fÃ¼r FoD			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e357942c	Waschen_vorne_aktiv_XIX_Wischer_01_XIX_E3V_VLAN_Connect	Status: Waschen vorne aktiv			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f114	Wischer_vorne_Normal_XIX_Wischer_01_XIX_E3V_VLAN_Connect	Wischer Front normal aktiv			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c5d	Wischer_vorne_aktiv_XIX_Wischer_01_XIX_E3V_VLAN_Connect	Status: Wischer vorne			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1de	ZR_AppConnect_Zustand_XIX_MainUnit_01_XIX_E3V_VLAN_Connect	Ist Zustand des AppConnect Kontextes im MIB			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f19e	ZV_HD_offen_XIX_ZV_02_XIX_E3V_VLAN_Connect	Status Heckdeckel			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579424	ZV_Rollo_auf_XIX_ZV_02_XIX_E3V_VLAN_Connect	KomfortÃ¶ffnen des Dachrollos			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c68	ZV_Rollo_zu_XIX_ZV_02_XIX_E3V_VLAN_Connect	KomfortschlieÃen des Dachrollos			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f0ec	ZV_SAD_zu_XIX_ZV_02_XIX_E3V_VLAN_Connect	KomfortschlieÃen des Schiebeausstelldaches			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e357939b	ZV_Tankklappe_offen_XIX_ZV_02_XIX_E3V_VLAN_Connect	Ãffnungsstatus der Tankklappe			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1c8f	ZV_ist_Zustand_verfuegbar_XIX_ZV_02_XIX_E3V_VLAN_Connect	VerfÃ¼gbarkeit IST-Zustand ZV			
0199b88b-b83a-74d1-8d51-ff00e79fefdb	cso_v1_drivingenvironment_roadattributes_streetClass_subscribe	Streetclass vehicle is currently on. Please note: Usage of this topic might lead to license and liability restrictions			All Data, Dynamic Technical Data Campaigns
019a0a1c-b5db-7370-9f21-af0f98ba8af9	HVLX_EVSEID	get the charging history for the high voltage battery			All Data, Dynamic Technical Data Campaigns
019a4d13-d54c-7128-b876-41b8062656f0	ELF_SessionId	get the charging history for the high voltage battery			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be6c	cso_v1_vehicle_highvoltage_charging_chargingoptions_targetSoc_subscribe	Get the maximum charge level			All Data, Dynamic Technical Data Campaigns
0199b88a-db0b-76ce-b5c4-746cf1c7ed23	eTM_Temperatur_1_XIX_eTM_01_XIX_E3V_VLAN_Connect	Wassertemperatur 1 KÃ¼hlkreis HV Komponenten			All Data, Dynamic Technical Data Campaigns

0199b88b-b83a-74d1-8d51-ff00e79fef99	AAG_Anhaenger_erkannt	Erkennung Anhaenger			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e35793fb	AB_Gurtschloss_Reihe2_BF_XIX_Airbag_02_XIX_E3V_VLAN_Connect	Gurtschlossstatus 2. Reihe Beifahrerseite, Mehrausstattung			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea7897	ACC_Anfahren_XIX_ACC_18_XIX_E3V_VLAN_Connect	Anforderung Anfahren			
019a61ac-1573-7a44-8b16-0b2939cb1ca7	ACC_FoD_Status_XIX_ACC_19_XIX_E3V_VLAN_Connect	Informiert den TSK und Kombi, ob die ACC-Funktion freigeschaltet ist oder nicht.			
019a7124-a083-776f-b8ee-3b8ef6ea7891	ACC_Optischer_Fahrerhinweis_XIX_ACC_19_XIX_E3V_VLAN_Connect	FahrerÃ¼bernahmeaufforderung; z.B. bei Erreichen der Systemgrenzen oder beim Auftreten von Fehlern in kritischen Situationen (VW).			
019a7124-a083-776f-b8ee-3b8ef6ea7884	ACC_Status_Stauende_XIX_ACC_19_XIX_E3V_VLAN_Connect	Information, ob ACC auf ein Stauende auf Basis von Car2X reagiert.			
019a7124-a083-776f-b8ee-3b8ef6ea789b	ACC_Tempolimitassistent_Ein_XIX_ACC_18_XIX_E3V_VLAN_Connect	Status ACC-Tempolimitassistent			
0199b88b-bd69-7380-9f48-c027e357938c	ACC_Zeitluecke_Abstandswarner_XIX_ACC_19_XIX_E3V_VLAN_Connect	Anzeige der aktuellen Zeitluecke zum vorausfahrenden Fahrzeug			All Data, Dynamic Technical Data Campaigns

0199b88b-bd69-7380-9f48-c027e3579381	ASTA_Stuetzlast_XIX_ASTA_Sensor_01_XIX_E3V_VLAN_Connect	Anzeigewert der Stuetzlast			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea78a2	AWV_AW_Zeitluecke_XIX_AWV_02_XIX_E3V_VLAN_Connect	Anzeige der aktuellen Zeitluecke zum vorausfahrenden Fahrzeug (AW == Abstandswarner)			
019a61ac-1573-7a44-8b16-0b2939cb1cab	AZK_Kessy_defekt_XIX_AZK_01_XIX_E3V_VLAN_Connect	Signalisierung der Kessy-Meldung "Kessy defekt" vom AZK an ein Anzeigeinstrument (Kombiinstrument, I-ID etc.)			
019a61ac-1573-7a44-8b16-0b2939cb1caf	AZK_Weiterfahrt_mit_Schluessel_XIX_AZK_01_XIX_E3V_VLAN_Connect	Signalisierung der Kessy-Meldung "Weiterfahrt mit SchlÃ¼ssel mÃ¶glich" vom AZK an ein Anzeigeinstrument (Kombiinstrument, I-ID etc.)			
0199b88b-bd69-7380-9f48-c027e35793a2	BCM1_MH_Schalter_XIX_BCM_01_XIX_E3V_VLAN_Connect	Motorhaubenkontakt			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f16c	BCM_BFS_Multif_Taster_XIX_BCM_Taster_02_XIX_E3V_VLAN_Connect	Ansteuerungs-Signalisierung der Pneumatik-Funktionen			All Data, Dynamic Technical Data Campaigns

0199b88a-3c9e-7f41-ac22-d009bf607e62	BCM_Bremsbelag_Sensor_XIX_BCM_01_XIX_E3V_VLAN_Connect	Sensorsignal der Stromschleife fÃ¼r BremsbelagverschleiÃ aktuell, entstÃ¶rt, unbewertet			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f206	BCM_Eco_Charisma_Taste_XIX_BCM_01_XIX_E3V_VLAN_Connect	BetÃ¤tigung Taster ECO alias BlueKey oder Charisma			All Data, Dynamic Technical Data Campaigns
0199b88b-b83a-74d1-8d51-ff00e79fef90	BCS_BrkFldWarn_XIX_ESC_03_XIX_HCP1_FlexRay_A	Warning Brake System: Warning that actual brake fluid level is too low. Signal-usage is only allowed for telltale			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9f-7e8e-9943-76deb3fbbe9d	BH_Lichthupe_XIX_SMLS_01_XIX_E3V_VLAN_Connect	Betaetigung Lichthupe			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be45	BMC_IWU_Wert_pos_XIX_BMC_HV_02_XIX_HCP4_CANFD03	Aktueller Isolationswert zwischen HV plus und Fahrzeug			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc49a	BMC_IstTemperaturMax_Sensor_ID_XIX_BMC_HV_08_XIX_HCP5_CANFD01	RTM-Signal: Nummer (ID) des Sensors (innerhalb des Moduls) mit dem aktuell hÃ¶chsten TemperaturmeÃwert			All Data, Dynamic Technical Data Campaigns

0199b88a-7c25-7d2b-96f6-64981efcc49c	BMC_IstZellSpannungMax_Modul_ID_XIX_BMC_HV_08_XIX_HCP5_CANFD01	RTM-Signal: Nummer (ID) des Moduls mit der aktuell hÃ¶chsten Zellspannung			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be70	BMC_RuecklaufTemperatur_XIX_BMC_HV_03_XIX_HCP5_CANFD01	Aktuelle Ruecklauftemperatur der Batterie			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4a7	BMC_Spannung_ZwischenKreis_2_XIX_BMC_HV_01_XIX_HCP5_CANFD01	Momentanwert: Zweite Zwischenkreisspannung fÃ¼r Batterien mit zwei HV Abgaengen (zwei HV Kreise)			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc49e	BMC_Spannung_ZwischenKreis_XIX_BMC_HV_01_XIX_HCP5_CANFD01	Momentanwert: Zwischenkreisspannung der Batterie.			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4a9	BMC_Temperatur_XIX_BMC_HV_03_XIX_HCP5_CANFD01	battery temperature / Momentanwert: Temperatur der Traktionsbatterie			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be53	BMC_VorlaufTemperatur_XIX_BMC_HV_03_XIX_HCP5_CANFD01	Aktuelle Vorlauftemperatur der Batterie			All Data, Dynamic Technical Data Campaigns
0199b88a-a399-76f6-9144-d8e4878e2889	BMS_DC_Ladeprofil_Wechsel_XIX_BMS_26_XIX_E3V_VLAN_Connect	WechselmÃ¶glichkeit des DC-Ladeprofils der HV-Batterie			All Data, Dynamic Technical Data Campaigns

019a7124-a083-776f-b8ee-3b8ef6ea78e4	BMS_Days_Since_Adequate_Charging_XIX_BMS_45_XIX_E3V_VLAN_Connect	Anzahl der Tage seit des letzten, fÃ¼r die UBE_Indikator-Berechnung adÃ¤quaten Ladehubs (aktuelle Forderung: > 50% SOC)			
0199b88a-a399-76f6-9144-d8e4878e2b17	BMS_IstTemperaturMin_Modul_ID_XIX_BMS_28_XIX_E3V_VLAN_Connect	RTM-Signal: Nummer (ID) des Moduls mit dem aktuell niedrigsten TemperaturmeÃwert			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9f-7e8e-9943-76deb3fbbeb4	BMS_IstTemperaturMin_Sensor_ID_XIX_BMS_28_XIX_E3V_VLAN_Connect	RTM-Signal: Nummer (ID) des Sensors (innerhalb des Moduls) mit dem aktuell niedrigsten TemperaturmeÃwert			All Data, Dynamic Technical Data Campaigns
0199b88a-a399-76f6-9144-d8e4878e2894	BMS_IstZellSpannungMin_Zell_ID_XIX_BMS_28_XIX_E3V_VLAN_Connect	RTM-Signal: Nummer (ID) der Zelle (innerhalb des Moduls) mit der aktuell niedrigsten Zellspannung			All Data, Dynamic Technical Data Campaigns

0199b88a-db0b-76ce-b5c4-746cf1c7ecec	BMS_Kapazitaet_02_XIX_BMS_04_XIX_E3V_VLAN_Connect	Nutzbare KapazitÃ¤t der Batterie, oder alterungsabhÃ¤ngige absolute GesamtkapazitÃ¤t der Batterie. ProjektabhÃ¤ngig kann die KapazitÃ¤t auf das nutzbare SOC-Fenster (zwischen oberer und unterer SOC-Grenze) bezogen sein, wobei sich dieses SOC-Fenster alterungsabhÃ¤ngig Ã¤ndern kann.			All Data, Dynamic Technical Data Campaigns
0199b88a-6c7a-7da6-99f9-2891db59dd29	BMS_MV_IstSpannung_XIX_BMS_MV_01_XIX_HCP5_CANFD02	actual voltage of the battery / Momentanwert: Batteriespannung			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9f-7e8e-9943-76deb3fbbe6d	BMS_RuecklaufTemperatur_XIX_BMS_25_XIX_E3V_VLAN_Connect	Aktueller Messwert der KÃ¼hlmittel-RÃ¼cklauftemperatur am KÃ¼hlmittel-Auslass des Batteriesystems.			All Data, Dynamic Technical Data Campaigns

0199b88a-a399-76f6-9144-d8e4878e2899	BMS_Spannung_XIX_BMS_20_XIX_E3V_VLAN_Connect	Aktuelle Spannung der Batterie. Innerhalb der Batterie an den Zellmodulen gemessen, also _vor_ den SchÃ¼tzen und der Sicherung.			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9f-7e8e-9943-76deb3fbbe70	BMS_Status_Ventil2_XIX_BMS_25_XIX_E3V_VLAN_Connect	Status des zweiten Ventils; wassergekÃ¼hltes Batteriesystem. FÃ¼r Systeme, wo die Batterie ein zweites Ventil ansteuert. Belegung projektabhÃ¤ngig. nicht-angesteuert = groÃer KÃ¼hlkreislauf (Niedertemperatur-KÃ¼hlkreis) abgetrennt vom Batteriesystem oder WÃ¤rmetauscher angesteuert = Batterie oder WÃ¤rmetauscher eingeschleift in groÃen KÃ¼hlkreislauf (Niedertemperatur-KÃ¼hlkreis)			All Data, Dynamic Technical Data Campaigns

0199b88a-3c9f-7e8e-9943-76deb3fbbe65	BMS_Temperatur_XIX_BMS_25_XIX_E3V_VLAN_Connect	battery temperature / Momentanwert: Temperatur der Traktionsbatterie			All Data, Dynamic Technical Data Campaigns
0199b88a-db0b-76ce-b5c4-746cf1c7ed1f	BMS_Verbrauch_Ueberlauf_XIX_BMS_05_XIX_E3V_VLAN_Connect	Verbrauchssignal mindest 1x Ã¼bergelaufen			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c66	BM_Wischblinken_XIX_Blinkmodi_02_XIX_E3V_VLAN_Connect	Blinkermodus Wisch_Blinken			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f14e	BT_FH_Bew_hoch_XIX_TSG_BT_01_XIX_E3V_VLAN_Connect	Fensterheber in Bewegung Richtung hoch			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0da	BT_FH_S_AutoHoch_XIX_TSG_BT_01_XIX_E3V_VLAN_Connect	FH Schalter automatisch hoch gedrÃ¼ckt			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c2e	BT_FH_S_AutoTief_XIX_TSG_BT_01_XIX_E3V_VLAN_Connect	FH Schalter automatisch tief gedrÃ¼ckt			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f210	BT_SP_lr_aktiv_XIX_TSG_BT_01_XIX_E3V_VLAN_Connect	Spiegelverstellung in Richtung links/rechts aktiv			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be7e	DCA_HMI_com_volkswagenag_assistant_SPEECH_DIALOG_UseCase_1_0	Assistant			All Data, Dynamic Technical Data Campaigns

0199b88b-b16d-77a2-8b45-d444aa7274e7	DW_Kilometerstand_XIX_Diagnose_01_XIX_HCP5_CANFD02	Fehler wird ausgegeben, falls Kilometerstand nicht restaurierbar			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e357942f	DiETa_HSH_Taste_XIX_DiETa_01_XIX_E3V_VLAN_Connect	Heckscheibenheizung AN/AUS			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579452	DiETa_Parken_XIX_DiETa_01_XIX_E3V_VLAN_Connect	Status Parkentaste			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579464	DiETa_Warnblink_Taste_XIX_DiETa_01_XIX_E3V_VLAN_Connect	Status Warnblinktaster			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea789a	EA_Blinken_XIX_EA_02_XIX_E3V_VLAN_Connect	Emergency Assist Anforderung Blinker			
019a7124-a083-776f-b8ee-3b8ef6ea7882	EA_Texte_XIX_EA_02_XIX_E3V_VLAN_Connect	Anzeige der EA Texte			
019a7124-a083-776f-b8ee-3b8ef6ea787e	EA_Tueren_Anf_XIX_EA_02_XIX_E3V_VLAN_Connect	Emergency Assist Anforderung TÃ¼ren entriegeln			
019a7124-a083-776f-b8ee-3b8ef6ea7889	EA_Warnlevel_XIX_EA_02_XIX_E3V_VLAN_Connect	KritikalitÃ¤t der Funktion Emergency Assist			
0199b88a-db0c-73df-ac62-80cf1ecde534	EBKV_Bremspedalweg_XIX_EBKV_03_Auth_XIX_E3V_VLAN_Connect	Bremspedalwert in Prozent. Der Wert ist Nullpunkt-abgeglichen. Bremspedalweg von der EBKV eingelesen.			All Data, Dynamic Technical Data Campaigns

019a1468-1323-785a-b8fa-3f570f743a74	ELM1_HVK_EoHVL_Status	Status der Erkennung offener HV-Leitung an der HV-Komponente			
019a1468-1323-785a-b8fa-3f570f743a77	ELM1_Status_Spgfreiheit	Status der HV Spannungsfreiheit der elektrischen Antriebseinheit			
0199b88b-b16d-77a2-8b45-d444aa7274f0	EM1_Strom_HV_XIX_EM1_01_XIX_E3V_VLAN_Connect	Momentanwert: HV DC-Strom des PWR			All Data, Dynamic Technical Data Campaigns
0199b88b-b16d-77a2-8b45-d444aa7274ee	EM2_Strom_HV_XIX_EM2_01_XIX_E3V_VLAN_Connect	Momentanwert: HV DC-Strom des PWR			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea788f	ESP_ASP_XIX_ESP_21_XIX_E3V_VLAN_Connect	MLB: Anhaenger-Stabilisierungs-Programm MQB: Gespannstabilisierung			
0199c202-d863-7e93-9c3d-93ff74e0f112	ESP_Allrad_Antrieb_XIX_ESP_52_XIX_E3V_VLAN_Connect	Im MQB wird das Signal nicht unterstÃ¼tzt!			All Data, Dynamic Technical Data Campaigns

0199b88a-3c9f-7e8e-9943-76deb3fbbecd	ESP_Laengsbeschl_XIX_ESC_50_XIX_E3V_VLAN_Connect	Beschleunigungswert in x-Achse MLB: Im AU64x und AU57x erfolgt die Bereitstellung der Sensorwerte durch SARA-SG! Im AU64x und AU57x wird bei ESP-Abschaltung durch modellgestÃ¼tzte Ãberwachung das Signal weiterhin ausgegeben. MQB: reines ABS schickt 0x3FE fÃ¼r "nicht vorhanden"			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea7887	ESP_PLA_Bremseingriff_XIX_ESP_21_XIX_E3V_VLAN_Connect	Signalisierung des aktiven Bremseingriffes des ESP aufgrund einer Bremsanforderung vom PLA.			
0199b88b-6db6-7e7d-a158-acde71ef514c	FAS_Taster_XIX_SMLS_01_XIX_E3V_VLAN_Connect	Betaetigung FAS Taster			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1cb3	FBS_Warn_Schluessel_Batt_XIX_ZV_02_XIX_E3V_VLAN_Connect	Kombi Prio Warnung Schluessel Batterie "Bitte SchlÃ¼sselbatterie wechseln!"			

0199b88b-c540-7457-9d9f-4c3cbac6f118	FFB_Auf_Taste_XIX_ZV_02_XIX_E3V_VLAN_Connect	Auf-Taste Funkschluessel			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e357940b	FS_Temp_Scheibe_XIX_Klima_Sensor_01_XIX_E3V_VLAN_Connect	gemessene Frontscheibentemperatur			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c4f	FT_FH_Oeffnung_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	Gibt den FensterÃ¶ffnungswert in % an.			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1b4	FT_HD_Taste_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	Taste in der FahrertÃ¼r zum Ãffnen des Heckschlosses			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1f5	FT_Lock_Taster_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	Verriegelungstaster betÃ¤tigt			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f205	FT_SP_Heizung_Status_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	Status der Spiegelheizung			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f185	FT_SP_ht_aktiv_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	Spiegelverstellung in Richtung hoch/tief aktiv			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f16d	FT_SP_lr_aktiv_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	Spiegelverstellung in Richtung links/rechts aktiv			All Data, Dynamic Technical Data Campaigns

019a61ac-1573-7a44-8b16-0b2939cb1cb4	FT_Schluesselschalter_zu_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect				
019a61ac-1573-7a44-8b16-0b2939cb1cb6	FoD_DTC_TSK_GRA_XIX_Motor_54_XIX_E3V_VLAN_Connect	DTC ist entweder bereits eingetragen oder wird eingetragen, sobald die zugehÃ¶rige FoD Funktion freigeschaltet wird.			
019a7124-a083-776f-b8ee-3b8ef6ea7864	Fronthaube_geoeffnet_XIX_SAM_01_XIX_E3V_VLAN_Connect	Information Ã¼ber den Status der Fronthaube			
0199b88a-3c9f-7e8e-9943-76deb3fbbe46	GNSS_Ortung_Hoehe_XIX_GNSS_04_XIX_E3V_VLAN_Connect	HÃ¶he Ã¼ber dem Meeresspiegel			All Data, Dynamic Technical Data Campaigns
0199bcdc-2d44-7d5f-9522-f4897daf26fa	GRA_Hauptschalter_XIX_GRA_ACC_01_XIX_E3V_VLAN_Connect	Stellung des GRA/ACC-Hauptschalters: Bei gerastetem Hauptschalter: 0: Hauptschalter aus 1: Hauptschalter ein Bei getastetem Hauptschalter: 0: Taster nicht betÃ¤tigt 1: Taster betÃ¤tigt			All Data, Dynamic Technical Data Campaigns
0199bcdc-2d44-7d5f-9522-f4897daf26f8	GRA_Tip_Hoch_XIX_GRA_ACC_01_XIX_E3V_VLAN_Connect	Tippschalter Tip Up / Geschwindigkeit erhÃ¶hen			All Data, Dynamic Technical Data Campaigns

0199b88b-b83a-74d1-8d51-ff00e79ff040	GRA_Tip_Wiederaufnahme	Tippschalter Wiederaufnahme			All Data, Dynamic Technical Data Campaigns
0199bcdc-2d44-7d5f-9522-f4897daf26f9	GRA_Typ_Bedienteil_XIX_GRA_ACC_01_XIX_E3V_VLAN_Connect	Das Signal kennzeichnet die Variante des GRA/ACC-Bedienteils: 0: Init 1: 4-Positionen-Bedienteil (z.B. GRA im Blinkerhebel) 2: 6-Positionen-Bedienteil (GRA/ACC-Bedienteil mit separaten Stellungen fÃ¼r Set/Resume/TipUp/TipDown) 3: 8-Positionen-Bedienteil: wie 6-Positionen-Bedienteil, jedoch mit zweistufiger TipUp- und TipDown-Position 4: Porsche 5-Positionen Bedienteil (ohne Setzen-Taste) 5: VW MFL Generation 2 6: VW MFL Generation 3 (zweistufige Geschwindigkeitsverstellung) 7: Porsche DX1.0 Bedienteil (GRA/ACC			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f20b	HBFS_FH_Oeffnung_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	Gibt den FensterÃ¶ffnungswert in % an.			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579463	HBFS_FH_S_HFS_ManHoch_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	Manuelles Hochfahren der Seitenscheibe HFS			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579429	HBFS_FH_S_HFS_ManTief_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	Manuelles Absenken der Seitenscheibe HFS			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579459	HBFS_FH_S_ManTief_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	Betaetigung FH Schalter man tief			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f19b	HBFS_Lock_Taster_inv_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	Lock Taster nicht betÃ¤tigt			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1ed	HBFS_MRollo_Schalter_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	| MRollo2 ---------- 0 | nicht_betaetigt 1 | (m) Zu 2 | (a) Zu 3 | (m) Auf 4 | (a) Auf 5 | Schalter nicht verfuegbar 6 | Init 7 | Fehlerfall			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f0bf	HBFS_SAD_Schalter_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	| Ausstelldach MD3 ---------- 0 | nicht_betaetigt 1 | 2 | 3 | 4 | 5 | (m) Auf 6 | (a) Auf 7 | (m) Zu 8 | (a) Zu 13| Schalter nicht verfuegbar 14| Init 15| Fehlerfall			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f134	HBFS_TIG_betaetigt_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	Betaetigung Tuerinnengriff			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c3d	HBFS_TIG_betaetigt_oeffnen_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	TÃ¼rinnenbetÃ¤tigung, Taster TÃ¼r Ã¶ffnen.			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c91	HBFS_TIG_betaetigt_schliessen_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	TÃ¼rinnenbetÃ¤tigung, Taster TÃ¼r schlieÃen.			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c75	HBFS_Tueroeffnen_Warnung_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	Bit wird gesetzt, wenn TÃ¼r wÃ¤hrend der Fahrt geoeffnet werden soll.			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f195	HFS_FH_Bew_tief_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	HFS Fenster bewegt sich in Richtung tief			All Data, Dynamic Technical Data Campaigns
0199b88b-6db6-7e7d-a158-acde71ef5152	HFS_FH_Oeffnung_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	Gibt den FensterÃ¶ffnungswert in % an.			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c2f	HFS_FH_S_AutoTief_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	Betaetigung FH Schalter auto tief			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f18a	HFS_FH_S_HBFS_AutoTief_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	Automatisches Absenken der Seitenscheibe HBFS			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579436	HFS_FH_S_ManHoch_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	Betaetigung FH Schalter man hoch			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1b0	HFS_Lock_Taster_inv_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	Lock Taster nicht betÃ¤tigt			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f13c	HFS_MRollo_Schalter_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	| MRollo2 ---------- 0 | nicht_betaetigt 1 | (m) Zu 2 | (a) Zu 3 | (m) Auf 4 | (a) Auf 5 | Schalter nicht verfuegbar 6 | Init 7 | Fehlerfall			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1ba	HFS_verriegelt_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	HFS Tuer verriegelt			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579447	HMI_WLC2_Systemzustand_intern_XIX_MainUnit_01_XIX_E3V_VLAN_Connect	Ãbertragung der HMI Einstellung fÃ¼r den WLC2 Systemzustand			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4b5	HVLE_Temperatur_XIX_IPB_03_XIX_HCP5_CANFD01	Isttemperatur SAC			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be46	HVLM_Aktive_Ladeart_XIX_HVLM_14_XIX_HCP4_CANFD03	informs about the used charging infrastructure - AC - DC - AWC.			All Data, Dynamic Technical Data Campaigns
0199b88b-b16d-77a2-8b45-d444aa72751d	HVLM_Max_Strom_Netz_L3_XIX_HVLM_13_XIX_HCP5_CANFD01	Gibt den maximal zulÃ¤ssigen Aufnahmestrom aus der Infrastruktur auf L3 an.			All Data, Dynamic Technical Data Campaigns

019a7124-a083-776f-b8ee-3b8ef6ea78e6	HVLM_RestladezeitFzgPlc_XIX_HVLM_PLC_01_XIX_E3V_VLAN_Connect	Verbleibende Zeit bis 100% Anzeige SOC erreicht sind / RemainingTimeToFullSoC (DIN70121 RC_2)			
019a7124-a083-776f-b8ee-3b8ef6ea78f4	HVLM_RestladezeitTeilladungPlc_XIX_HVLM_PLC_01_XIX_E3V_VLAN_Connect	Verbleibende Zeit bis der Teil SOC erreicht ist / RemainingTimeToBulkSoC (DIN70121 RC_2)			
0199b88b-b16d-77a2-8b45-d444aa727508	HVLM_SollSOCFzgPlc_XIX_HVLM_PLC_01_XIX_HCP5_CANFD01	Soll SOC des Fzg / TargetSOC			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea78f8	HVLM_Steckerstatus_B_XIX_HVLM_14_XIX_E3V_VLAN_Connect	Gibt den Steckerstatus aus der Ladedose B an			
0199b88b-ade0-704f-9ab6-916f1b71be4f	HVLM_VasAnzeige_ZielSoc_XIX_HVLM_17_XIX_HCP5_CANFD01	Anzeigewert des aktueller Zielladezustand an einer Wallbox, die ValueAddedServices nach VW-Spezifikation unterstÃ¼tzt			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f1db	HVLS_LadeklappePosition_Lk1_XIX_HVLS_Ladedose_SG1_XIX_E3V_VLAN_Connect	Gibt die aktuelle, Ã¼ber den Endlagenschalter bestimmte, Position der Ladeklappe 1 an.			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f139	HVLS_LdTaster_Anf_LK2_XIX_HVLS_Ladedose_SG2_XIX_E3V_VLAN_Connect	Gibt an ob der Taster an der Ladedose bei Ladeklappe 2 gedrÃ¼ckt wurde			All Data, Dynamic Technical Data Campaigns

0199c202-d863-7e93-9c3d-93ff74e0f195	HVLS_LdTaster_Spielschutz_LK1_XIX_HVLS_Ladedose_SG1_XIX_E3V_VLAN_Connect	Gibt an ob der Spielschutz des Tasters an der Ladedose bei der Ladeklappe 1 gedrÃ¼ckt wurde			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f106	HVLS_PP_Status_A_XIX_HVLS_Ladedose_SG1_XIX_E3V_VLAN_Connect	Status Plug Present A			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f1b2	HVLS_SteckerEntriegelungVerbot_C_XIX_HVLS_Ladedose_SG3_XIX_E3V_VLAN_Connect	Verbot zur Ladesteckerentriegelung			All Data, Dynamic Technical Data Campaigns
0199b88b-b16d-77a2-8b45-d444aa727509	HVLS_Temp_DC_plus_XIX_HVLS_Ladedose_SG1_XIX_HCP5_CANFD01	aktuelle Temperatur des Pins DC (+) der Ladedose			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea78f5	HVLX_Isond_EVSEProcessing_Status_XIX_ISOND_01_XIX_E3V_VLAN_Connect	Dieses Signal gibt den aktuellen Status der Ladesaeule			
019a7124-a083-776f-b8ee-3b8ef6ea78fe	HVLX_Isond_LadeartDCCorePlc_XIX_ISOND_01_XIX_E3V_VLAN_Connect	Gibt an, ob die PLC-Ladesaeule das DC-Laden nach IEC 62196 ueber die Core-Pins unterstuetzt			
019a7124-a083-776f-b8ee-3b8ef6ea7901	HVLX_Isond_LsNotification_Plc_XIX_ISOND_01_XIX_E3V_VLAN_Connect	Rueckmeldestatus der Ladesaeule (HLC nach ISO15118-2) zur Aufforderung einer Interaktion seitens des Fahrzeuges			

019a7124-a083-776f-b8ee-3b8ef6ea78db	HVLX_Isond_NormLsPlc_XIX_ISOND_01_XIX_E3V_VLAN_Connect	Gibt an, welcher Protokollstandard (DIN70121/ ISO15118) die Ladesaeule im Application-Layer verwendet			
019a7124-a083-776f-b8ee-3b8ef6ea78fd	HVLX_Isond_PLC_Message_Status_XIX_ISOND_01_XIX_E3V_VLAN_Connect	Dieses Signal meldet den PLC Triggerstatus der Ladesaeule zurueck			
019a7124-a083-776f-b8ee-3b8ef6ea78e0	HVLX_PlcGefundeneLadesaeule_XIX_ISOND_01_XIX_E3V_VLAN_Connect	Anzahl der gefundenen Ladesaeulen mit PLC-Funktion, die im PLC-Modul gespeichert sind			
0199b88b-bd69-7380-9f48-c027e3579403	ISA_Tempolimit_Regelung_XIX_Motor_53_XIX_E3V_VLAN_Connect	Anzeige des expliziten Tempolimits zur Regelgrundanzeige			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1c92	ISP_Taste_betaetigt_XIX_FLA_01_XIX_E3V_VLAN_Connect	ISP Taste betÃ¤tigt (200ms Task)			
0199b88b-c540-7457-9d9f-4c3cbac6f0e0	KBI_aktive_Laengsfunktion_02_XIX_FAS_Anzeigen_01_XIX_E3V_VLAN_Connect	Auswahl, der vom Fahrer gewÃ¼nschten Laengsregelfunktion			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c8c	KL_AC_Schalter_XIX_Klima_11_XIX_E3V_VLAN_Connect	AC Schalter			All Data, Dynamic Technical Data Campaigns

0199b88b-c53f-718d-b010-636bf9b22c5e	KL_Geblaese_Status_XIX_Klima_03_XIX_E3V_VLAN_Connect	Status Geblaese			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579413	KL_Innentemp_KBT_Sensor_XIX_Klima_EV_04_XIX_E3V_VLAN_Connect	Temperatur Innenraum vor Klimabedienteil			All Data, Dynamic Technical Data Campaigns
0199b88a-db0b-76ce-b5c4-746cf1c7ed25	KL_K_Status_XIX_Klima_EV_06_XIX_E3V_VLAN_Connect	Satus der Klimatisierung und WÃ¤rmepumpe wird ausgegeben.			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f162	KL_Standklima_Status_02_XIX_Klima_EV_04_XIX_E3V_VLAN_Connect	Status der Standklimatisierung (Innenraum)			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0f6	KL_Temp_Kundenwunsch_XIX_Klima_EV_06_XIX_E3V_VLAN_Connect	Temeratur, die auf der Fahrerseite der Climatronic vom Kunden vorgegeben wird.			All Data, Dynamic Technical Data Campaigns
019a1992-cd99-7f6b-8acf-1a1955a6f4e5	KL_Umluft_Taste_XIX_Klima_03_XIX_E3V_VLAN_Connect	Betaetigung Umlufttaste			
0199cc4f-0634-7c4d-9601-d022c7a9e196	KL_Umluftklappe_Status_XIX_Klima_12_XIX_E3V_VLAN_Connect	Status Umluftklappe			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c4c	KRH_Soll_li_XIX_Klima_12_XIX_E3V_VLAN_Connect	Ausgabe des Sollwertes fÃ¼r die Kopfraumheizung links.			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f0a2	KRH_Stufe_LED_li_XIX_BCM_05_XIX_E3V_VLAN_Connect	Statusmeldung Kopfraumheizung links			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9f-7e8e-9943-76deb3fbbe37	LDW_Texte_XIX_LDW_02_XIX_E3V_VLAN_Connect	Bei Anzeige eines Fehlertextes im Kombi ertÃ¶nt ein akustisches Signal			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f102	LH_Bremslicht_H_aktiv_XIX_Licht_hinten_01_XIX_E3V_VLAN_Connect	Bremslicht hinten			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f17f	LH_Standlicht_H_aktiv_XIX_Licht_hinten_01_XIX_E3V_VLAN_Connect	Standlicht hinten			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e357943f	LIM_S_Rollo_vo_XIX_BCM_Taster_02_XIX_E3V_VLAN_Connect	Schalterfeld LIM fÃ¼r Sonnenrolle Schiebedach vorne			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4be	LL_BatteEnergContrModulUDS_ReadDataByIdentMeasuValue_High_Voltage_Battery_Maximum_Temperature_0x1E0E_1	High_Voltage_Battery_Maximum_Temperature			All Data, Dynamic Technical Data Campaigns
0199b88b-b480-74b1-ba03-0e84b0e34a9c	LL_BatteEnergContrModulUDS_ReadDataByIdentMeasuValue_High_Voltage_Battery_Minimum_Temperature_0x1E0F_2	High_Voltage_Battery_Minimum_Temperature			All Data, Dynamic Technical Data Campaigns

019c7421-8555-722b-8921-aa1c2a473494	LL_CentrElectUDS_ReadDataByIdentMeasuValue_Anti_Theft_Alarm_System_Cycle_Data_0x8405	Anti_Theft_Alarm_System_Cycle_Data			
019c7421-8555-722b-8921-aa1c2a473496	LL_CentrElectUDS_ReadDataByIdentMeasuValue_Backup_Horn_Alarm_Trigger_Cycle_Data_0x1986	Backup_Horn_Alarm_Trigger_Cycle_Data			
019bd9ab-f017-7e58-ab83-0056eae1e586	LL_CentrElectUDS_ReadDataByIdentMeasuValue_Mpu_Access_Violation_0x1038	Mpu_Access_Violation			
019bb598-a9d2-73fe-b364-c7207e9e1690	LL_EnginContrModul1UDS_ReadDataByIdentMeasuValue_Engine oil level_0x2006	Engine oil level			
019bb598-a9d2-73fe-b364-c7207e9e1694	LL_EnginContrModul1UDS_ReadDataByIdentMeasuValue_Engine_oil_level_actual_value_0x58D1	Engine_oil_level_actual_value			
0199b88a-7c25-7d2b-96f6-64981efcc4da	LL_GatewUDS_ReadDataByIdentMeasuValue_Calculated_value_range_display_0x2AB6_1	Calculated_value_range_display			All Data, Dynamic Technical Data Campaigns
0199b88a-db0b-76ce-b5c4-746cf1c7ecdf	LL_GatewUDS_ReadDataByIdentMeasuValue_Life Cycle Data 5 Generation 2_0x3504	Life Cycle Data 5 Generation 2			All Data, Dynamic Technical Data Campaigns

019c7421-8555-722b-8921-aa1c2a4734a1	LL_GatewUDS_ReadDataByIdentMeasuValue_Life_cycle_data_68_0x1AAC	Life_cycle_data_68			
0199b88a-a399-76f6-9144-d8e4878e29af	LL_GatewUDS_ReadDataByIdentMeasuValue_Low_voltage_battery_0x2AF7	Low_voltage_battery			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4ba	LL_SmartActuaChargInterDevic1UDS_ReadDataByIdentMeasuValue_Charge_plug_state_0x346	Charge_plug_state			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4c4	LL_SmartActuaChargInterDevic1UDS_ReadDataByIdentMeasuValue_HVLS_temperature_0x302	HVLS_temperature			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4c1	LL_SmartActuaChargInterDevic2UDS_ReadDataByIdentMeasuValue_HVLS_temperature_0x302	HVLS_temperature			All Data, Dynamic Technical Data Campaigns
019c7421-8555-722b-8921-aa1c2a47349a	LL_ThermManagUDS_ReadDataByIdentMeasuValue_Core_Wdg_0x1034	Core_Wdg			
019c7421-8555-722b-8921-aa1c2a473499	LL_ThermManagUDS_ReadDataByIdentMeasuValue_Fsm_error_counter_0x1022	Fsm_error_counter			

0199b88b-b83a-74d1-8d51-ff00e79fef97	LL_TirePressMonit1UDS_ReadDataByIdentMeasuValue_Left front tire pressure sensor remaining operation time_0x4E94	Left front tire pressure sensor remaining operation time			All Data, Dynamic Technical Data Campaigns
0199b88b-b83a-74d1-8d51-ff00e79fef94	LL_TirePressMonit1UDS_ReadDataByIdentMeasuValue_Right front tire pressure sensor remaining operation time_0x4E95	Right front tire pressure sensor remaining operation time			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e357944a	LRH_Taster_XIX_BCM_01_XIX_E3V_VLAN_Connect	TasterbetÃ¤tigung Lenkradheizung			All Data, Dynamic Technical Data Campaigns
0199b88b-6db6-7e7d-a158-acde71ef5159	LRH_aktiv_XIX_SMLS_01_XIX_E3V_VLAN_Connect	Signal gibt an, ob ein Heizstrom durch die Lenkradheizung flieÃt. Es dient der Auswertung durch das Energiemanagement.			All Data, Dynamic Technical Data Campaigns

0199b88b-6db6-7e7d-a158-acde71ef5132	LSS_Tastencode_XIX_SMLS_01_XIX_E3V_VLAN_Connect	0x00 = No key pressed / key released 0x01 = Menu 0x02 = Menu Up / Next Screen 0x03 = Menu Down / Previous Screen 0x04 = Up 0x05 = Down 0x06 = Up / Down ThumbWheel 0x07 = OK (ThumbWheel-Button) 0x08 = Cancel / Escape 0x09..0x0F = reserved for further menu controls 0x10 = Volume Up 0x11 = Volume Down 0x12 = Volume Up / Down ThumbWheel 0x13 = Volume-ThumbWheel-Button 0x14 = Audio Source 0x15 = Arrow A Up / Right 0x16 = Arrow A Down / Left 0x17 = Arrow B Up / Right			All Data, Dynamic Technical Data Campaigns
0199b88a-db0b-76ce-b5c4-746cf1c7ed46	LS_Helligkeit_FW_XIX_RLS_01_XIX_E3V_VLAN_Connect	Vorfeldhelligkeit			All Data, Dynamic Technical Data Campaigns

0199b88b-6db6-7e7d-a158-acde71ef512d	LS_Helligkeit_IR_XIX_RLS_01_XIX_E3V_VLAN_Connect	Globalfeldhelligkeit			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1cac	LS_Helligkeit_IR_XIX_RLS_02_XIX_E3V_VLAN_Connect	Globalfeldhelligkeit			
0199b88b-c540-7457-9d9f-4c3cbac6f156	LV_AFL_aktiv_Anzeige_XIX_Licht_vorne_01_XIX_E3V_VLAN_Connect	Anzeige AFL-Funktion			All Data, Dynamic Technical Data Campaigns
0199b88b-6db6-7e7d-a158-acde71ef5165	LV_Blinker_VL_aktiv_XIX_Licht_vorne_01_XIX_E3V_VLAN_Connect	Blinker vorne links			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea7878	LV_FLA_Sensor_blockiert_XIX_Licht_vorne_01_XIX_E3V_VLAN_Connect	Status FLA-Sensor (Anzeige des entsprechenden Fehlertext im Kombi)			
0199b88b-c540-7457-9d9f-4c3cbac6f0e2	LV_Fernlicht_Anzeige_XIX_Licht_vorne_01_XIX_E3V_VLAN_Connect	Fernlicht_aktiv			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f18f	LV_Standlicht_Anzeige_XIX_Licht_vorne_01_XIX_E3V_VLAN_Connect	Anzeige Standlicht			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579392	Ladezustand_gering_XIX_Motor_52_XIX_E3V_VLAN_Connect	Fahrerwarnung bezÃ¼glich geringem Ladezustand der HV-Batterie			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f169	LiSi_HSH_Taste_XIX_LTMs_01_XIX_E3V_VLAN_Connect	Heckscheibenheizung AN/AUS			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f138	LiSi_Touch_Event_XIX_LTMs_01_XIX_E3V_VLAN_Connect	Touch_Events fÃ¼r Informationen einer FunktionsauslÃ¶sung auf der LiSi, welches dann fÃ¼r bspw. ein akustisches Signal zentral umgesetzt werden kÃ¶nnen.			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c84	MD1_Lage_XIX_SAD_01_XIX_E3V_VLAN_Connect	Lage Schiebedachstellung 1 (Signal wird 1:1 vom BCM2 geroutet; ursprÃ¼nglicher Sender: SAD = LIN-Slave vom BCM2)			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea786c	MIK_Gurtverlauf_R1_FS_XIX_MIK_05_XIX_E3V_VLAN_Connect	Ergebnis der Gurt-Misuse-Erkennung in der MIK			
019a7124-a083-776f-b8ee-3b8ef6ea786d	MIK_Insassenpos_R1_BFS_XIX_MIK_05_XIX_E3V_VLAN_Connect	Position des Insassen in Reihe 1, Beifahrerseite			
019a7124-a083-776f-b8ee-3b8ef6ea786e	MIK_Insassenschutz_Status_OoP_BF_XIX_MIK_05_XIX_E3V_VLAN_Connect	Status der MIK Out-of-Position Erkennung der Funktion "Warnung Sicherheitsdefizit Sitzposition" fÃ¼r den Beifahrersitz			

019a61ac-1573-7a44-8b16-0b2939cb1cb7	MO_FoD_Performance_Status_XIX_Motor_54_XIX_E3V_VLAN_Connect	Aktueller Fahrzeug Performanceupgrade Status			
0199b88a-db0c-73df-ac62-80cf1ecde530	MO_Kickdown_XIX_Motor_14_XIX_E3V_VLAN_Connect	Es gilt: Signalspec MO_Kickdown v1.0			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea78f2	MO_OnePedalDriving_integriert_XIX_Motor_54_XIX_E3V_VLAN_Connect	Zeigt an, dass das AntriebssteuergerÃ¤t die Funktion OnePedalDriving unterstÃ¼tzt.			
0199b88a-db0c-73df-ac62-80cf1ecde50f	MO_Rekuperationsstufe_XIX_Motor_41_XIX_E3V_VLAN_Connect	In Projekten mit variablen oder anwÃ¤hlbaren Rekuperationsstufen soll dem Fahrer die aktuell ausgewÃ¤hlte Stufe Ã¼ber ein Icon in den Anzeigeinstrumenten visualisiert werden kÃ¶nnen. Dies dient der Nachvollziehbarkeit fÃ¼r den Kunden in Bezug auf eine zukÃ¼nftige Schubphase. Umsetzung fÃ¼r J1 PAG geplant			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f12f	MTHBFS_Pos1_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	BetÃ¤tigung Postionstaste 1 HBFS			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0c0	MTHBFS_Pos3_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	BetÃ¤tigung Postionstaste 3 HBFS			All Data, Dynamic Technical Data Campaigns
0199b88b-b16d-77a2-8b45-d444aa72751c	OBD_Aussen_Temp_gef_XIX_OBD_03_XIX_HCP5_CANFD01	Gefilterte Aussentemperatur vom Motor fÃ¼r OBD Funktionen.			All Data, Dynamic Technical Data Campaigns

019a7124-a083-776f-b8ee-3b8ef6ea78f7	PDC_Tonausgabe_Heck_XIX_Parkhilfe_01_XIX_E3V_VLAN_Connect	In AbhÃ¤ngigkeit der SystemaktivitÃ¤ten werden unterschiedliche Tonwarnungen ausgegeben. Kombi spielt entsprechende WAV.-Datei Ã¼ber internen Audiomaster ab. 0 = kein Ton 1 = Intervallton 1 2 = Intervallton 2 3 = Intervallton 3 4 = Intervallton 4 5 = Intervallton 5 6 = Dauerton 7 = Fehlerton 8 = Erstwarnton (entspricht Intervallton 5) 9 = RCTATON 10..15 res			
0199b88b-c540-7457-9d9f-4c3cbac6f167	PH_Display_Kundenwunsch_XIX_Parkhilfe_01_XIX_E3V_VLAN_Connect	Anzeige der bei Aktivierung verwendeten Parameter bzgl. Kundenwunsch Displayanziege. Änderungen werden erst bei erneuter Aktivierung aktualisiert.			All Data, Dynamic Technical Data Campaigns

019a7124-a083-776f-b8ee-3b8ef6ea7900	PH_Stoermeldung_XIX_Parkhilfe_01_XIX_E3V_VLAN_Connect	Meldung einer StÃ¶rung der PDC an das Kombi			
019a7124-a083-776f-b8ee-3b8ef6ea7908	PH_Taster_XIX_Parkhilfe_01_XIX_E3V_VLAN_Connect	Taster Status (fÃ¼r RVC/TopView)			
0199b88a-3c9f-7e8e-9943-76deb3fbbe3c	PH_Ton_Pausenlaenge_XIX_Parkhilfe_04_XIX_E3V_VLAN_Connect	Pause zwischen den angeforderten TÃ¶nen beim MIB3 durch die Parkhilfe. Nur fÃ¼r IntervalltÃ¶ne, nicht relevant fÃ¼r Dauerton und Quittierungston.			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579434	Parken_aktives_System_XIX_Parken_01_XIX_E3V_VLAN_Connect	Das Signal zeigt an, welches der Parksysteme auf dem zFAS gerade aktiv ist.			All Data, Dynamic Technical Data Campaigns
019add4e-9add-7cac-b101-e8fedadcef69	RS_Regenmenge_XIX_RLSs_01_XIX_HCP4_LIN01	Regenmenge			
0199b88b-6db6-7e7d-a158-acde71ef5147	RS_Schwall_XIX_RLS_01_XIX_E3V_VLAN_Connect	Schwallereignis			All Data, Dynamic Technical Data Campaigns
0199b88b-6db6-7e7d-a158-acde71ef5135	RS_Wischergeschwindigkeit_XIX_RLS_02_XIX_E3V_VLAN_Connect	Wischergeschwindigkeit (HÃ¼be/min)			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1e0	SIL_Stufe_LED_li_XIX_BCM_05_XIX_E3V_VLAN_Connect	Statusmeldung SitzlÃ¼ftung links			All Data, Dynamic Technical Data Campaigns

0199b88a-3c9f-7e8e-9943-76deb3fbbedd	SMLS_Hupe_XIX_SMLS_01_XIX_E3V_VLAN_Connect	Betaetigung Hupe			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579444	SP_abklappen_XIX_Spiegel_01_XIX_E3V_VLAN_Connect	Spiegel abklappen			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0f9	SP_anklappen_XIX_Spiegel_01_XIX_E3V_VLAN_Connect	Spiegel anklappen			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1c96	SWA_SDA_Abstand_Spur_E1_XIX_SWA_SDA_01_XIX_E3V_VLAN_Connect	Abstand zum 1. Fahrzeug auf der Ego Spur ausgehend von Ego Fahrzeug.			
019a61ac-1573-7a44-8b16-0b2939cb1ca1	SWA_SDA_Abstand_Spur_R2_XIX_SWA_SDA_01_XIX_E3V_VLAN_Connect	Abstand zum 2. Fahrzeug auf der Rechten Spur ausgehend von Ego Fahrzeug.			
0199b88b-c540-7457-9d9f-4c3cbac6f0b2	SWA_SDA_Status_XIX_SWA_SDA_01_XIX_E3V_VLAN_Connect	Funktionsstatus			All Data, Dynamic Technical Data Campaigns
019b0b9c-4285-7b1f-9f3b-3242edfe784f	TA_aktiv_HMI_XIX_TA_01_XIX_E3V_VLAN_Connect	Signalwert an AnzeigegerÃ¤t welche Funktion aktiv			
0199b88b-c540-7457-9d9f-4c3cbac6f1ce	TM_Door_Unlock_XIX_TM_01_XIX_E3V_VLAN_Connect	Remote Door unlock angefordert: ZV auf/entriegeln			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f129	TM_Warnblinken_XIX_TM_01_XIX_E3V_VLAN_Connect	Remote Blinken aktiviert			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea78b2	TPMS_RaceTrckMdSts_XIX_RDK_11_XIX_E3V_VLAN_Connect	State of the racetrack mode			
019a7124-a083-776f-b8ee-3b8ef6ea78b4	TPMS_SensTypFrLe_XIX_RDK_11_XIX_E3V_VLAN_Connect	TPM sensor type front left			
019a7124-a083-776f-b8ee-3b8ef6ea78b5	TPMS_TarPTmpDepReRi_XIX_RDK_11_XIX_E3V_VLAN_Connect	Temperature dependent target pressure rear right			
019a7124-a083-776f-b8ee-3b8ef6ea78ac	TPMS_Warn1TireReLe_XIX_RDK_11_XIX_E3V_VLAN_Connect	Stage 1 warning for left rear tires			
019a7124-a083-776f-b8ee-3b8ef6ea78bb	TPMS_Warn2TireFrLe_XIX_RDK_11_XIX_E3V_VLAN_Connect	Stage 2 warning for left front tires			
019a7124-a083-776f-b8ee-3b8ef6ea78d6	TPMS_Warn2_XIX_RDK_11_XIX_E3V_VLAN_Connect	General Warning Level 2			
019a7124-a083-776f-b8ee-3b8ef6ea78b8	TPMS_Warn3TireFrLe_XIX_RDK_11_XIX_E3V_VLAN_Connect	Stage 3 warning for left front tire			
019a7124-a083-776f-b8ee-3b8ef6ea78b3	TPMS_Warn3TireFrRi_XIX_RDK_11_XIX_E3V_VLAN_Connect	Stage 3 warning for right front tire			
019a7124-a083-776f-b8ee-3b8ef6ea78cb	TPMS_Warn3TireReLe_XIX_RDK_11_XIX_E3V_VLAN_Connect	Stage 3 warning for left rear tire			

019a7124-a083-776f-b8ee-3b8ef6ea78b7	TPMS_Warn4TireReLe_XIX_RDK_11_XIX_E3V_VLAN_Connect	Stage 4 warning for left rear tyres			
019a7124-a083-776f-b8ee-3b8ef6ea78d7	TPMS_WarnSysLrn_XIX_RDK_11_XIX_E3V_VLAN_Connect	Warning when the TPMS system is learning			
019a7124-a083-776f-b8ee-3b8ef6ea78a5	TPMS_WarnWhlChgDet_XIX_RDK_11_XIX_E3V_VLAN_Connect	Warning on wheel change detected			
019a7124-a083-776f-b8ee-3b8ef6ea78ce	TPMS_WhlChgDetFrLe_XIX_RDK_11_XIX_E3V_VLAN_Connect	Wheel change front left detected			
019a7124-a083-776f-b8ee-3b8ef6ea78d4	TPMS_WhlChgDetReLe_XIX_RDK_11_XIX_E3V_VLAN_Connect	Wheel change rear left detected			
019a7124-a083-776f-b8ee-3b8ef6ea789d	TSK_praediktiver_Hinweis_XIX_Motor_53_XIX_E3V_VLAN_Connect	Anzeigesteuerung ob Geschwindigkeitshinweis als Vorschlag (zur Ãbernahme) oder als Hinweis (bei automatischer Ãbernahme) behandelt werden soll			
0199b88b-b83a-74d1-8d51-ff00e79fefda	VDSO_ALatOfsCmp	Formula: IMU_Alat-VDSO_ALatOfs=VDSO_ALatOfsCmp			All Data, Dynamic Technical Data Campaigns
0199b88b-b83a-74d1-8d51-ff00e79fefdf	VDSO_ALgtOfsCmp	Formula: IMU_Algt-VDSO_ALgtOfs=VDSO_ALgtOfsCmp			All Data, Dynamic Technical Data Campaigns

0199b88b-ade0-704f-9ab6-916f1b71be73	VDSO_Vx3dKmph_XIX_VDSO_05_XIX_HCP5_CANFD01	Longitudinal velocity estimated at the centre of rear axle. Estimation requires 3D IMU.			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9f-7e8e-9943-76deb3fbbef4	VZE_Anzeige_VZ_1_XIX_VZE_04_XIX_E3V_VLAN_Connect	Das Signal spiegelt eines der Verkehrszeichen: Geschwindigkeitsgebot, Ãberholverbot, Aufhebungszeichen wider. Wertebereich lt. Hashtabelle			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9f-7e8e-9943-76deb3fbbf07	VZE_Anzeige_VZ_2_XIX_VZE_04_XIX_E3V_VLAN_Connect	Das Signal spiegelt eines der Verkehrszeichen: Geschwindigkeitsgebot, Ãberholverbot, Aufhebungszeichen wider. Wertebereich lt. Hashtabelle			All Data, Dynamic Technical Data Campaigns
0199b88b-6db6-7e7d-a158-acde71ef5124	WH_Frontwaschen_XIX_SMLS_01_XIX_E3V_VLAN_Connect	Wischerhebel: Stellung Wisch Wasch vorne			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9f-7e8e-9943-76deb3fbbea3	WH_Intervall_XIX_SMLS_01_XIX_E3V_VLAN_Connect	Wischerhebel: Stellung Intervall			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f154	Wischer_vorne_Parklage_XIX_Wischer_01_XIX_E3V_VLAN_Connect	Wischer Front in Parklage			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1c8e	ZM_Fahrzeugabstellzeit_Status_XIX_ZeitMaster_01_XIX_E3V_VLAN_Connect	Status Fahrzeugabstellzeit			
019a61ac-1573-7a44-8b16-0b2939cb1c9c	ZM_HV_Auszeit_XIX_ZeitMaster_01_XIX_E3V_VLAN_Connect	Zeit seit letzter HochvoltaktivitÃ¤t			
019a61ac-1573-7a44-8b16-0b2939cb1c9e	ZV_HS_offen_XIX_ZV_02_XIX_E3V_VLAN_Connect	Status Heckscheibe			
0199b88b-c540-7457-9d9f-4c3cbac6f16b	ZV_Heckeinzelentriegelung_XIX_ZV_02_XIX_E3V_VLAN_Connect	Heckdeckeleinzelentriegelung			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1c97	ZV_Ladeklappe_VerEntriegeln_XIX_SAM_01_XIX_E3V_VLAN_Connect	Ver- u. Entriegeln der Ladeklappe			
0199b88b-bd69-7380-9f48-c027e357943c	ZV_verriegelt_extern_ist_XIX_ZV_02_XIX_E3V_VLAN_Connect	Istzustand: Verriegelung Fahrzeug aussen			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f14b	ZV_verriegelt_intern_ist_XIX_ZV_02_XIX_E3V_VLAN_Connect	Istzustand: Verriegelung Fahrzeug innen			All Data, Dynamic Technical Data Campaigns

0199b88a-db0b-76ce-b5c4-746cf1c7ed21	eTM_Pumpe1_Volumenstrom_XIX_eTM_01_XIX_E3V_VLAN_Connect	Soll-KÃ¼hlwasservolumenstrom von Pumpe 1 KÃ¼hlkreis HV Komponenten			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e35793df	AB_Belegung_VB_XIX_Airbag_02_XIX_E3V_VLAN_Connect	Belegungserkennung vorne Beifahrer. Wird in US-SteuergerÃ¤ten Ã¼ber Bladder-Matte bedient, optional bei RdW, falls SBE_EuroNCAP entschieden wird.			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea787d	ACC_Anforderung_HMS_XIX_ACC_18_XIX_E3V_VLAN_Connect	Bremsanforderung an den Haltemanager			
019a7124-a083-776f-b8ee-3b8ef6ea7892	ACC_Boost_XIX_ACC_18_XIX_E3V_VLAN_Connect	AktivitÃ¤t der Boost-Funktion des ACC			
019a7124-a083-776f-b8ee-3b8ef6ea788a	ACC_Regelgeschw_XIX_ACC_19_XIX_E3V_VLAN_Connect	Zur Anzeige der Regelgeschwindigkeit (z.B. Kurven- / Tempolimitassistent) im Kombiinstrument			
019a7124-a083-776f-b8ee-3b8ef6ea7888	ACC_Typ_LNS_XIX_ACC_19_XIX_E3V_VLAN_Connect	VW: Anzeige der Klasse des linken Nebenspurobjektes (LNS)			
019a7124-a083-776f-b8ee-3b8ef6ea7899	ACC_relevanter_Fehler_XIX_ACC_18_XIX_E3V_VLAN_Connect	Frontradar-SG erkennt einen Fehler, mit FSP-Eintrag.			

019a7124-a083-776f-b8ee-3b8ef6ea78cf	ACF_Lampe_Hands_Off_XIX_EA_02_XIX_E3V_VLAN_Connect	Anzeige, ob der Fahrer die HÃ¤nde am Lenkrad hat.			
019a7124-a083-776f-b8ee-3b8ef6ea788c	AWV_AW_Abstand_XIX_AWV_02_XIX_E3V_VLAN_Connect	Signal dient zur Anzeige des Abstands im Kombi.			
019a61ac-1573-7a44-8b16-0b2939cb1c9b	AZK_Kessy_nicht_gefunden_XIX_AZK_01_XIX_E3V_VLAN_Connect	Signalisierung der Kessy-Meldung "Kessy nicht gefunden" vom AZK an ein Anzeigeinstrument (Kombiinstrument, I-ID etc.)			
019a61ac-1573-7a44-8b16-0b2939cb1c9d	AZK_MobileKey_defekt_XIX_AZK_01_XIX_E3V_VLAN_Connect	Signalisierung der DKM-Meldung "System Mobile Key defekt" vom AZK an ein Anzeigeinstrument (Kombiinstrument, I-ID etc.)			
019a61ac-1573-7a44-8b16-0b2939cb1ca5	AZK_Mobilgeraet_nicht_gefunden_XIX_AZK_01_XIX_E3V_VLAN_Connect	Signalisierung der DKM-Meldung "MobilgerÃ¤t nicht gefunden" vom AZK an ein Anzeigeinstrument (Kombiinstrument, I-ID etc.)			
019a61ac-1573-7a44-8b16-0b2939cb1ca2	AZK_Schluessel_nicht_gefunden_XIX_AZK_01_XIX_E3V_VLAN_Connect	Signalisierung der Meldung "Schluessel nicht gefunden" der AZK SW-Unit im MDK-ZuKo an ein Anzeigeinstrument (Kombiinstrument, I-ID etc.)			

0199b88a-6c7a-7da6-99f9-2891db59dcf2	BCM1_Aussen_Temp_ungef_XIX_Klima_Sensor_02_MQB_XIX_E3V_VLAN_Connect	ungefilterter Wert des Aussentemperatursensors			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c3a	BCM1_Licht_Dunkelheit_aktiv_XIX_Licht_vorne_01_XIX_E3V_VLAN_Connect	Licht aktiv aufgrund von Dunkelheit (nicht bei Autobahn-, Tagfahr- oder Regenlicht)			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f18e	BCM1_Warnblink_Taster_XIX_BCM_01_XIX_E3V_VLAN_Connect	Warnblinktaster			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f111	BCM_BFS_Massage_Taster_XIX_BCM_Taster_02_XIX_E3V_VLAN_Connect	Ansteuerungs-Signalisierung der Pneumatik-Funktionen			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c3c	BCM_BFS_Pneumatik_Verstellung_XIX_BCM_Taster_02_XIX_E3V_VLAN_Connect	Ansteuerungs-Signalisierung der Pneumatik-Funktionen			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f116	BCM_BFS_Programmwipe_XIX_BCM_Taster_02_XIX_E3V_VLAN_Connect	Ansteuerungs-Signalisierung der Pneumatik-Funktionen			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0f5	BCM_FS_Massage_Taster_XIX_BCM_Taster_02_XIX_E3V_VLAN_Connect	Ansteuerungs-Signalisierung der Pneumatik-Funktionen			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e357944c	BCM_FS_Pneumatik_Verstellung_XIX_BCM_Taster_02_XIX_E3V_VLAN_Connect	Ansteuerungs-Signalisierung der Pneumatik-Funktionen			All Data, Dynamic Technical Data Campaigns

0199b88b-c53f-718d-b010-636bf9b22c89	BCM_FS_Programmwippe_XIX_BCM_Taster_02_XIX_E3V_VLAN_Connect	Ansteuerungs-Signalisierung der Pneumatik-Funktionen			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0cc	BCM_HDF_betaetigt_XIX_BCM_01_XIX_E3V_VLAN_Connect	BetÃ¤tigung Taster fÃ¼r Heckdeckelfernentriegelung in Mittelkonsole			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1be	BCM_Offroad_Taste_XIX_BCM_01_XIX_E3V_VLAN_Connect	BetÃ¤tigung der Offroad-Taste			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be5a	BDM_Spannung_XIX_BDMs_Ruhe_XIX_HCP5_LIN01				All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be59	BDM_Strom_dyn_XIX_BDMs_Dyn_XIX_HCP5_LIN01				All Data, Dynamic Technical Data Campaigns
0199b88b-6db6-7e7d-a158-acde71ef5138	BH_Fernlicht_XIX_SMLS_01_XIX_E3V_VLAN_Connect	Betaetigung Fernlicht			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be40	BMC_IWU_Wert_neg_XIX_BMC_HV_02_XIX_HCP4_CANFD03	Aktueller Isolationswert zwischen HV minus und Fahrzeug			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4b7	BMC_IstTemperaturMax_Modul_ID_XIX_BMC_HV_08_XIX_HCP5_CANFD01	RTM-Signal: Nummer (ID) des Moduls mit dem aktuell hÃ¶chsten TemperaturmeÃwert			All Data, Dynamic Technical Data Campaigns

0199b88a-7c25-7d2b-96f6-64981efcc4ae	BMC_IstTemperaturMin_Modul_ID_XIX_BMC_HV_08_XIX_HCP5_CANFD01	RTM-Signal: Nummer (ID) des Moduls mit dem aktuell niedrigsten TemperaturmeÃwert			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be52	BMC_IstZellspannungMin_XIX_BMC_HV_02_XIX_HCP4_CANFD03	Aktuell niedrigste Zellspannung in der Batterie			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be6d	BMC_NutzbarerSOC_XIX_BMC_HV_02_XIX_HCP4_CANFD03	Aktueller relativer Ladezustand der HV-Batterie/Der angezeigte Bereich fÃ¼r Kunde ist von 0-100%/Reserve wird im negativen Bereich abgebildet/Werte Ã¼ber 100% signalisieren eine unzulÃ¤ssige Ãberladung. Physikalischer Wertebereich liegt zw. -20% bis 120%.			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc497	BMC_Spannung_DC_Ladesaeule_XIX_BMC_HV_02_XIX_HCP5_CANFD01	DC-Spannung der Ladesaeule. Messung zwischen den DC HV-Leitungen.			All Data, Dynamic Technical Data Campaigns

0199b88a-7c25-7d2b-96f6-64981efcc4d5	BMC_Strom_XIX_BMC_HV_01_XIX_HCP5_CANFD01	Momentanwert: Batteriestrom; Stromrichtung: ein Ladestrom wird mit positiven, ein Entladestrom mit negativen Werten angegeben			All Data, Dynamic Technical Data Campaigns
0199b88a-a399-76f6-9144-d8e4878e2b1f	BMS_IstTemperaturMax_Modul_ID_XIX_BMS_28_XIX_E3V_VLAN_Connect	RTM-Signal: Nummer (ID) des Moduls mit dem aktuell hÃ¶chsten TemperaturmeÃwert			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9f-7e8e-9943-76deb3fbbebe	BMS_IstTemperaturMax_Sensor_ID_XIX_BMS_28_XIX_E3V_VLAN_Connect	RTM-Signal: Nummer (ID) des Sensors (innerhalb des Moduls) mit dem aktuell hÃ¶chsten TemperaturmeÃwert			All Data, Dynamic Technical Data Campaigns
0199b88a-994a-7e24-97fc-90e5a1603a2c	BMS_IstTemperatur_niedrigste_XIX_BMS_11_XIX_E3V_VLAN_Connect	aktuell niedrigsteTemperatur in der Batterie			All Data, Dynamic Technical Data Campaigns
0199b88a-a399-76f6-9144-d8e4878e2895	BMS_IstZellSpannungMax_Modul_ID_XIX_BMS_28_XIX_E3V_VLAN_Connect	RTM-Signal: Nummer (ID) des Moduls mit der aktuell hÃ¶chsten Zellspannung			All Data, Dynamic Technical Data Campaigns
0199b88a-a399-76f6-9144-d8e4878e2888	BMS_IstZellSpannungMin_Modul_ID_XIX_BMS_28_XIX_E3V_VLAN_Connect	RTM-Signal: Nummer (ID) des Moduls mit der aktuell niedrigsten Zellspannung			All Data, Dynamic Technical Data Campaigns

0199b88a-994a-7e24-97fc-90e5a1603a2d	BMS_IstZellspannung_niedrigste_XIX_BMS_11_XIX_E3V_VLAN_Connect	niedrigster Wert aller Zellspannungen im BMS			All Data, Dynamic Technical Data Campaigns
0199b88a-db0b-76ce-b5c4-746cf1c7ece9	BMS_Rekuperation_Ueberlauf_XIX_BMS_05_XIX_E3V_VLAN_Connect	Rekuperationleistungssignal BMS_Rekuperation mindest 1x Ã¼bergelaufen			All Data, Dynamic Technical Data Campaigns
0199b88a-994a-7e24-97fc-90e5a1603a2a	BMS_Strom_XIX_BMS_20_XIX_E3V_VLAN_Connect	Aktueller Strom der Batterie. Stromrichtung: Ladestrom wird mit positiven, Entladestrom mit negativen Werten angegeben.			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9f-7e8e-9943-76deb3fbbe68	BMS_VorlaufTemperatur_XIX_BMS_25_XIX_E3V_VLAN_Connect	Aktueller Messwert der KÃ¼hlmittel-Vorlauftemperatur am KÃ¼hlmittel-Einlass des Batteriesystems.			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0ee	BM_Autobahn_XIX_Blinkmodi_02_XIX_E3V_VLAN_Connect	Status Autobahnblinken			All Data, Dynamic Technical Data Campaigns
0199b88b-6db6-7e7d-a158-acde71ef5164	BM_links_XIX_Blinkmodi_02_XIX_E3V_VLAN_Connect	Richtungsblinken links			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f146	BT_FH_Bew_tief_XIX_TSG_BT_01_XIX_E3V_VLAN_Connect	Fensterheber in Bewegung Richtung tief			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f0de	BT_SP_ht_aktiv_XIX_TSG_BT_01_XIX_E3V_VLAN_Connect	Spiegelverstellung in Richtung hoch/tief aktiv			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1e7	BT_Schluesselschalter_auf_XIX_TSG_BT_01_XIX_E3V_VLAN_Connect	SchlÃ¼sselschalter Richtung auf betÃ¤tigt			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0e4	BT_Schluesselschalter_zu_XIX_TSG_BT_01_XIX_E3V_VLAN_Connect	Schluesselschalter Richtung zu betaetigt			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f10b	BT_TAG_betaetigt_XIX_TSG_BT_01_XIX_E3V_VLAN_Connect	TÃ¼raussengriff			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0db	BT_Tuer_geoeffnet_XIX_TSG_BT_01_XIX_E3V_VLAN_Connect	Zeigt eine geÃ¶ffnete TÃ¼r an			All Data, Dynamic Technical Data Campaigns
0199b88a-db0b-76ce-b5c4-746cf1c7ecd8	DC_IstStrom_NV_XIX_DCDC_01_XIX_E3V_VLAN_Connect	Momentanwert: Strom vom DC/DC in das Bordnetz Tiefsetzen - positiv Hochsetzen - negativ			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0c1	DWA_aktiv_XIX_ZV_02_XIX_E3V_VLAN_Connect	Status DWA aktiv			All Data, Dynamic Technical Data Campaigns

0199b88a-6c7a-7da6-99f9-2891db59dd2f	DW_Kilometerstand_XIX_Diagnose_01_XIX_HCP5_CANFD01	Fehler wird ausgegeben, falls Kilometerstand nicht restaurierbar			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1a2	DiETa_Car_XIX_DiETa_01_XIX_E3V_VLAN_Connect	Status Car-Taste			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0c8	DiETa_Defrost_Taste_XIX_DiETa_01_XIX_E3V_VLAN_Connect	Max. Defrost AN/AUS			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0bd	DiETa_FSH_Taste_XIX_DiETa_01_XIX_E3V_VLAN_Connect	Frontscheibenheizung AN/AUS			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f212	DiETa_Klima_XIX_DiETa_01_XIX_E3V_VLAN_Connect	Status Klimataste			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c5f	DiETa_Mode_XIX_DiETa_01_XIX_E3V_VLAN_Connect	Status Modetaste			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e357945a	DiETa_Touch_Event_XIX_DiETa_01_XIX_E3V_VLAN_Connect	Touch_Events fÃ¼r Informationen einer FunktionsauslÃ¶sung auf DiETa, welches dann fÃ¼r bspw. ein akustisches Signal zentral umgesetzt werden kÃ¶nnen.			All Data, Dynamic Technical Data Campaigns

019a7124-a083-776f-b8ee-3b8ef6ea7895	EA_Infotainment_Anf_XIX_EA_02_XIX_E3V_VLAN_Connect	Emergency Assist Anforderung Absenkung Infotainment-Funktionen			
019a7124-a083-776f-b8ee-3b8ef6ea788d	EA_Status_HMI_XIX_EA_02_XIX_E3V_VLAN_Connect	Anzeige Emergency Assist-Statusleuchte im Fahrerinformationsdisplay			
019a7124-a083-776f-b8ee-3b8ef6ea7898	EA_eCall_Anf_XIX_EA_02_XIX_E3V_VLAN_Connect	Emergency Assist Anforderung eCall			
0199b88b-c540-7457-9d9f-4c3cbac6f0af	EBKV_Fahrer_bremst_deutlich_XIX_EBKV_03_Auth_XIX_E3V_VLAN_Connect	RÃ¼ckmeldung des eBKVs, ob der Fahrer deutlich eine Bremsung wÃ¼nscht. Eine Aktivierung des Signals erfolgt bei 50N Pedalkraft (DruckÃ¤quivalent= 20bar, verwendet in AWV-Fkt.)			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be44	ELM1_WMot	aufgenommene elektrische Energie (Ãberlaufbehaftet)			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1c9f	ESP_Dachrelingsensor_XIX_ESP_20_XIX_E3V_VLAN_Connect	Erkennung auf Verbau des Dachrelingsensors und DachquertrÃ¤ger.			

0199b88a-3c9f-7e8e-9943-76deb3fbbedb	ESP_v_Signal_XIX_ESP_21_XIX_E3V_VLAN_Connect	Geschwindigkeitssignal vom ABS/ASR oder ESP. Mittelwert der angetriebenen RÃ¤der. Bei MSR oder ABS Eingriffen wird die ABS-Referenzgeschwindigkeit fÃ¼r >= 200ms eingespiegelt (Zeit wird mit Aktiv-Flanke der Funktionsbits getriggert) MQB: Bei Frontantrieb und gesteuertem Allrad (Haldex) Mittelwert der VorderrÃ¤der.			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f170	FAS_Profile_Taster_XIX_BCM_Taster_02_XIX_E3V_VLAN_Connect	Das Signal beschreibt den Zustand der FAS-Profile-Tasters			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0fe	FFB_CarFinder_XIX_ZV_02_XIX_E3V_VLAN_Connect	Car Finder Funktion (Blinken ohne zu entriegeln)			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e357945c	FFB_Komfortschliessen_XIX_ZV_02_XIX_E3V_VLAN_Connect	Komfortschliessen Funk			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea787c	FLA_Abblendursache_XIX_FLA_01_XIX_E3V_VLAN_Connect	FLA Abblendursache (20ms Task)			

019a7124-a083-776f-b8ee-3b8ef6ea7877	FLA_Aufblenden_XIX_FLA_01_XIX_E3V_VLAN_Connect	FLA Aufblenden (20ms Task)			
019a7124-a083-776f-b8ee-3b8ef6ea7872	FLA_aktiv_XIX_FLA_01_XIX_E3V_VLAN_Connect	FLA aktiv (200ms Task)			
019a7124-a083-776f-b8ee-3b8ef6ea7869	FT_Cargolock_bet_XIX_TSG_FT_02_XIX_E3V_VLAN_Connect	CargoLock-Taste betÃ¤tigt			
019a7124-a083-776f-b8ee-3b8ef6ea7879	FT_FH_Bew_hoch_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	Fensterheber in Bewegung Richtung hoch			
0199b88b-c540-7457-9d9f-4c3cbac6f203	FT_FH_Bew_tief_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	Fensterheber in Bewegung Richtung tief			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0fd	FT_FH_S_ManTief_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	FH Schalter manuell tief gedrÃ¼ckt			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f16a	FT_Kisi_Taster_li_02_XIX_TSG_FT_02_XIX_E3V_VLAN_Connect	Der Kindersicherungstaster hinten links aktiv.			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c87	FT_Kisi_Taster_re_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	Rechter Kisi Taster betaetigt			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1d1	FT_Kisi_re_aktiv_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	Aktivierungsstatus der Kindersicherung rechts			All Data, Dynamic Technical Data Campaigns

019a7124-a083-776f-b8ee-3b8ef6ea7862	FT_Lock_Taster_02_XIX_TSG_FT_02_XIX_E3V_VLAN_Connect	Lock-Taster betÃ¤tigt			
019a7124-a083-776f-b8ee-3b8ef6ea7871	FT_Lock_Unlock_Taster_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	ZV Funktion Lock Unlock mit Toggle-Logik			
019a7124-a083-776f-b8ee-3b8ef6ea7874	FT_SP_ausgerastet_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	Spiegel ausgerastet			
0199b88b-bd69-7380-9f48-c027e357943a	FT_Schluesselschalter_auf_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	SchlÃ¼sselschalter Richtung auf betÃ¤tigt			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1cbb	FT_Schluesselschalter_zu_02_XIX_TSG_FT_02_XIX_E3V_VLAN_Connect	SchlÃ¼sselschalter fÃ¼r SchlieÃen betÃ¤tigt			
019a7124-a083-776f-b8ee-3b8ef6ea7873	FT_Sp_Heizung_Anf_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	Kundenanforderung der AuÃenspiegelheizung FahrertÃ¼r			
0199b88b-c53f-718d-b010-636bf9b22c30	FT_TAG_betaetigt_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	TÃ¼raussengriff wird nicht im MLB-B8 verwendet			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0fa	FT_TD_Taste_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	Tankdeckelentriegelungs-Taste betÃ¤tigt			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c72	FT_TIG_betaetigt_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	TÃ¼rinnengriff wird nicht im MLB-B8 verwendet			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f123	FT_Tuer_Status_XIX_TSG_FT_02_XIX_E3V_VLAN_Connect	TÃ¼r geÃ¶ffnet oder TÃ¼r geschlossen			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579421	FT_Tuer_geoeffnet_XIX_TSG_FT_01_XIX_E3V_VLAN_Connect	Zeigt eine geÃ¶ffnete TÃ¼r an			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1ca0	FoD_DTC_TSK_ACC_XIX_Motor_54_XIX_E3V_VLAN_Connect	DTC ist entweder bereits eingetragen oder wird eingetragen, sobald die zugehÃ¶rige FOD Funktion freigeschaltet wird.			
0199bcdc-2d44-7d5f-9522-f4897daf26f6	GRA_Abbrechen_XIX_GRA_ACC_01_XIX_E3V_VLAN_Connect	GRA : aus mit speichern ACC : Soft aus			All Data, Dynamic Technical Data Campaigns
0199bcdc-2d44-7d5f-9522-f4897daf26ee	GRA_LIM_Taste_verfuegbar_XIX_GRA_ACC_01_XIX_E3V_VLAN_Connect	Das Signal zeigt an, ob eine Limiter-Umschalttaste am jeweiligen GRA/ACC-Bedienelement vorhanden ist.			All Data, Dynamic Technical Data Campaigns
0199bcdc-2d44-7d5f-9522-f4897daf26f5	GRA_Tip_Runter_XIX_GRA_ACC_01_XIX_E3V_VLAN_Connect	Tippschalter Tip Down / Geschwindigkeit reduzieren			All Data, Dynamic Technical Data Campaigns
0199bcdc-2d44-7d5f-9522-f4897daf26ec	GRA_Tip_Setzen_XIX_GRA_ACC_01_XIX_E3V_VLAN_Connect	Tippschalter Set			All Data, Dynamic Technical Data Campaigns

019a7124-a083-776f-b8ee-3b8ef6ea788b	GRA_Typ_Bedienteil_erw_XIX_GRA_ACC_01_XIX_E3V_VLAN_Connect	Das Signal kennzeichnet die Variante des GRA/ACC-Bedienteils als erweiterte Bedienvariante: "KIS" (Kip IT Simple) ZusÃ¤tzlich zu dem Signal "GRA_Typ_Bedienteil"			
0199bcdc-2d44-7d5f-9522-f4897daf26f2	GRA_Verstellung_Zeitluecke_XIX_GRA_ACC_01_XIX_E3V_VLAN_Connect	Verstellung der ZeitlÃ¼cke fÃ¼r ACC DIST -1 = Zeitluecke um 1 Stufe kleiner DIST +1 = Zeitluecke um 1 Stufe groeÃer DIST Toggle = ZeitlÃ¼cke um 1 Stufe kleiner, von kleinster Stufe auf grÃ¶Ãte Stufe			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f197	HBFS_FH_S_AutoHoch_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	Betaetigung FH Schalter auto tief			All Data, Dynamic Technical Data Campaigns
0199b88b-bd69-7380-9f48-c027e3579466	HBFS_FH_S_AutoTief_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	Betaetigung FH Schalter auto hoch			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f202	HBFS_FH_S_HFS_AutoTief_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	Automatisches Absenken der Seitenscheibe HFS			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f1a9	HBFS_Status_KiSi_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	Status Kindersicherung HBFS			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0a1	HBFS_TAG_betaetigt_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	Betaetigung TÃ¼raussengriff			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0ac	HD_Hauptraste_XIX_SAM_01_XIX_E3V_VLAN_Connect	SBL-Schloss (MQB/MLBevo): Drehfalle Heckdeckel sonst (MQB): Hauptraste Heckdeckel			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0a5	HD_Vorraste_XIX_SAM_01_XIX_E3V_VLAN_Connect	SBL_Schloss (MQB/MLBevo): Sperrklinke Heckdeckel sonst (MQB): Vorraste Heckdeckel			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f140	HFS_FH_S_HBFS_AutoHoch_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	Automatisches Hochfahren der Seitenscheibe HBFS			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0d0	HFS_FH_S_HBFS_ManTief_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	Manuelles Absenken der Seitenscheibe HBFS			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c74	HFS_TIG_betaetigt_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	Betaetigung TÃ¼rinnengriff			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f1ff	HFS_TIG_betaetigt_oeffnen_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	TÃ¼rinnenbetÃ¤tigung, Taster TÃ¼r Ã¶ffnen.			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f178	HSH_Status_XIX_BCM_05_XIX_E3V_VLAN_Connect	Status Heckscheibenheizung			All Data, Dynamic Technical Data Campaigns
0199b88b-b16d-77a2-8b45-d444aa727512	HVLM_Max_Strom_Netz_L2_XIX_HVLM_13_XIX_HCP5_CANFD01	Gibt den maximal zulÃ¤ssigen Aufnahmestrom aus der Infrastruktur auf L2 an.			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be47	HVLM_OBG_SollModus_XIX_HVLM_13_XIX_HCP4_CANFD03	Anforderung des Sollmodus an das LadegerÃ¤t.			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea78ea	HVLM_SollSOCFzgPlc_XIX_HVLM_PLC_02_XIX_E3V_VLAN_Connect	Soll SOC des Fzg / TargetSOC			
0199b88a-7c25-7d2b-96f6-64981efcc4b9	HVLM_Steckerstatus_XIX_HVLM_14_XIX_HCP5_CANFD01	Stellt den Status eines Ladesteckers im Fahrzeug hinsichtlich PrÃ¤senz zur VerfÃ¼gung			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f0bd	HVLS_LadedosenVerbaut_SG1_XIX_HVLS_Ladedose_SG1_XIX_E3V_VLAN_Connect	Gibt an welche Ladedosen des angeschlossenen SteuergerÃ¤tes verbaut und ausgewertet werden			All Data, Dynamic Technical Data Campaigns

0199c202-d863-7e93-9c3d-93ff74e0f173	HVLS_LkSensor_Betaetigun_Lk1_XIX_HVLS_Ladedose_SG1_XIX_E3V_VLAN_Connect	Gibt an ob eine BetÃ¤tigung des Ladeklappensensors an der Ladeklappe 1 detektiert wurde			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f15c	HVLS_LkSensor_Betaetigun_Lk2_XIX_HVLS_Ladedose_SG2_XIX_E3V_VLAN_Connect	Gibt an ob eine BetÃ¤tigung des Ladeklappensensors an der Ladeklappe 2 detektiert wurde			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f19f	HVLS_NotoeffnungErkannt_Lk1_XIX_HVLS_Ladedose_SG1_XIX_E3V_VLAN_Connect	Erkennung einer manuellen NotÃ¶ffnung der Ladeklappe durch den Kunden an Ladeklappe 1			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f14a	HVLS_NotoeffnungErkannt_Lk2_XIX_HVLS_Ladedose_SG2_XIX_E3V_VLAN_Connect	Erkennung einer manuellen NotÃ¶ffnung der Ladeklappe durch den Kunden an Ladeklappe 2			All Data, Dynamic Technical Data Campaigns
0199c202-d863-7e93-9c3d-93ff74e0f1af	HVLS_SteckerEntriegelungVerbot_B_XIX_HVLS_Ladedose_SG2_XIX_E3V_VLAN_Connect	Verbot zur Ladesteckerentriegelung			All Data, Dynamic Technical Data Campaigns
0199b88b-ade0-704f-9ab6-916f1b71be4c	HVLS_SteckerVeriegelungStatus_B_XIX_HVLS_Ladedose_SG2_XIX_HCP5_CANFD01	Zeigt den Status des Verriegelungsaktors der Ladedose an B			All Data, Dynamic Technical Data Campaigns

0199c202-d863-7e93-9c3d-93ff74e0f181	HVLS_Steckerstatus_SG2_XIX_HVLS_Ladedose_SG2_XIX_E3V_VLAN_Connect	Stellt den Status eines Ladesteckers am SteuergerÃ¤t hinsichtlich PrÃ¤senz zur VerfÃ¼gung			All Data, Dynamic Technical Data Campaigns
0199b88b-b16d-77a2-8b45-d444aa727520	HVLS_Temp_AC_A_XIX_HVLS_Ladedose_SG1_XIX_HCP5_CANFD01	aktuelle Temperatur der AC-Ladedose an A			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4c5	HVLX_Isond_IstStromLadesaeule_XIX_ISOND_01_XIX_HCP5_CANFD01	Iststrom der Ladestation / EVSEPresentCurrent (DIN70121 RC_2)			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea78ed	HVLX_Isond_LadeartAC1PCorePlc_XIX_ISOND_01_XIX_E3V_VLAN_Connect	Gibt an, ob die PLC-Ladesaeule das einphasige AC-Laden nach IEC 62196 unterstuetzt			
019a7124-a083-776f-b8ee-3b8ef6ea78e3	HVLX_Isond_PlcKommFehler_XIX_ISOND_01_XIX_E3V_VLAN_Connect	Fehler bei der Kommunikaion mit der Ladesaeule (Status vom Stack, nicht Teil der Norm) (DIN70121 RC_2)			
019a7124-a083-776f-b8ee-3b8ef6ea78dd	HVLX_Isond_VASBedAnzStatus_LsPlc_XIX_ISOND_01_XIX_E3V_VLAN_Connect	Status ob die Ladesaeule den Value Added Service "ControlAndDisplayExtension" Anbietet			

019a7124-a083-776f-b8ee-3b8ef6ea78e5	HVLX_Isond_VASErwLFStatus_LsPlc_XIX_ISOND_01_XIX_E3V_VLAN_Connect	Status ob die Ladesaeule ueber die Value Added Service den Dienst "ChargingExtensions" Anbietet			
0199b88a-a399-76f6-9144-d8e4878e2b1d	HVL_Steckerstatus_XIX_HVL_01_XIX_E3V_VLAN_Connect	Stellt den Status des Ladesteckers hinsichtlich PrÃ¤senz zur VerfÃ¼gung			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f18d	IPA_TPA_Remote_XIX_Parken_01_XIX_E3V_VLAN_Connect	Status hinsichtlich Umschaltung auf fernbedienten Parkvorgang			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f141	IRUE_aktiv_XIX_ZV_02_XIX_E3V_VLAN_Connect	Status InnenraumÃ¼berwachung			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea78fc	KL_Beschlagsgefahr_XIX_Klima_12_XIX_E3V_VLAN_Connect	Beschlagsgefahr auf der Frontscheibe im Bereich des Spiegelfusses. Dient zur prÃ¤ventiven Ansteuerung der Kamera-Scheibenheizung, um Kamera-Blindheit zu vermeiden PHEV: volle Leistungsfreigabe HV Heizer und HV EKK bei Scheibenbeschlag			

0199cc4f-0634-7c4d-9601-d022c7a9e194	KL_HSH_Soll_XIX_Klima_16_XIX_E3V_VLAN_Connect	Sollstatus Heckscheibenheizung			All Data, Dynamic Technical Data Campaigns
0199b88a-db0b-76ce-b5c4-746cf1c7ed22	KL_Innen_Temp_XIX_Klima_03_XIX_E3V_VLAN_Connect	Innentemperatur			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f186	KL_LRH_Taster_XIX_Klima_12_XIX_E3V_VLAN_Connect	TasterbetÃ¤tigung Lenkradheizung			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f20a	KL_SIL_Soll_re_XIX_Klima_12_XIX_E3V_VLAN_Connect	Einstellung SitzlÃ¼ftung Beifahrer (0...6)			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f13e	KL_Standklima_Remote Modus_XIX_Klima_EV_04_XIX_E3V_VLAN_Connect	Modus (LÃ¼ften, KÃ¼hlen, Heizen) der Standklimatisierung (Innenraum) zur Remote Anzeige			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c76	KRH_Stufe_LED_re_XIX_BCM_05_XIX_E3V_VLAN_Connect	Statusmeldung Kopfraumheizung rechts			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea78af	LH_Blinker_HR_akt_XIX_Licht_hinten_01_XIX_E3V_VLAN_Connect	Blinker hinten rechts			
0199b88b-c540-7457-9d9f-4c3cbac6f125	LH_Parklicht_HR_aktiv_XIX_Licht_hinten_01_XIX_E3V_VLAN_Connect	Parklicht hinten rechts			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f107	LIM_iCall_Taster_XIX_BCM_Taster_02_XIX_E3V_VLAN_Connect	BetÃ¤tigungsstatus des Info Call Tasters im Dachmodul			All Data, Dynamic Technical Data Campaigns
019ce045-6b79-77e2-9035-d823e09bea30	LL_AppliServe1Syste2JavaUDS_ReadDataByIdentMeasuValue_Performance_domain_microprocessor_embedded_non_volatile_memory_state_0x30E	Performance_domain_microprocessor_embedded_non_volatile_memory_state			
0199b88b-b480-74b1-ba03-0e84b0e34aa0	LL_BatteEnergContrModulUDS_ReadDataByIdentMeasuValue_High_Voltage_Battery_Maximum_Temperature_0x1E0E_2	High_Voltage_Battery_Maximum_Temperature			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4bd	LL_BatteEnergContrModulUDS_ReadDataByIdentMeasuValue_Minimum_Cell_Voltage_0x1E34_1	Minimum_Cell_Voltage			All Data, Dynamic Technical Data Campaigns
0199b88b-b480-74b1-ba03-0e84b0e34a9e	LL_BatteEnergContrModulUDS_ReadDataByIdentMeasuValue_Minimum_Cell_Voltage_0x1E34_2	Minimum_Cell_Voltage			All Data, Dynamic Technical Data Campaigns
0199b88a-db0b-76ce-b5c4-746cf1c7ed04	LL_BatteEnergContrModulUDS_ReadDataByIdentMeasuValue_Standard_ambient_conditions_0x2BD	Standard_ambient_conditions			All Data, Dynamic Technical Data Campaigns

0199b88b-b481-7df3-b7fb-f2405d6c1f6b	LL_BatteEnergContrModulUDS_ReadDataByIdentMeasuValue_Temperature_of_battery_junction_box_0x58E2	Temperature_of_battery_junction_box			All Data, Dynamic Technical Data Campaigns
019bd9ab-f017-7e58-ab83-0056eae1e585	LL_CentrElectUDS_ReadDataByIdentMeasuValue_Fsm_error_counter_0x1022	Fsm_error_counter			
019c09eb-c61d-7054-a7ab-6f4af2796dc6	LL_CentrElectUDS_ReadDataByIdentMeasuValue_History_memory_reset_counter_coc_0x1024	History_memory_reset_counter_coc			
019bd9ab-f017-7e58-ab83-0056eae1e583	LL_CentrElectUDS_ReadDataByIdentMeasuValue_Number_of_unplanned_ecu_resets_0x1020	Number_of_unplanned_ecu_resets			
019bd9ab-f017-7e58-ab83-0056eae1e587	LL_CentrElectUDS_ReadDataByIdentMeasuValue_Write_Outside_Allowed_Memory_Asynchronous_0x1029	Write_Outside_Allowed_Memory_Asynchronous			
019bd9ab-f017-7e58-ab83-0056eae1e581	LL_CentrElectUDS_ReadDataByIdentMeasuValue_Write_Outside_Allowed_Memory_Synchronous_0x1028	Write_Outside_Allowed_Memory_Synchronous			

0199b88b-b16d-77a2-8b45-d444aa727528	LL_EnginContrModul1UDS_ReadDataByIdentMeasuValue_Intake camshaft phasing bank1, actual angle_0x201E	Intake camshaft phasing bank1, actual angle			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4c6	LL_HighVoltaCentrUnitUDS_ReadDataByIdentMeasuValue_Sac_temperature_actual_value_0x375	Sac_temperature_actual_value			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc4ab	LL_SmartActuaChargInterDevic2UDS_ReadDataByIdentMeasuValue_Charge_plug_state_0x346	Charge_plug_state			All Data, Dynamic Technical Data Campaigns
019c09eb-c61d-7054-a7ab-6f4af2796dc1	LL_ThermManagUDS_ReadDataByIdentMeasuValue_History_memory_reset_counter_0x1021	History_memory_reset_counter			
019c09eb-c61d-7054-a7ab-6f4af2796dca	LL_ThermManagUDS_ReadDataByIdentMeasuValue_Number_of_unplanned_ecu_resets_0x1020	Number_of_unplanned_ecu_resets			
0199b88b-b83a-74d1-8d51-ff00e79fef91	LL_TirePressMonit1UDS_ReadDataByIdentMeasuValue_Left rear tire pressure sensor remaining operation time_0x4E96	Left rear tire pressure sensor remaining operation time			All Data, Dynamic Technical Data Campaigns

0199b88b-6db6-7e7d-a158-acde71ef5149	LRH_On_Off_XIX_SMLS_01_XIX_E3V_VLAN_Connect	Status Lenkradheizung			All Data, Dynamic Technical Data Campaigns
0199b88b-6db6-7e7d-a158-acde71ef5123	LS_Dunkel_XIX_RLS_02_XIX_E3V_VLAN_Connect	Regen- / Lichtsensor			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea787a	LTM_StatusLichttastenmodul_XIX_LTMs_01_XIX_E3V_VLAN_Connect	Betriebszustand Lichttastenmodul			
0199b88b-6db6-7e7d-a158-acde71ef5166	LV_Blinker_VR_aktiv_XIX_Licht_vorne_01_XIX_E3V_VLAN_Connect	Blinker vorne links			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f0ff	LV_Tagfahrlicht_Anzeige_XIX_Licht_vorne_01_XIX_E3V_VLAN_Connect	Anzeige Tagfahrlicht			All Data, Dynamic Technical Data Campaigns
0199b88b-b83a-74d1-8d51-ff00e79fefd8	LWI_AgStgWhl	Output of steering angle. Output range is limited according to signal specification.			All Data, Dynamic Technical Data Campaigns
019a7124-a083-776f-b8ee-3b8ef6ea7861	MIK_OoP_Meldung_R1_FS_XIX_MIK_05_XIX_E3V_VLAN_Connect	Signal zur Aktivierung der HMI-Ausgabe bei Erkennung eines Out-of-Position Sitzszenarios fÃ¼r den Fahrer in der 1. SR			

0199b88b-c53f-718d-b010-636bf9b22c80	MO_Anzeige_Betriebsmodus_XIX_Motor_53_XIX_E3V_VLAN_Connect	Info an das Kombi zur Anzeige verschiedener Betriebsmodi			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1cbc	MO_Anzeige_Betriebsmodus_XIX_Motor_53_XIX_E3V_VLAN_Connect_1	Info an das Kombi zur Anzeige verschiedener Betriebsmodi			
019a61ac-1573-7a44-8b16-0b2939cb1cb0	MO_FoD_Performance_Switch_Status_XIX_Motor_54_XIX_E3V_VLAN_Connect	Status zum Wechsel des Performance upgrades			
0199b88b-bd69-7380-9f48-c027e3579442	MTHBFS_Pos2_XIX_TSG_HBFS_01_XIX_E3V_VLAN_Connect	BetÃ¤tigung Postionstaste 2 HBFS			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f15c	MTHFS_M_Taste_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	BetÃ¤tigung M-Taste HFS			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f180	MTHFS_Pos3_XIX_TSG_HFS_01_XIX_E3V_VLAN_Connect	BetÃ¤tigung Postionstaste 3 HFS			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1c99	Nav_FoD_Status_XIX_MainUnit_01_XIX_E3V_VLAN_Connect	FoD Status der Navigation			
0199b88b-b16d-77a2-8b45-d444aa727534	OBD_MIL_XIX_OBD_04_XIX_HCP5_CAN03	Ansteuerung der MIL			All Data, Dynamic Technical Data Campaigns

0199b88b-c540-7457-9d9f-4c3cbac6f112	OCU_Privacymode_Locationdata_XIX_TM_01_XIX_E3V_VLAN_Connect	Signal zur Ausgabe des speziellen Privacymode Status zur Ausleitung von Fahrzeugpositionsdaten. 0 = Init 1 = Ausgabe der Fahrzeugpositionsdaten ist erlaubt 2 = Ausgabe der Fahrzeugpositionsdaten ist untersagt			All Data, Dynamic Technical Data Campaigns
0199b88b-b16d-77a2-8b45-d444aa727537	ORU_Status_XIX_ORU_01_XIX_HCP5_CANFD02	Verteilung des internen ORU Zustandes			All Data, Dynamic Technical Data Campaigns
019add4e-9add-7cac-b101-e8fedadcef6b	OTP_Aussen_Temp_ungef_XIX_OTP_01_XIX_HCP4_CANFD01	ungefilterter Wert des Aussentemperatursensors			
019a7124-a083-776f-b8ee-3b8ef6ea78e7	PH_Opt_Anzeige_V_ein_XIX_Parkhilfe_01_XIX_E3V_VLAN_Connect	OPS vorne ist im Display aktiv bzw. Anzeigemodule vorne sind eingeschaltet. Funktion nur bei gesicherter RÃ¼ckmeldung vom ASG gegeben.			
019a7124-a083-776f-b8ee-3b8ef6ea7907	PH_Ton_Richtung_XIX_Parkhilfe_04_XIX_E3V_VLAN_Connect	Abspielrichtung des angeforderten Ton beim MIB3 durch die Parkhilfe			

0199b88b-bd69-7380-9f48-c027e35793ad	PH_Verschmutzungsmeldung_XIX_Parkhilfe_04_XIX_E3V_VLAN_Connect	Meldung einer Verschmutzung/Vereisung der PDC an das Kombi			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9f-7e8e-9943-76deb3fbbf0a	PSD_Strassenkategorie_XIX_PSD_04_XIX_E3V_VLAN_Connect	Klassifizierung der StraÃe des beschriebenen Segments			All Data, Dynamic Technical Data Campaigns
0199b88b-6db6-7e7d-a158-acde71ef5136	RS_Regenfahrlicht_XIX_RLS_02_XIX_E3V_VLAN_Connect	Regenlicht Anforderung			All Data, Dynamic Technical Data Campaigns
0199b88b-c53f-718d-b010-636bf9b22c92	SP_BT_oben_XIX_Spiegel_01_XIX_E3V_VLAN_Connect	Spiegel BeifahrertÃ¼r nach oben			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f1ad	SP_BT_unten_XIX_Spiegel_01_XIX_E3V_VLAN_Connect	Spiegel BeifahrertÃ¼r nach unten			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f155	SP_FT_links_XIX_Spiegel_01_XIX_E3V_VLAN_Connect	Spiegel FahrertÃ¼r nach links			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1cb2	SWA_SDA_Abstand_Spur_E2_XIX_SWA_SDA_01_XIX_E3V_VLAN_Connect	Abstand zum 2. Fahrzeug auf der Ego Spur ausgehend von Ego Fahrzeug			

019a61ac-1573-7a44-8b16-0b2939cb1ca3	TA_FoD_Status_XIX_TA_01_XIX_E3V_VLAN_Connect	TAwird durch FoD geschÃ¼tzt sein und so reicht die PR/Zieldatencontainer basierte Codierung nicht mehr aus. Aus diesem Grund brauch wir ein separates Signal, dass uns den Freischaltezustand mitteilt.			
019a7124-a083-776f-b8ee-3b8ef6ea78ba	TPMS_CalTyp_XIX_RDK_11_XIX_E3V_VLAN_Connect	Specification type of target pressure			
019a7124-a083-776f-b8ee-3b8ef6ea78cc	TPMS_PDeFrLe_XIX_RDK_11_XIX_E3V_VLAN_Connect	Pressure deviation between actual and set pressure front left, normalized to 20Â°C			
019a7124-a083-776f-b8ee-3b8ef6ea78a8	TPMS_PDeFrRi_XIX_RDK_11_XIX_E3V_VLAN_Connect	Pressure deviation between actual and set pressure front right, normalized to 20Â°C			
019a7124-a083-776f-b8ee-3b8ef6ea78ad	TPMS_SensPFrLe_XIX_RDK_11_XIX_E3V_VLAN_Connect	Sensor measured pressure (tire pressure uncompensated) front left			
019a7124-a083-776f-b8ee-3b8ef6ea78d0	TPMS_SensPFrRi_XIX_RDK_11_XIX_E3V_VLAN_Connect	Sensor measured pressure (tire pressure uncompensated) front right			

019a7124-a083-776f-b8ee-3b8ef6ea78ab	TPMS_SensPReRi_XIX_RDK_11_XIX_E3V_VLAN_Connect	Sensor measured pressure (tire pressure uncompensated) rear right			
019a7124-a083-776f-b8ee-3b8ef6ea78b0	TPMS_SensTypReLe_XIX_RDK_11_XIX_E3V_VLAN_Connect	TPM sensor type rear left			
019a7124-a083-776f-b8ee-3b8ef6ea78c1	TPMS_SensTypReRi_XIX_RDK_11_XIX_E3V_VLAN_Connect	TPM sensor type rear right			
019a7124-a083-776f-b8ee-3b8ef6ea78b1	TPMS_TarPTmpDepFrLe_XIX_RDK_11_XIX_E3V_VLAN_Connect	Temperature dependent target pressure front left			
019a7124-a083-776f-b8ee-3b8ef6ea78d1	TPMS_TarPTmpDepReLe_XIX_RDK_11_XIX_E3V_VLAN_Connect	Temperature dependent target pressure rear left			
019a7124-a083-776f-b8ee-3b8ef6ea78c9	TPMS_Warn1_XIX_RDK_11_XIX_E3V_VLAN_Connect	General Warning Level 1			
019a7124-a083-776f-b8ee-3b8ef6ea78c8	TPMS_Warn3TireReRi_XIX_RDK_11_XIX_E3V_VLAN_Connect	Stage 3 warning for right rear tire			
019a7124-a083-776f-b8ee-3b8ef6ea78d3	TPMS_WarnCalOk_XIX_RDK_11_XIX_E3V_VLAN_Connect	Text output for correct calibration (only necessary for switch calibration)			
019a7124-a083-776f-b8ee-3b8ef6ea78ca	TPMS_WarnFltIdc_XIX_RDK_11_XIX_E3V_VLAN_Connect	Warning when the TPMS is in fault			
019a7124-a083-776f-b8ee-3b8ef6ea78c5	TPMS_WhlChgDetFrRi_XIX_RDK_11_XIX_E3V_VLAN_Connect	Wheel change front right detected			

019b0b9c-4285-7b1f-9f3b-3242edfe7850	TSK_Limiter_ausgewaehlt_XIX_Motor_51_Auth_XIX_E3V_VLAN_Connect	ACC/GRA-Betrieb nur bei nicht ausgewÃ¤hltem Limiter mÃ¶glich			
019a7124-a083-776f-b8ee-3b8ef6ea7896	TSK_praed_Wunschgeschw_XIX_Motor_53_XIX_E3V_VLAN_Connect	Zur Anzeige der prÃ¤diktiven Wunschgeschwindigkeit von GRA/Speedlimiter im Kombiinstrument			
0199b88b-ade0-704f-9ab6-916f1b71be57	VDSO_Vx3dKmph_XIX_VDSO_05_XIX_HCP5_CAN03	Longitudinal velocity estimated at the centre of rear axle. Estimation requires 3D IMU.			All Data, Dynamic Technical Data Campaigns
019add4e-9add-7cac-b101-e8fedadcef6a	VDSO_Vx3d_XIX_VDSO_05_XIX_HCP5_CAN03	Geschwindigkeitssignal vom ABS/ASR oder ESP. Mittelwert der angetriebenen RÃ¤der. Bei MSR oder ABS Eingriffen wird die ABS-Referenzgeschwindigkeit fÃ¼r >= 200ms eingespiegelt (Zeit wird mit Aktiv-Flanke der Funktionsbits getriggert) MQB: Bei Frontantrieb und gesteuertem Allrad (Haldex) Mittelwert der VorderrÃ¤der.			

0199b88b-c540-7457-9d9f-4c3cbac6f14f	VZE_Anhaenger_Vmax_XIX_VZE_04_XIX_E3V_VLAN_Connect	Ãbertragung der aus Kundeneinstellung und lÃ¤nderspezifischen Regelungen (StVO, Rechtsprechung...) berechneten legalen HÃ¶chstgeschwindigkeit fÃ¼r das Gespann. 10+ 0*10 = 10 km/h 10+ 1*10 = 20 km/h ... 10+ 5*10 = 60 km/h 10+ 6*10 = 70 km/h ... 10+ 13*10 = 140 km/h			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9f-7e8e-9943-76deb3fbbeff	VZE_Anzeige_VZ_3_XIX_VZE_04_XIX_E3V_VLAN_Connect	Das Signal spiegelt eines der Verkehrszeichen: Geschwindigkeitsgebot, Ãberholverbot, Aufhebungszeichen wider. Wertebereich lt. Hashtabelle			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9f-7e8e-9943-76deb3fbbf01	VZE_Tempowarnung_Status_XIX_VZE_04_XIX_E3V_VLAN_Connect	0 - Tempowarnung aktiv 1 - Tempowarnung desktiv			All Data, Dynamic Technical Data Campaigns

0199b88b-6db6-7e7d-a158-acde71ef512b	WH_Heckwaschen_XIX_SMLS_01_XIX_E3V_VLAN_Connect	Wischerhebel: Stellung Wisch Wasch hinten			All Data, Dynamic Technical Data Campaigns
0199b88b-6db6-7e7d-a158-acde71ef5134	WH_Intervallstufen_XIX_SMLS_01_XIX_E3V_VLAN_Connect	Wischerhebel: Stellung Intervallstufen			All Data, Dynamic Technical Data Campaigns
0199b88b-6db6-7e7d-a158-acde71ef5125	WH_SRA_XIX_SMLS_01_XIX_E3V_VLAN_Connect	Scheinwerferreinigungsanlage derzeit nur bei PAG umgesetzt			All Data, Dynamic Technical Data Campaigns
0199b88b-6db6-7e7d-a158-acde71ef5140	WH_Tipwischen_XIX_SMLS_01_XIX_E3V_VLAN_Connect	Wischerhebel: Tippwischen MQB A0/ PQ26: Bei Verbau LSS (kein SMLS): gespiegelter Wert zu Signal WH_WischerStufe1			All Data, Dynamic Technical Data Campaigns
0199b88b-c540-7457-9d9f-4c3cbac6f14e	Wischer_vorne_defekt_XIX_Wischer_01_XIX_E3V_VLAN_Connect	Fehlerstatus Wischer vorne (Anzeige im Kombi)			All Data, Dynamic Technical Data Campaigns
019a61ac-1573-7a44-8b16-0b2939cb1c9a	ZM_HV_Auszeit_Status_XIX_ZeitMaster_01_XIX_E3V_VLAN_Connect	Status HV-Auszeit			
019a1992-cd99-7f6b-8acf-1a1955a6f4e8	ZV_LadeklappenStatus_XIX_SAM_01_XIX_E3V_VLAN_Connect	Gibt den Staus der Ladeklappe aus			

0199b88b-c540-7457-9d9f-4c3cbac6f1f0	ZV_Oeffnungsmodus_XIX_ZV_02_XIX_E3V_VLAN_Connect	Konfigurierter Oeffnungsmodus fuer ZV: 0 = globale Oeffnung (alle Tueren) 1 = ZV mit Einzeltuerentriegelung (FFB - nur Fahrertuer, Kessy - nur bediente Tuer) 2 = ZV individuell selektive Oeffnung (FFB - Fahrerseite, Kessy - bediente Tuer + Fahrertuer) 3 = ZV seitenselektive Oeffnung			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9f-7e8e-9943-76deb3fbbe2b	cso_v1_drivingenvironment_outdoorTemperature_subscribe	This topic contains the outdoor temperature in Kelvin			All Data, Dynamic Technical Data Campaigns
0199b88a-3c9e-7f41-ac22-d009bf607e57	cso_v1_vehicle_tripstatistics_total_mileage_subscribe	This topic contains the total traveled distance of the vehicle in km.			All Data, Dynamic Technical Data Campaigns
0199b88a-7c25-7d2b-96f6-64981efcc467	viwi_CallServices_2.0.0_get_basicServiceInfo	Provides basic information about this Service, like signal quality and provider names.			All Data, Dynamic Technical Data Campaigns