# S7 Troubleshooting Guide

## Error codes E1–E3

**E1 — Wheel stuck.** Turn the robot over and remove hair or debris from both drive wheels.

**E2 — Cliff sensor blocked.** Wipe the four cliff sensors on the underside with a dry cloth.

**E3 — Side brush jammed.** Remove the side brush and clear tangled hair.

## Error codes E4–E7

**E4 — Battery too low to return to dock.** Place the robot on the dock manually.

**E5 — Dustbin missing.** Reinsert the dustbin until it clicks.

**E7 — Wi-Fi connection failed.** Make sure the router broadcasts a 2.4 GHz network, restart the router, then pair the robot again.

## Robot is not charging

Clean the charging contacts on the robot and the dock with a dry cloth. The dock needs 0.5 m of clear space on each side and 1.5 m in front of it.