S7 Troubleshooting Guide

Error codes E1-E3

E1 — Wheel stuck. Turn the robot over and remove hair or debris from both drive wheels.

E2 — Cliff sensor blocked. Wipe the four cliff sensors on the underside with a dry cloth.

E3 — Side brush jammed. Remove the side brush and clear tangled hair.

Error codes E4-E7

E4 — Battery too low to return to dock. Place the robot on the dock manually.

E5 — Dustbin missing. Reinsert the dustbin until it clicks.

E7 — Wi-Fi connection failed. Make sure the router broadcasts a 2.4 GHz network, restart the router, then pair the robot again.

Robot is not charging

Clean the charging contacts on the robot and the dock with a dry cloth. The dock needs 0.5 m of clear space on each side and 1.5 m in front of it.