

- . Changing SYSFS to ATTRS
- Changing BUS to SUBSYSTEM
- Changing \$TEMPNODE to \$tempnode

A copy of the fixed xusbdfwu.rules is below; you can just copy this over the installed values and then reload the udev rules with udevadm control --reload-rules

```
# version 0003
ATTRS{idVendor}=="03fd", ATTRS{idProduct}=="0008", MODE="666"
SUBSYSTEM=="usb", ACTION=="add", ATTRS{idVendor}=="03fd", ATTRS{idProduct}=="0
SUBSYSTEM=="usb", ACTION=="add", ATTRS{idVendor}=="03fd", ATTRS{idProduct}=="0
SUBSYSTEM=="usb", ACTION=="add", ATTRS{idVendor}=="03fd", ATTRS{idProduct}=="0
SUBSYSTEM == "usb", \ ACTION == "add", \ ATTRS \{idVendor\} == "03fd", \ ATTRS \{idProduct\} ==
SUBSYSTEM=="usb", ACTION=="add", ATTRS{idVendor}=="03fd", ATTRS{idProduct}=="0
SUBSYSTEM=="usb", ACTION=="add", ATTRS{idVendor}=="03fd", ATTRS{idProduct}=="0
```

1 of 2 03/08/2015 07:03 PM After all that, you should then plug in your Xilinx Platform Cable USB and the "Connector Signals" / "Status" light in the top right hand corner should turn red indicating the fxload command worked. If this light is **not** red then something has gone wrong and probably fxload was not able to load the firmware.

© 2015 GitHub, Inc. Terms Privacy Security Contact

()

Status API Training Shop Blog About

2 of 2 03/08/2015 07:03 PM