
ezDV

User's Guide

Mooneer Salem

2024-03-17

Contents

1	Introduction	4
2	Setting up ezDV	4
2.1	Initial assembly	4
2.2	Radio wiring	7
2.2.1	Radios without Wi-Fi support	7
2.2.2	Radios with Wi-Fi support	7
Flex 6000 series radios	7	
Icom IC-705	7	
2.3	Initial configuration	7
2.3.1	Transmit audio levels	9
Flex 6000 series	9	
Other radios	9	
2.3.2	Wi-Fi configuration	11
2.3.3	Radio connection	12
Flex 6000 series	12	
Icom IC-705	12	
2.3.4	Reporting configuration	13
2.3.5	Final setup	14
3	Basic usage	17
3.1	External controls	17
3.2	Powering ezDV on and off	18
3.3	FreeDV operation	19
3.4	Radio setup and usage	19
3.4.1	Flex 6000 series	19
3.4.2	Others	20
3.5	Volume controls	20
3.6	Voice keyer	20
3.7	Summary of controls	20
4	Using the web interface	21
4.1	Accessing the web interface	21
4.2	Changing FreeDV mode	22
4.3	Changing LED brightness	23
4.4	Using and configuring the voice keyer	23
4.5	Reporting to FreeDV Reporter	25

4.6 Configuring Wi-Fi	27
4.7 Configuring radio connection and headset	28
4.8 Updating firmware	31
4.9 Rebooting ezDV	31
5 Appendix: Configuring Wi-Fi on the Icom IC-705	32
5.1 Using the IC-705's built-in access point	35
5.2 Connecting the IC-705 to an existing network	36
5.3 Configuring the Radio User	41
5.4 Configuring Audio	44
6 Example Wiring Configurations	48
6.1 Elecraft KX3	48

1 Introduction

ezDV is a handheld hardware device that allows easy use of FreeDV, whether on the go or at home. Powered by an ESP32-S3 microcontroller, its built-in Wi-Fi support allows completely wireless setup (with supported radios) along with enabling more modern functionality such as FreeDV Reporter reporting and wireless firmware updates.

For those radios without network capability, interfacing them with ezDV is straightforward through the use of the industry standard 3.5mm TRRS audio jack. This jack is configured similarly to what is used with wired headsets for mobile phones. Analog audio is also passed in and out from/to your wired headset using a second 3.5mm audio jack.

This document describes the configuration and recommended usage of the ezDV device for maximum enjoyment and minimal frustration. Hope to hear you on the air!

2 Setting up ezDV

There are several steps required to get ezDV up and running with your radio.

2.1 Initial assembly

If ezDV did not already come with a battery, you will need to obtain a 3.7V lithium polymer (LiPo) battery. One recommended battery can be purchased from Amazon.

WARNING: Do not puncture or otherwise damage lithium batteries as injury and/or property damage could result! Neither the project nor its creator take responsibility for any damage or injury due to misuse of batteries. A battery with a protection module (such as the one linked above) is highly recommended.

The battery should be plugged into the BT1 connector on the bottom of the ezDV circuit board, which is the circled connector below:




Figure 1: The back of the ezDV circuit board with BT1 circled

Once a battery is attached, you should flip the switch to the right of the BT1 connector upwards (towards the back of the ezDV board) to connect the battery to the rest of the board. This switch is designed to allow for long-term storage or shipping of ezDV without discharging the battery. Note that ezDV may power on immediately after flipping this switch; you can power it down by pushing and holding the Mode button (second button from the top when looking downward) until red lights turn on on the

right-hand side.

Note: it is not recommended to use this switch for normal operation of ezDV. Some features require an orderly shutdown of ezDV (which is accomplished by using the Mode button) and may not function properly if power is suddenly lost.

Next, plug ezDV into a USB-C charger (similar to what would be done to charge a cell phone or portable power bank). A red LED may light on the bottom of ezDV indicating that the battery is charging as well as some or all of the LEDs on the right hand side (indicating its current state of charge in 25% increments). When ezDV is done charging, a green LED will turn on and the red LED will turn off. This may take several hours or more depending on the state of the battery.

Finally, plug in a wired headset on the TRRS jack located on the right side of the ezDV board (when looking from above). This headset should be wired for compatibility with Android phones, which is as follows:

- Tip: RX audio from ezDV
- Ring 1: RX audio from ezDV
- Ring 2: GND
- Shield: TX microphone audio to ezDV

Once attached, ezDV will appear as follows:




Figure 2: ezDV with headset attached

2.2 Radio wiring

2.2.1 Radios without Wi-Fi support

Radios without Wi-Fi support will need an interface cable. One end of this cable should be a male 3.5mm four conductor (TRRS) with the following pinout:

- Tip: TX audio from ezDV to your radio
- Ring 1: PTT to radio (this is connected to GND when you push the PTT button)
- Ring 2: GND
- Shield: RX audio from your radio to ezDV

There is also silkscreen labeling on the back of the board corresponding to the location of the radio jack that indicates the pinout. This jack is on the left hand side of ezDV when looking downward at the front of the device.

More information on example wiring configurations for various radios can be found in the “Example Wiring Configurations” section.

2.2.2 Radios with Wi-Fi support

If you have a radio that is capable of remote network access, you can configure ezDV to connect to the radio over Wi-Fi. Currently this is supported only for the FlexRadio 6000 series radios and the Icom IC-705.

Flex 6000 series radios Ensure that you can access your radio using the SmartSDR software from a PC on the same network (i.e. *not* using SmartLink). Once this is confirmed, skip to Initial Configuration.

Icom IC-705 Several settings will need to be adjusted in the IC-705 before it can be used with ezDV. See “Configuring Wi-Fi on the Icom IC-705” or your radio’s user manual for more information on configuring Wi-Fi.

2.3 Initial configuration

To perform initial configuration of ezDV, push and hold both the Mode and Volume Down buttons at the same time until all four of the LEDs on the right hand side of ezDV turn on.




Figure 3: ezDV showing the buttons to push and hold (red circles) and the location of the LEDs (pink circle)

Once the LEDs turn off, go to your PC or cell phone's Wi-Fi configuration and join a network named "ezDV xxxx", where "xxxx" is the last few alphanumeric digits of its MAC address (a unique identifier for each network device). Once joined, open your Web browser and navigate to <http://192.168.4.1/>. You

should see a page similar to the following:




Figure 4: Screenshot showing ezDV's main Web page

2.3.1 Transmit audio levels

Flex 6000 series ezDV uses a hardcoded transmit level when connected to the Flex 6000 series of radios, so adjusting the transmit level on ezDV has no effect.

Other radios *Note: for the Icom IC-705, this can only be done after configuring Wi-Fi and the radio connection.*

ezDV's transmit audio levels will need to be adjusted to ensure that your radio does not indicate too much ALC, similar to other HF digital modes. You can adjust the transmit audio by pushing the Volume Up or Volume Down buttons while holding the PTT button as indicated below:




Figure 5: ezDV showing the PTT button (red circle) and the Volume Up/Down buttons (pink circle)

For most radios, ezDV's transmit level should be such that little to no ALC is indicated on the radio display. The specific ALC level required depends on the radio, so your radio's user manual is the best


source for determining this. Alternatively, you can increase the TX audio level until your power output stops increasing, then decrease it again until your power output begins to decrease.

Note: it's recommended to have your radio attached to a dummy load while adjusting your transmit audio levels to prevent interference to other operators.

2.3.2 Wi-Fi configuration

Note: this is optional unless you are using a radio with Wi-Fi support or wish to use other Internet connected features (such as reporting to FreeDV Reporter).

Click or tap on the “Wi-Fi” tab and check the “Enable Wi-Fi” checkbox. You’ll see something similar to the following:



The screenshot shows the Wi-Fi configuration page of the ezDV software. At the top, there is a navigation bar with tabs: General, Reporting, Voice Keyer, Wi-Fi (which is selected and highlighted in blue), Radio, and Firmware Update. Below the tabs, there is a checked checkbox labeled "Enable Wi-Fi". A note below the checkbox states: "(Note: you can always return here even if disabled by holding down Volume Down while turning on ezDV.)". The main configuration area contains the following fields:

Hostname	ezdv-flex-6300
Wireless Mode	Client
Network Name	(Redacted)
SSID	(Redacted)
Security Type	Open
Channel	1
Password

At the bottom of the form are two buttons: a green "Save" button and a red "Reset" button.

Figure 6: ezDV showing the Wi-Fi tab

To connect ezDV to the network that your radio is on, select “Client” for “Wireless Mode”. Select your Wi-Fi network from the list that appears (which may take a few seconds while ezDV scans for your


network) and enter its password (if required). If desired, you can also change ezDV's name by modifying the "Hostname" field; this may allow you to access ezDV later by entering this name instead of trying to find its IP address. Click or tap Save to save your Wi-Fi settings.

2.3.3 Radio connection

Note: this is optional unless you are using a radio with Wi-Fi support.

Click on the "Radio" tab and check the "Use Wi-Fi Network for Radio RX/TX" checkbox. Select your radio model in the "Radio Type" drop-down list, which will bring up different fields depending on the radio being configured.

Flex 6000 series Select the name of your radio from the "Radio" drop-down list as shown below. Your radio's IP address should automatically be filled in the "IP Address" field:



The screenshot shows the ezDV configuration interface with the "Radio" tab selected. The "Radio Type" dropdown is set to "Flex 6000 series". The "IP Address" field contains "10.0.1.111". Below the form are two buttons: "Save" (green) and "Reset" (red).

General	Reporting	Voice Keyer	Wi-Fi	Radio	Firmware Update
<input checked="" type="checkbox"/> Enable PTT using headset button					
Time Out Timer (seconds):		120			
<input checked="" type="checkbox"/> Use Wi-Fi Network for Radio RX/TX					
Radio Type	Flex 6000 series				
Radio	FLEX-6300 (K6AQ)				
IP Address	10.0.1.111				
			Save	Reset	

Figure 7: ezDV showing a FlexRadio configuration

Click or tap Save to save the radio configuration.

Icom IC-705 Enter your radio's IP address, username and password that you saved when you configured Wi-Fi on the IC-705:

Enable PTT using headset button

Time Out Timer (seconds):

Use Wi-Fi Network for Radio RX/TX

Radio Type	<input type="text" value="Icom (e.g. IC-705)"/>
IP Address	<input type="text" value="10.0.1.111"/>
Port	<input type="text" value="50001"/>
Username	<input type="text"/>
Password	<input type="text"/>

Save Reset

Figure 8: ezDV showing a Icom IC-705 configuration


Click or tap Save to save the radio configuration.

2.3.4 Reporting configuration

It is highly recommended to configure your callsign and grid square. This has several benefits:

1. If ezDV is lost or stolen, someone can access its Web page and use callsign databases like QRZ to find a way to get it back to you.
2. Other users will be able to decode your callsign and report spots on FreeDV Reporter.
3. If ezDV has Internet access, it will also be able to decode callsigns from received signals and report them itself to FreeDV Reporter.

To do this, click or tap on the “Reporting” tab and enter your callsign and grid square where prompted:



The screenshot shows the 'Reporting' tab selected in the ezDV software interface. The 'General' tab is also visible. The configuration fields are:

- Your callsign: K6AQ
- Grid square/locator: DM12kw
- Message: (empty field)

Figure 9: ezDV showing a sample reporting configuration

If desired, you can also enter a short message that will appear on FreeDV Reporter. This message is transmitted solely over the Internet, not over RF.

Once done, click or tap Save to save the reporting configuration.

2.3.5 Final setup

After your radio, Wi-Fi and reporting configuration are complete, simply click or tap on the General tab and then click or tap on the Reboot button. ezDV will first show two red LEDs on the right hand side for a few seconds, then show all four LEDs for a few seconds, then turn them all off. If you're using a wired connection to ezDV, it is now ready for use.

If you configured a Wi-Fi network and radio for ezDV to connect to, ezDV should then begin blinking a blue LED (indicating that it is connected to the Wi-Fi network) followed by showing a solid blue LED if it's able to connect to the radio. On the IC-705, a WLAN indicator will appear if ezDV is connected to the radio as shown below:



Figure 10: Icom IC-705 properly connected to ezDV (WLAN indicator at the top of the screen)

For Flex 6000 series radios, opening the SmartSDR software will show a “FDVU” (for upper sideband) and “FDVL” (for lower sideband) if ezDV is properly connected to the radio:




Figure 11: Flex 6300 properly connected to ezDV (existence of FDVU/FDVL modes)

3 Basic usage

3.1 External controls

ezDV has four buttons on the left, in order from top to bottom:

- Push To Talk (PTT)
- Mode
- Volume Up
- Volume Down

as well as four status LEDs on the right hand side (again from top to bottom):

- PTT (red; on if transmitting)
- Sync (green; on if ezDV can decode an incoming FreeDV signal)
- Overload (red; on if the incoming RX/TX audio is clipping)
- Network (blue; will blink if it has a network connection and will be solid if connected to the radio)

These controls and LEDs are shown below:



Figure 12: ezDV button and LED locations

3.2 Powering ezDV on and off

To turn on ezDV, press and hold the Mode button for ≥ 1 second. All four LEDs on the right hand side of the board should light briefly and then extinguish. You will also hear the last used mode in Morse Code on your wired headset or through SmartSDR if using a Flex radio. (On first start, this will be “700D”, which corresponds to FreeDV 700D mode.) Holding this button again for ≥ 1 second will result in ezDV turning off (with “73” also being piped through the headset in Morse Code, corresponding to the

well-known ham radio term for “goodbye”).

If Wi-Fi is enabled on ezDV, you will additionally hear the letter “N” emitted in Morse Code once the network interface comes up. If ezDV is configured to connect to an existing wireless network, you will hear the last octet of the IP address immediately afterward. For example, if your router assigns the IP address “192.168.1.100” to ezDV, you will hear “N100” in the headset.

Note: if your wireless network is configured with a “netmask” other than “255.255.255.0”, you may need to load your router’s configuration to obtain the rest of ezDV’s IP address. Otherwise, you can typically replace the last octet of your computer’s IP address with the number after the “N” when accessing ezDV with a web browser.

3.3 FreeDV operation

Pushing the Mode button briefly while in receive will cycle through the following modes:

- FreeDV 700D (“700D” will beep in Morse code)
- FreeDV 700E (“700E” will beep in Morse code)
- FreeDV 1600 (“1600” will beep in Morse code)
- Analog passthrough (“ANA” will beep in Morse code)

The current FreeDV mode can also be adjusted using ezDV’s web interface if preferred. See “Using the web interface” for more information.

Pressing and holding the PTT button will place the radio into transmit mode and transmit a FreeDV signal out over the air (or your voice verbatim if you are in analog passthrough mode). If configured, you can also use the call button on your wired headset to place the radio into transmit; pushing and releasing the call button will toggle between transmit and receive.

3.4 Radio setup and usage

3.4.1 Flex 6000 series

To use ezDV, simply start the SmartSDR software on your PC or iPad and select either FDVU mode (for upper sideband) or FDVL (for lower sideband). Decoded audio as well as Morse code beeps will be output to your speaker. Use the MOX button in SmartSDR (or the PTT button on a microphone attached to the radio) to transmit, similar to when operating the other voice modes.

3.4.2 Others

If your radio has a “data” mode, it’s recommended to enable this while using ezDV (or any FreeDV application or device). This typically disables any processing the radio would normally do for SSB voice, preventing the signal from being garbled. Please see your radio’s user manual for information about how to enable this mode.

3.5 Volume controls

The Volume Up and Down buttons adjust the receive audio by default. If the PTT button is also held while pushing Volume Up or Volume Down, the transmit audio level is adjusted instead. For best results, transmit audio should be adjusted while in 700D/700E/1600 mode such that the ALC indicator on your radio is just barely showing (similar to how to configure data modes).

3.6 Voice keyer

If configured, you can activate ezDV’s voice keyer functionality by holding down PTT and then pressing the Mode button. ezDV will then load the voice keyer file in its internal storage and play it back up to the number of times configured (with it pausing a configured number of seconds). By default, ezDV is configured to transmit the voice keyer file up to ten times, pausing for five seconds in between each transmission.

While the voice keyer is active, pressing any button on ezDV will stop the voice keyer and place it back into regular operation. If using a Flex 6000 series radio, you can also stop the voice keyer by pushing the MOX button in SmartSDR

Configuration of the voice keyer functionality (as well as stopping and starting of the voice keyer) can also be done via ezDV’s web interface. See “Using the web interface” for more information.

3.7 Summary of controls

Button	Action	Also pressed	ezDV behavior
PTT	Hold	(none)	Places radio into transmit and outputs FreeDV signal/analog audio.
	Hold	Mode	If voice keyer configured, activates voice keyer. Otherwise, cycles between FreeDV modes.

Also			
Button	Action	pressed	ezDV behavior
	Hold	Volume Up	Increases transmit audio level.
	Hold	Volume Down	Decreases transmit audio level.
Mode	Press	(none)	Cycles between available FreeDV modes and analog passthrough.
	Hold*	(none)	Powers up or shuts down ezDV.
	Hold*	PTT	When off, powers up ezDV in Hardware Test Mode (see Troubleshooting).
	Hold*	Volume Down	When off, powers up ezDV with default Wi-Fi settings (see “Using the web interface”).
Volume Up	Press/Hold	(none)	Increases ezDV volume through headset.
Volume Down	Press/Hold	(none)	Decreases ezDV volume through headset.

* Must be held for at least one second.

4 Using the web interface

ezDV provides a web interface to allow users to adjust its configuration and operate some of its features. When Wi-Fi is enabled on ezDV, this interface is accessible through a regular web browser (such as Google Chrome or Microsoft Edge).

4.1 Accessing the web interface

By default, Wi-Fi on ezDV is disabled for security reasons. To enable it (or recover from a bad configuration), hold down the Mode and Volume Down buttons until ezDV turns on. This will cause ezDV to create an access point named “ezDV” followed by the last two octets of its MAC address. From there, you can connect your PC or mobile device to that network and open <http://192.168.4.1/> in your web browser.

If ezDV is configured to connect to an existing Wi-Fi network, you can open a web browser on a PC or mobile device connected to the same network as ezDV and enter ezDV's IP address into the browser's location box. This IP address can typically be found in your router's listing of connected devices; ezDV will also beep the letter "N" followed by the last octet of the IP address when it connects to the network (for example, "N100" for "192.168.1.100").

Alternatively, depending on your router, you can also use the configured hostname in your browser instead. By default, ezDV's hostname is "ezdv", which means that you can enter <http://ezdv/> instead of its IP address.

Regardless of how you access ezDV's web interface, you should see a page similar to the below:




Figure 13: Screenshot showing ezDV's main Web page

From here, you can choose one of several tabs:

- General: Contains miscellaneous ezDV configuration options.
- Reporting: Configures and operates the FreeDV Reporter reporting feature.
- Voice Keyer: Configures ezDV's voice keyer feature.
- Wi-Fi: Configures how ezDV connects to Wi-Fi.
- Radio: Configures how ezDV connects to your network-enabled radio.
- Firmware Update: Allows the user to perform a firmware update on ezDV.

4.2 Changing FreeDV mode

The web interface provides the ability to change the current FreeDV mode, similar to when pushing the Mode button on the top of ezDV. To change the current FreeDV mode, simply push one of the mode buttons in the General tab:



Figure 14: ezDV mode buttons on web interface

Once pushed, ezDV will behave identically as if the mode was switched using the Mode button, including beeping the current mode in Morse Code through the wired headset.

4.3 Changing LED brightness

ezDV allows you to change the brightness of the LEDs on the front of the device. This can make ezDV more comfortable to use at night (for example). This can be done by going to the General tab and moving the LED Brightness slider:



Figure 15: ezDV LED Brightness slider

Changes to the LED Brightness slider take effect immediately and are preserved, so it's not necessary to readjust every time ezDV is powered off and then on again.

4.4 Using and configuring the voice keyer

To activate and deactivate the voice keyer, you can push the Voice Keyer button in the General tab. When active, the Voice Keyer button will turn red as shown below:



Figure 16: Voice Keyer button when active

Pushing the button again will turn off the voice keyer:




Figure 17: Voice Keyer button when not active

If the voice keyer feature is disabled, the Voice Keyer button will be grayed out. In order to configure the voice keyer, you will need to go into the Voice Keyer tab:

The screenshot shows the "Voice Keyer" tab selected from a horizontal menu. Below the menu, there is a checked checkbox labeled "Enable voice keyer". Underneath this, there are three input fields: "Voice keyer file" with a "Choose File" button and a "No file chosen" message; "Number of times to transmit" with the value "10"; and "Number of seconds to wait after transmit" with the value "10". At the bottom are two buttons: a green "Save" button and a red "Reset" button.

Figure 18: Voice Keyer tab for configuration

The following can be set here to enable the voice keyer feature:

Setting	Description
Enable voice keyer	When checked, this enables use of the voice keyer. The Voice Keyer button in the General tab will be allowed to be pushed, as well as be able to be activated by pushing on the Mode button on the front of ezDV while holding down PTT.

Setting	Description
Voice keyer file	Allows uploading of a new voice keyer file. Optional if one has already been uploaded to ezDV. Note: ezDV requires a WAV file encoded with a sample rate of 8000 Hz and containing only one audio channel. If a file is uploaded that does not meet these requirements, ezDV will reject the upload.
Number of times to transmit	The number of times that ezDV will transmit the voice keyer file before it disables the voice keyer. You can also disable the voice keyer early by pushing on the Voice Keyer button or pushing on any of the physical buttons on the front of ezDV.
Number of seconds to wait after transmit	The number of seconds to wait after transmitting the voice keyer file before starting another transmit cycle.

Pushing Save will immediately update the voice keyer configuration and enable its use if desired.

4.5 Reporting to FreeDV Reporter

ezDV has the ability to report its current state to the FreeDV Reporter spotting service. Operation of this feature can be done through the Reporting tab:

General	Reporting	Voice Keyer	Wi-Fi	Radio	Firmware Update
Your callsign	K6AQ				
Grid square/locator	DM12kw				
Message	pre-1.0.2 FW testing				
<input type="checkbox"/> Force reporting without radio connection					
Current frequency (MHz)	14.2360				
<input style="background-color: #2e7131; color: white; border-radius: 5px; padding: 5px; margin-right: 10px;" type="button" value="Save"/> <input style="background-color: #dc3545; color: white; border-radius: 5px; padding: 5px;" type="button" value="Reset"/>					

Figure 19: Example of a reporting configuration on ezDV

When configured with a callsign and grid square, ezDV will automatically connect to FreeDV Reporter if it has access to an internet connection and is able to connect to a supported radio over Wi-Fi. You can also force a connection to FreeDV Reporter for radios without Wi-Fi support by checking the “Force reporting without radio connection” checkbox and manually entering the current frequency.

Once connected to FreeDV Reporter, a new row will appear corresponding to your connection:

K5WH	EL29fx	ezDV 1.0.2-20240317	28.3300 MHz	Receiving	Testing EzDV 1.0.2	700D	3/17/2024 10:58:27 AM	--	--	--	3/17/2024 11:29:48 AM
------	--------	---------------------	-------------	-----------	--------------------	------	-----------------------	----	----	----	-----------------------

Figure 20: Example of an entry on FreeDV Reporter

If ezDV is able to decode a callsign from a received signal, it will transmit the received callsign and SNR to FreeDV Reporter. Your row will then update to indicate the received callsign, SNR and mode as well as highlight your row in a blue background for several seconds to alert others that you’re receiving a signal. When ezDV is transmitting, FreeDV Reporter will also highlight your row with a red background to indicate to others that you’re transmitting.

With radios that support connections over Wi-Fi, ezDV will also follow frequency changes on the radio and report them to FreeDV Reporter. FreeDV Reporter will then indicate your current frequency, allowing others to change to your frequency and potentially make a contact with you. Manual frequency updates (for those radios attached to ezDV with a wired connection) will also be sent to FreeDV Reporter as they’re made.

The following can be updated in the Reporting tab to operate FreeDV Reporter reporting:


Setting	Description
Your callsign	The callsign to report to FreeDV Reporter. This callsign is also transmitted as part of your FreeDV signal so that others can report receipt of your signal.
Grid square/locator	The 4-6 digit grid square to report to FreeDV Reporter. You can use a service such as this to calculate your grid square if not known. <i>Note: Clearing this field disables FreeDV Reporter reporting.</i>
Message	A short message to display on the FreeDV Reporter website next to your callsign. This is transmitted solely on the internet, not over RF.
Force reporting without radio connection	When checked, ezDV will connect to FreeDV Reporter even without a valid radio configuration.

Setting	Description
Current frequency (MHz)	When “Force reporting without radio connection” is checked, ezDV will transmit this frequency to FreeDV Reporter as your current frequency.

Pushing Save will immediately connect or disconnect to FreeDV Reporter (as desired/required) as well as transmit updates to the current frequency or short message.

4.6 Configuring Wi-Fi

The Wi-Fi tab allows configuration of ezDV’s Wi-Fi connection:



The image shows the Wi-Fi configuration screen of the ezDV application. At the top, there is a navigation bar with tabs: General, Reporting, Voice Keyer, Wi-Fi (which is selected and highlighted in blue), Radio, and Firmware Update. Below the tabs, there is a checkbox labeled "Enable Wi-Fi" which is checked. A note below it says: "(Note: you can always return here even if disabled by holding down Volume Down while turning on ezDV.)". The main configuration area contains the following fields:

- Hostname: ezdv-flex-6300
- Wireless Mode: Client
- Network Name: (redacted)
- SSID: (redacted)
- Security Type: Open
- Channel: 1
- Password: (redacted)

At the bottom of the screen are two buttons: a green "Save" button and a red "Reset" button.

Figure 21: ezDV showing the Wi-Fi tab

The following can be configured in this screen:

Setting	Description
Enable Wi-Fi	Enables or disables the Wi-Fi radio on ezDV.
Hostname	The name to call ezDV on the network (default “ezdv”). Only letters, numbers and ‘-’ can be used for the name.
Wireless Mode	Can be either “Client” (to connect to an existing Wi-Fi network) or “Access Point” (to have ezDV generate its own Wi-Fi network).
Network Name	The Wi-Fi network to connect to in “Client” mode. ezDV populates this list with the networks that it’s able to see, or you can choose “(other)” and manually enter the name of the network in the “SSID” field.
SSID	Typically automatically filled in if you select a network in the “Network Name” list. If “(other)” is selected, you can manually enter the name of the Wi-Fi network here (for example, if the network doesn’t broadcast its presence).
Security Type	In “Access Point” mode, controls the security of the Wi-Fi network ezDV provides. Can be either “Open” (no encryption/security) or one of “WEP”, “WPA”, “WPA2” or “WPA/WPA2”. Note: <i>WPA2 is recommended for the best security.</i>
Channel	In “Access Point” mode, this controls the 2.4 GHz Wi-Fi channel (1-11) ezDV uses.
Password	In “Access Point” mode (and when something other than “Open” is selected for “Security Type”), the password ezDV will require to allow other devices to connect to it. In “Client” mode, this is the password for the network selected or entered in “Network Name”/“SSID”.

Pushing Save here will save these settings to ezDV’s internal flash but require rebooting or power cycling ezDV for the settings to take effect.

4.7 Configuring radio connection and headset

The Radio tab allows configuration of ezDV’s connection to a network-enabled radio as well as headset-related functions. Currently ezDV supports connections to the Icom IC-705 and Flex 6000 series radios,

as shown below:

The screenshot shows the 'Radio' tab of the ezDV configuration interface. At the top, there are tabs for General, Reporting, Voice Keyer, Wi-Fi, Radio, and Firmware Update. The Radio tab is selected. Below the tabs, there are several configuration options:

- Enable PTT using headset button
- Time Out Timer (seconds):
- Use Wi-Fi Network for Radio RX/TX
- Radio Type: Flex 6000 series
- Radio: FLEX-6300 (K6AQ)
- IP Address: 10.0.1.111

At the bottom are two buttons: a green 'Save' button and a red 'Reset' button.

Figure 22: ezDV showing a FlexRadio configuration

The screenshot shows the configuration interface for an Icom IC-705. The 'Radio' tab is selected. The configuration fields are as follows:

- Enable PTT using headset button
- Time Out Timer (seconds):
- Use Wi-Fi Network for Radio RX/TX
- Radio Type: Icom (e.g. IC-705) (highlighted)
- IP Address: 10.0.1.111
- Port: 50001
- Username:
- Password:

At the bottom are two buttons: a green 'Save' button and a red 'Reset' button.

Figure 23: ezDV showing a Icom IC-705 configuration

The following can be configured in this screen:

Setting	Description
Enable PTT using headset button	Enables the usage of the “call” button on your wired headset for toggling PTT. (See “Basic usage” for more information.)
Time Out Timer (seconds)	Configures ezDV’s “time out timer”, which automatically puts the radio back into receive if the radio is stuck in transmit mode for too long.
Use Wi-Fi Network for Radio RX/TX	When checked, allows ezDV to connect to a supported radio over Wi-Fi instead of using a wired headset.
Radio Type	The type of radio that ezDV should connect to. This can be either “Flex 6000 series” or “Icom (e.g. IC-705)”. Relevant settings for each radio type will appear in this tab as appropriate.
Radio	Displays the list of Flex radios that ezDV is able to see on the network. You can also choose “(other)” and manually enter its IP address.
IP Address	For Flex radios, this is typically auto-filled when selecting a radio from the Radio list. Otherwise, this is the IP address of the radio which to connect to.
Port	For the IC-705, this is the control port number of the built-in server running on the radio. Defaults to “50001” and should not normally need to be changed.
Username	For the IC-705, this is the “Network User1” or “Network User2” user ID. (See “Configuring Wi-Fi on the IC-705” or your radio’s user manual for information on configuring these users.)
Password	For the IC-705, this is the “Network User1” or “Network User2” password.

Pushing Save here will save these settings to ezDV’s internal flash but require rebooting or power cycling ezDV for the settings to take effect.

4.8 Updating firmware

From time to time, new ezDV firmware may be released that contains feature enhancements and/or bug fixes. These updates are typically posted on the project's releases page and are announced in various other locations (such as the FreeDV mailing lists). ezDV can be upgraded or downgraded by using the "Firmware Update" tab:




Figure 24: ezDV showing the "Firmware Update" tab

To update the firmware, perform the following steps:

1. Download the firmware file ending in "-ota.tar.gz" to your PC and save it to a known location (such as your Downloads folder).
2. Go to ezDV's "Firmware Update" tab and select the file you just downloaded.
3. Press the "Update" button. *Note: this may take several minutes to complete. Do not close your browser or navigate away from the ezDV web interface while the update is taking place.*

Once complete, the new firmware is stored on ezDV's internal memory but will not take effect until ezDV is turned off and on again or rebooted.

4.9 Rebooting ezDV

You can reboot ezDV from the web interface instead of powering it on and off using the physical controls. This is typically done after saving radio or Wi-Fi settings or after uploading new firmware. To do this, go to the General tab and press the Reboot button:



Figure 25: ezDV showing the Reboot button

ezDV may take up to a minute to turn itself off and then turn itself on again. Once the web browser

is able to communicate with ezDV again, it will automatically refresh the Web interface so that any changes to it due to any firmware updates can be made visible immediately.

Note: changes to Wi-Fi settings may cause ezDV to no longer be accessible on the IP address that was originally used. See “Accessing the web interface” for information on finding its new address if required.

5 Appendix: Configuring Wi-Fi on the Icom IC-705

First, you will need to decide whether you want to join your IC-705 to an existing Wi-Fi network or whether you want to configure ezDV to use the IC-705’s built-in access point.

Note: it is recommended to join your IC-705 to an existing Wi-Fi network in order to be able to access ezDV’s Web interface (and to take advantage of certain features if an Internet connection is available).

Next, you’ll need to turn on your radio and push the Menu button. This will bring up the following screen:



Figure 26: Icom IC-705 on menu screen

Tap the Set button on the lower-right corner of the display and then select “WLAN Set” as shown

below:



Figure 27: Icom IC-705 with WLAN Set selected

Next, tap the WLAN option on the first page and turn it OFF. Once switched OFF, tap the Connection Type setting and tap either Station (for connecting to an existing Wi-Fi network) or Access Point (for connecting ezDV to the IC-705's access point):



Figure 28: Icom IC-705 displaying WLAN Set options



Figure 29: Icom IC-705 displaying Connection Type menu

5.1 Using the IC-705's built-in access point

If you're using the IC-705's Access Point mode, it is a good idea to double-check your radio's SSID (aka Wi-Fi network name) and Wi-Fi password by tapping "Connection Settings (Access Point)" and then tapping each option as shown below, updating them as needed:



Figure 30: Icom IC-705 displaying Access Point settings

Also, note the IP address that your IC-705 is using on this page as you will need it for later configuration of ezDV. Once the settings here are satisfactory, tap the Back button on the lower right hand corner of the screen, tap the WLAN option and then change it to ON.

5.2 Connecting the IC-705 to an existing network

First, tap the WLAN option on the WLAN Set page and change it to ON. This is needed in order to turn on the Wi-Fi radio in the IC-705 and allow it to scan for networks.

Next, tap “Connection Settings (Station)”. You will see the following page on the IC-705:



Figure 31: Icom IC-705 displaying the Connection Settings (Station) page

From here, you can either tap “Access Point” to select your network from a list or “Manual Connect” if it’s not broadcasting its name. Tapping “Access Point” will bring up a page similar to the following:



Figure 32: Icom IC-705 displaying a list of Wi-Fi networks

Tap your preferred network from the list that appears. If it's not already saved in the IC-705, you may see a page similar to the following:




Figure 33: Icom IC-705 displaying the Connect page

Tapping Password will display the following page that will allow you to enter your Wi-Fi network's password:



Figure 34: Icom IC-705 displaying the Password page

Once entered, tap the ENT button to save it, then tap the Connect option to connect to the network. If successful, the Access Point page will show “Connected” below your network’s name. Tap the Back button until you return to the “Connection Settings (Station)” page and make sure you see an IP address under “DHCP (Valid After Restart)”:



Figure 35: Icom IC-705 displaying an IP address

Note this address as it will be needed for later configuration of ezDV.

5.3 Configuring the Radio User

The IC-705 requires a username and password to connect to the radio. If this is not already set up, you will need to do so now before continuing with ezDV setup. First, ensure that you're on the “WLAN Set” page and then go to the second page of options. You will see a “Remote Settings” option:



Figure 36: Icom IC-705 displaying the Remote Settings option

Tap on “Remote Settings” and then tap on “Network User1”:



Figure 37: Icom IC-705 displaying the “Network User1” option.

The following page should appear. Tap on “Network User1 ID” and “Network User1 Password” and enter a username and password (if not already saved). Make a note of these as you’ll need them later. Additionally, make sure “Network User1 Administrator” is set to “YES”.



Figure 38: Icom IC-705 displaying the “Network User1” settings.

Tap the Back button until you reach the Set menu.

5.4 Configuring Audio

The IC-705 must be configured to accept transmit audio from the Wi-Fi interface in order for transmit with ezDV to work properly. From the Set menu, select “Connectors” as shown below:



Figure 39: Icom IC-705 displaying the “Connectors” option.

Next, scroll until you find the “MOD Input” option and then tap it to continue:



Figure 40: Icom IC-705 displaying the “MOD Input” option.

Finally, tap the “DATA MOD” option and ensure that it is set to “WLAN”:



Figure 41: Icom IC-705 displaying the “MOD Input” menu.



Figure 42: List of valid “DATA MOD” options.

Note: if you share the IC-705 with other data mode applications over USB (for example, WSJT-X for FT8), make sure that “DATA MOD” is set to one of the “USB” options above when done using ezDV.

6 Example Wiring Configurations

Some example configurations are below.

6.1 Elecraft KX3

If you have an Elecraft KX3, you can use off the shelf parts for your interface cable (no soldering required). These parts consist of a 3.5mm splitter and a 3.5mm TRRS cable. The microphone connector on the splitter should be plugged into PHONES on the KX3 while the speaker connector should be plugged into MIC.

This setup will look like the following when plugged in:



Figure 43: ezDV plugged into an Elecraft KX3