M Key Guide for FAGCI SPC0002

This guide describes **OSFW-SPC0002**, the latest firmware build generated for this project. The Romanian original was checked against the firmware source on October 13, 2026. This version includes the NAME editor and Spectrum saving with Side Key 2. The AM comparison with Egzumer did not change the firmware.

Using the main menu

1. From the main screen, briefly press **M / MENU**.
2. Select an option with ▲/▼, or enter its number. For example, press **5 then 0** to select NAME.
3. Press **M** to enter the setting.
4. Change the value with the arrow keys or, where supported, the number keys.
5. Press **M** to accept. **EXIT** cancels editing; press EXIT again to close the menu.

MEM-CH, DEL-CH and RESET require an additional confirmation: after selecting the value, press M to display **SURE?**, then press M again to perform the operation.

Normal menu: options 01-50

The numbers and labels below are those displayed by SPC0002. Options 01-49 retain their original numbering; NAME is the new option 50.

No.	Display	Function	Values or usage
01	**SQL**	Squelch threshold; 0 keeps reception open.	0-9
02	**STEP**	Tuning step. Changes through this menu are accepted only in VFO mode.	0.01 / 0.1 / 0.5 / 1 / 2.5 / 5 / 6.25 / 8.33 / 10 / 12.5 / 25 / 100 kHz
03	**TXP**	Transmit power for the active VFO/channel.	LOW / MID / HIGH
04	**R_DCS**	Receive DCS code.	OFF or normal/inverted DCS code
05	**R_CTCS**	Receive CTCSS tone.	OFF or one of 50 tones
06	**T_DCS**	Transmit DCS code.	OFF or normal/inverted DCS code
07	**T_CTCS**	Transmit CTCSS tone.	OFF or one of 50 tones
08	**SFT-D**	Transmit frequency offset direction.	OFF / + / -
09	**OFFSET**	RX-TX frequency offset, displayed in MHz.	Number keys or arrow keys
10	**W/N**	Channel filter bandwidth.	WIDE / NARROW
11	**SCR**	Channel scrambling, intended for FM.	OFF / 1-10; also depends on SCREN
12	**BCL**	Blocks transmission when the channel is busy.	OFF / ON
13	**MEM-CH**	Stores the current parameters in the selected memory slot. Requires SURE? confirmation.	CH-001 to CH-200
14	**SAVE**	Battery saving. SAVE here does not store a channel.	OFF / 1:1 / 1:2 / 1:3 / 1:4
15	**VOX**	Voice-activated transmission and trigger level.	OFF / 1-10

No.	Display	Function	Values or usage
16	**BACKLI**	Display backlight duration.	OFF / 5 sec / 10 sec / 20 sec / 1 min / 2 min / ON
17	**DW**	Dual Watch: monitors both VFOs, with the associated A/B selection.	OFF / CHAN_A / CHAN_B
18	**WX**	Routes reception and transmission between VFOs A/B. In this source, it is the cross-band setting, although the display says WX.	OFF / CHAN_A / CHAN_B
19	**BEEP**	Keypad sounds.	OFF / ON
20	**TOT**	Maximum duration of a transmission.	OFF / 1-10 min
21	**VOICE**	Inherited voice announcement language selector. This source does not implement voice playback linked to this setting.	OFF / CHI / ENG
22	**SC-REV**	Scan behavior when a signal is detected: timed resume, resume after the carrier disappears, or stop.	TO / CO / SE
23	**MDF**	Memory channel display format.	FREQ / CHAN / NAME / NAME+F
24	**AUTOLK**	Automatic keypad lock.	OFF / ON
25	**S-ADD1**	Includes the channel in scan list 1.	OFF / ON
26	**S-ADD2**	Includes the channel in scan list 2.	OFF / ON
27	**STE**	Squelch tail elimination, where applicable.	OFF / ON
28	**RP-STE**	Repeater tail elimination delay.	OFF / 1-10 x 100 ms
29	**MIC**	Transmit microphone sensitivity.	0-4
30	**1-CALL**	One-touch call channel, subsequently accessed with F → 9.	CH-001 to CH-200
31	**S-LIST**	Default memory channel scan list.	LIST1 / LIST2
32	**SLIST1**	Views list 1 and its priority channels. Does not edit priorities.	Channels in the list / NULL
33	**SLIST2**	Views list 2 and its priority channels. Does not edit priorities.	Channels in the list / NULL
34	**ANI-ID**	Displays your own DTMF identifier. Cannot be edited here.	View only
35	**UPCODE**	Displays the DTMF code sent at the beginning of transmission. Cannot be edited here.	View only
36	**DWCODE**	Displays the DTMF code sent at the end of transmission. Cannot be edited here.	View only
37	**D-ST**	Local monitoring of DTMF tones.	OFF / ON
38	**D-RSP**	Response to a decoded DTMF call.	NULL / RING / REPLY / BOTH
39	**D-HOLD**	DTMF call hold/automatic reset time.	5-60 sec
40	**D-PRE**	Delay before sending the DTMF code.	3-99 x 10 ms

No.	Display	Function	Values or usage
41	**PTT-ID**	When the DTMF identifier is sent during PTT operation.	OFF / BOT at start / EOT at end / BOTH
42	**D-DCD**	Enables DTMF decoding on the channel.	OFF / ON
43	**D-LIST**	Selects a DTMF contact. Confirming a valid contact prepares it for a call.	1-16 / NULL for an invalid entry
44	**PONMSG**	Startup screen: full display, message, or battery voltage.	FULL / MSG / VOL
45	**ROGER**	End-of-transmission signal.	OFF / ROGER / MDC
46	**VOL**	Displays battery voltage. VOL in this menu is not a volume adjustment.	View only, in volts
47	**MODUL**	Basic modulation selector in the main menu.	OFF = FM / ON = AM; see modulation notes
48	**DEL-CH**	Deletes the selected channel from usable memory. Requires SURE? confirmation.	CH-001 to CH-200
49	**RESET**	Resets settings or performs a full reset. Requires SURE? confirmation and restarts the radio.	VFO / ALL
50	**NAME**	Views and edits the active memory channel name.	Up to 10 ASCII characters; see steps below

Editing a channel name

First select a memory channel, then use **M → 50 NAME → M**. The screen shows the channel number and full name, regardless of the MDF setting.

Key in the NAME editor	Action
▲ / ▼	Changes the character under the cursor; holding the key repeats the change.
F	Moves the cursor right.
*	Moves the cursor left.
0-9	Inserts the digit directly and advances the cursor.
M	Saves the name and finishes editing.
EXIT	Discards the changes.

Names can contain up to **10 characters**, without accented letters. The cursor wraps around at either end. To shorten a name, replace its final characters with spaces; ten spaces clear the name. NAME does not create channels and displays **MR ONLY** unless a valid memory channel is selected.

Saving a channel from the main menu

Set the frequency and parameters, then follow:

M → 13 MEM-CH → M → select CH-xxx → M → SURE? → M

Check the slot number before the final confirmation. An occupied slot will be overwritten. **14 SAVE** is battery saving and does not replace MEM-CH.

In SPC0002, ordinary parameter changes, such as TXP, tones or MODUL, automatically save the VFO settings but do not rewrite the parameters of an existing MR channel. To retain these changes in a memory channel, explicitly use **MEM-CH** afterwards. The NAME editor and S-ADD1/S-ADD2 scan list membership have their own save paths.

Available modulation modes

Option **47 MODUL** offers only **OFF = FM** and **ON = AM**, even though its title suggests a general selector. Accepting this option on a USB/BYP/RAW channel selects FM or AM.

Cycle through the five modes **FM, AM, USB/SSB, BYP, RAW** with **F** → **7** from the main screen, or **0** in Spectrum. To retain a mode change in an MR channel, use MEM-CH or Spectrum saving.

What M does in Spectrum

Enter Spectrum from the main screen: press **F**, release it, then press **5**. The function of M depends on the current screen:

Screen	What M does
Spectrum graph	Does not open the main menu or a help screen. The extended register menu on this screen is disabled in SPC0002.
Frequency entry, after pressing 5	Accepts the entered frequency and returns to the previous Spectrum/listening state.
Spectrum fixed-frequency listening	Cycles through LNAs, LNA, PGA, MIX, IF, DEV, CMP and MIC adjustments. The arrow keys change the selected setting.
Slot selection after Side Key 2	The first press requests confirmation; the second saves.

To switch from the graph to fixed-frequency listening on the detected peak, briefly press PTT and release it. **During fixed-frequency listening, another PTT press may start transmission**; PTT is not the save button.

During fixed-frequency listening, EXIT first closes the adjustment selection, if active; the next EXIT returns to the graph. From the graph, EXIT closes Spectrum.

Special adjustments are temporary. In SPC0002, Side Key 2 **does not save** LNAs/LNA/PGA/MIX/IF/DEV/CMP/MIC settings or the squelch/RSSI threshold.

Saving from Spectrum with Side Key 2

1. Press and release **Side Key 2**, the lower side button. In Spectrum, this replaces its backlight toggle function.
2. Check the displayed frequency. The captured frequency is the graph peak frequency, or the tuned frequency during fixed-frequency listening.
3. The first free slot is suggested. Use ▲/▼ to select a different slot if needed.
4. Press and release **M**: **SAVE?** appears for an empty slot, or **REPLACE?** for an occupied slot.
5. Press **M** again to save. **SAVED CH-xxx** appears, then you return to Spectrum.

EXIT cancels at either stage. Changing the slot cancels the previous confirmation. Holding M cannot automatically confirm an overwrite. PTT is ignored on this screen.

The frequency, modulation, tuning step and Wide/Narrow bandwidth are saved. The Spectrum 6.25 kHz filter is stored as Narrow. The channel is created without an offset or tones, using the active VFO's transmit power and

membership in both scan lists. When overwriting, the existing name is preserved; a new slot has an empty name that can later be edited with NAME.

Saving does not automatically select the new channel on the main screen. After leaving Spectrum, select the saved slot to use or rename it.

Special options 51-56

These options appear in the special mode accessed by powering on the radio while holding **PTT + Side Key 1** simultaneously. Side Key 1 is the small button immediately below PTT. Release both buttons when menu **51 - 350TX** appears. They configure transmission permissions and global scrambling; they are not AERO sensitivity or AM AGC adjustments.

No.	Display	Function	Values
51	**350TX**	Configured permission to transmit in the 350 MHz range.	OFF / ON
52	**F-LOCK**	Transmit frequency limit profile.	OFF / FCC / CE / GB / LPD PMR
53	**200TX**	Configured permission to transmit in the 200 MHz range.	OFF / ON
54	**500TX**	Configured permission to transmit in the 500 MHz range.	OFF / ON
55	**ALL_TX**	General transmission permission mode.	DEFAULT / ENABLE / DISABLE
56	**SCREN**	Global scrambling enable.	OFF / ON

Quick reference

- **13 MEM-CH:** saves a channel.
- **14 SAVE:** battery saving.
- **23 MDF:** name or frequency display.
- **46 VOL:** battery voltage.
- **47 MODUL:** FM/AM only in the main menu.
- **48 DEL-CH:** deletes a channel.
- **49 RESET:** reset; not required to enable the new features.
- **50 NAME:** edits a channel name.
- **F → 5:** Spectrum.
- **Side Key 2 in Spectrum:** selects a slot for saving.

This is an external guide for the existing version. Creating this document did not add a HELP screen to the firmware or change the behavior of the M key.