ToddySoft Connect EtherNet/IP Driver - Ignition 8.1

Ignition 8.1 module for connecting to Allen-Bradley **Logix** controllers — ControlLogix, CompactLogix and family — over EtherNet/IP and CIP. Tags are addressed by the **symbol names from the Logix program**, controller-scoped or program-scoped, with dotted paths for struct members and bracketed indices for arrays.

> **Reads are batched, writes are per-tag.** The driver coalesces a multi-tag read into one CIP multi-service request, so a tag group of many tags costs far less than the tag count suggests. Aggregates are a deliberate exception in the other direction — see *Arrays and structures*.

Installation


> **This module is for Ignition 8.1 only.** It is built against the Ignition 8.1 SDK and will not run on any other major version. For Ignition 8.3, install the separate `…-8.3.modl` build instead — the two are not interchangeable, and each gateway needs the build that matches it.
>
> **Ignition 8.0 and earlier are not supported and cannot be.** The module is built on the device-driver API that Ignition introduced with 8.1, so on 8.0 the gateway fails to load it with `NoClassDefFoundError: … opcua.server.api.AbstractDeviceModuleHook`.
>
> Both builds carry the same name in the gateway's module list, so tell them apart by the file you installed or by the module description, which names the Ignition version.
>
> **Ignition's OPC UA module must be installed and running.** This is an OPC UA device driver: it registers with Ignition's own OPC UA server, and every tag it exposes is served through it. With that module absent the gateway cannot load this one, and the log fills with `ClassNotFoundException` / `NoClassDefFoundError` naming `com.inductiveautomation.opcua…` classes. The OPC UA module ships with Ignition and is installed by default, so in practice this bites only on a gateway where it has been removed or disabled. **Ignition 8.1 cannot refuse the module for you** — its descriptor has no way to mark a dependency as required, a mechanism that arrived in 8.3 — but it does name the cause plainly, one line before the stack trace. In `logs/wrapper.log`, look for:
>
> `Module "com.toddysoft.connect.…" depends on "com.inductiveautomation.opcua", but it doesn't exist.`
>
> It then attempts to load the module anyway, which produces the class errors above. Ignition's own drivers behave identically in this situation, so this is how the platform works and not a fault in this module.

The ToddySoft Connect modules are signed with a self-signed certificate (issued to *ToddySoft GmbH*) rather than a publicly accredited code-signing certificate. Ignition therefore asks you to review and accept that certificate once during installation - it is then remembered for all future ToddySoft modules signed with the same certificate.

1. Open the Ignition Gateway web interface and navigate to **Config > System > Modules**. Scroll to the bottom and click **Install or Upgrade a Module...**.
2. Choose the `ToddySoft-Connect-EIP-Driver-8.1.modl` file and click **Install**.

3. Ignition shows the self-signed certificate details (subject and issuer *ToddySoft GmbH*) together with a warning that the module was not written by Inductive Automation. Review the certificate, tick **I understand the risk and want to install this module** and click **Add Certificate and Install Module**.

4. The module is now trusted and listed under the **ToddySoft GmbH (self-signed certificate)** group with the state **Running**.




Before you start: the controller side

- **EtherNet/IP enabled.** CompactLogix and ControlLogix CPUs with built-in Ethernet have it on by default; a ControlLogix with a separate 1756-ENBT / 1756-EN2T card needs that card configured.
- **"Allow external access" enabled** in the program properties (Studio 5000 / RSLogix 5000). Some sites disable it by default, and with it disabled the connection is made and the tags are not readable.
- **The tag database must be accessible.** An empty or password-locked program database prevents symbolic browsing — there is nothing else to address by.
- **TCP port 44818** reachable from the gateway host.


There are no credentials to configure: EtherNet/IP as this driver speaks it is unauthenticated, so this module has no username or password fields at all. Access is governed on the controller.

Creating a Device Connection

1. Go to **Config > OPC UA > Device Connections**.




2. Click **Create new Device...**, select **ToddySoft Connect EIP Driver** as the device type and click **Next**.



3. Configure the connection settings (see the sections below) and click **Save**.

4. The new device then appears in the Device Connections list.




> **Device discovery is an Ignition 8.3 feature.** The protocol does support it — EtherNet/IP has a LIST IDENTITY broadcast — but it needs the custom configuration form the 8.3 module ships, which the 8.1 device-settings API cannot render. On 8.1, enter the host, backplane and slot by hand. Neither version offers a *Test Connection* action for this driver.

Setting blocks

The configuration is organized into categories: **General**, **Transport Settings**, **EIP Settings** and **Audit Log Settings**.

General

Assigns a name (and optional description) to the connection and controls whether it is enabled.



Setting	Description	Default
Name	Unique name for this device connection	
Description	Optional description for this connection	
Enabled	Whether the connection is active	`true`

This is the name the connection is then referenced under in other parts of Ignition.


Transport Settings



Setting	Description	Default
Host	Hostname or IP address of the EtherNet/IP device	
Port	TCP port number	`44818`

There is no transport selector, and none is missing: EtherNet/IP explicit messaging runs over plain TCP on 44818, and there is no TLS variant to choose here.

EIP Settings



Setting	Description	Default
Backplane	Backplane number of the target controller	`1`
Slot	Slot number of the target controller	`0`
Request Timeout	Milliseconds allowed for one request	`5000`

Setting	Description	Default
Max Service Nesting Depth	Nesting accepted when parsing CIP services from the device	`20`
Browse Queries	Query string for symbol browsing	`**`

Backplane and slot are worth double-checking


They identify *which module in the chassis* the CIP route ends at. A wrong pair does not usually fail politely: a **ForwardOpen rejected with CIP general status `0x01`** is the common symptom, and the same status is what you get when the controller simply has **no free connection slots** — an open Studio 5000 session counts against that budget. Check the chassis layout first, then look for other clients.

For a CompactLogix with a built-in Ethernet port the controller is usually backplane `1`, slot `0`, which is the default here.

Max Service Nesting Depth

This bounds what the *device* can make the driver parse. A CIP `MultipleServiceRequest` carries an array of services, so without a limit the nesting depth of a response is chosen by the device rather than by the driver. Real responses are one or two levels deep; the default of `20` sits far above that. Raise it only for a device known to nest further.

Audit Log Settings



Setting	Description	Default
Audit Log File	Path to a file protocol audit events are written to; empty disables	

The audit log records protocol-level events and grows quickly, so enable it only while investigating a problem.

Tag Addressing

EIP addresses are **symbolic** — the names from the Logix program:

```
<scope>:<tag>(.<member>)*([<index>(,<index>)*])*
scope ::= (omitted = controller-scoped) | <program-name>
```

Address	Meaning
`MyTag`	A controller-scoped tag
`Program:MainProgram.LocalTag`	A program-scoped tag inside `MainProgram`
`MyStruct.Field`	A struct member
`MyArray[5]`	Element 5 of an array
`MyArray[2,3]`	A cell of a multi-dimensional array
`Channels[0].Id`	A selection on an intermediate path segment
`Matrix[0].Row[1]`	Selections on more than one segment

Controller-scoped versus program-scoped is the usual cause of `INVALID_ADDRESS`. A tag local to a program needs the `Program:<name>.` prefix; a controller-scoped tag must not have one. Browse to discover the legal names rather than transcribing them from Studio 5000.

An index above 255 is refused, because a CIP `MemberID` cannot encode it. A range before the last path segment is refused too, because one request carries a single element count.

Arrays and structures

Naming an array without a subscript reads the whole array. A 3×4 reads as 12 elements in wire order, and the count comes from the controller's tag table, so it agrees with what browsing reports.

- **Packed BOOL arrays are unpacked for you.** Logix stores `BOOL[32]` as one `DWORD`; the driver returns 32 `BOOL`s, least significant bit first. Reading a single element such as `g_arrBool[3]` selects the bit. **Writing** a single element is refused, because changing one bit of a shared word needs a read-modify-write that would clobber the other 31 if anything else touched them meanwhile. Write the whole array instead.
- **Strings read whole**, including user-defined string types (`STRING_16`, `STRING_32`, …). A string is recognised by its layout — a `DINT LEN` followed by a `SINT DATA` array — not by one hardcoded type.
- **An array of UDTs does not read.** The driver decodes no other user-defined structure, so such a tag reports `UNSUPPORTED` rather than a partial value.
- **A member array resolves through the controller's struct definitions**, one-dimensional members only: the type information a controller publishes carries an element count for those alone, so a multi-dimensional member reads one element and should be addressed per element.

An aggregate is readable but not writable, and browsing says so — a structure or array node reports `readable=true`, `writable=false`. The asymmetry is deliberate: the driver decodes a structure on read through the controller's own template definitions, and has no encoding for one on write.

Configure **Browse Queries** to control which symbols appear when browsing tags in the Ignition Designer.

Tag Groups

By default, all tags are collected in the default tag group, which means all selected tags are fetched at the default interval of once a second.

If different intervals are desired, create additional tag groups, configure the desired intervals there, and assign tags to the corresponding tag groups.

Reads within one group are coalesced into a CIP multi-service request, so grouping tags that are read together is what makes this driver efficient — spreading the same tags across many groups costs more, not less.

Licence diagnosis

When a device reports a licence problem, the module explains it on the gateway itself. Open **Status > Other > ToddySoft Licence (EIP)**. A device with a licence problem says so in its status and points there.

The diagnosis shows:

- **which gateway** this is, and its role if it is part of a redundant pair;
- **Ignition's licence** for this module on this gateway: activated, trial running (with its end) or trial expired;
- **what ToddySoft licence data arrived** with Ignition's licence: how many parts, whether they are complete, and a checksum that identifies the licence without revealing it;
- the **driver's own verdict** and the **cause**, in words.

Cause	Meaning	What to do
`IGNITION_UNLICENSED`	Ignition applies no activated licence to this module on this gateway (trial running or expired). ToddySoft licence data only arrives with an activated licence.	Activate a licence key that covers this module on this gateway. In a redundant pair every node needs its own activation.

Cause	Meaning	What to do
`NO_DATA_FOR_DRIVER`	The activated key carries no ToddySoft licence for this driver.	Send the report to ToddySoft.
`DATA_INCOMPLETE`	The licence data arrived incomplete or damaged.	Send the report to ToddySoft; the licence has to be delivered again.
`DATA_REJECTED`	The driver refused the delivered licence; the reason is shown.	Send the report to ToddySoft.
`RUNNING_ON_BUNDLED_TRIAL`	A licence was delivered but not accepted, and the driver runs on its built-in trial until that ends.	Send the report to ToddySoft.
`NOT_CHECKED`	Licence data arrived, but the driver gave no verdict - for instance because it could not be loaded.	Send the report to ToddySoft.
`VALID`	Licensed; tier and expiry are shown.	Nothing.
`NOT_YET_KNOWN`	The first seconds after start-up, before Ignition reports a licence state.	Wait a moment.

Sending a report to support. The diagnosis comes as a plain-text report, the one thing to send with any licence question. The page shows it ready to select and copy. The same text is served at `http://<gateway>:<port>/data/com.toddysoft.connect.eip/licence-report` to a logged-in user. It contains no licence data, no keys, no credentials and no customer details. In a redundant pair, send the report from both nodes.

The gateway log carries the same report once each time the licence situation changes.

Troubleshooting

Licensing problems after a new or renewed licence key was activated — `DATA_INCOMPLETE` with "duplicate fragment index" in the licence diagnosis:

- **Two licence keys covering this module are activated on the gateway at the same time**, typically a renewed or upgraded key activated alongside the old one. Ignition hands the module the licence data of both, in numbered parts that carry

the same numbers; the module cannot tell which parts belong together, keeps one of each pair, and the licence it reassembles is unreadable. Depending on the parts it keeps, devices are refused or run on the module's bundled trial until that ends.
- Keep exactly **one** activated licence key that covers this module per gateway: deactivate the old one under **Config > System > Licensing**, then restart the module (or the gateway). In a redundant pair, check every node.

The module will not load, or the log shows `ClassNotFoundException` / `NoClassDefFoundError`:

- Ignition's **OPC UA** module is missing or disabled. This driver is an OPC UA device driver and cannot load without it. Install or re-enable it under **Config > System > Modules** and restart the gateway — see Installation

Device shows "Faulted":

- Verify the controller is reachable and TCP port 44818 is open through any site firewall
- Confirm EtherNet/IP is enabled on the controller or its communications card
- Review Gateway logs: **Status > Diagnostics > Logs**

ForwardOpen rejected, CIP general status `0x01`:

- Wrong **Backplane** / **Slot** for the chassis layout, **or** the controller has no free connection slots. An open Studio 5000 session counts against that budget — close other clients and retry

ForwardOpen rejected, CIP general status `0x09`:

- The routing path does not match a real route in the chassis. Re-check the chassis hardware

`INVALID_ADDRESS` on a symbolic read:

- The tag does not exist in the cached symbol table, or the scope is wrong. `Program:Name.Tag` for program-scoped, bare `Tag` for controller-scoped

`OUT_OF_RANGE` on an array read:

- The index is past the array's declared bounds. Check the dimensions in Studio 5000 or by browsing

CIP general status `0x05` (Object does not exist):

- The tag was deleted, or the program was redownloaded with a different schema. Re-browse; the cache invalidates on a tag-list version change, but a stale cache may need an explicit reconnect

CIP general status `0x10` (Device state conflict):

- The controller is in a mode that disallows the operation. Writes generally need RUN mode

Tags read but nothing can be browsed:

- "Allow external access" is disabled in the program properties, or the tag database is empty or password-locked

A write to an array or structure is refused:

- Expected, and deliberate. Aggregates are read-only on this driver; write the individual elements, or the whole array in the packed-BOOL case

Docker related issues

The EtherNet/IP protocol carries no identity for this end of the connection, so a container's internal address is never announced to the controller and nothing has to be reconciled. A gateway in a bridged container connects normally, provided port 44818 is routable.

VPN related issues

A remote controller reached over a VPN needs nothing special from this driver, for the same reason: the connection is an ordinary outbound TCP session. Note that LIST IDENTITY discovery (Ignition 8.3) is a *broadcast* and will not cross a routed VPN — enter such a controller's address by hand.

Version history

Unreleased — 1.3.0

- First release of this manual.
- **New:** licence diagnosis — why a device is or is not licensed, shown on the gateway, with a report to send to support. See Licence diagnosis.
- **New:** troubleshooting for two licence keys covering this module activated on one gateway at the same time. See Troubleshooting.