

# **Custom Compiler**

Layout Editor (LE)
Abutment and Align Functions

O-2018.09




## **Unit Objectives**



- After completing this unit, you will be able to:
  - Use the abutment function to overlap pin shapes
  - Use the alignment function to align objects

## **Full Custom Compiler Flow**




#### **Pcell Abutment**

#### Abutment

- Sharing of diffusion for layout compactness
- Advantages of abutment
  - Sharing pin shapes to create cell interconnections
  - Reduces layout area
  - Accelerated layout
  - Correct by design construction
- Abutment function is written by Pcell author for Pcells abutment
- Global Preference leAutoAbutment should be ON to trigger abutment
- Abutment is also controlled by abutment option on Pcells


## **Hierarchy Connect**

- Similar to abutment and triggered when the colored objects and the instances pins or custom vias shapes overlapped
- Works when leAutoHierConnect preference is on
- Uses user-defined TCL code that specifies process of connect and disconnect




## **Pcell Abutment / Un-Abutment Triggers**


Pcells abutment is triggered when pin shapes overlap and abutment preference is on.




Move m2 over m1 to abut left/right pins




Pcells un-abutment is triggered when pin shapes no longer overlap/abut.




Move m2 away from m1



## **Pcell Abutment Rejection**




Move m2 to overlap m1 right terminal



Returned is spacing outside the terminals


## **External connection option for Abutment**

- Option to control external connection of abutment, and support of external connection parameter/property look up
  - Added with 3 values: Auto, Enable and Disable
    - Auto: first look for parameter/property.
       If parameter/property not defined, will abut as abutment proc does
    - Enable: Always keep terminals
    - Disable: Never keep terminals




#### **Post Abutment Procedure**

- Allows to trigger user defined procedure after abutment performed
  - Enabled from Options → Design → Command
  - Option name: Post Auto Abutment Connection
  - Preference name: *lePostAutoAbutmentConnection*
  - User defined post abutment procedure should have the following TCL signature:
    - proc post\_abut\_proc\_name {{Instld1 Instld2 ...}}
  - Required instance to have postAbutTrigger property with value "2".



## Perpendicular Align on Abutment

- Feature allows to not align Pycell instances and Guard Rings when abut shifted vertically
  - abutPerpendicularAlign optional Boolean property is used
  - Value must be set to false in Property Editor Properties section



10


## **Align and Distribute Functions**


- Invoked from Edit → Arrange → Align or Edit → Arrange → Distribute
- Alignment Function
  - Adjust placement of an object/instance to another object/instance
  - Perform stretch function for shapes edges
- Full/Partial selection alignment is allowed
- Supports
  - Infix mode
  - Works in post selection mode

## **Align: Fully Selected**

#### Alignment of fully selected objects

- Selection mode-Full
- Source marked red and selected in center
- Target marked green
- Source center will be aligned with the center of target






**12** 

## **Align: Fully Selected**

#### Alignment of fully selected objects


- Selection mode-Full
- Source marked red and selected in top edge
- Target edge center marked green
- Source will be aligned with the center of the edge of target




## **Align: Fully Selected**

#### Alignment of fully selected objects

- Source marked red
- Target edge marked green
- Source center will be aligned with the line of the edge of target






## **Align: Partially Selected**

# Alignment of partially selected objects


- Source edge marked red
- Target edge marked green
- Source edge will be stretched to target edge line



## **Distribute: Fully Selected**

### Alignment of several fully selected objects


- Source marked red
  - Hold Shift key and click to select several objects
- Target edge marked green
- Source center will be aligned with target line
- Set 'Align As Group' ON
- Switch to 'Spacing' and enter a spacing value
- Set 'Distribute From' to Topmost



## **Distribute: Fully Selected**

### Alignment of several fully selected objects


- Source marked red
  - Hold Shift key and click to select several objects
- Target edge marked green
- Source center of first object will be aligned with target line
- Set "Alignment Side" to Reference
- Switch to 'Pitch' and enter a pitch value
- Set 'Distribute From' to Leftmost
- Objects are distributed with uniform pitch




**17** 

## **Auto Alignment Assistant**


- Options → Design
- Aligns during editing if Gravity is "on"
  - Move, Stretch
- Implicit
  - Aligns cursor to edges



#### **Single Align**




#### **Multi Aligns**



## **Auto Alignment Assistant**

- Options → Design
- Aligns during editing if Gravity is "on"
  - Move, Stretch
- Implicit
  - Aligns cursor to edges
- Explicit
  - Aligns cursor to the center of coordinate markers
- Tracks take precedence for paths





## **Test For Understanding**






Abutment adjusts placement of one instance with respect to another instance: True / False

## **Lab 1: Layout Advanced Editing Functions**



#### Goals:

- Build a mask layout of a differential amplifier by using:
  - pcells
  - ◆ Instance creation
  - Manual placement
  - Routing functions



Copyright © 2018 Synopsys, Inc. All rights reserved.