NODIC 资料搜索 NRF52832 环境搭建 代码测试和 Sniffer 使用

如有错误敬请谅解并可一起探讨

Email: 450547566@qq.com

一、 资源准备(搜索 NORDIC 官网 NRF52832 资源)

1.1、需要的资料有如下图

		大小	类型 ▼	
₹ _mdl:514		355,626 K	B 应用程序	2
🗲 Keil_ARM_MDK_5.00_Keygen_serial_Crack	Α	42 K	B 应用程序	2
≔ s132_nr f52_2, 0, 0−8, alpha	R	263 K	B WinRAR ZIP 压缩	2
≥ nRF52_SDK_0. 9. 2_dbc28c9	C	4,672 K	B WinRAR ZIP 压缩	2
■1#Unrfgostudio win-32 1.20.0 installer	D	62.572 K	B Windows Install	2
■ 🔊 NordicSemiconductor.nRF DeviceFamilyPa	.ck. 8. 0. 3	E 312 K	B uVision Softwar	2

A:MDK5.14 安装包和破解工具

B:协议栈 HEX 文件以及相关文档


C:NORDIC 提供的一些 Demo 代码软件开发包

D:NORDIC 提供下载协议栈用的工具


E:KEIL需要加装的关于 nrf51822 和 nrf52832 的相关启动配置用的文件的 PACK

1.2、从官网下载 B、C、D 和 E


- 1、网站: www.nordicsemi.com
- 2、点击 Products



3、点击 2.4GHZ RF




5、点击 nrf52832




如下图: (记得点击 DOWNLOADS)

- 7 为协议栈即为第一张图的 B;
- 8 是留给 KEIL4 用的,因为 4 版本不能加装 PACK,这里没有用;
- 9 是 KEIL5 需要加装的 PACK, 也就是第一张图的 E;
- 10 是协议栈和应用代码用的下载工具,也就是第一张图的 D;


那么 SDK 软件开发包在哪???????????????



如下图,点击 NRF52 SDK 进入下下张图



由上图进入下图后再次点击如下图页码的 nRF52 SDK,进入真正的下载界面。




如上图,15 即为 PACK;16 为 SDK,注意这个 SDK 是不需要安装的,解压后直接可以用 KEIL5.14 打开。


二、安装和破解 MDK5.14

这里安装文件和破解文件都有,就不再啰嗦怎么安装了。


看结果吧!!!!




三、PACK 包安装




如上图点击 PACK Install 出现如下图, 去掉勾然后点击 OK




接着如下图 File—>import



如下图选择 需要加装的 PACK, 也就是第一张图中的 E 文件




加装结果如下图:




四、用 MDK5.14 打开一个作为外围设备的 心率计程序


4.1、解压 SDK 包





4.2 找到程序打开



tings\Administrator\桌面\nRF52832\nRF52 SDK 0.9.2 dbc28c s132 tings\Administrator\桌面\nRF52832\nRF52_SDK_0.9.2_dbc28c9\examples\ble_periph 大小 类型 修改日期 🛅 arm5_no_packs 文件夹 2015-10-文件夹 2015-10-🛅 armgcc ings\Administrator\桌面\nRF52832\nRF52_SDK_0.9.2_dbc28c9\examples\ble_peripheral\ble_app_hrs\pc ^ 大小 类型 修改日期 名称 ▲ Mille ann bre e132 nea10036 8 KB IMMPTX 文件 2015 J 16:16 2 15-10-15 16:16 B ble_app_hrs_s132_pca10036 141 KB 礦ision5 Project 2015-10-15 16:16 🔟 ble_app_hrs_s132_pca10036. uvguix 1 KB UVGUIX 文件 🤻 C:\Documents and Settings\Administrator\桌面\nRF52832\nRF52_SDK_0.9.2_dbc28c9\examples\ble_peripheral\bl <u>F</u>ile <u>E</u>dit <u>V</u>iew <u>P</u>roject Fl<u>a</u>sh <u>D</u>ebug Peripherals <u>T</u>ools <u>S</u>VCS <u>W</u>indow <u>H</u>elp 👱 🗟 🏴 🔍 🌢 🕠 🔗 □ 🚰 🛃 🐉 🐧 🖰 🗢 🗢 🗢 🗎 🍇 選 準 進 版 💆 🗹 🎊 🔒 🖶 🥎 🚳 s132_nrf52_1.0.0-3.alpha_licence_agreement.txt Project: ble_app_hrs_s132_pca10036 S110/S120/S130/S132 license agreement







五、安装 stdio 下载协议和心率计应用

5.1、安装 stdio


安装就免了,下一步下一步就完事了。

5.2、解压协议栈





5.3、下载协议栈

将 NRF52832 的电池隔离塑料拿掉,将 jlink 插上电脑




打开 stdio,选择 1 目标板, 2 擦除全部, 3 选择协议栈





5.4、下载心率计应用程序

有两种方法,一种用 stdio;一种直接用 MDK5.14 下载,我喜欢用 MDK 下载和调试。



f52832_xxaa_s132.axf" - 0 Error(s), 0 Warning(s). lapsed: 00:00:00

suments and Settings\\Administrator\\桌面\\nRF52832\\nRF52 SDK_0.9.2_dbc28c9\\examples\\ble peripheral\\b: pject File to "C:\Documents and Settings\Administrator\桌面\nRF52832\\nRF52832\\nRF52_SDK_0.9.2_dbc28c9\examples\ble

不过很失败哦!!! 下载的协议栈

s132_nrf52_2.0.0-8.alpha_softdevi ce 用不了哦!!!!

在 SDK 中有一个 HEX 协议栈,下载这个吧!可能是应用和协议栈不匹配:




下载应用程序后 LED1 每隔一定时间进行闪烁,这表示程序运行成功了。。。。。


六、手机连接测试和 Sniffer 采集











Capturing from \\.\pipe	\wireshark_nordic	ble [Vireshark 1.10.13 (v1.10.13-0-g3b7ff66 from master-1.10)]
jile <u>E</u> dit <u>V</u> iew <u>G</u> o <u>C</u> apture <u>A</u>	nalyze <u>S</u> tatistics Telep	ohony Tools Internals Help
		⇒ ₹ ½ □ □ □ Q Q Q □ W W № % D
ilter: btle		Expression Clear Apply Save
Time Source	Destination Protocol	Length Info
469 28.75001700(Master	Slave ATT	33 Rcvd Exchange MTU Request, Client Rx MTU: 158
470 28.75072700(Slave	Master BLE Da1	
471 28.77847000(Master		
472 28.77959300(slave		33 Rcvd Exchange MTU Response, Server Rx MTU: 23
473 28.80910500(Master		37 Rovd Read By Group Type Request, GATT Primary Service Decla
474 28.81000400C5lave	Master BLE Dat	
475 28.83897600(Master		
476 28.84033800CSlave		50 Rcvd Read By Group Type Response, Attribute List Length: 3 37 Rcvd Read By Group Type Request, GATT Primary Service Decla
477 28.86918200(Master 478 28.86991100(Slave	Slave ATT Master BLE Dat	
478 28.80991100051aVE 479 28.898531000Master		
480 28.89994700CSlave		44 Royd Read By Group Type Response, Attribute List Length: 2
481 28.92920200(Master		37 Royd Read By Type Request, GATT Characteristic Declaration,
482 28.9292000CMaster	Master BLE Dat	3 31 1 1
483 28.95850300(Master		
484 28.95957400(slave		39 Rcvd Read By Type Response, Attribute List Length: 1
485 28.98884300(Master		35 Rcvd Find Information Request, Handles: 0x000b0x000b
486 28.99112300(slave	Master BLE Dat	
487 29.01854000CMaster		
488 29.01954600Cslave	Master ATT	36 Rcvd Find Information Response
489 29.04911700(Master	Slave ATT	35 Rcvd Write Request, Handle: 0x000b
490 29.04983100(Slave	Master BLE Dat	a 26 Empty Data PDU
491 29.07859900(Master	Slave BLE Dat	a 26 Empty Data PDU
492 29.07943400Cslave	Master ATT	31 Rcvd Write Response
493 29.10911300(Master	Slave ATT	37 Rcvd Read By Type Request, GATT Characteristic Declaration,
494 29.11017800(Slave	Master BLE Dat	a 26 Empty Data PDU
495 29.13853900(Master	Slave BLE Dat	a 26 Empty Data PDU
496 29.140034000sTave	Master ATT	46 Rcvd Read By Type Response, Attribute List Length: 2
497 29.16914000(Master	Slave ATT	37 Rcvd Read By Type Request, GATT Characteristic Declaration,
498 29.16999400(slave	Master BLE Dat	
499 29.19848600(Master		
500 29.19991100Cslave		39 Rcvd Read By Type Response, Attribute List Length: 1
501 29.22872300(Master	Slave ATT	35 Rcvd Find Information Request, Handles: 0x000f0x000f
Frame 1: 59 bytes on wire (472 bits), 59 bytes captured (472 bits) on interface 0		
000 04 06 34 01 e7 0f 06	5 Oa 01 25 35 00	00 e4 e8 024 %5
010 00 d6 be 89 8e 40 21		f5 03 19 41@!U 7wA
020 03 02 01 06 07 03 00	1 18 Of 18 Oa 18	
030 72 64 69 63 5f 48 52	2 4d 5† e4 ca	rdic_HRM