## A. Power steering 765 (LS 90, LS 68)

Part No.	Installed in model	Steering gear	Reaction piston dia.	Code number	Pitch Ball circulation	Remarks
107 460 13 01 LL <sup>1</sup> ) 107 460 14 01 RL <sup>2</sup> )	107. 1st version	765.700	11		10.5	
114 460 17 01 LL <sup>1</sup> ) 114 460 18 01 RL <sup>2</sup> )	107 2nd version 114, 115 1st version	765.700	10		10.5	
114 460 08 01 LL <sup>1</sup> ) 114 460 09 01 RL <sup>2</sup> )	107 3rd version 114, 115 2nd version 116.02, 116.032/033 1st version	765.701	10		10.5	_
114 460 21 01 LL <sup>1</sup> ) 114 460 22 02 RL <sup>2</sup> )	107 4th version 114, 115 3rd version	765.701	11	1	10.5	_
107 460 17 01 LL <sup>1</sup> ) 107 460 18 01 RL <sup>2</sup> )	107 5th version 114, 115 4th version 123 1st version	765.701	11.5	1	10.5	_
107 460 19 00 LL <sup>1</sup> )	107 6th version	765.701	11.5	1 1	10.5	Identification "S" on steering case = additional stop
16 460 10 01 LL <sup>1</sup> ) 16 460 11 01 RL <sup>2</sup> )	116.02 116.032/033 2nd version	765.702	9	9 1	0.5	
16 460 12 01 LL <sup>1</sup> ) 16 460 13 01 RL <sup>2</sup> )	116.036	765.703	8	8 1	0.5	
23 460 47 01 LL <sup>1</sup> ) 23 460 48 01 RL <sup>2</sup> )	123 2nd version	765.704	11.5	1 1	0.5	Steering locks in teering case, dentification "A"
23 460 58 01 LL <sup>1</sup> ) 23 460 59 01 RL <sup>2</sup> )	123 3rd version	765.704	11.5	1 9	1-01-000	

Part No.	Installed in model	Steering gear	Reaction piston dia.	Code number	Pitch Ball circulation	Remarks
126 460 04 01 LL <sup>1</sup> ) 126 460 05 01 RL <sup>2</sup> )	126.02 126.03 1st version	765.706	13		10.5	Identification "D" (degressive reaction)
126 460 14 01 LL <sup>1</sup> ) 126 460 15 01 RL <sup>2</sup> )	126.04 1st version 126.02 126.03 2nd version	765.706	13		10	Identification "D" and automatic compensation for play
201 460 57 01 LL <sup>1</sup> ) 201 460 58 01 RL <sup>2</sup> )	201.02 1st version	765.900	11.5		10	Automatic com- pensation for play. Grey iron housing, with dowel sleeve
201 460 43 01 LL <sup>1</sup> ) 201 460 49 01 RL <sup>2</sup> )	201.02 2nd version 201.1 1st version	765.900	11.5		10	Automatic com- pensation for play. Light alloy housing, with dowel sleeve
201 460 66 01 LL <sup>1</sup> ) 201 460 67 01 RL <sup>2</sup> )	201.02 3rd version 201.1 2nd version	765,900	11.5	_	10	Automatic com- pensation for play. Light alloy housing, without dowel sleeve
201 460 60 01 LL <sup>1</sup> )	201.03	765.902	11.5		11	Automatic com- pensation for play. Light alloy housing, without dowel sleeve

<sup>1)</sup> LL = lefthand steering
2) RL = righthand steering

## B. Mechanical steering 760 (L 1 Z, L 075 Z)

Part No.	Installed in model	Steering gear	Pitch Ball circulation	Remarks
115 460 19 01 LL <sup>1</sup> ) 115 460 20 01 RL <sup>2</sup> )	114, 115 1st version	760.100	9	Pertinent pitman arm 115 463 07 01 LL <sup>1</sup> ), 115 463 08 01 RL <sup>2</sup> )
115 460 21 01 LL <sup>1</sup> ) 115 460 22 01 RL <sup>2</sup> )	114, 115 2nd version	760.100	10	Pertinent pitman arm 115 463 12 01 LL <sup>1</sup> ), 115 463 13 01 RL <sup>2</sup> )
123 460 38 01 LL <sup>1</sup> ) 123 460 39 01 RL <sup>2</sup> )	123 1st version	760.100	9	Pitman shaft dia. 30 mm
123 460 62 01 LL <sup>1</sup> ) 123 460 63 01 RL <sup>2</sup> )	123 2nd version	760.100	9	Pitman shaft dia. 32 mm
201 460 52 01 LL <sup>1</sup> ) 201 460 55 01 RL <sup>2</sup> )	201 1st version	760.700	9	With dowel sleeve
201 460 68 01 LL <sup>1</sup> ) 201 460 69 01 RL <sup>2</sup> )	201 2nd version	760.700	9	Without dowel sleeve

<sup>1)</sup> LL = lefthand steering
2) RL = righthand steering