A. Power steering 765 (LS 90, LS 68)

| Part No. | Installed in model | Steering gear | Reaction piston dia. | Code number | Pitch Ball circulation | Remarks |
|--|--|---------------|----------------------|----------------|------------------------------|---|
| 107 460 13 01 LL ¹) 107 460 14 01 RL ²) | 107. 1st version | 765.700 | 11 | | 10.5 | |
| 114 460 17 01 LL ¹) 114 460 18 01 RL ²) | 107 2nd version 114, 115 1st version | 765.700 | 10 | | 10.5 | |
| 114 460 08 01 LL ¹) 114 460 09 01 RL ²) | 107 3rd version 114, 115 2nd version 116.02, 116.032/033 1st version | 765.701 | 10 | | 10.5 | |
| 114 460 21 01 LL ¹) 114 460 22 02 RL ²) | 107 4th version 114, 115 3rd version | 765.701 | 11 | 1 | 10.5 | |
| 107 460 17 01 LL ¹) 107 460 18 01 RL ²) | 107 5th version 114, 115 4th version 123 1st version | 765.701 | 11.5 | 1 | 10.5 | |
| 107 460 19 00 LL ¹) | 107 6th version | 765.701 | 11.5 | 1 | 10.5 | Identification "S" on steering case = additional stop |
| 116 460 10 01 LL ¹) 116 460 11 01 RL ²) | 116.02 116.032/033 2nd version | 765.702 | 9 | 9 | 10.5 | _ |
| 116 460 12 01 LL ¹) 116 460 13 01 RL ²) | 116.036 | 765.703 | 8 | 8 | 10.5 | **** |
| 123 460 47 01 LL ¹) 123 460 48 01 RL ²) | 123 2nd version | 765.704 | 11.5 | 1 | 10.5 | Steering locks in steering case, identification "A" |
| 123 460 58 01 LL ¹) 123 460 59 01 RL ²) | 123 3rd version | 765.704 | 11.5 | 1 | 9 | |

| Part No. | Installed in model | Steering gear | Reaction piston dia. | Code number | Pitch Ball circulation | Remarks |
|--|--|---------------|----------------------|----------------|------------------------------|--|
| 126 460 04 01 LL ¹) 126 460 05 01 RL ²) | 126.02 126.03 1st version | 765.706 | 13 | _ | 10.5 | Identification "D" (degressive reaction) |
| 126 460 14 01 LL ¹) 126 460 15 01 RL ²) | 126.04 1st version 126.02 126.03 2nd version | 765.706 | 13 | | 10 | Identification "D" and automatic compensation for play |
| 201 460 57 01 LL ¹) 201 460 58 01 RL ²) | 201.02 1st version | 765.900 | 11.5 | | 10 | Automatic com- pensation for play. Grey iron housing, with dowel sleeve |
| 201 460 43 01 LL ¹) 201 460 49 01 RL ²) | 201.02 2nd version 201.1 1st version | 765.900 | 11.5 | - | 10 | Automatic com- pensation for play. Light alloy housing, with dowel sleeve |
| 201 460 66 01 LL ¹) 201 460 67 01 RL ²) | 201.02 3rd version 201.1 2nd version | 765.900 | 11.5 | | 10 | Automatic compensation for play. Light alloy housing, without dowel sleeve |
| 201 460 60 01 LL ¹) | 201.03 | 765.902 | 11.5 | | 11 | Automatic com- pensation for play. Light alloy housing, without dowel sleeve |

¹⁾ LL = lefthand steering
2) RL = righthand steering