



SVI™
SPECTRA/VIDEO

Screen Display



Tips on Handling and Storage

1. Avoid touching the tape with your fingers; you may cause drop-outs or scratches.
2. Protect your cassette from dust and damage when not in use by keeping it in its protective plastic box.
3. The tape should be wound snugly on the cassette reels; if the tape is loose, carefully wind it on to one of the reels by gently turning one of the hubs.
4. Keep the recorder head and pinch roller clean by regular use of a good cassette head cleaner.

5. Avoid prolonged exposure of cassettes to excessive heat, sunlight and strong magnetic fields. Do not store near heating appliances, TV sets or similar equipment.

6. To preserve valuable or prized recordings, punch out and remove the erasure prevention tab on the top edge of the cassette.



325 SQUASH

Introduction

Do you find it difficult to make time to play squash or book a court when you want one -- now you can play in the comfort and convenience of your own home. Using your joystick or cursor controls keys you can bash-it-out in a this action packed game computer squash.

Hardware Requirements

1. SVI-318 or SVI-328 Computer
2. Data Cassette
3. One Joystick (Optional)

Getting Started

1. Hook up your computer to the TV or monitor and connect the data cassette as per the instructions in your User's Manual.
2. Turn all units on.
3. Insert tape and Rewind Fully. Type:

load ENTER

Wait until the filename is Found and the "Ok" prompt appears.

4. Press F5 to run the program. Refer to the instructions section for details.

Instructions

1. Once loaded the program will display the copyright credits, then a brief description of the game.
2. Press ENTER to begin playing. The court will be drawn and the score and the number of balls remaining will be displayed at the top of the screen (refer to Fig. 1). You score 1 point for every time the ball hits the top wall. The object of the game is to score as many points as possible before losing three balls.

The ball is served automatically. You must be in the correct position. Press the keys to properly position the racket and return the ball (see below).

RACKET LEFT-----RACKET RIGHT

RACKET DOWN

RACKET CONTROL WITH JOYSTICK
OR ARROW KEYS

4. The game ends when you have used up all three balls. Simply press ENTER to play another match.

In the Event of Difficulty

1. If the program is in progress, and the computer hangs up, hold down the CTRL key while pressing the STOP key. When the "Ok" prompt is displayed, press F5 to run the game. If this fails to eliminate the problem try step 2.

2. Turn off all equipment and check all connecting cables.

Rewind tape and retry the procedures outlined in "Getting Started".

