

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 1 of 29

Communication interface control document

ICD

For Micro Sting systems

	Position	Name	Date
Prepared by	SW team lead	Lior Malik	14-Sep-2025
Approved by	Technical Manager	Ido Appelbaum	14-Sep-2025
Approved by	VP R&D	David Chernya	14-Sep-2025

© MICROCON

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 2 of 29

Table of Contents

Enumerated Lists (Enums).....	4
1. Enums List.....	4
Functions List.....	7
2. Gimbal	7
2.1. Init.....	7
2.2. Ready	7
2.3. Drift Calibration	7
2.4. Rate.....	7
2.5. Position	8
2.6. Gyro Report	8
2.7. GRR (Ground Reference Rate)	9
2.8. GRR+Rate	9
2.9. Stabilization Error	10
2.10. Control Data	10
2.11. BIT Status	10
3. Cameras	11
3.1. Day Camera	11
3.2. TI Camera.....	14
3.3. Camera BITs	16
4. Video Channel.....	17
4.1. Video Channel Command	17
4.2. Video Channel Report.....	18
4.3. Video Channel RunTime Config	19
4.4. Video Record	20
5. Algorithms	21
5.1. Tracker	21
5.2. Gate Parameters.....	22
5.3. Tracker Movement	23
5.4. VMD.....	24

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 3 of 29

5.5. ATR.....	24
6. System	25
6.1. Keep Alive	25
6.2. Get Specific Data	25
6.3. General Reports.....	25
6.4. Log Records	25
6.5. Power Management	26
6.6. System Clock.....	27
6.7. System Version	28

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 4 of 29

Enumerated Lists (Enums)

This section outlines the enumerated lists (enums) used throughout our API. An enum is a data type that defines a set of named integer constants, which are used to represent a fixed set of values for specific fields.

Using these enums ensures consistency and clarity in data representation across the API, replacing arbitrary numbers with descriptive, human-readable names. When integrating with our API, please refer to the following definitions to correctly handle all possible states and values for each respective field.

1. Enums List

Enum Type	Value
Camera	TI = 1 DTV = 2
PIP	On = 1 Off = 2
TOperationMode_Micro	Ready = 0 Init = 1 Rate = 2 Position_RelativeAngles = 3 DriftCalibration = 4 BIT = 5 Safe = 6 Center = 7 Launch = 8 STOW = 9 Track = 10 GimbalCalibration = 11 SystemLoading = 12
ZoomChange	Nochange = 0 Zoomout = 1 Zoomin = 2
TrackerType	Autogatesize20pix = 0 StructureSmall = 1 StructureMedium = 2 StructureLarge = 3 Human = 4 Vehicle = 5 Truck = 6
TrackerStatus	NoTrack = 0 TrackerOK = 1 Prediction = 2 TrackLoss = 3
GenericIncDecVal	NoChange = 0 DecreaseValue = 1 IncreaseValue = 2

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 5 of 29

Enum Type	Value
DTVExposureMode	ManualExposureMode = 9 AutomaticExposureMode = 12
DTVExposureModeSet	SetAutomaticExposureMode = 0 SetManualExposureMode = 1
ThermalCameraColorPalette	SetColorPaletteNC = 0 SetColorPaletteWhiteHot = 1 SetColorPaletteBlackHot = 2 SetColorPaletteRainbow = 3 SetColorPaletteRainbowHC = 4 SetColorPalettelronBow = 5
ThermalCameraGainMode	GainModeNC = 0 GainModeHigh = 1 GainModeLow = 2 GainModeAuto = 3
ThermalCameraSyncMode	SyncModeNC = 0 SyncModeDisabled = 1 SyncModeMaster = 2
ThermalCameraColorPalleteMode	ColorPaletteNC = 0 ColorPaletteWhiteHot = 1 ColorPaletteBlackHot = 2 ColorPaletteRainbow = 3 ColorPaletteRainbowHC = 4 ColorPalettelronBow = 5
NUCMode	NucModeManual = 0 NucModeAuto = 1 NucModeExternal = 2 NucModeShutterTest = 3
ThermalCameraFFCMode	FFCModeNC = 0 FFCModeManual = 1 FFCModeAuto = 2
NUCForceActivate	NoForceNUC = 0 SetForceNuc = 1
PowerStatesRequest	PowerRequestNC = 0 PowerRequestOn = 1 PowerRequestOff = 2
PowerStatesReport	PowerReportOff = 0 PowerReportOn = 1
RetreiveDataType	StopRetreive = 0 CyclicRetreive = 1 OnceRetreive = 2 OnArrival = 4
FontColor	BLACK = 0 RED = 1 GREEN = 2 YELLOW = 3

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 6 of 29

Enum Type	Value
	BLUE = 4 MAGENTA = 5 CYAN = 6 LIGHT_GREY = 7 GREY = 8 BRIGHT_RED = 9 BRIGHT_GREEN = 10 BRIGHT_YELLOW = 11 BRIGHT_BLUE = 12 BRIGHT_MAGENTA = 13 BRIGHT_CYAN = 14 WHITE = 15

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 7 of 29

Functions List

This section provides a comprehensive list of all available API functions, detailing their purpose, parameters, and return values. Each function is a specific operation your application can call to interact with our system, such as gimbal movements, camera control etc

2. Gimbal

2.1. Init

Function Name	Args	Description	Return Type	Signature
SystemInit	None	Initialize the system - Gimbals and Sensors. This process takes few seconds	int Success	int SetSystemInit();

2.2. Ready

Function Name	Args	Description	Return Type	Signature
IDLE	None	Enter to Idle Mode. Shutdown gimbals' motors and releases gimbal's current loop.	int Success	int SetIDLE();

2.3. Drift Calibration

Function Name	Args	Description	Return Type	Signature
DriftCalibration	None	Performs calibration to gimbal. This process takes few seconds.	int Success	int SetDriftCalibration();

2.4. Rate

Function Name	Args	Description	Return Type	Signature
RateCommandAngularVelocities_X	float AngularVelocities_X	Set Angular Velocities for both axes, in units [°/Sec] On X Axis	int Success	int SetRateCommandAngularVelocities_X(float AngularVelocities_X);
RateCommandAngularVelocities_Y	float AngularVelocities_Y	Set Angular Velocities for both axes, in units	int Success	int SetRateCommandAngularVelocities_Y(float

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 8 of 29

Function Name	Args	Description	Return Type	Signature
		[°/Sec] On Y Axis		AngularVelocities_Y);

2.5. Position

2.5.1. Position

Function Name	Args	Description	Return Type	Signature
PositionCommandLOSAngles_X	float LOSAngles_X	Set Line Of Sight Command in angels [°] On X Axis	int Success	int SetPositionCommandLOSAngles_X(float LOSAngles_X);
PositionCommandLOSAngles_Y	float LOSAngles_Y	Set Line Of Sight Command in angels [°] On Y Axis	int Success	int SetPositionCommandLOSAngles_Y(float LOSAngles_Y);

2.5.2. Center Position

Function Name	Args	Description	Return Type	Signature
CenterMode	None	Set system as Center Mode. Sets predefined gimbal angles and sensors FOV	int Success	int SetCenterMode();

2.5.3. Safe Position

Function Name	Args	Description	Return Type	Signature
SafeMode	None	Set system to Safe Mode. Set predefined gimbal angles and sensors FOV	int Success	int SetSafeMode();

2.5.4. Position Report

Function Name	Args	Description	Return Type	Signature
PositionReportRelativeGimbalAngles_X	None	Gets Line Of Sight in angels, in units [°] On X Axis		float GetPositionReportRelativeGimbalAngles_X();
PositionReportRelativeGimbalAngles_Y	None	Gets Line Of Sight in angels, in units [°] On Y Axis		float GetPositionReportRelativeGimbalAngles_Y();

2.6. Gyro Report

Function Name	Args	Description	Return Type	Signature
---------------	------	-------------	-------------	-----------

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 9 of 29

Function Name	Args	Description	Return Type	Signature
GyroRawReportControlGyroTimeTag	None	Gets Control Gyro Message Time Tag	uint64_t	uint64_t GetGyroRawReportControlGyroTimeTag();
GyroRawReportGyroYaw	None	Gets Gyro Yaw Value	float	float GetGyroRawReportGyroYaw();
GyroRawReportGyroPitch	None	Gets Gyro Pitch Value	float	float GetGyroRawReportGyroPitch();
GyroRawReportGyroRoll	None	Gets Gyro Roll Value	float	float GetGyroRawReportGyroRoll();

2.7. GRR (Ground Reference Rate)

Function Name	Args	Description	Return Type	Signature
GroundReferenceCommandAngularVelocities_X	float AngularVelocities_X	Sets GRR (Ground Reference Rate) Angular Velocities, in units [°/Sec] On X Axis	int Success	int SetGroundReferenceCommandAngularVelocities_X(float AngularVelocities_X);
GroundReferenceCommandAngularVelocities_Y	float AngularVelocities_Y	Sets GRR (Ground Reference Rate) Angular Velocities, in units [°/Sec] On Y Axis	int Success	int SetGroundReferenceCommandAngularVelocities_Y(float AngularVelocities_Y);
GroundReferenceCommandSlantRange	float SlantRange	Sets Slant Range, in units [meters]	int Success	int SetGroundReferenceCommandSlantRange(float SlantRange);
GroundReferenceReportAngularVelocities_X	None	Gets GRR (Ground Reference Rate) Angular Velocities, in units [°/Sec] On X Axis		float GetGroundReferenceReportAngularVelocities_X();
GroundReferenceReportAngularVelocities_Y	None	Gets GRR (Ground Reference Rate) Angular Velocities, in units [°/Sec] On Y Axis		float GetGroundReferenceReportAngularVelocities_Y();
GroundReferenceReportSlantRange	None	Gets Slant Range, in units [meters]		float GetGroundReferenceReportSlantRange();

2.8. GRR+Rate

Function Name	Args	Description	Return Type	Signature
Rate_GRRAngularVelocities_X	None	Gets Angular Velocities + GRR, in units [°/Sec] On		float GetRate_GRRAngularVelocities_X();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 10 of 29

Function Name	Args	Description	Return Type	Signature
		X Axis		
Rate_GRRAngularVelocities_Y	None	Gets Angular Velocities + GRR, in units [°/Sec] On Y Axis		float GetRate_GRRAngularVelocities_Y();

2.9. Stabilization Error

Function Name	Args	Description	Return Type	Signature
StabilizationErrorAngularVelocitiesX	None	Gets Angular Velocities Error On X Axis	int16_t	int16_t GetStabilizationErrorAngularVelocitiesX();
StabilizationErrorAngularVelocitiesY	None	Gets Angular Velocities Error On Y Axis	int16_t	int16_t GetStabilizationErrorAngularVelocitiesY();

2.10. Control Data

Function Name	Args	Description	Return Type	Signature
GimbalControlDataAxisXCurrentConsumption	None	Gets Current Consumption Of X Axis Motor	float	float GetGimbalControlDataAxisXCurrentConsumption();
GimbalControlDataAxisYCurrentConsumption	None	Gets Current Consumption Of Y Axis Motor	float	float GetGimbalControlDataAxisYCurrentConsumption();

2.11. BIT Status

Function Name	Args	Description	Return Type	Signature
GimbalMasterBITStatusSystemBusy	None	Gets Busy Flag Mode	bool	bool GetGimbalMasterBITStatusSystemBusy();
GimbalMasterBITStatusGimbalnotinitialized	None	Gets Control Operational Failure	bool	bool GetGimbalMasterBITStatusGimbalnotinitialized();
GimbalMasterBITStatusGimballnitFail	None	Gets HW + Sensors	bool	bool GetGimbalMasterBITStatusGimballnitFail();
GimbalMasterBITStatusGimbalFail	None	Gets Azimuth Gimbal General Bit	bool	bool GetGimbalMasterBITStatusGimbalFail();
GimbalMasterBITStatusGimbalHigh_LowTempWarning	None	Gets Elevation Gimbal General Bit	bool	bool GetGimbalMasterBITStatusGimbalHigh_LowTempWarning();
GimbalMasterBITStatusPayloadcommfail	None	Gets Elevation Gimbal General	bool	bool GetGimbalMasterBITStatusPayl

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 11 of 29

Function Name	Args	Description	Return Type	Signature
		Bit		oadcommfail();
GimbalMasterBITStatusLowstoragewarning	None	Gets Elevation Gimbal General Bit	bool	bool GetGimbalMasterBITStatusLowstoragewarning();
GimbalMasterBITStatusHiveTemperaturewarning	None	Gets Elevation Gimbal General Bit	bool	bool GetGimbalMasterBITStatusHiveTemperaturewarning();
GimbalMasterBITStatusHivesoftwarefail	None	Gets Elevation Gimbal General Bit	bool	bool GetGimbalMasterBITStatusHivesoftwarefail();
GimbalMasterBITStatusHostCommfail	None	Gets Elevation Gimbal General Bit	bool	bool GetGimbalMasterBITStatusHostCommfail();
GimbalMasterBITStatusVISWideFail	None	Gets Wide Visible Camera fail Bit	bool	bool GetGimbalMasterBITStatusVISWideFail();
GimbalMasterBITStatusVISNarrowFail	None	Gets Narrow Visible Camera fail Bit	bool	bool GetGimbalMasterBITStatusVISNarrowFail();
GimbalMasterBITStatusTIFail	None	Gets TI Camera fail Bit	bool	bool GetGimbalMasterBITStatusTIFail();

3. Cameras

3.1. Day Camera

3.1.1. Commands

Function Name	Args	Description	Return Type	Signature
DayCameraCommandZoomCommand	enum ZoomChange ZoomCommand	Sets DayLightCamera Zoom	int Success	int SetDayCameraCommandZoomCommand(enum ZoomChange ZoomCommand);
DayCameraCommandSharpnessCommand	enum GenericIncDecVal SharpnessCommand	Sets DayLightCamera Sharpness	int Success	int SetDayCameraCommandSharpnessCommand(enum GenericIncDecVal SharpnessCommand);
DayCameraCommandGammaCommand	enum GenericIncDecVal GammaCommand	Sets DayLightCamera Gamma	int Success	int SetDayCameraCommandGammaCommand(enum GenericIncDecVal GammaCommand);

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 12 of 29

Function Name	Args	Description	Return Type	Signature
DayCameraCommandSaturationCommand	enum GenericIncDecVal SaturationCommand	Sets DayLightCamera Saturation	int Success	int SetDayCameraCommandSaturationCommand(enum GenericIncDecVal SaturationCommand);
DayCameraCommandGainCommand	enum GenericIncDecVal GainCommand	Sets DayLightCamera Gain	int Success	int SetDayCameraCommandGainCommand(enum GenericIncDecVal GainCommand);
DayCameraCommandLevelCommand	enum GenericIncDecVal LevelCommand	Sets DayLightCamera Level	int Success	int SetDayCameraCommandLevelCommand(enum GenericIncDecVal LevelCommand);
DayCameraCommandExposureMode	enum DTVExposureModeSet ExposureMode	Sets DayLightCamera Exposure Mode	int Success	int SetDayCameraCommandExposureMode(enum DTVExposureModeSet ExposureMode);
DayCameraCommandExposureTime	enum GenericIncDecVal ExposureTime	Sets DayLightCamera Exposure Time	int Success	int SetDayCameraCommandExposureTime(enum GenericIncDecVal ExposureTime);
DayCameraCommandExposureGain	enum GenericIncDecVal ExposureGain	Sets DayLightCamera Exposure Gain	int Success	int SetDayCameraCommandExposureGain(enum GenericIncDecVal ExposureGain);
DayCameraCommandAutoWhiteBalance	bool AutoWhiteBalance	Sets Auto White Balance	int Success	int SetDayCameraCommandAutoWhiteBalance(bool AutoWhiteBalance);
DayCameraCommandTemperature	uint8_t Temperature	Sets Temperature	int Success	int SetDayCameraCommandTemperature(uint8_t Temperature);
DayCameraCommandFlickerMode	int8_t FlickerMode	Sets Flicker Mode	int Success	int SetDayCameraCommandFlickerMode(int8_t FlickerMode);
DayCameraCommandRestoreToDefault	bool RestoreToDefault	Restores All Parameters And Disables All Changes Except Zoom While Active	int Success	int SetDayCameraCommandRestoreToDefault(bool RestoreToDefault);

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 13 of 29

3.1.2. Reports

Function Name	Args	Description	Return Type	Signature
DayCameraReportExposureMode	None	Gets DayLightCamera Exposure Mode	DTVExposureMode	enum DTVExposureMode GetDayCameraReportExposureMode();
DayCameraReportExposureTime	None	Gets DayLightCamera Exposure Time	int32_t	int32_t GetDayCameraReportExposureTime();
DayCameraReportExposureGain	None	Gets DayLightCamera Exposure Gain	int32_t	int32_t GetDayCameraReportExposureGain();
DayCameraReportGammaValue	None	Gets DayLightCamera Gamma Value	float	float GetDayCameraReportGammaValue();
DayCameraReportSaturationValue	None	Gets DayLightCamera Saturation Value	float	float GetDayCameraReportSaturationValue();
DayCameraReportContrastValue	None	Gets DayLightCamera Contrast Value	float	float GetDayCameraReportContrastValue();
DayCameraReportSharpnessValue	None	Gets DayLightCamera Sharpness Value	float	float GetDayCameraReportSharpnessValue();
DayCameraReportFOV	None	Gets DayLightCamera FOV	float	float GetDayCameraReportFOV();
DayCameraReportZoomXAxisCenter	None	Gets DayLightCamera Zoom X Axis Center	float	float GetDayCameraReportZoomXAxisCenter();
DayCameraReportZoomYAxisCenter	None	Gets DayLightCamera Zoom Y Axis Center	float	float GetDayCameraReportZoomYAxisCenter();
DayCameraReportBrightnessValue	None	Gets DayLightCamera Brightness Value	float	float GetDayCameraReportBrightnessValue();
DayCameraReportAutoWhiteBalance	None	Gets DayLightCamera Auto White Balance	int32_t	int32_t GetDayCameraReportAutoWhiteBalance();
DayCameraReportTemperatureValue	None	Gets DayLightCamera Temperature Value	int32_t	int32_t GetDayCameraReportTemperatureValue();
DayCameraReportFlickerMode	None	Gets	float	float

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 14 of 29

Function Name	Args	Description	Return Type	Signature
		DayLightCamera Flicker Mode		GetDayCameraReportFlickerMode();

3.2. TI Camera

3.2.1. Commands

Function Name	Args	Description	Return Type	Signature
ThermalCameraCommandZoomCommand	enum ZoomChange ZoomCommand	Sets Thermal Camera Zoom Command	int Success	int SetThermalCameraCommandZoomCommand(enum ZoomChange ZoomCommand);
ThermalCameraCommandGainCommand	enum GenericIncDecVal GainCommand	Sets Thermal Camera Gain Command	int Success	int SetThermalCameraCommandGainCommand(enum GenericIncDecVal GainCommand);
ThermalCameraCommandLevelCommand	enum GenericIncDecVal LevelCommand	Sets Thermal Camera Level Command	int Success	int SetThermalCameraCommandLevelCommand(enum GenericIncDecVal LevelCommand);
ThermalCameraCommandGainModeCommand	enum ThermalCameraGainMode GainModeCommand	Sets Thermal Camera Gain Mode Command	int Success	int SetThermalCameraCommandGainModeCommand(enum ThermalCameraGainMode GainModeCommand);
ThermalCameraCommandLinearPercentCommand	enum GenericIncDecVal LinearPercentCommand	Sets Thermal Camera Linear Percent Command	int Success	int SetThermalCameraCommandLinearPercentCommand(enum GenericIncDecVal LinearPercentCommand);
ThermalCameraCommandACECommand	enum GenericIncDecVal ACECommand	Sets Thermal Camera Gamma Corective Value (ACE) Command	int Success	int SetThermalCameraCommandACECommand(enum GenericIncDecVal ACECommand);
ThermalCameraCommandSharpnessCommand	enum GenericIncDecVal SharpnessCommand	Sets Thermal Camera Sharpness Command	int Success	int SetThermalCameraCommandSharpnessCommand(enum GenericIncDecVal SharpnessCommand);
ThermalCameraCommandNUCMode	enum ThermalCameraFFCMode NUCMode	Sets Thermal Camera NUC Mode	int Success	int SetThermalCameraCommandNUCMode(enum ThermalCameraFFCMode NUCMode);

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 15 of 29

Function Name	Args	Description	Return Type	Signature
				ThermalCameraFFCMode NUCMode);
ThermalCameraCommandColor Palette	enum ThermalCameraC olorPalette ColorPalette	Sets Thermal Camera Color Palette Command	int Success	int SetThermalCameraCommandCo lorPalette(enum ThermalCameraColorPalette ColorPalette);
ThermalCameraCommandNUC	enum NUCForceActivate NUC	Sets Thermal Camera NUC Force Set	int Success	int SetThermalCameraCommandN UC(enum NUCForceActivate NUC);
ThermalCameraCommandResto reToDefault	bool RestoreToDefault	Restores All Parameters And Disables All Changes Excpet Zoom While Active	int Success	int SetThermalCameraCommandRe storeToDefault(bool RestoreToDefault);
ThermalCameraCommandSync ModeCommand	enum ThermalCameraSy ncMode SyncModeComma nd	Sets Thermal Camera Sync Mode Command	int Success	int SetThermalCameraCommandSy ncModeCommand(enum ThermalCameraSyncMode SyncModeCommand);

3.2.2. Reports

Function Name	Args	Description	Return Type	Signature
ThermalCameraReportGainMod e	None	Gets Thermal Camera Gain Mode	ThermalCameraG ainMode	enum ThermalCameraGainMode GetThermalCameraReportGain Mode();
ThermalCameraReportSyncMod e	None	Gets Thermal Camera Sync Mode	ThermalCameraSy ncMode	enum ThermalCameraSyncMode GetThermalCameraReportSync Mode();
ThermalCameraReportLinearPe rcent	None	Gets Thermal Camera Linear Percent	float	float GetThermalCameraReportLinea rPercent();
ThermalCameraReportACEValu e	None	Gets Thermal Camera Gamma Corective Value (ACE)	float	float GetThermalCameraReportACEV alue();
ThermalCameraReportDDEValu e	None	Gets Thermal Camera Headroom Detail (DDE)	float	float GetThermalCameraReportDDEV alue();
ThermalCameraReportColorPal	None	Gets Thermal	ThermalCameraC	enum

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 16 of 29

Function Name	Args	Description	Return Type	Signature
ette		Camera Color Palette Mode	olorPalleteMode	ThermalCameraColorPalleteMode GetThermalCameraReportColorPalette();
ThermalCameraReportNUCMode	None	Gets Noc Enable Mode	NUCMode	enum NUCMode GetThermalCameraReportNUCMode();
ThermalCameraReportFOV	None	Gets Thermal Camera Field Of View	float	float GetThermalCameraReportFOV();
ThermalCameraReportGainValue	None	Gets Thremal Camera Gain Value	int32_t	int32_t GetThermalCameraReportGainValue();
ThermalCameraReportLevelValue	None	Gets Thremal Camera Level Value	int32_t	int32_t GetThermalCameraReportLevelValue();

3.3. Camera BITs

3.3.1. Commands

Function Name	Args	Description	Return Type	Signature
ClearStickyBIT	None	Clear Cameras Sticky BITs	int Success	int SetClearStickyBIT();

3.3.2. Reports

Function Name	Args	Description	Return Type	Signature
CamerasBITStatusDTVNarrowActiveError	None	Gets DTV Narrow Active Error BIT	bool	bool GetCamerasBITStatusDTVNarrowActiveError();
CamerasBITStatusDTVNarrowStickyError	None	Gets DTV Narrow Sticky Error BIT	bool	bool GetCamerasBITStatusDTVNarrowStickyError();
CamerasBITStatusDTVNarrowInitError	None	Gets DTV Narrow Init Error BIT	bool	bool GetCamerasBITStatusDTVNarrowInitError();
CamerasBITStatusDTVNarrowVideoErrorsCounter	None	Gets DTV Narrow Video Errors Counter BIT	uint8_t	uint8_t GetCamerasBITStatusDTVNarrowVideoErrorsCounter();
CamerasBITStatusDTVWideActiveError	None	Gets DTV Wide Active Error BIT	bool	bool GetCamerasBITStatusDTVWideActiveError();
CamerasBITStatusDTVWideStickyError	None	Gets DTV Wide Sticky Error BIT	bool	bool GetCamerasBITStatusDTVWideStickyError();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 17 of 29

Function Name	Args	Description	Return Type	Signature
CamerasBITStatusDTVWideInitError	None	Gets DTV Wide Init Error BIT	bool	bool GetCamerasBITStatusDTVWideInitError();
CamerasBITStatusDTVWideVideoErrorsCounter	None	Gets DTV Wide Video Errors Counter BIT	uint8_t	uint8_t GetCamerasBITStatusDTVWideVideoErrorsCounter();
CamerasBITStatusTIActiveError	None	Gets TI Active Error BIT	bool	bool GetCamerasBITStatusTIActiveError();
CamerasBITStatusTISTickyError	None	Gets TI Sticky Error BIT	bool	bool GetCamerasBITStatusTISTickyError();
CamerasBITStatusTIInitError	None	Gets TI Init Error BIT	bool	bool GetCamerasBITStatusTIInitError();
CamerasBITStatusTIVideoErrorsCounter	None	Gets TI Video Errors Counter BIT	uint8_t	uint8_t GetCamerasBITStatusTIVideoErrorsCounter();
CamerasBITStatusUSBHubActiveError	None	Gets USB Hub Active Error BIT	bool	bool GetCamerasBITStatusUSBHubActiveError();
CamerasBITStatusUSBHubStickyError	None	Gets USB Hub Sticky Error BIT	bool	bool GetCamerasBITStatusUSBHubStickyError();
CamerasBITStatusUSBHubInitError	None	Gets USB Hub Init Error BIT	bool	bool GetCamerasBITStatusUSBHubInitError();

4. Video Channel

4.1. Video Channel Command

Function Name	Args	Description	Return Type	Signature
VideoChannelCommandPrimaryVideoChannel	enum Camera PrimaryVideoChannel	Select primary sensors DTV/TI	int Success	int SetVideoChannelCommandPrimaryVideoChannel(enum Camera PrimaryVideoChannel);
VideoChannelCommandFOVSynchronizationMode	bool FOVSynchronizationMode	Enables/Disables sensors sync - secondary sensor changes its FOV according primary's FOV	int Success	int SetVideoChannelCommandFOVSynchronizationMode(bool FOVSynchronizationMode);
VideoChannelCommandImageStabilizationEnable	bool ImageStabilization	Enables/Disables Image	int Success	int SetVideoChannelCommandImageStabilizationEnable(bool ImageStabilization);

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 18 of 29

Function Name	Args	Description	Return Type	Signature
	Enable	Stabilization		geStabilizationEnable(bool ImageStabilizationEnable);
VideoChannelCommandImageStabilizationMethod	bool ImageStabilizationMethod	Sets image stabilization method. 0 - Image based. 1 - IMU Based	int Success	int SetVideoChannelCommandImageStabilizationMethod(bool ImageStabilizationMethod);
VideoChannelCommandOSDDisabled	bool OSDDisabled	Disables/Enables OSD layer (Set '1' to disable)	int Success	int SetVideoChannelCommandOSDDisabled(bool OSDDisabled);
VideoChannelCommandPIPEnable	enum PIP PIPEnable	Enables/Disables streaming secondary sensor as Picture-In-Picture on video stream	int Success	int SetVideoChannelCommandPIPEnable(enum PIP PIPEnable);
VideoChannelCommandHistogramEnable	bool HistogramEnable	Enables/Disables Histogram on video stream	int Success	int SetVideoChannelCommandHistogramEnable(bool HistogramEnable);
VideoChannelCommandFontColor	enum FontColor FontColor	Sets OSD font color	int Success	int SetVideoChannelCommandFontColor(enum FontColor FontColor);

4.2. Video Channel Report

Function Name	Args	Description	Return Type	Signature
VideoChannelReportPrimaryVideoChannel	None	Select primary sensors DTV/TI	Camera	enum Camera GetVideoChannelReportPrimaryVideoChannel();
VideoChannelReportFOVSynchronizationMode	None	Enables/Disables sensors sync - secondary sensor changes its FOV according primary's FOV	bool	bool GetVideoChannelReportFOVSynchronizationMode();
VideoChannelReportImageStabilizationEnable	None	Enables/Disables Image Stabilization	bool	bool GetVideoChannelReportImageStabilizationEnable();
VideoChannelReportImageStabilizationMethod	None	Sets image stabilization method. 0 - Image based. 1 - IMU Based	bool	bool GetVideoChannelReportImageStabilizationMethod();
VideoChannelReportOSDDisabled	None	Disables/Enables	bool	bool

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 19 of 29

Function Name	Args	Description	Return Type	Signature
ed		OSD layer (Set '1' to disable)		GetVideoChannelReportOSDDisabled();
VideoChannelReportPIPEnable	None	Enables/Disables streaming secondary sensor as Picture-In-Picture on video stream	bool	bool GetVideoChannelReportPIPEnable();
VideoChannelReportHistogram Enable	None	Gets Enables/Disables Histogram on video stream	bool	bool GetVideoChannelReportHistogramEnable();
VideoChannelReportFontColor	None	Sets OSD font color	FontColor	enum FontColor GetVideoChannelReportFontColor();

4.3. Video Channel RunTime Config

Function Name	Args	Description	Return Type	Signature
VideoChannelRunTimeConfigStopChannel0Stream	bool StopChannel0Stream	Stop Channel 0 Stream	int Success	int SetVideoChannelRunTimeConfigStopChannel0Stream(bool StopChannel0Stream);
VideoChannelRunTimeConfigStartChannel0Stream	bool StartChannel0Stream	Start Channel 0 Stream	int Success	int SetVideoChannelRunTimeConfigStartChannel0Stream(bool StartChannel0Stream);
VideoChannelRunTimeConfigH264Channel0Stream	bool H264Channel0Stream	Set Channel 0 Stream to H264 encoding	int Success	int SetVideoChannelRunTimeConfigH264Channel0Stream(bool H264Channel0Stream);
VideoChannelRunTimeConfigH265Channel0Stream	bool H265Channel0Stream	Set Channel 0 Stream to H265 encoding	int Success	int SetVideoChannelRunTimeConfigH265Channel0Stream(bool H265Channel0Stream);
VideoChannelRunTimeConfigBandwidthChannel0Stream	int32_t BandwidthChannel0Stream	Set Channel 0 Bandwidth - leave 0 if no change required	int Success	int SetVideoChannelRunTimeConfigBandwidthChannel0Stream(int32_t BandwidthChannel0Stream);
VideoChannelRunTimeConfigStopDTVStream	bool StopDTVStream	Stop DTV Wide and DTV Narrow pipeline	int Success	int SetVideoChannelRunTimeConfigStopDTVStream(bool StopDTVStream);
VideoChannelRunTimeConfigStopTISStream	bool StopTISStream	Stop TI pipeline	int Success	int SetVideoChannelRunTimeConfigStopTISStream(bool StopTISStream);

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 20 of 29

Function Name	Args	Description	Return Type	Signature
				gStopTIStream(bool StopTIStream);

4.4. Video Record

4.4.1. Command

Function Name	Args	Description	Return Type	Signature
RecordVideoCommandEnable	bool Enable	Starts/Stops Recording Video	int Success	int SetRecordVideoCommandEnable(bool Enable);
RecordVideoCommandEnableRaw	bool EnableRaw	Starts/Stops Recording Raw Video	int Success	int SetRecordVideoCommandEnableRaw(bool EnableRaw);
RecordVideoCommandDeleteALLRecords	bool DeleteALLRecords	Deletes All Records	int Success	int SetRecordVideoCommandDeleteALLRecords(bool DeleteALLRecords);
RecordVideoCommandFolderName	char* FolderName, size_t Size - C string should be at most 19 Bytes.	Sets Record Video Folder Name	int Success	int SetRecordVideoCommandFolderName(char* FolderName, size_t Size);

4.4.2. Report

Function Name	Args	Description	Return Type	Signature
RecordVideoReportRecordVideoTimestamp_nSec_	None	Gets Record Video Timestamp [nSec]	int64_t	int64_t GetRecordVideoReportRecordVideoTimestamp_nSec_();
RecordVideoReportRecordRawVideoTimestamp_nSec_	None	Gets Record Raw Video Timestamp [nSec]	int64_t	int64_t GetRecordVideoReportRecordRawVideoTimestamp_nSec_();
RecordVideoReportDiskFreeSpace_GB_	None	Disk Free Space [GB]	float	float GetRecordVideoReportDiskFreeSpace_GB_();
RecordVideoReportDiskFreeSpace_Percent_	None	Disk Free Space [%]	float	float GetRecordVideoReportDiskFreeSpace_Percent_();
RecordVideoReportTotalDiskSize_GB_	None	Total Disk Size [GB]	float	float GetRecordVideoReportTotalDiskSize_GB_();
RecordVideoReportRecordVideoEnable	None	Record Video Enable	int32_t	int32_t GetRecordVideoReportRecordVideoEnable();
RecordVideoReportRecordRaw	None	Record Raw Video	int32_t	int32_t

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 21 of 29

Function Name	Args	Description	Return Type	Signature
VideoEnable		Enable		GetRecordVideoReportRecordRawVideoEnable();
RecordVideoReportVideoDelete	None	ALL Recorded video is in deletion process	int32_t	int32_t GetRecordVideoReportVideoDelete();
RecordVideoReportDiskStatus	None	Disk Status	int32_t	int32_t GetRecordVideoReportDiskStatus();
RecordVideoReportFolderName	char* Buffer, size_t Size - Buffer size should be at least 20	Sets Record Video Folder Name	void	void GetRecordVideoReportFolderName(char* Buffer, size_t Size);

5. Algorithms

5.1. Tracker

5.1.1. Command

Function Name	Args	Description	Return Type	Signature
Track	int16_t TargetXCoordinate, int16_t TargetYCoordinate	Change X, Y coordination in pixels, relative to center of screen. Positive direction is Right, Down.	int Success	int SetTrack(int16_t TargetXCoordinate, int16_t TargetYCoordinate);

5.1.2. Report

Function Name	Args	Description	Return Type	Signature
TrackerTargetErrorReportCamera	None	Gets active sensor	Camera	enum Camera GetTrackerTargetErrorReportCamera();
TrackerTargetErrorReportTrackerGeneralStatus	None	Gets tracker status	TrackerStatus	enum TrackerStatus GetTrackerTargetErrorReportTrackerGeneralStatus();
TrackerTargetErrorReportTrackingQuality	None	Gets tracker quality, in range [0 (worst) ÷ 7(best)]	uint8_t	uint8_t GetTrackerTargetErrorReportTrackingQuality();
TrackerTargetErrorReportCurrentFOV	None	Gets current FOV of selected sensor	uint16_t	uint16_t GetTrackerTargetErrorReportCurrentFOV();
TrackerTargetErrorReportTrackerXError	None	Gets tracker error at X axis, in pixels	float	float GetTrackerTargetErrorReportTrackerXError();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 22 of 29

Function Name	Args	Description	Return Type	Signature
				ackerXError();
TrackerTargetErrorReportTrackerYError	None	Gets tracker error at Y axis, in pixles	float	float GetTrackerTargetErrorReportTrackerYError();
TrackerTargetErrorReportGMC	None	Gets GMC value	int8_t	int8_t GetTrackerTargetErrorReportGMC();
TrackerTargetErrorReportGateSizeX	None	Gets tracker gate size width	uint16_t	uint16_t GetTrackerTargetErrorReportGateSizeX();
TrackerTargetErrorReportGateSizeY	None	Gets tracker gate size heigh	uint16_t	uint16_t GetTrackerTargetErrorReportGateSizeY();

5.2. Gate Parameters

Function Name	Args	Description	Return Type	Signature
TrackerParametersTrackerType	enum TrackerType TrackerType	Sets target type according to TargetType Table. This field sets automatically the gate size.	int Success	int SetTrackerParametersTrackerType(enum TrackerType TrackerType);
TrackerParametersGateXSize	uint16_t GateXSize	Sets gate width in case of manual gate size. The value range $[5 \div (\text{screen width} / 2)]$	int Success	int SetTrackerParametersGateXSize(uint16_t GateXSize);
TrackerParametersGateYSize	uint16_t GateYSize	Sets gate heigh in case of manual gate size. The value range $[5 \div (\text{screen heigh} / 2)]$	int Success	int SetTrackerParametersGateYSize(uint16_t GateYSize);
TrackerParametersGateSizeEnable	bool GateSizeEnable	Enables/Disables manual gate size according provided X, Y sizes. When disabled, gate size will be according to TargetType	int Success	int SetTrackerParametersGateSizeEnable(bool GateSizeEnable);
TrackerGateParametersReportTrackerType	None	Gets selected target type.	int8_t	int8_t GetTrackerGateParametersReportTrackerType();
TrackerGateParametersReportGateXSize	None	Gets current gate X size	uint16_t	uint16_t GetTrackerGateParametersRep

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 23 of 29

Function Name	Args	Description	Return Type	Signature
				ortGateXSize();
TrackerGateParametersReportGateYSize	None	Gets current gate Y size	uint16_t	uint16_t GetTrackerGateParametersReportGateYSize();
TrackerGateParametersReportGateSizeEnable	None	Gets if manual gate size enabled/disabled	bool	bool GetTrackerGateParametersReportGateSizeEnable();

5.3. Tracker Movement

5.3.1. Adjust

Function Name	Args	Description	Return Type	Signature
TrackerAdjustControls	bool AdjustEnable, int16_t MovementCommand_X, int16_t MovementCommand_Y	Sets the values how much to adjust the tracker gate, in units of pixels, for both axis X, Y. Positive direction is Right, Down. On Y Axis	int Success	int SetTrackerAdjustControls(bool AdjustEnable, int16_t MovementCommand_X, int16_t MovementCommand_Y);
TrackerAdjustControlsReportAdjustEnable	None	Gets if adjust function is enabled/disabled	bool	bool GetTrackerAdjustControlsReportAdjustEnable();
TrackerAdjustControlsReportMovementX	None	Returns provided adjust X movement	int16_t	int16_t GetTrackerAdjustControlsReportMovementX();
TrackerAdjustControlsReportMovementY	None	Returns provided adjust Y movement	int16_t	int16_t GetTrackerAdjustControlsReportMovementY();

5.3.2. Offset

Function Name	Args	Description	Return Type	Signature
TrackerOffsetControls	bool OffsetEnable, int16_t Movementcommand_X, int16_t Movementcommand_Y	Sets the values how much to Offset the tracker gate, in units of pixels, for both axis X, Y. Positive direction is Right, Down. On Y Axis	int Success	int SetTrackerOffsetControls(bool OffsetEnable, int16_t Movementcommand_X, int16_t Movementcommand_Y);
TrackerOffsetControlsReportOffsetEnable	None	Gets if offset function is enabled/disabled	bool	bool GetTrackerOffsetControlsReportOffsetEnable();
TrackerOffsetControlsReportM	None	Returns provided	int16_t	int16_t

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 24 of 29

Function Name	Args	Description	Return Type	Signature
ovementX		offset X movement		GetTrackerOffsetControlsReportMovementX();
TrackerOffsetControlsReportMovementY	None	Returns provided offset Y movement	int16_t	int16_t GetTrackerOffsetControlsReportMovementY();

5.4. VMD

5.4.1. Command

Function Name	Args	Description	Return Type	Signature
VMDControlsEnable	bool Enable	Enable/Disable VMD	int Success	int SetVMDControlsEnable(bool Enable);

5.4.2. Report

Function Name	Args	Description	Return Type	Signature
VMDReportEnableVMD	None		bool	bool GetVMDReportEnableVMD();
VMDReportQuantityofDetections	None		uint8_t	uint8_t GetVMDReportQuantityofDetections();

5.5. ATR

5.5.1. Command

Function Name	Args	Description	Return Type	Signature
ATRControlsDetectionsReport	bool DetectionsReport	Enable/Disable ATR	int Success	int SetATRControlsDetectionsReport(bool DetectionsReport);
ATRControlsDetectionThreshold	int8_t DetectionThreshold	Set Detection Threshold [0-100]	int Success	int SetATRControlsDetectionThreshold(int8_t DetectionThreshold);

5.5.2. Report

Function Name	Args	Description	Return Type	Signature
ATRReportEnabled	None	Gets ATR Status Enabled/Disabled	bool	bool GetATRReportEnabled();
ATRReportQuantityofDetections	None	Gets Quantity of Detections	uint8_t	uint8_t GetATRReportQuantityofDetections();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 25 of 29

6. System

6.1. Keep Alive

Function Name	Args	Description	Return Type	Signature
KeepAlive	None	Keep Alive signal. Need to send to system every ~500 mSec	int Success	int SetKeepAlive();

6.2. Get Specific Data

Function Name	Args	Description	Return Type	Signature
GetData	uint16_t Data, RetrieveDataType RetrieveType	Set method to retrieve data	int Success	int SetGetData(uint16_t Data, RetrieveDataType RetrieveType);

6.3. General Reports

Function Name	Args	Description	Return Type	Signature
SystemGeneralReportOperationMode	None	Gets Operation Mode Status	TOperationMode_Micro	enum TOperationMode_Micro GetSystemGeneralReportOperationMode();
SystemGeneralReportHybridMode	None	Gets Hybrid Mode Status	bool	bool GetSystemGeneralReportHybridMode();
SystemGeneralReportHiveTemperature	None	Gets Hive Temperature	int8_t	int8_t GetSystemGeneralReportHiveTemperature();

6.4. Log Records

6.4.1. Command

Function Name	Args	Description	Return Type	Signature
LogRecordCommandEnable	bool Enable	Enables/Disables system logging	int Success	int SetLogRecordCommandEnable(bool Enable);
LogRecordCommandErrorLevel	bool ErrorLevel	Enables/Disables Error Level	int Success	int SetLogRecordCommandErrorLevel(bool ErrorLevel);
LogRecordCommandInfoLevel	bool InfoLevel	Enables/Disables Info Level	int Success	int SetLogRecordCommandInfoLevel(bool InfoLevel);
LogRecordCommandDebugLevel	bool DebugLevel	Enables/Disables Debug Level	int Success	int SetLogRecordCommandDebugLevel(bool DebugLevel);

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 26 of 29

Function Name	Args	Description	Return Type	Signature
				evel(bool DebugLevel);
LogRecordCommandFreeText	char* FreeText, size_t Size - C string should be at most 19 Bytes.	Sets folder name to save log file	int Success	int SetLogRecordCommandFreeTex t(char* FreeText, size_t Size);

6.4.2. Report

Function Name	Args	Description	Return Type	Signature
LogRecordReportEnable	None	Gets if log is Enabled/Disabled	bool	bool GetLogRecordReportEnable();
LogRecordReportErrorLevel	None	Gets if Error Level is Enabled/Disabled	bool	bool GetLogRecordReportErrorLevel();
LogRecordReportInfoLevel	None	Gets if Info Level is Enabled/Disabled	bool	bool GetLogRecordReportInfoLevel() ;
LogRecordReportDebugLevel	None	Gets if Debug Level is Enabled/Disabled	bool	bool GetLogRecordReportDebugLeve l();
LogRecordReportFileName	char* Buffer, size_t Size - Buffer size should be at least 15	Gets log's folder name	void	void GetLogRecordReportFileName(c har* Buffer, size_t Size);

6.5. Power Management

6.5.1. Command

Function Name	Args	Description	Return Type	Signature
CameraPowerControlDayLightC ameraPower	enum PowerStatesRequ est DayLightCameraP ower	Enables/Disables DTV Sensor	int Success	int SetCameraPowerControlDayLig htCameraPower(enum PowerStatesRequest DayLightCameraPower);
CameraPowerControlThermalC ameraPower	enum PowerStatesRequ est ThermalCameraPo wer	Enables/Disables TI Sensor	int Success	int SetCameraPowerControlTherm alCameraPower(enum PowerStatesRequest ThermalCameraPower);

6.5.2. Report

Function Name	Args	Description	Return Type	Signature
CameraPowerReportWideDTVS tate	None	Gets Enabled/Disabled	PowerStatesRepor t	enum PowerStatesReport GetCameraPowerReportWideD

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 27 of 29

Function Name	Args	Description	Return Type	Signature
		Wide DTV		TVState();
CameraPowerReportNarrowDTVState	None	Gets Enabled/Disabled Narrow DTV	PowerStatesReport	enum PowerStatesReport GetCameraPowerReportNarrowDTVState();
CameraPowerReportTIStateState	None	Gets Enabled/Disabled TI	PowerStatesReport	enum PowerStatesReport GetCameraPowerReportTIStateState();

6.6. System Clock

6.6.1. Time Tag Report

Function Name	Args	Description	Return Type	Signature
TimeTagReportSystemTimeTag	None	Gets System Message Time Tag	uint64_t	uint64_t GetTimeTagReportSystemTimeTag();
TimeTagReportControlTimeTag	None	Gets Latest Control Message Time Tag	uint64_t	uint64_t GetTimeTagReportControlTimeTag();

6.6.2. Set System Clock

Function Name	Args	Description	Return Type	Signature
SetSystemClockYear	uint16_t Year	Sets Year as decimal integer [YYYY]	int Success	int SetSetSystemClockYear(uint16_t Year);
SetSystemClockMonth	uint8_t Month	Sets Month as decimal integer [1-12]	int Success	int SetSetSystemClockMonth(uint8_t Month);
SetSystemClockDay	uint8_t Day	Sets Day as decimal integer [1-31]	int Success	int SetSetSystemClockDay(uint8_t Day);
SetSystemClockHour	uint8_t Hour	Sets Hour as decimal integer in 24Hrs Pattern [0-23]	int Success	int SetSetSystemClockHour(uint8_t Hour);
SetSystemClockMinute	uint8_t Minute	Sets Minute as decimal integer [0-59]	int Success	int SetSetSystemClockMinute(uint8_t Minute);
SetSystemClockSecond	uint8_t Second	Sets Second as decimal integer [0-59]	int Success	int SetSetSystemClockSecond(uint8_t Second);

6.6.3. Get System Clock

Function Name	Args	Description	Return Type	Signature
---------------	------	-------------	-------------	-----------

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 28 of 29

Function Name	Args	Description	Return Type	Signature
CurrentSystemTimeYear	None	Gets Year as decimal integer	uint16_t	uint16_t GetCurrentSystemTimeYear();
CurrentSystemTimeMonth	None	Gets Month as decimal integer	uint8_t	uint8_t GetCurrentSystemTimeMonth() ;
CurrentSystemTimeDay	None	Gets Day as decimal integer	uint8_t	uint8_t GetCurrentSystemTimeDay();
CurrentSystemTimeHour	None	Gets Hour as decimal integer in 24Hrs Pattern	uint8_t	uint8_t GetCurrentSystemTimeHour();
CurrentSystemTimeMinute	None	Gets Minute as decimal integer	uint8_t	uint8_t GetCurrentSystemTimeMinute() ;
CurrentSystemTimeSecond	None	Gets Second as decimal integer	uint8_t	uint8_t GetCurrentSystemTimeSecond() ;

6.7. System Version

Function Name	Args	Description	Return Type	Signature
SystemVersionBundle	None	Bundle Version	int8_t	int8_t GetSystemVersionBundle();
SystemVersionCPU	char* Buffer, size_t Size - Buffer size should be at least 16	CPU Version	void	void GetSystemVersionCPU(char* Buffer, size_t Size);
SystemVersionControl	None	Control Version	uint32_t	uint32_t GetSystemVersionControl();
SystemVersionDTVLibrary	char* Buffer, size_t Size - Buffer size should be at least 16	DTV Library Version	void	void GetSystemVersionDTVLibrary(c har* Buffer, size_t Size);
SystemVersionECVML	char* Buffer, size_t Size - Buffer size should be at least 16	ECVML Version	void	void GetSystemVersionECVML(char* Buffer, size_t Size);
SystemVersionSensorsWide	char* Buffer, size_t Size - Buffer size should be at least 16	Sensors Wide Version	void	void GetSystemVersionSensorsWide(char* Buffer, size_t Size);
SystemVersionSensorsNarrow	char* Buffer, size_t Size - Buffer size should be at least 16	Sensors Narrow Version	void	void GetSystemVersionSensorsNarro w(char* Buffer, size_t Size);
SystemVersionSensorsThermal	char* Buffer, size_t Size - Buffer	Sensors Thermal Version	void	void GetSystemVersionSensorsTher

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 29 of 29

Function Name	Args	Description	Return Type	Signature
	size should be at least 16			mal(char* Buffer, size_t Size);