

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 1 of 44

Communication interface control document

ICD

For Micro Sting systems

	Position	Name	Date
Prepared by	SW team lead	Lior Malik	28-Dec-2025
Approved by	Technical Manager	Ido Appelbaum	28-Dec-2025
Approved by	VP R&D	David Chernya	28-Dec-2025

© MICROCON

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 2 of 44

Table of Contents

Enumerated Lists (Enums).....	4
1. Enums List.....	5
Functions List.....	8
2. Gimbal	9
2.1. Init.....	9
2.2. Ready	9
2.3. Drift Calibration	9
2.4. Rate.....	9
2.5. Position	9
2.6. Gyro Report	10
2.7. GRR (Ground Reference Rate)	11
2.8. GRR+Rate	11
2.9. Stabilization Error	12
2.10. Control Data	12
2.11. BIT Status	12
3. Cameras	14
3.1. Day Camera	14
3.2. TI Camera.....	16
3.3. SeeSpot Camera	19
3.4. Camera BITs	19
4. Video Channel.....	21
4.1. Video Channel Command	21
4.2. Video Channel Report.....	21
4.3. Video Channel RunTime Config	22
4.4. Video Record	23
5. Algorithms	25
5.1. Tracker	25
5.2. Gate Parameters.....	26
5.3. Tracker Movement	27

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 3 of 44

5.4. VMD	28
5.5. ATR.....	28
6. Navigation.....	29
6.1. Navigation Init	29
6.2. Navigation Properties	30
6.3. Navigation Data	31
6.4. Navigation Record	35
6.5. Navigation BIT.....	35
7. Designator	37
7.1. Designator Mode	37
7.2. Designator Fire	37
7.3. Designator NATO Code	38
8. Illuminator	39
8.1. Illuminator Arm	39
8.2. Illuminator Fire	39
9. System	40
9.1. Keep Alive	40
9.2. Get Specific Data	40
9.3. General Reports.....	40
9.4. Log Records	40
9.5. Power Management	41
9.6. System Clock.....	42
9.7. System Version	43

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 4 of 44

Enumerated Lists (Enums)

This section outlines the enumerated lists (enums) used throughout our API. An enum is a data type that defines a set of named integer constants, which are used to represent a fixed set of values for specific fields.

Using these enums ensures consistency and clarity in data representation across the API, replacing arbitrary numbers with descriptive, human-readable names. When integrating with our API, please refer to the following definitions to correctly handle all possible states and values for each respective field.

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 5 of 44

1. Enums List

Enum Type	Value
Camera	TI = 1 DTV = 2 SeeSpot = 4
PIP	On = 1 Off = 2
TOperationMode_Micro	IDLE = 0 Init = 1 Rate = 2 Position_RelativeAngles = 3 DriftCalibration = 4 BIT = 5 Safe = 6 Center = 7 Track = 10 GimbalCalibration = 11 Rate_Pos = 12 SystemLoading = 13
NavigationType	InertialNavigation = 0 VerticalGyro = 1 AddgimbalanglestoexternalINSdata = 2 Nonavigation = 7
ZoomChange	Nochange = 0 Zoomout = 1 Zoomin = 2
TrackerType	Autogatesize20pix = 0 StructureSmall = 1 StructureMedium = 2 StructureLarge = 3 Human = 4 Vehicle = 5 Truck = 6
TrackerStatus	NoTrack = 0 TrackerOK = 1 Prediction = 2 TrackLoss = 3
GenericIncDecVal	NoChange = 0 DecreaseValue = 1 IncreaseValue = 2
DTVExposureMode	ManualExposureMode = 0 AutomaticGainMode = 9 AutomaticExposureMode = 12
DTVExposureModeSet	SetAutomaticExposureMode = 0 SetAutomaticGainMode = 1

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 6 of 44

Enum Type	Value
	SetManualExposureMode = 2
ThermalCameraColorPalette	SetColorPaletteNC = 0 SetColorPaletteWhiteHot = 1 SetColorPaletteBlackHot = 2 SetColorPaletteRainbow = 3 SetColorPaletteRainbowHC = 4 SetColorPalettelronBow = 5
ThermalCameraGainMode	GainModeNC = 0 GainModeHigh = 1 GainModeLow = 2 GainModeAuto = 3
ThermalCameraSyncMode	SyncModeNC = 0 SyncModeDisabled = 1 SyncModeMaster = 2
ThermalCameraColorPalleteMode	ColorPaletteNC = 0 ColorPaletteWhiteHot = 1 ColorPaletteBlackHot = 2 ColorPaletteRainbow = 3 ColorPaletteRainbowHC = 4 ColorPalettelronBow = 5
NUCMode	NucModeManual = 0 NucModeAuto = 1 NucModeExternal = 2 NucModeShutterTest = 3
ThermalCameraFFCMode	FFCModeNC = 0 FFCModeManual = 1 FFCModeAuto = 2
NUCForceActivate	NoForceNUC = 0 SetForceNuc = 1
PowerStatesRequest	PowerRequestNC = 0 PowerRequestOn = 1 PowerRequestOff = 2
PowerStatesReport	PowerReportOff = 0 PowerReportOn = 1
RetreiveDataType	StopRetreive = 0 CyclicRetreive = 1 OnceRetreive = 2 OnArrival = 4
FontColor	BLACK = 0 RED = 1 GREEN = 2 YELLOW = 3 BLUE = 4 MAGENTA = 5 CYAN = 6

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 7 of 44

Enum Type	Value
	LIGHT_GREY = 7 GREY = 8 BRIGHT_RED = 9 BRIGHT_GREEN = 10 BRIGHT_YELLOW = 11 BRIGHT_BLUE = 12 BRIGHT_MAGENTA = 13 BRIGHT_CYAN = 14 WHITE = 15
DTVAutoWhiteBalanceType	AWBNC = 0 AWBOn = 1 AWBManual = 2
NavAltitudeType	Ellipsoid = 0 Meansealevel = 1

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 8 of 44

Functions List

This section provides a comprehensive list of all available API functions, detailing their purpose, parameters, and return values. Each function is a specific operation your application can call to interact with our system, such as gimbal movements, camera control etc

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 9 of 44

2. Gimbal

2.1. Init

Function Name	Args	Description	Return Type	Signature
SystemInit	None	Initialize the system - Gimbals and Sensors. This process takes few seconds	int Success	int SetSystemInit();

2.2. Ready

Function Name	Args	Description	Return Type	Signature
IDLE	None	Enter to Idle Mode. Shutdown gimbals' motors and releases gimbal's current loop.	int Success	int SetIDLE();

2.3. Drift Calibration

Function Name	Args	Description	Return Type	Signature
DriftCalibration	None	Performs calibration to gimbal. This process takes few seconds.	int Success	int SetDriftCalibration();

2.4. Rate

Function Name	Args	Description	Return Type	Signature
RateCommandAngularVelocities_X	float AngularVelocities_X	Set Angular Velocities for both axes, in units [°/Sec] On X Axis	int Success	int SetRateCommandAngularVelocities_X(float AngularVelocities_X);
RateCommandAngularVelocities_Y	float AngularVelocities_Y	Set Angular Velocities for both axes, in units [°/Sec] On Y Axis	int Success	int SetRateCommandAngularVelocities_Y(float AngularVelocities_Y);

2.5. Position

2.5.1. Position

Function Name	Args	Description	Return Type	Signature
---------------	------	-------------	-------------	-----------

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 10 of 44

Function Name	Args	Description	Return Type	Signature
PositionCommandLOSAngles_X	float LOSAngles_X	Set Line Of Sight Command in angels [°] On X Axis	int Success	int SetPositionCommandLOSAngles_X(float LOSAngles_X);
PositionCommandLOSAngles_Y	float LOSAngles_Y	Set Line Of Sight Command in angels [°] On Y Axis	int Success	int SetPositionCommandLOSAngles_Y(float LOSAngles_Y);

2.5.2. Center Position

Function Name	Args	Description	Return Type	Signature
CenterMode	None	Set system as Center Mode. Sets predefined gimbal angles and sensors FOV	int Success	int SetCenterMode();

2.5.3. Safe Position

Function Name	Args	Description	Return Type	Signature
SafeMode	None	Set system to Safe Mode. Set predefined gimbal angles and sensors FOV	int Success	int SetSafeMode();

2.5.4. Position Report

Function Name	Args	Description	Return Type	Signature
PositionReportRelativeGimbalAngles_X	None	Gets Line Of Sight in angels, in units [°] On X Axis		float GetPositionReportRelativeGimbalAngles_X();
PositionReportRelativeGimbalAngles_Y	None	Gets Line Of Sight in angels, in units [°] On Y Axis		float GetPositionReportRelativeGimbalAngles_Y();

2.6. Gyro Report

Function Name	Args	Description	Return Type	Signature
GyroRawReportControlGyroTimeTag	None	Gets Control Gyro Message Time Tag	uint64_t	uint64_t GetGyroRawReportControlGyroTimeTag();
GyroRawReportGyroYaw	None	Gets Gyro Yaw Value	float	float GetGyroRawReportGyroYaw();
GyroRawReportGyroPitch	None	Gets Gyro Pitch Value	float	float GetGyroRawReportGyroPitch();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 11 of 44

Function Name	Args	Description	Return Type	Signature
GyroRawReportGyroRoll	None	Gets Gyro Roll Value	float	float GetGyroRawReportGyroRoll();

2.7. GRR (Ground Reference Rate)

Function Name	Args	Description	Return Type	Signature
GroundReferenceCommandAngularVelocities_X	float AngularVelocities_X	Sets GRR (Ground Reference Rate) Angular Velocities, in units [°/Sec] On X Axis	int Success	int SetGroundReferenceCommandAngularVelocities_X(float AngularVelocities_X);
GroundReferenceCommandAngularVelocities_Y	float AngularVelocities_Y	Sets GRR (Ground Reference Rate) Angular Velocities, in units [°/Sec] On Y Axis	int Success	int SetGroundReferenceCommandAngularVelocities_Y(float AngularVelocities_Y);
GroundReferenceCommandSlantRange	float SlantRange	Sets Slant Range, in units [meters]	int Success	int SetGroundReferenceCommandSlantRange(float SlantRange);
GroundReferenceReportAngularVelocities_X	None	Gets GRR (Ground Reference Rate) Angular Velocities, in units [°/Sec] On X Axis		float GetGroundReferenceReportAngularVelocities_X();
GroundReferenceReportAngularVelocities_Y	None	Gets GRR (Ground Reference Rate) Angular Velocities, in units [°/Sec] On Y Axis		float GetGroundReferenceReportAngularVelocities_Y();
GroundReferenceReportSlantRange	None	Gets Slant Range, in units [meters]		float GetGroundReferenceReportSlantRange();

2.8. GRR+Rate

Function Name	Args	Description	Return Type	Signature
Rate_GRRAngularVelocities_X	None	Gets Angular Velocities + GRR, in units [°/Sec] On X Axis		float GetRate_GRRAngularVelocities_X();
Rate_GRRAngularVelocities_Y	None	Gets Angular Velocities + GRR, in units [°/Sec] On Y Axis		float GetRate_GRRAngularVelocities_Y();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 12 of 44

2.9. Stabilization Error

Function Name	Args	Description	Return Type	Signature
StabilizationErrorAngularVelocitiesX	None	Gets Angular Velocities Error On X Axis	int16_t	int16_t GetStabilizationErrorAngularVelocitiesX();
StabilizationErrorAngularVelocitiesY	None	Gets Angular Velocities Error On Y Axis	int16_t	int16_t GetStabilizationErrorAngularVelocitiesY();

2.10. Control Data

Function Name	Args	Description	Return Type	Signature
GimbalControlDataAxisXCurrentConsumption	None	Gets Current Consumption Of X Axis Motor	float	float GetGimbalControlDataAxisXCurrentConsumption();
GimbalControlDataAxisYCurrentConsumption	None	Gets Current Consumption Of Y Axis Motor	float	float GetGimbalControlDataAxisYCurrentConsumption();

2.11. BIT Status

Function Name	Args	Description	Return Type	Signature
GimbalMasterBITStatusSystemBusy	None	Gets Busy Flag Mode	bool	bool GetGimbalMasterBITStatusSystemBusy();
GimbalMasterBITStatusGimbalnotinitialized	None	Gets Control Operational Failure	bool	bool GetGimbalMasterBITStatusGimbalnotinitialized();
GimbalMasterBITStatusGimbalinitFail	None	Gets HW + Sensors	bool	bool GetGimbalMasterBITStatusGimbalinitFail();
GimbalMasterBITStatusGimbalFail	None	Gets Azimuth Gimbal General Bit	bool	bool GetGimbalMasterBITStatusGimbalFail();
GimbalMasterBITStatusGimbalHigh_LowTempWarning	None	Gets Elevation Gimbal General Bit	bool	bool GetGimbalMasterBITStatusGimbalHigh_LowTempWarning();
GimbalMasterBITStatusTrackInitFlag	None	Gets Track Init Flag	bool	bool GetGimbalMasterBITStatusTrackInitFlag();
GimbalMasterBITStatusPayloadcommfail	None	Gets Elevation Gimbal General Bit	bool	bool GetGimbalMasterBITStatusPayloadcommfail();
GimbalMasterBITStatusLowstoragewarning	None	Gets Elevation Gimbal General Bit	bool	bool GetGimbalMasterBITStatusLowstoragewarning();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 13 of 44

Function Name	Args	Description	Return Type	Signature
GimbalMasterBITStatusHiveTemperaturewarning	None	Gets Elevation Gimbal General Bit	bool	bool GetGimbalMasterBITStatusHiveTemperaturewarning();
GimbalMasterBITStatusHivesoftwarefail	None	Gets Elevation Gimbal General Bit	bool	bool GetGimbalMasterBITStatusHivesoftwarefail();
GimbalMasterBITStatusHostCommfail	None	Gets Elevation Gimbal General Bit	bool	bool GetGimbalMasterBITStatusHostCommfail();
GimbalMasterBITStatusVISWideFail	None	Gets Wide Visible Camera fail Bit	bool	bool GetGimbalMasterBITStatusVISWideFail();
GimbalMasterBITStatusVISNarrowFail	None	Gets Narrow Visible Camera fail Bit	bool	bool GetGimbalMasterBITStatusVISNarrowFail();
GimbalMasterBITStatusTIFail	None	Gets TI Camera fail Bit	bool	bool GetGimbalMasterBITStatusTIFail();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 14 of 44

3. Cameras

3.1. Day Camera

3.1.1. Commands

Function Name	Args	Description	Return Type	Signature
DayCameraCommandZoomCommand	enum ZoomChange ZoomCommand	Sets DayLightCamera Zoom	int Success	int SetDayCameraCommandZoomCommand(enum ZoomChange ZoomCommand);
DayCameraCommandSharpnessCommand	enum GenericIncDecVal SharpnessCommand	Sets DayLightCamera Sharpness	int Success	int SetDayCameraCommandSharpnessCommand(enum GenericIncDecVal SharpnessCommand);
DayCameraCommandGammaCommand	enum GenericIncDecVal GammaCommand	Sets DayLightCamera Gamma	int Success	int SetDayCameraCommandGammaCommand(enum GenericIncDecVal GammaCommand);
DayCameraCommandSaturationCommand	enum GenericIncDecVal SaturationCommand	Sets DayLightCamera Saturation	int Success	int SetDayCameraCommandSaturationCommand(enum GenericIncDecVal SaturationCommand);
DayCameraCommandGainCommand	enum GenericIncDecVal GainCommand	Sets DayLightCamera Gain	int Success	int SetDayCameraCommandGainCommand(enum GenericIncDecVal GainCommand);
DayCameraCommandLevelCommand	enum GenericIncDecVal LevelCommand	Sets DayLightCamera Level	int Success	int SetDayCameraCommandLevelCommand(enum GenericIncDecVal LevelCommand);
DayCameraCommandExposureMode	enum DTVExposureModeSet ExposureMode	Sets DayLightCamera Exposure Mode	int Success	int SetDayCameraCommandExposureMode(enum DTVExposureModeSet ExposureMode);
DayCameraCommandExposureTime	enum GenericIncDecVal ExposureTime	Sets DayLightCamera Exposure Time	int Success	int SetDayCameraCommandExposureTime(enum GenericIncDecVal ExposureTime);

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 15 of 44

Function Name	Args	Description	Return Type	Signature
DayCameraCommandExposureGain	enum GenericIncDecVal ExposureGain	Sets DayLightCamera Exposure Gain	int Success	int SetDayCameraCommandExposureGain(enum GenericIncDecVal ExposureGain);
DayCameraCommandAutoWhiteBalance	enum DTVAutoWhiteBalanceType AutoWhiteBalance	Sets Auto White Balance	int Success	int SetDayCameraCommandAutoWhiteBalance(enum DTVAutoWhiteBalanceType AutoWhiteBalance);
DayCameraCommandTemperature	uint8_t Temperature	Sets Temperature	int Success	int SetDayCameraCommandTemperature(uint8_t Temperature);
DayCameraCommandFlickerMode	int8_t FlickerMode	Sets Flicker Mode	int Success	int SetDayCameraCommandFlickerMode(int8_t FlickerMode);
DayCameraCommandRestoreToDefault	bool RestoreToDefault	Restores All Parameters And Disables All Changes Except Zoom While Active	int Success	int SetDayCameraCommandRestoreToDefault(bool RestoreToDefault);
DayCameraSetFOVSetFOVCommand	float SetFOVCommand	Sets DayLightCamera Field Of View	int Success	int SetDayCameraSetFOVSetFOVCommand(float SetFOVCommand);

3.1.2. Reports

Function Name	Args	Description	Return Type	Signature
DayCameraReportExposureMode	None	Gets DayLightCamera Exposure Mode	DTVExposureMode	enum DTVExposureMode GetDayCameraReportExposureMode();
DayCameraReportExposureTime	None	Gets DayLightCamera Exposure Time	int32_t	int32_t GetDayCameraReportExposureTime();
DayCameraReportExposureGain	None	Gets DayLightCamera Exposure Gain	int32_t	int32_t GetDayCameraReportExposureGain();
DayCameraReportGammaValue	None	Gets DayLightCamera Gamma Value	float	float GetDayCameraReportGammaValue();
DayCameraReportSaturationValue	None	Gets DayLightCamera Saturation Value	float	float GetDayCameraReportSaturationValue();
DayCameraReportContrastValue	None	Gets DayLightCamera	float	float GetDayCameraReportContrastV

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 16 of 44

Function Name	Args	Description	Return Type	Signature
		Contrast Value		alue();
DayCameraReportSharpnessValue	None	Gets DayLightCamera Sharpness Value	float	float GetDayCameraReportSharpnessValue();
DayCameraReportFOV	None	Gets DayLightCamera FOV	float	float GetDayCameraReportFOV();
DayCameraReportZoomXAxisCenter	None	Gets DayLightCamera Zoom X Axis Center	float	float GetDayCameraReportZoomXAxisCenter();
DayCameraReportZoomYAxisCenter	None	Gets DayLightCamera Zoom Y Axis Center	float	float GetDayCameraReportZoomYAxisCenter();
DayCameraReportBrightnessValue	None	Gets DayLightCamera Brightness Value	float	float GetDayCameraReportBrightnessValue();
DayCameraReportAutoWhiteBalance	None	Gets DayLightCamera Auto White Balance	int32_t	int32_t GetDayCameraReportAutoWhiteBalance();
DayCameraReportTemperatureValue	None	Gets DayLightCamera Temperature Value	int32_t	int32_t GetDayCameraReportTemperatureValue();
DayCameraReportFlickerMode	None	Gets DayLightCamera Flicker Mode	float	float GetDayCameraReportFlickerMode();

3.2. TI Camera

3.2.1. Commands

Function Name	Args	Description	Return Type	Signature
ThermalCameraCommandZoomCommand	enum ZoomChange ZoomCommand	Sets Thermal Camera Zoom Command	int Success	int SetThermalCameraCommandZoomCommand(enum ZoomChange ZoomCommand);
ThermalCameraCommandGainCommand	enum GenericIncDecVal GainCommand	Sets Thermal Camera Gain Command	int Success	int SetThermalCameraCommandGainCommand(enum GenericIncDecVal GainCommand);
ThermalCameraCommandLevel	enum	Sets Thermal	int Success	int

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 17 of 44

Function Name	Args	Description	Return Type	Signature
Command	GenericIncDecVal LevelCommand	Camera Level Command		SetThermalCameraCommandLe velCommand(enum GenericIncDecVal LevelCommand);
ThermalCameraCommandGain ModeCommand	enum ThermalCameraG ainMode GainModeComma nd	Sets Thremal Camera Gain Mode Command	int Success	int SetThermalCameraCommandGa inModeCommand(enum ThermalCameraGainMode GainModeCommand);
ThermalCameraCommandLinea rPercentCommand	enum GenericIncDecVal LinearPercentCom mand	Sets Thremal Camera Linear Percent Command	int Success	int SetThermalCameraCommandLi nearPercentCommand(enum GenericIncDecVal LinearPercentCommand);
ThermalCameraCommandACEC ommand	enum GenericIncDecVal ACECommand	Sets Thremal Camera Gamma Corective Value (ACE) Command	int Success	int SetThermalCameraCommandAC ECommand(enum GenericIncDecVal ACECommand);
ThermalCameraCommandSharp nessCommand	enum GenericIncDecVal SharpnessComma nd	Sets Thremal Camera Sharpness Command	int Success	int SetThermalCameraCommandSh arpnessCommand(enum GenericIncDecVal SharpnessCommand);
ThermalCameraCommandNUC Mode	enum ThermalCameraFF CMode NUCMode	Sets Thremal Camera NUC Mode	int Success	int SetThermalCameraCommandN UCMode(enum ThermalCameraFFCMode NUCMode);
ThermalCameraCommandColor Palette	enum ThermalCameraC olorPalette ColorPalette	Sets Thremal Camera Color Palette Command	int Success	int SetThermalCameraCommandCo lorPalette(enum ThermalCameraColorPalette ColorPalette);
ThermalCameraCommandNUC	enum NUCForceActivate NUC	Sets Thremal Camera NUC Force Set	int Success	int SetThermalCameraCommandN UC(enum NUCForceActivate NUC);
ThermalCameraCommandResto reToDefault	bool RestoreToDefault	Restores All Parameters And Disables All Changes Excpet Zoom While Active	int Success	int SetThermalCameraCommandRe storeToDefault(bool RestoreToDefault);
ThermalCameraCommandSync ModeCommand	enum ThermalCameraSy	Sets Thremal Camera Sync	int Success	int SetThermalCameraCommandSy

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 18 of 44

Function Name	Args	Description	Return Type	Signature
	ncMode SyncModeCommand	Mode Command		ncModeCommand(enum ThermalCameraSyncMode SyncModeCommand);
TICameraSetFOVSetFOVCommand	float SetFOVCommand	Sets TI Field Of View	int Success	int SetTICameraSetFOVSetFOVCommand(float SetFOVCommand);

3.2.2. Reports

Function Name	Args	Description	Return Type	Signature
ThermalCameraReportGainMode	None	Gets Thermal Camera Gain Mode	ThermalCameraGainMode	enum ThermalCameraGainMode GetThermalCameraReportGainMode();
ThermalCameraReportSyncMode	None	Gets Thermal Camera Sync Mode	ThermalCameraSyncMode	enum ThermalCameraSyncMode GetThermalCameraReportSyncMode();
ThermalCameraReportLinearPercent	None	Gets Thermal Camera Linear Percent	float	float GetThermalCameraReportLinearPercent();
ThermalCameraReportACEValue	None	Gets Thermal Camera Gamma Corective Value (ACE)	float	float GetThermalCameraReportACEValue();
ThermalCameraReportDDEVValue	None	Gets Thermal Camera Headroom Detail (DDE)	float	float GetThermalCameraReportDDEVValue();
ThermalCameraReportColorPalette	None	Gets Thermal Camera Color Palette Mode	ThermalCameraColorPalleteMode	enum ThermalCameraColorPalleteMode GetThermalCameraReportColorPalette();
ThermalCameraReportNUCMode	None	Gets Noc Enable Mode	NUCMode	enum NUCMode GetThermalCameraReportNUCMode();
ThermalCameraReportFOV	None	Gets Thermal Camera Field Of View	float	float GetThermalCameraReportFOV();
ThermalCameraReportGainValue	None	Gets Thermal Camera Gain Value	int32_t	int32_t GetThermalCameraReportGainValue();
ThermalCameraReportLevelValue	None	Gets Thermal Camera Level Value	int32_t	int32_t GetThermalCameraReportLevelValue();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 19 of 44

3.3. SeeSpot Camera

3.3.1. Commands

Function Name	Args	Description	Return Type	Signature
SeeSpotControlCommandPower	bool Power	Sets SeeSpot camera 0 - Off. 1 - On	int Success	int SetSeeSpotControlCommandPower(bool Power);
SeeSpotControlCommandFreeze	bool Freeze	Sets video freeze frame 0 - Off. 1 - On	int Success	int SetSeeSpotControlCommandFreeze(bool Freeze);

3.3.2. Reports

Function Name	Args	Description	Return Type	Signature
SeeSpotControlCommandPower	None	Sets SeeSpot camera 0 - Off. 1 - On	bool	bool GetSeeSpotControlCommandPower();
SeeSpotControlCommandFreeze	None	Sets video freeze frame 0 - Off. 1 - On	bool	bool GetSeeSpotControlCommandFreeze();

3.4. Camera BITs

3.4.1. Commands

Function Name	Args	Description	Return Type	Signature
ClearStickyBIT	None	Clear Cameras Sticky BITs	int Success	int SetClearStickyBIT();

3.4.2. Reports

Function Name	Args	Description	Return Type	Signature
CamerasBITStatusDTVNarrowActiveError	None	Gets DTV Narrow Active Error BIT	bool	bool GetCamerasBITStatusDTVNarrowActiveError();
CamerasBITStatusDTVNarrowStickyError	None	Gets DTV Narrow Sticky Error BIT	bool	bool GetCamerasBITStatusDTVNarrowStickyError();
CamerasBITStatusDTVNarrowInitError	None	Gets DTV Narrow Init Error BIT	bool	bool GetCamerasBITStatusDTVNarrowInitError();
CamerasBITStatusDTVNarrowVideoErrorsCounter	None	Gets DTV Narrow Video Errors Counter BIT	uint8_t	uint8_t GetCamerasBITStatusDTVNarrowVideoErrorsCounter();
CamerasBITStatusDTVWideActiveError	None	Gets DTV Wide Active Error BIT	bool	bool GetCamerasBITStatusDTVWideActiveError();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 20 of 44

Function Name	Args	Description	Return Type	Signature
				ActiveError();
CamerasBITStatusDTVWideStickyError	None	Gets DTV Wide Sticky Error BIT	bool	bool GetCamerasBITStatusDTVWideStickyError();
CamerasBITStatusDTVWideInitError	None	Gets DTV Wide Init Error BIT	bool	bool GetCamerasBITStatusDTVWideInitError();
CamerasBITStatusDTVWideVideoErrorsCounter	None	Gets DTV Wide Video Errors Counter BIT	uint8_t	uint8_t GetCamerasBITStatusDTVWideVideoErrorsCounter();
CamerasBITStatusTIActiveError	None	Gets TI Active Error BIT	bool	bool GetCamerasBITStatusTIActiveError();
CamerasBITStatusTISTickyError	None	Gets TI Sticky Error BIT	bool	bool GetCamerasBITStatusTISTickyError();
CamerasBITStatusTIInitError	None	Gets TI Init Error BIT	bool	bool GetCamerasBITStatusTIInitError();
CamerasBITStatusTIVideoErrorsCounter	None	Gets TI Video Errors Counter BIT	uint8_t	uint8_t GetCamerasBITStatusTIVideoErrorsCounter();
CamerasBITStatusUSBHubActiveError	None	Gets USB Hub Active Error BIT	bool	bool GetCamerasBITStatusUSBHubActiveError();
CamerasBITStatusUSBHubStickyError	None	Gets USB Hub Sticky Error BIT	bool	bool GetCamerasBITStatusUSBHubStickyError();
CamerasBITStatusUSBHubInitError	None	Gets USB Hub Init Error BIT	bool	bool GetCamerasBITStatusUSBHubInitError();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 21 of 44

4. Video Channel

4.1. Video Channel Command

Function Name	Args	Description	Return Type	Signature
VideoChannelCommandPrimaryVideoChannel	enum Camera PrimaryVideoChannel	Select primary sensors DTV/TI	int Success	int SetVideoChannelCommandPrimaryVideoChannel(enum Camera PrimaryVideoChannel);
VideoChannelCommandFOVSynchronizationMode	bool FOVSynchronizationMode	Enables/Disables sensors sync - secondary sensor changes its FOV according primary's FOV	int Success	int SetVideoChannelCommandFOVSynchronizationMode(bool FOVSynchronizationMode);
VideoChannelCommandImageStabilizationEnable	bool ImageStabilizationEnable	Enables/Disables Image Stabilization	int Success	int SetVideoChannelCommandImageStabilizationEnable(bool ImageStabilizationEnable);
VideoChannelCommandImageStabilizationMethod	bool ImageStabilizationMethod	Sets image stabilization method. 0 - Image based. 1 - IMU Based	int Success	int SetVideoChannelCommandImageStabilizationMethod(bool ImageStabilizationMethod);
VideoChannelCommandOSDDisabled	bool OSDDisabled	Disables/Enables OSD layer (Set '1' to disable)	int Success	int SetVideoChannelCommandOSDDisabled(bool OSDDisabled);
VideoChannelCommandPIPEnable	enum PIP PIPEnable	Enables/Disables streaming secondary sensor as Picture-In-Picture on video stream	int Success	int SetVideoChannelCommandPIPEnable(enum PIP PIPEnable);
VideoChannelCommandHistogramEnable	bool HistogramEnable	Enables/Disables Histogram on video stream	int Success	int SetVideoChannelCommandHistogramEnable(bool HistogramEnable);
VideoChannelCommandFontColor	enum FontColor FontColor	Sets OSD font color	int Success	int SetVideoChannelCommandFontColor(enum FontColor FontColor);

4.2. Video Channel Report

Function Name	Args	Description	Return Type	Signature
VideoChannelReportPrimaryVid	None	Select primary	Camera	enum Camera

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 22 of 44

Function Name	Args	Description	Return Type	Signature
eoChannel		sensors DTV/TVI		GetVideoChannelReportPrimaryVideoChannel();
VideoChannelReportFOVSynchronizationMode	None	Enables/Disables sensors sync - secondary sensor changes its FOV according primary's FOV	bool	bool GetVideoChannelReportFOVSynchronizationMode();
VideoChannelReportImageStabilizationEnable	None	Enables/Disables Image Stabilization	bool	bool GetVideoChannelReportImageStabilizationEnable();
VideoChannelReportImageStabilizationMethod	None	Sets image stabilization method. 0 - Image based. 1 - IMU Based	bool	bool GetVideoChannelReportImageStabilizationMethod();
VideoChannelReportOSDDisabled	None	Disables/Enables OSD layer (Set '1' to disable)	bool	bool GetVideoChannelReportOSDDisabled();
VideoChannelReportPIPEnable	None	Enables/Disables streaming secondary sensor as Picture-In-Picture on video stream	bool	bool GetVideoChannelReportPIPEnable();
VideoChannelReportHistogramEnable	None	Gets Enables/Disables Histogram on video stream	bool	bool GetVideoChannelReportHistogramEnable();
VideoChannelReportFontColor	None	Sets OSD font color	FontColor	enum FontColor GetVideoChannelReportFontColor();

4.3. Video Channel RunTime Config

Function Name	Args	Description	Return Type	Signature
VideoChannelRunTimeConfigStopChannel0Stream	bool StopChannel0Stream	Stop Channel 0 Stream	int Success	int SetVideoChannelRunTimeConfigStopChannel0Stream(bool StopChannel0Stream);
VideoChannelRunTimeConfigStartChannel0Stream	bool StartChannel0Stream	Start Channel 0 Stream	int Success	int SetVideoChannelRunTimeConfigStartChannel0Stream(bool StartChannel0Stream);
VideoChannelRunTimeConfigH264Channel0Stream	bool H264Channel0Stream	Set Channel 0 Stream to H264	int Success	int SetVideoChannelRunTimeConfigH264Channel0Stream(bool H264Channel0Stream);

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 23 of 44

Function Name	Args	Description	Return Type	Signature
	eam	encoding		gH264Channel0Stream(bool H264Channel0Stream);
VideoChannelRunTimeConfigH265Channel0Stream	bool H265Channel0Stream	Set Channel 0 Stream to H265 encoding	int Success	int SetVideoChannelRunTimeConfigH265Channel0Stream(bool H265Channel0Stream);
VideoChannelRunTimeConfigBandwidthChannel0Stream	int32_t BandwidthChannel0Stream	Set Channel 0 Bandwidth - leave 0 if no change required	int Success	int SetVideoChannelRunTimeConfigBandwidthChannel0Stream(int32_t BandwidthChannel0Stream);
VideoChannelRunTimeConfigStopDTVStream	bool StopDTVStream	Stop DTV Wide and DTV Narrow pipeline	int Success	int SetVideoChannelRunTimeConfigStopDTVStream(bool StopDTVStream);
VideoChannelRunTimeConfigStopTISStream	bool StopTISStream	Stop TI pipeline	int Success	int SetVideoChannelRunTimeConfigStopTISStream(bool StopTISStream);

4.4. Video Record

4.4.1. Command

Function Name	Args	Description	Return Type	Signature
RecordVideoCommandEnable	bool Enable	Starts/Stops Recording Video	int Success	int SetRecordVideoCommandEnable(bool Enable);
RecordVideoCommandEnableRaw	bool EnableRaw	Starts/Stops Recording Raw Video	int Success	int SetRecordVideoCommandEnableRaw(bool EnableRaw);
RecordVideoCommandDeleteALLRecords	bool DeleteALLRecords	Deletes All Records	int Success	int SetRecordVideoCommandDeleteALLRecords(bool DeleteALLRecords);
RecordVideoCommandFolderName	char* FolderName, size_t Size - C string should be at most 19 Bytes.	Sets Record Video Folder Name	int Success	int SetRecordVideoCommandFolderName(char* FolderName, size_t Size);

4.4.2. Report

Function Name	Args	Description	Return Type	Signature
RecordVideoReportRecordVideoTimestamp_nSec_	None	Gets Record Video Timestamp [nSec]	int64_t	int64_t GetRecordVideoReportRecordV

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 24 of 44

Function Name	Args	Description	Return Type	Signature
				ideoTimestamp_nSec_());
RecordVideoReportRecordRawVideoTimestamp_nSec_	None	Gets Record Raw Video Timestamp [nSec]	int64_t	int64_t GetRecordVideoReportRecordRawVideoTimestamp_nSec_());
RecordVideoReportDiskFreeSpace_GB_	None	Disk Free Space [GB]	float	float GetRecordVideoReportDiskFreeSpace_GB_());
RecordVideoReportDiskFreeSpace_Percent_	None	Disk Free Space [%]	float	float GetRecordVideoReportDiskFreeSpace_Percent_());
RecordVideoReportTotalDiskSize_GB_	None	Total Disk Size [GB]	float	float GetRecordVideoReportTotalDiskSize_GB_());
RecordVideoReportRecordVideoEnable	None	Record Video Enable	int32_t	int32_t GetRecordVideoReportRecordVideoEnable();
RecordVideoReportRecordRawVideoEnable	None	Record Raw Video Enable	int32_t	int32_t GetRecordVideoReportRecordRawVideoEnable();
RecordVideoReportVideoDelete	None	ALL Recorded video is in deletion process	int32_t	int32_t GetRecordVideoReportVideoDelete();
RecordVideoReportDiskStatus	None	Disk Status	int32_t	int32_t GetRecordVideoReportDiskStatus();
RecordVideoReportFolderName	char* Buffer, size_t Size - Buffer size should be at least 20	Sets Record Video Folder Name	void	void GetRecordVideoReportFolderName(char* Buffer, size_t Size);

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 25 of 44

5. Algorithms

5.1. Tracker

5.1.1. Command

Function Name	Args	Description	Return Type	Signature
Track	int16_t TargetXCoordinate, int16_t TargetYCoordinate	Change X, Y coordination in pixels, relative to center of screen. Positive direction is Right, Down.	int Success	int SetTrack(int16_t TargetXCoordinate, int16_t TargetYCoordinate);

5.1.2. Report

Function Name	Args	Description	Return Type	Signature
TrackerTargetErrorReportCamera	None	Gets active sensor	Camera	enum Camera GetTrackerTargetErrorReportCamera();
TrackerTargetErrorReportTrackerGeneralStatus	None	Gets tracker status	TrackerStatus	enum TrackerStatus GetTrackerTargetErrorReportTrackerGeneralStatus();
TrackerTargetErrorReportTrackingQuality	None	Gets tracker quality, in range [0 (worst) ÷ 7(best)]	uint8_t	uint8_t GetTrackerTargetErrorReportTrackingQuality();
TrackerTargetErrorReportFirstTimeTrack	None		bool	bool GetTrackerTargetErrorReportFirstTimeTrack();
TrackerTargetErrorReportCurrentFOV	None	Gets current FOV of selected sensor	uint16_t	uint16_t GetTrackerTargetErrorReportCurrentFOV();
TrackerTargetErrorReportTrackerXError	None	Gets tracker error at X axis, in pixels	float	float GetTrackerTargetErrorReportTrackerXError();
TrackerTargetErrorReportTrackerYError	None	Gets tracker error at Y axis, in pixels	float	float GetTrackerTargetErrorReportTrackerYError();
TrackerTargetErrorReportGMC	None	Gets GMC value	int8_t	int8_t GetTrackerTargetErrorReportGMC();
TrackerTargetErrorReportGateSizeX	None	Gets tracker gate size width	uint16_t	uint16_t GetTrackerTargetErrorReportGateSizeX();
TrackerTargetErrorReportGateSizeY	None	Gets tracker gate size height	uint16_t	uint16_t GetTrackerTargetErrorReportGateSizeY();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 26 of 44

Function Name	Args	Description	Return Type	Signature
izeY		size heigh		GetTrackerTargetErrorReportGateSizeY();

5.2. Gate Parameters

Function Name	Args	Description	Return Type	Signature
TrackerParametersTrackerType	enum TrackerType TrackerType	Sets target type according to TargetType Table. This field sets automatically the gate size.	int Success	int SetTrackerParametersTrackerType(enum TrackerType TrackerType);
TrackerParametersGateXSize	uint16_t GateXSize	Sets gate width in case of manual gate size. The value range $[5 \div (\text{screen width} / 2)]$	int Success	int SetTrackerParametersGateXSize(uint16_t GateXSize);
TrackerParametersGateYSize	uint16_t GateYSize	Sets gate heigh in case of manual gate size. The value range $[5 \div (\text{screen heigh} / 2)]$	int Success	int SetTrackerParametersGateYSize(uint16_t GateYSize);
TrackerParametersGateSizeEnable	bool GateSizeEnable	Enables/Disables manual gate size according provided X, Y sizes. When disabled, gate size will be according to TargetType	int Success	int SetTrackerParametersGateSizeEnable(bool GateSizeEnable);
TrackerParametersReportTrackerType	None	Gets selected target type.	int8_t	int8_t GetTrackerParametersReportTrackerType();
TrackerParametersReportGateXSize	None	Gets current gate X size	uint16_t	uint16_t GetTrackerParametersReportGateXSize();
TrackerParametersReportGateYSize	None	Gets current gate Y size	uint16_t	uint16_t GetTrackerParametersReportGateYSize();
TrackerParametersReportGateSizeEnable	None	Gets if manual gate size enabled/disabled	bool	bool GetTrackerParametersReportGateSizeEnable();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 27 of 44

5.3. Tracker Movement

5.3.1. Adjust

Function Name	Args	Description	Return Type	Signature
TrackerAdjustControls	bool AdjustEnable, int16_t MovementComm and_X, int16_t MovementComm and_Y	Sets the values how much to adjust the tracker gate, in units of pixels, for both axis X, Y. Positive direction is Right, Down. On Y Axis	int Success	int SetTrackerAdjustControls(bool AdjustEnable, int16_t MovementCommand_X, int16_t MovementCommand_Y);
TrackerAdjustControlsReportAdjustEnable	None	Gets if adjust function is enabled/disabled	bool	bool GetTrackerAdjustControlsReportAdjustEnable();
TrackerAdjustControlsReportMovementX	None	Returns provided adjust X movement	int16_t	int16_t GetTrackerAdjustControlsReportMovementX();
TrackerAdjustControlsReportMovementY	None	Returns provided adjust Y movement	int16_t	int16_t GetTrackerAdjustControlsReportMovementY();

5.3.2. Offset

Function Name	Args	Description	Return Type	Signature
TrackerOffsetControls	bool OffsetEnable, int16_t Movementcommand_X, int16_t Movementcommand_Y	Sets the values how much to Offset the tracker gate, in units of pixels, for both axis X, Y. Positive direction is Right, Down. On Y Axis	int Success	int SetTrackerOffsetControls(bool OffsetEnable, int16_t Movementcommand_X, int16_t Movementcommand_Y);
TrackerOffsetControlsReportOffsetEnable	None	Gets if offset function is enabled/disabled	bool	bool GetTrackerOffsetControlsReportOffsetEnable();
TrackerOffsetControlsReportMovementX	None	Returns provided offset X movement	int16_t	int16_t GetTrackerOffsetControlsReportMovementX();
TrackerOffsetControlsReportMovementY	None	Returns provided offset Y movement	int16_t	int16_t GetTrackerOffsetControlsReportMovementY();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 28 of 44

5.4. VMD

5.4.1. Command

Function Name	Args	Description	Return Type	Signature
VMDControlsEnable	bool Enable	Enable/Disable VMD	int Success	int SetVMDControlsEnable(bool Enable);

5.4.2. Report

Function Name	Args	Description	Return Type	Signature
VMDReportEnableVMD	None		bool	bool GetVMDReportEnableVMD();
VMDReportQuantityofDetections	None		uint8_t	uint8_t GetVMDReportQuantityofDetections();

5.5. ATR

5.5.1. Command

Function Name	Args	Description	Return Type	Signature
ATRControlsDetectionsReport	bool DetectionsReport	Enable/Disable ATR	int Success	int SetATRControlsDetectionsReport(bool DetectionsReport);
ATRControlsDetectionThreshold	int8_t DetectionThreshold	Set Detection Threshold [0-100]	int Success	int SetATRControlsDetectionThreshold(int8_t DetectionThreshold);

5.5.2. Report

Function Name	Args	Description	Return Type	Signature
ATRReportEnabled	None	Gets ATR Status Enabled/Disabled	bool	bool GetATRReportEnabled();
ATRReportQuantityofDetections	None	Gets Quantity of Detections	uint8_t	uint8_t GetATRReportQuantityofDetections();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 29 of 44

6. Navigation

6.1. Navigation Init

6.1.1. Command

Function Name	Args	Description	Return Type	Signature
NavigationInitXMountingAngle	int16_t XMountingAngle	Sets platform X mounting angle installation [LSB:360°/65536]	int Success	int SetNavigationInitXMountingAngle(int16_t XMountingAngle);
NavigationInitYMountingAngle	int16_t YMountingAngle	Sets platform Y mounting angle installation [LSB:360°/65536]	int Success	int SetNavigationInitYMountingAngle(int16_t YMountingAngle);
NavigationInitZMountingAngle	int16_t ZMountingAngle	Sets platform Z mounting angle installation [LSB:360°/65536]	int Success	int SetNavigationInitZMountingAngle(int16_t ZMountingAngle);
NavigationInitLeverArmX	int16_t LeverArmX	Sets platform lever arm X installation [LSB: 1CM]	int Success	int SetNavigationInitLeverArmX(int16_t LeverArmX);
NavigationInitLeverArmY	int16_t LeverArmY	Sets platform lever arm Y installation [LSB: 1CM]	int Success	int SetNavigationInitLeverArmY(int16_t LeverArmY);
NavigationInitLeverArmZ	int16_t LeverArmZ	Sets platform lever arm Z installation [LSB: 1CM]	int Success	int SetNavigationInitLeverArmZ(int16_t LeverArmZ);
NavigationInitPlatformBodyAzimuth	int16_t PlatformBodyAzimuth	Sets platform body azimuth installation [LSB:360°/65536]	int Success	int SetNavigationInitPlatformBodyAzimuth(int16_t PlatformBodyAzimuth);
NavigationInitPlatformBodyPitch	int16_t PlatformBodyPitch	Sets platform body pitch installation [LSB:360°/65536]	int Success	int SetNavigationInitPlatformBodyPitch(int16_t PlatformBodyPitch);
NavigationInitPlatformBodyRoll	int16_t PlatformBodyRoll	Sets platform body roll installation [LSB:360°/65536]	int Success	int SetNavigationInitPlatformBodyRoll(int16_t PlatformBodyRoll);

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 30 of 44

6.1.2. Report

Function Name	Args	Description	Return Type	Signature
NavigationInitXMountingAngle	None	Gets platform X mounting angle installation [LSB:360°/65536]	int16_t	int16_t GetNavigationInitXMountingAngle();
NavigationInitYMountingAngle	None	Gets platform Y mounting angle installation [LSB:360°/65536]	int16_t	int16_t GetNavigationInitYMountingAngle();
NavigationInitZMountingAngle	None	Gets platform Z mounting angle installation [LSB:360°/65536]	int16_t	int16_t GetNavigationInitZMountingAngle();
NavigationInitLeverArmX	None	Gets platform lever arm X installation [LSB: 1CM]	int16_t	int16_t GetNavigationInitLeverArmX();
NavigationInitLeverArmY	None	Gets platform lever arm Y installation [LSB: 1CM]	int16_t	int16_t GetNavigationInitLeverArmY();
NavigationInitLeverArmZ	None	Gets platform lever arm Z installation [LSB: 1CM]	int16_t	int16_t GetNavigationInitLeverArmZ();
NavigationInitPlatformBodyAzimuth	None	Gets platform body azimuth installation [LSB:360°/65536]	int16_t	int16_t GetNavigationInitPlatformBodyAzimuth();
NavigationInitPlatformBodyPitch	None	Gets platform body pitch installation [LSB:360°/65536]	int16_t	int16_t GetNavigationInitPlatformBodyPitch();
NavigationInitPlatformBodyRoll	None	Gets platform body roll installation [LSB:360°/65536]	int16_t	int16_t GetNavigationInitPlatformBodyRoll();

6.2. Navigation Properties

6.2.1. Command

Function Name	Args	Description	Return Type	Signature
NavigationPropertiesPlatformDataSource	int8_t PlatformDataSour	Enables data position and	int Success	int SetNavigationPropertiesPlatfor

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 31 of 44

Function Name	Args	Description	Return Type	Signature
	ce	velocity from platform. 0 - Disable. 1 - Enable		mDataSource(int8_t PlatformDataSource);
NavigationPropertiesUsePlatformData	bool UsePlatformData	Sets either to use platform data (if Platform Data source enabled). 0 - Disable. 1 - Enable	int Success	int SetNavigationPropertiesUsePlatformData(bool UsePlatformData);
NavigationPropertiesNavigationType	enum NavigationType NavigationType	Sets navigation type from. 0 - Payload IMU. 1 - Base IMU + Encoders	int Success	int SetNavigationPropertiesNavigationType(enum NavigationType NavigationType);
NavigationPropertiesAltitudeType	enum NavAltitudeType AltitudeType	Sets Altitude type. 0 - ellipsoid. 1 - mean sea level.	int Success	int SetNavigationPropertiesAltitudeType(enum NavAltitudeType AltitudeType);

6.2.2. Report

Function Name	Args	Description	Return Type	Signature
NavigationStatusPlatformDataSource	None	Gets data position and velocity from platform. 0 - Disable. 1 - Enable	int8_t	int8_t GetNavigationStatusPlatformDataSource();
NavigationStatusUsePlatformData	None	Gets either to use platform data (if Platform Data source enabled). 0 - Disable. 1 - Enable	bool	bool GetNavigationStatusUsePlatformData();
NavigationStatusNavigationType	None	Gets navigation type from. 0 - Payload IMU. 1 - Base IMU + Encoders	NavigationType	enum NavigationType GetNavigationStatusNavigationType();
NavigationStatusAltitudeType	None	Gets Altitude type. 0 - ellipsoid. 1 - mean sea level.	NavAltitudeType	enum NavAltitudeType GetNavigationStatusAltitudeType();

6.3. Navigation Data

6.3.1. Command

Function Name	Args	Description	Return Type	Signature
---------------	------	-------------	-------------	-----------

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 32 of 44

Function Name	Args	Description	Return Type	Signature
PlatformNavigationDataAccuracyPositionAccuracy	int8_t PositionAccuracy	Estimated accuracy of platform horizontal position data (latitude, longitude)	int Success	int SetPlatformNavigationDataAccuracyPositionAccuracy(int8_t PositionAccuracy);
PlatformNavigationDataAccuracyAltitudeAccuracy	int8_t AltitudeAccuracy	Estimated accuracy of platform altitude data	int Success	int SetPlatformNavigationDataAccuracyAltitudeAccuracy(int8_t AltitudeAccuracy);
PlatformNavigationDataAccuracyAttitudeAccuracy	int8_t AttitudeAccuracy	Estimated accuracy of platform Attitude data	int Success	int SetPlatformNavigationDataAccuracyAttitudeAccuracy(int8_t AttitudeAccuracy);
PlatformNavigationDataAccuracyAzimuthAccuracy	int8_t AzimuthAccuracy	Estimated accuracy of platform Azimuth data	int Success	int SetPlatformNavigationDataAccuracyAzimuthAccuracy(int8_t AzimuthAccuracy);
PlatformNavigationDataAccuracyVelocityAccuracy	int8_t VelocityAccuracy	Estimated accuracy of platform horizontal velocity data	int Success	int SetPlatformNavigationDataAccuracyVelocityAccuracy(int8_t VelocityAccuracy);
PlatformNavigationDataAccuracyRateofClimbAccuracy	int8_t RateofClimbAccuracy	Estimated accuracy of platform vertical velocity data	int Success	int SetPlatformNavigationDataAccuracyRateofClimbAccuracy(int8_t RateofClimbAccuracy);
PlatformNavigationDataTimeTag	int32_t TimeTag	Sets platform Time Tag [GPS TOW uSec, cyclic data]	int Success	int SetPlatformNavigationDataTimeTag(int32_t TimeTag);
PlatformNavigationDataPlatformLongitude	float PlatformLongitude	Sets platform longitude [rad, cyclic data]	int Success	int SetPlatformNavigationDataPlatformLongitude(float PlatformLongitude);
PlatformNavigationDataPlatformLatitude	float PlatformLatitude	Sets platform Latitude [rad, cyclic data]	int Success	int SetPlatformNavigationDataPlatformLatitude(float PlatformLatitude);
PlatformNavigationDataPlatformAltitude	float PlatformAltitude	Sets platform Altitude [rad, cyclic data]	int Success	int SetPlatformNavigationDataPlatformAltitude(float PlatformAltitude);
PlatformNavigationDataPlatform	float	Sets platform	int Success	int

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 33 of 44

Function Name	Args	Description	Return Type	Signature
mBodyAzimuth	PlatformBodyAzimuth	body azimuth [rad, cyclic data]		SetPlatformNavigationDataPlatformBodyAzimuth(float PlatformBodyAzimuth);
PlatformNavigationDataPlatformBodyPitch	float PlatformBodyPitch	Sets platform body pitch [rad, cyclic data]	int Success	int SetPlatformNavigationDataPlatformBodyPitch(float PlatformBodyPitch);
PlatformNavigationDataPlatformBodyRoll	float PlatformBodyRoll	Sets platform body roll [rad, cyclic data]	int Success	int SetPlatformNavigationDataPlatformBodyRoll(float PlatformBodyRoll);
PlatformNavigationDataGroundSpeed	int8_t GroundSpeed	Sets platform ground speed [1cm/sec, cyclic data]	int Success	int SetPlatformNavigationDataGroundSpeed(int8_t GroundSpeed);
PlatformNavigationDataRateofClimb	int8_t RateofClimb	Sets platform rate of climb [1cm/sec, cyclic data]	int Success	int SetPlatformNavigationDataRateofClimb(int8_t RateofClimb);

6.3.2. Report

Function Name	Args	Description	Return Type	Signature
PlatformNavigationDataTimeTag	None	Gets platform Time Tag [GPS TOW uSec, cyclic data]	int32_t	int32_t GetPlatformNavigationDataTimeTag();
PlatformNavigationDataPlatformLongitude	None	Gets platform longitude [rad, cyclic data]	float	float GetPlatformNavigationDataPlatformLongitude();
PlatformNavigationDataPlatformLatitude	None	Gets platform Latitude [rad, cyclic data]	float	float GetPlatformNavigationDataPlatformLatitude();
PlatformNavigationDataPlatformAltitude	None	Gets platform Altitude [rad, cyclic data]	float	float GetPlatformNavigationDataPlatformAltitude();
PlatformNavigationDataLOSAzimuth	None	Gets LOS Azimuth [rad, cyclic data]	float	float GetPlatformNavigationDataLOSAzimuth();
PlatformNavigationDataLOSPitch	None	Gets LOS Pitch [rad, cyclic data]	float	float GetPlatformNavigationDataLOSPitch();
PlatformNavigationDataLOSRoll	None	Gets LOS Roll [rad, cyclic data]	float	float GetPlatformNavigationDataLOSRoll();
PlatformNavigationDataTargetLongitude	None	Gets LOS Azimuth [rad, cyclic data]	float	float GetPlatformNavigationDataTargetLongitude();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 34 of 44

Function Name	Args	Description	Return Type	Signature
				etLongitude();
PlatformNavigationDataTargetLatitude	None	Gets LOS Pitch [rad, cyclic data]	float	float GetPlatformNavigationDataTargetLatitude();
PlatformNavigationDataTargetAltitude	None	Gets LOS Roll [rad, cyclic data]	float	float GetPlatformNavigationDataTargetAltitude();
PlatformNavigationDataGroundSpeed	None	Gets platform ground speed [1cm/sec, cyclic data]	int8_t	int8_t GetPlatformNavigationDataGroundSpeed();
PlatformNavigationDataRateofClimb	None	Gets platform rate of climb [1cm/sec, cyclic data]	int8_t	int8_t GetPlatformNavigationDataRateofClimb();
NavigationIMUDataIMUTimeTag	None	Gets IMU Time Tag [GPS TOW uSec]	int64_t	int64_t GetNavigationIMUDataIMUTimeTag();
NavigationIMUDataIMUXRate	None	Gets IMU X Rate [LSB:1urad/sec]	int32_t	int32_t GetNavigationIMUDataIMUXRate();
NavigationIMUDataIMUYRate	None	Gets IMU Y Rate [LSB:1urad/sec]	int32_t	int32_t GetNavigationIMUDataIMUYRate();
NavigationIMUDataIMUZRate	None	Gets IMU Z Rate [LSB:1urad/sec]	int32_t	int32_t GetNavigationIMUDataIMUZRate();
NavigationIMUDataIMUXAcc	None	Gets IMU X Acc [LSB:1uG]	int32_t	int32_t GetNavigationIMUDataIMUXAcc();
NavigationIMUDataIMUYAcc	None	Gets IMU Y Acc [LSB:1uG]	int32_t	int32_t GetNavigationIMUDataIMUYAcc();
NavigationIMUDataIMUZAcc	None	Gets IMU Z Acc [LSB:1uG]	int32_t	int32_t GetNavigationIMUDataIMUZAcc();
NavigationIMUDataIMUTemperature	None	Gets IMU Temperature [LSB:°C]	int8_t	int8_t GetNavigationIMUDataIMUTemperature();
NavigationIMUDataIMUStatus	None	Gets IMU Status	int16_t	int16_t GetNavigationIMUDataIMUStatus();
GPSDataLongitude	None	Gets GPS Longitude [rad]	int32_t	int32_t GetGPSDataLongitude();
GPSDataLatitude	None	Gets GPS Latitude [rad]	int32_t	int32_t GetGPSDataLatitude();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 35 of 44

Function Name	Args	Description	Return Type	Signature
GPSDataAltitude	None	Gets GPS Altitude [rad]	int32_t	int32_t GetGPSDataAltitude();
GPSDataAzimuth	None	Gets GPS Azimuth [LSB:360°/65536]	int16_t	int16_t GetGPSDataAzimuth();
GPSDataSecond	None	Gets GPS Time in seconds elapsed since Jan. 6, 1980. [LSB: 1 sec]	uint32_t	uint32_t GetGPSDataSecond();
GPSDatamilliseconds	None	Gets GPS Time remainder in msec. [LSB: 1 msec]	uint32_t	uint32_t GetGPSDatamilliseconds();
GPSDataNumeOfSatellites	None	Gets GPS Numer of Satellites	int8_t	int8_t GetGPSDataNumeOfSatellites();
GPSDataPositionValid	None	Gets GPS Position information valid. 0 - valid. 1 - not valid	bool	bool GetGPSDataPositionValid();

6.4. Navigation Record

6.4.1. Command

Function Name	Args	Description	Return Type	Signature
NavigationRecordRecordLevel	int8_t RecordLevel	Enables navigation record and level	int Success	int SetNavigationRecordRecordLevel(int8_t RecordLevel);

6.4.2. Report

Function Name	Args	Description	Return Type	Signature
GPSRecordingGPSRecordingLevel	None	Gets GPS Recording level status	int8_t	int8_t GetGPSRecordingGPSRecordingLevel();
GPSRecordingGPSFreeMemory	None	Gets free memory on recording device in kBytes	int32_t	int32_t GetGPSRecordingGPSFreeMemory();

6.5. Navigation BIT

6.5.1. Report

Function Name	Args	Description	Return Type	Signature
NavigationBITNavigationaccuracyWarning	None	Gets Navigation accuracy Warning	bool	bool GetNavigationBITNavigationaccuracyWarning();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 36 of 44

Function Name	Args	Description	Return Type	Signature
		Flag		uracyWarning();
NavigationBITGPSCommFail	None	Gets GPS Comm Fail	bool	bool GetNavigationBITGPSCommFail();
NavigationBITGPSprecisionFail	None	Gets GPS precision Fail	bool	bool GetNavigationBITGPSprecisionFail();
NavigationBITGPSantennaFail	None	Gets GPS antenna Fail	bool	bool GetNavigationBITGPSantennaFail();
NavigationBITIMUFail	None	Gets IMU Fail	bool	bool GetNavigationBITIMUFail();
NavigationBITPPSFail	None	Gets PPS Fail	bool	bool GetNavigationBITPPSFail();
NavigationBITCalibrationFail	None	Gets Calibration Fail	bool	bool GetNavigationBITCalibrationFail();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 37 of 44

7. Designator

7.1. Designator Mode

7.1.1. Command

Function Name	Args	Description	Return Type	Signature
DesignatorPower	bool Power	Sets Designator Power 0 - Off. 1 - On	int Success	int SetDesignatorPower(bool Power);
DesignatorArm	bool Arm	Sets Designator Arm 0 - Off. 1 - On	int Success	int SetDesignatorArm(bool Arm);

7.1.2. Report

Function Name	Args	Description	Return Type	Signature
DesignatorStatusPower	None	Gets Designator Power 0 - Off. 1 - On	bool	bool GetDesignatorStatusPower();
DesignatorStatusArm	None	Gets Designator Arm 0 - Off. 1 - On	bool	bool GetDesignatorStatusArm();
DesignatorStatusReady	None	Gets Designator Ready 0 - Not Ready for fire. 1 - Ready for fire	bool	bool GetDesignatorStatusReady();
DesignatorStatusSafetySwitch	None	Gets Designator Safety Switch 0 - Off (Fire Disabled). 1 - On (Fire Enabled)	bool	bool GetDesignatorStatusSafetySwitch();
DesignatorStatusEnable	None	Gets Designator HW Input status 0 - Off (Designator Disabled). 1 - On (Designator Enabled)	bool	bool GetDesignatorStatusEnable();

7.2. Designator Fire

7.2.1. Command

Function Name	Args	Description	Return Type	Signature
DesignatorFire	bool Fire	Sets Designator Fire. 0 - Fire Off. 1 - Fire On	int Success	int SetDesignatorFire(bool Fire);

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 38 of 44

7.2.2. Report

Function Name	Args	Description	Return Type	Signature
DesignatorFire	None	Gets Designator Fire. 0 - Fire Off. 1 - Fire On	bool	bool GetDesignatorFire();
DesignatorFireBlocked	None	Gets Fire Blocked. 0 - Fire not blocked. 1 - Fire blocked	bool	bool GetDesignatorFireBlocked();

7.3. Designator NATO Code

7.3.1. Command

Function Name	Args	Description	Return Type	Signature
DesignatorNATOCodValue	uint16_t CodeValue	Sets fire frequency. Set the value -50,000 [uSec]	int Success	int SetDesignatorNATOCodValue(uint16_t CodeValue);

7.3.2. Report

Function Name	Args	Description	Return Type	Signature
DesignatorNATOCodValue	None	Sets fire frequency. Set the value -50,000 [uSec]	uint16_t	uint16_t GetDesignatorNATOCodValue();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 39 of 44

8. Illuminator

8.1. Illuminator Arm

8.1.1. Command

Function Name	Args	Description	Return Type	Signature
IlluminatorPower	bool Power	Sets Illuminator Power . 0 - Off 1 - On	int Success	int SetIlluminatorPower(bool Power);
IlluminatorArm	bool Arm	Sets Illuminator Arm . 0 - Off 1 - On	int Success	int SetIlluminatorArm(bool Arm);

8.1.2. Report

Function Name	Args	Description	Return Type	Signature
IlluminatorPower	None	Sets Illuminator Power . 0 - Off 1 - On	bool	bool GetIlluminatorPower();
IlluminatorArm	None	Sets Illuminator Arm . 0 - Off 1 - On	bool	bool GetIlluminatorArm();

8.2. Illuminator Fire

8.2.1. Command

Function Name	Args	Description	Return Type	Signature
IlluminatorMode	int8_t Mode	Sets Illuminator Mode	int Success	int SetIlluminatorMode(int8_t Mode);
IlluminatorFire	bool Fire	Sets Illuminator Fire. 0 - Fire Off. 1 - Fire On	int Success	int SetIlluminatorFire(bool Fire);

8.2.2. Report

Function Name	Args	Description	Return Type	Signature
IlluminatorMode	None	Sets Illuminator Mode	int8_t	int8_t GetIlluminatorMode();
IlluminatorFire	None	Sets Illuminator Fire. 0 - Fire Off. 1 - Fire On	bool	bool GetIlluminatorFire();

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 40 of 44

9. System

9.1. Keep Alive

Function Name	Args	Description	Return Type	Signature
KeepAlive	None	Keep Alive signal. Need to send to system every ~500 mSec	int Success	int SetKeepAlive();

9.2. Get Specific Data

Function Name	Args	Description	Return Type	Signature
GetData	uint16_t Data, enum RetrieveDataType RetrieveType	Set method to retrieve data	int Success	int SetGetData(uint16_t Data, enum RetrieveDataType RetrieveType);

9.3. General Reports

Function Name	Args	Description	Return Type	Signature
SystemGeneralReportOperation Mode	None	Gets Operation Mode Status	TOperationMode_Micro	enum TOperationMode_Micro GetSystemGeneralReportOperationMode();
SystemGeneralReportHybridMode	None	Gets Hybrid Mode Status	bool	bool GetSystemGeneralReportHybridMode();
SystemGeneralReportHiveTemperature	None	Gets Hive Temperature	int8_t	int8_t GetSystemGeneralReportHiveTemperature();

9.4. Log Records

9.4.1. Command

Function Name	Args	Description	Return Type	Signature
LogRecordCommandEnable	bool Enable	Enables/Disables system logging	int Success	int SetLogRecordCommandEnable(bool Enable);
LogRecordCommandErrorLevel	bool ErrorLevel	Enables/Disables Error Level	int Success	int SetLogRecordCommandErrorLevel(bool ErrorLevel);
LogRecordCommandInfoLevel	bool InfoLevel	Enables/Disables Info Level	int Success	int SetLogRecordCommandInfoLevel(bool InfoLevel);
LogRecordCommandDebugLevel	bool DebugLevel	Enables/Disables	int Success	int

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 41 of 44

Function Name	Args	Description	Return Type	Signature
l		Debug Level		SetLogRecordCommandDebugLevel(bool DebugLevel);
LogRecordCommandFreeText	char* FreeText, size_t Size - C string should be at most 19 Bytes.	Sets folder name to save log file	int Success	int SetLogRecordCommandFreeText(char* FreeText, size_t Size);

9.4.2. Report

Function Name	Args	Description	Return Type	Signature
LogRecordReportEnable	None	Gets if log is Enabled/Disabled	bool	bool GetLogRecordReportEnable();
LogRecordReportErrorLevel	None	Gets if Error Level is Enabled/Disabled	bool	bool GetLogRecordReportErrorLevel();
LogRecordReportInfoLevel	None	Gets if Info Level is Enabled/Disabled	bool	bool GetLogRecordReportInfoLevel();
LogRecordReportDebugLevel	None	Gets if Debug Level is Enabled/Disabled	bool	bool GetLogRecordReportDebugLevel();
LogRecordReportFileName	char* Buffer, size_t Size - Buffer size should be at least 15	Gets log's folder name	void	void GetLogRecordReportFileName(char* Buffer, size_t Size);

9.5. Power Management

9.5.1. Command

Function Name	Args	Description	Return Type	Signature
CameraPowerControlDayLightCameraPower	enum PowerStatesRequest DayLightCameraPower	Enables/Disables DTV Sensor	int Success	int SetCameraPowerControlDayLightCameraPower(enum PowerStatesRequest DayLightCameraPower);
CameraPowerControlThermalCameraPower	enum PowerStatesRequest ThermalCameraPower	Enables/Disables TI Sensor	int Success	int SetCameraPowerControlThermalCameraPower(enum PowerStatesRequest ThermalCameraPower);

9.5.2. Report

Function Name	Args	Description	Return Type	Signature
CameraPowerReportWideDTVS	None	Gets	PowerStatesReport	enum PowerStatesReport

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 42 of 44

Function Name	Args	Description	Return Type	Signature
tate		Enabled/Disabled Wide DTV	t	GetCameraPowerReportWideDTVState();
CameraPowerReportNarrowDTVState	None	Gets Enabled/Disabled Narrow DTV	PowerStatesReport	enum PowerStatesReport GetCameraPowerReportNarrowDTVState();
CameraPowerReportTIStateState	None	Gets Enabled/Disabled TI	PowerStatesReport	enum PowerStatesReport GetCameraPowerReportTIStateState();

9.6. System Clock

9.6.1. Time Tag Report

Function Name	Args	Description	Return Type	Signature
TimeTagReportSystemTimeTag	None	Gets System Message Time Tag	uint64_t	uint64_t GetTimeTagReportSystemTimeTag();
TimeTagReportControlTimeTag	None	Gets Latest Control Message Time Tag	uint64_t	uint64_t GetTimeTagReportControlTimeTag();

9.6.2. Set System Clock

Function Name	Args	Description	Return Type	Signature
SetSystemClockYear	uint16_t Year	Sets Year as decimal integer [YYYY]	int Success	int SetSetSystemClockYear(uint16_t Year);
SetSystemClockMonth	uint8_t Month	Sets Month as decimal integer [1-12]	int Success	int SetSetSystemClockMonth(uint8_t Month);
SetSystemClockDay	uint8_t Day	Sets Day as decimal integer [1-31]	int Success	int SetSetSystemClockDay(uint8_t Day);
SetSystemClockHour	uint8_t Hour	Sets Hour as decimal integer in 24Hrs Pattern [0-23]	int Success	int SetSetSystemClockHour(uint8_t Hour);
SetSystemClockMinute	uint8_t Minute	Sets Minute as decimal integer [0-59]	int Success	int SetSetSystemClockMinute(uint8_t Minute);
SetSystemClockSecond	uint8_t Second	Sets Second as decimal integer [0-59]	int Success	int SetSetSystemClockSecond(uint8_t Second);

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 43 of 44

9.6.3. Get System Clock

Function Name	Args	Description	Return Type	Signature
CurrentSystemTimeYear	None	Gets Year as decimal integer	uint16_t	uint16_t GetCurrentSystemTimeYear();
CurrentSystemTimeMonth	None	Gets Month as decimal integer	uint8_t	uint8_t GetCurrentSystemTimeMonth() ;
CurrentSystemTimeDay	None	Gets Day as decimal integer	uint8_t	uint8_t GetCurrentSystemTimeDay();
CurrentSystemTimeHour	None	Gets Hour as decimal integer in 24Hrs Pattern	uint8_t	uint8_t GetCurrentSystemTimeHour();
CurrentSystemTimeMinute	None	Gets Minute as decimal integer	uint8_t	uint8_t GetCurrentSystemTimeMinute() ;
CurrentSystemTimeSecond	None	Gets Second as decimal integer	uint8_t	uint8_t GetCurrentSystemTimeSecond() ;

9.7. System Version

Function Name	Args	Description	Return Type	Signature
SystemVersionBundle	None	Bundle Version	int8_t	int8_t GetSystemVersionBundle();
SystemVersionCPU	char* Buffer, size_t Size - Buffer size should be at least 16	CPU Version	void	void GetSystemVersionCPU(char* Buffer, size_t Size);
SystemVersionControl	None	Control Version	uint32_t	uint32_t GetSystemVersionControl();
SystemVersionDTVLibrary	char* Buffer, size_t Size - Buffer size should be at least 16	DTV Library Version	void	void GetSystemVersionDTVLibrary(char* Buffer, size_t Size);
SystemVersionECVML	char* Buffer, size_t Size - Buffer size should be at least 16	ECVML Version	void	void GetSystemVersionECVML(char* Buffer, size_t Size);
SystemVersionSensorsWide	char* Buffer, size_t Size - Buffer size should be at least 16	Sensors Wide Version	void	void GetSystemVersionSensorsWide(char* Buffer, size_t Size);
SystemVersionSensorsNarrow	char* Buffer, size_t Size - Buffer size should be at least 16	Sensors Narrow Version	void	void GetSystemVersionSensorsNarrow(char* Buffer, size_t Size);

	Unclassified	14-Sep-25
Document: Micro Sting communication ICD		
Document No.: MS30-0001-00-0050	Rev: -	Page: 44 of 44

Function Name	Args	Description	Return Type	Signature
SystemVersionSensorsThermal	char* Buffer, size_t Size - Buffer size should be at least 16	Sensors Thermal Version	void	void GetSystemVersionSensorsThermal(char* Buffer, size_t Size);
SystemVersionDesignator	char* Buffer, size_t Size - Buffer size should be at least 16	Designator Version	void	void GetSystemVersionDesignator(char* Buffer, size_t Size);
SystemVersionIlluminator	char* Buffer, size_t Size - Buffer size should be at least 16	Illuminator Version	void	void GetSystemVersionIlluminator(char* Buffer, size_t Size);
SystemVersionSensorsSeeSpot	char* Buffer, size_t Size - Buffer size should be at least 16	Sensors SeeSpot Version	void	void GetSystemVersionSensorsSeeSpot(char* Buffer, size_t Size);