







: PARTS LOCATION

C	ODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
,	J 1	27				

: RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)	
6	17	R/B NO.6 (UNDER THE HEADLIGHT LH)	
7	18	R/B NO.7 (RIGHT SIDE OF J/B NO.1	

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)	
1A	18	COWL WIRE AND J/B NO.1 (LEFT SIDE OF STEERING COLUMN TUBE)	
1B	18	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT SIDE OF STEERING COLUMN TUBE)	
2A	20	ENGINE ROOM MAIN WIRE AND J/B NO.2 (ENGINE COMPARTMENT LEFT)	
3A			
3C	22	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)	
3D			

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)			
32	COWL WIRE AND ENGINE ROOM MAIN WIRE (INSIDE OF J/B NO.2)			
32	ENGINE NO.4 WIRE, FOR ALTERNATOR AND ENGINE ROOM MAIN WIRE (RIGHT SIDE OF J/B NO.2)			
34	FRONT DOOR LH WIRE AND COWL WIRE (LEFT KICK PANEL)			
34	INSTRUMENT PANEL WIRE AND COWL WIRE (J/B NO.1)			
34	INSTRUMENT PANEL WIRE AND COWL WIRE (BEHIND GLOVE BOX)			
36	INSTRUMENT PANEL WIRE AND A/C NO.1 WIRE (BEHIND GLOVE BOX)			
	ENGINE WIRE AND COMMANDE WINDER THE CLOVE DOWN			
36	ENGINE WIRE AND COWL WIRE (UNDER THE GLOVE BOX)			
36	FLOOR NO.1 WIRE AND COWL WIRE (UNDER THE GLOVE BOX)			
36	COWL WIRE AND ROOF WIRE (BEHIND GLOVE BOX)			
36	FRONT DOOR RH WIRE AND COWL WIRE (RIGHT KICK PANEL)			
36	COWL WIRE AND A/C NO.2 WIRE (BEHIND GLOVE BOX)			
20	COMMUNITE AND FLOOD NO CHAIRE (LEFT MOVED AND L			
38	COWL WIRE AND FLOOR NO.2 WIRE (LEFT KICK PANEL)			
40	FLOOR NO.2 WIRE AND FRONT SEAT LH WIRE (UNDER THE FRONT LH SEAT)			
40	FLOOR NO.1 WIRE AND FRONT SEAT RH WIRE (UNDER THE FRONT RH SEAT)			
38	REAR DOOR LH WIRE AND FLOOR NO.2 WIRE (LEFT CENTER PILLAR)			
38	REAR DOOR RH WIRE AND FLOOR NO.1 WIRE (RIGHT CENTER PILLAR)			
38	FLOOR NO.1 WIRE AND FLOOR NO.2 WIRE (UNDER THE LEFT SIDE OF REAR SEAT CUSHION)			
38	FLOOR NO.3 WIRE AND FLOOR NO.2 WIRE (UNDER THE LEFT REAR PILLAR)			
	32 32 34 34 36 36 36 36 36 36 36 36 36 36			

: GROUND POINTS

v		
CODE	SEE PAGE	GROUND POINTS LOCATION
EA	32	FRONT SIDE OF RIGHT FENDER
EB	32	FRONT SIDE OF LEFT FENDER
EC	32	REAR SIDE OF CYLINDER HEAD RH
ED	32	REAR SIDE OF CYLINDER HEAD LH
IE	34	LEFT KICK PANEL
IF	34	INSTRUMENT PANEL BRACE LH
IG	34	INSTRUMENT PANEL BRACE RH
IH	34	RIGHT KICK PANEL
BI	38	UNDER THE LEFT REAR PILLAR
BJ	38	UNDER THE RIGHT REAR PILLAR
BK	38	BACK PANEL RIGHT

: SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E 1			В 3		
E 3			B 7	38	ROOF WIRE
E 7			B 11		
E 8	32	ENGINE ROOM MAIN WIRE	B 12	38	FRONT DOOR LH WIRE
E 18			B 14		
E 20			B 16		
E 23			B 17	1	EDON'T BOOD BLUMIDE
E 44	32	ENGINE WIRE	B 19	38	FRONT DOOR RH WIRE
E 81			B 21		
E 83	32		B 26		FLOOR NO.2 WIRE
D 98	32		B 28		
E100			B 30		
l 20			B 36	38	
l 21			B 37		
I 25			B 40		
I 43			B 45		
I 46			B 53		
I 50			B 54		
I 51		COWL WIRE INSTRUMENT PANEL WIRE	B 55		
I 58			B 56		
I 62			B 63		
I 65			B 64		
I 74	36		B 66		
I 75			B 68		
I 78			B 75	38	FLOOR NO.1 WIRE
I 92			B 81		
I 94			B 82		
I100			B 90		
I110			B 96		
I118 I122	- - - -		B106 B107	FLOOR NO.2 WIRE	
				20	DEAD DOOD LILWIDE
I124 I133			B108 B109	38	REAR DOOR LH WIRE REAR DOOR RH WIRE
I135			B109	36	NEAR BOOK KIT WIKE
I135 I145			B112	_	
1145	36		B115	40	FRONT SEAT LH WIRE
I150			B119		
1177	36	ENGINE WIRE	B119	-	
I180	36	A/C NO.1 WIRE	B121	-	
1183	36	A/C NO.2 WIRE	B126		
B 1	38	ROOF WIRE	B128	40	FRONT SEAT RH WIRE

