







#### : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
J 1	27				

#### : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)	
6	17	R/B NO.6 (UNDER THE HEADLIGHT LH)	
7	18	R/B NO.7 (RIGHT SIDE OF J/B NO.1	

# : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1A	18	COWL WIRE AND J/B NO.1 (LEFT SIDE OF STEERING COLUMN TUBE)
1B	18	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT SIDE OF STEERING COLUMN TUBE)
2A	20	ENGINE ROOM MAIN WIRE AND J/B NO.2 (ENGINE COMPARTMENT LEFT)
3A		
3C	22	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)
3D		

#### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

_						
CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)				
EA3	32	COWL WIRE AND ENGINE ROOM MAIN WIRE (INSIDE OF J/B NO.2)				
EC1	32	ENGINE NO.4 WIRE, FOR ALTERNATOR AND ENGINE ROOM MAIN WIRE (RIGHT SIDE OF J/B NO.2)				
IG1	- 34	FRONT DOOR LH WIRE AND COWL WIRE (LEFT KICK PANEL)				
IG2	34	FRONT DOOR LE WIRE AND COWL WIRE (LEFT KICK PAINEL)				
IH1	34	INSTRUMENT PANEL WIRE AND COWL WIRE (J/B NO.1)				
IH2	34	INSTRUMENT PANEL WIRE AND COWL WIRE (BEHIND GLOVE BOX)				
IJ1	36	INSTRUMENT PANEL WIRE AND A/C NO.1 WIRE (BEHIND GLOVE BOX)				
IL1	36	ENCINE WIDE AND COMUNIDE (LINDED THE CLOVE DOV)				
IL2	36	ENGINE WIRE AND COWL WIRE (UNDER THE GLOVE BOX)				
IM2	36	FLOOR NO.1 WIRE AND COWL WIRE (UNDER THE GLOVE BOX)				
IN1	36	COWL WIRE AND ROOF WIRE (BEHIND GLOVE BOX)				
102	36	FRONT DOOR RH WIRE AND COWL WIRE (RIGHT KICK PANEL)				
IP1	36	COWL WIRE AND A/C NO.2 WIRE (BEHIND GLOVE BOX)				
BQ2	- 38	COMILIMIDE AND ELOOPING SIMIDE (LEET KICK DANEL)				
BQ3	30	COWL WIRE AND FLOOR NO.2 WIRE (LEFT KICK PANEL)				
BS1	40	FLOOR NO.2 WIRE AND FRONT SEAT LH WIRE (UNDER THE FRONT LH SEAT)				
BT1	40	FLOOR NO.1 WIRE AND FRONT SEAT RH WIRE (UNDER THE FRONT RH SEAT)				
BU1	38	REAR DOOR LH WIRE AND FLOOR NO.2 WIRE (LEFT CENTER PILLAR)				
BV1	38	REAR DOOR RH WIRE AND FLOOR NO.1 WIRE (RIGHT CENTER PILLAR)				
BW1	38	FLOOR NO.1 WIRE AND FLOOR NO.2 WIRE (UNDER THE LEFT SIDE OF REAR SEAT CUSHION)				
BX1	38	FLOOR NO.3 WIRE AND FLOOR NO.2 WIRE (UNDER THE LEFT REAR PILLAR)				

## : GROUND POINTS

v		
CODE	SEE PAGE	GROUND POINTS LOCATION
EA	32	FRONT SIDE OF RIGHT FENDER
EB	32	FRONT SIDE OF LEFT FENDER
EC	32	REAR SIDE OF CYLINDER HEAD RH
ED	32	REAR SIDE OF CYLINDER HEAD LH
IE	34	LEFT KICK PANEL
IF	34	INSTRUMENT PANEL BRACE LH
IG	34	INSTRUMENT PANEL BRACE RH
IH	34	RIGHT KICK PANEL
BI	38	UNDER THE LEFT REAR PILLAR
BJ	38	UNDER THE RIGHT REAR PILLAR
BK	38	BACK PANEL RIGHT

## : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E 1	GEETAGE	White I walked a will of Elde I chard	I193	36	COWL WIRE
E 7	7 8		B 1		OOME WINE
E 8		ENGINE ROOM MAIN WIRE	В 3	20	ROOF WIRE
E 20			B 7	38	
E 44	32	ENGINE WIRE	B 11		
E 81	32	COWL WIRE		38	FRONT DOOR LH WIRE
			B 12		
E 83 E100	32		B 14		
			B 16		FRONT DOOR RH WIRE
E105	_		B 17	38	
E111	_		B 19		
E112			B 21		
E113	32	ENGINE ROOM MAIN WIRE	B 26		FLOOR NO.2 WIRE
E114			B 28		
E115			B 30		
E116			B 36		
E118	36	COWL WIRE	B 37		
I 20			B 40		
I 21			B 45		
I 43			B 53	38	
I 46			B 54		
I 50			B 55		
I 58			B 56		
I 62			B 63		
I 65			B 64		
I 69			B 66		
175	36	COWL WIRE	B 68		
I 78	30	COWL WIRE	B 75		
I 92			B 81		
I 94			B 82	38	FLOOR NO.1 WIRE
I100			B 90		
I110			B 96		
I118			B106	00	FLOOR NO.2 WIRE
l122	1		B107	38	
l124	1		B108	38	REAR DOOR LH WIRE
l129	1		B109	38	REAR DOOR RH WIRE
I135			B112		
I145		INSTRUMENT PANEL WIRE	B113		
I150	36		B115	40	FRONT SEAT LH WIRE
I151	1		B119		
l177	36	ENGINE WIRE	B120		
I180	36	A/C NO.1 WIRE	B121		
I183	36	A/C NO.2 WIRE	B126		
1190	36	COWL WIRE	B128	40	FRONT SEAT RH WIRE

