

Memory Map

The Memory Map for 'SAL-16' is:

Region	Address Range		Description
ROM	0x0000	0x000F	Boot Code
	0x0010	0x0013	Interrupt Vector Table
	0x0014	0x00FF	-
	0x0100	0x0FFF	Interrupt Handlers
	0x1000	0x1FFF	BIOS
	0x2000	0x2FFF	Maths Library
	0x3000	0x3FFF	Graphics Library
	0x4000	0x4FFF	Strings Library
	0x5000	0x5FFF	Casts Library
	0x6000	0x7FFF	-
RAM	0x8000	0xAFFF	Program Code
	0xB000	0xB0FF	ENTER_1 Interrupt Service Routine
	0xB100	0xB1FF	ENTER_2 Interrupt Service Routine
	0xB200	0xB2FF	KBD Interrupt Service Routine
	0xB300	0xBFFF	-
	0xC000	0XC001	Heap Size & Heap End Address
	0xC002		Heap Starts (grows upwards)
		0xFFEF	Stack Starts (grows downwards)
I/O	0xFFFF0		ERR State
	0xFFFF1		KBD Buffer
	0xFFFF2		TTY Buffer
	0xFFFF3		IN_1 Buffer
	0xFFFF4		WAIT_1 State
	0xFFFF5		ENTER_1 State
	0xFFFF6		OUT_1 Buffer
	0xFFFF7		IN_2 Buffer
	0xFFFF8		WAIT_2 State
	0xFFFF9		ENTER_2 State
	0xFFFFA		OUT_2 Buffer
	0xFFFFB	0xFFFF	-