

**F-16** Block 50-52

Cockpit Checklists (Interior Check)

# Not suited for Real Operations For FALCON 4.0 Use Only.

Consider this volume as your preflight visit. Mandatory for cockpit builders but useful for any F4 driver doing ramp starts to ensure correct sequence with the main checklists

## Rev: 1107 BMS 4.32

### PAGE INTENTIONALLY LEFT BLANK ADD YOUR OWN BEFORE LAUNCHING F4 LIST

#### **COCKPIT CHECK – LEFT CONSOLE**

Rev: 1107 BMS 4 32

PROBE HEAT switch
FLCS PWR test switch
DIGITAL BACKUP switch
ALT FLAPS switch
MANUAL TF FLY UP switch
LE FLAPS switch
BIT switch
OFF
OFF
OFF
OFF
OFF

BIT switch
TRIM A/P DISC switch
TRIMS knobs/displays

OFF
NORM
Center

FUEL MASTER switch ON (Guard Down)

C&I (CNI)

TACAN (backup channel)

EXT Lighting

MASTER LIGHT switch

BACKUP

As desired

As required

NORM

EPU switch NORM (Guard Down)

MAIN POWER switch OFF ECM POWER OFF

COM1 Volume knob Fully Clockwise COM1 Mode knob SQL

COM2 Volume knob Fully Clockwise

COM2 Mode knob SQL
MSL tone knob Fully Clockwise

Threat tone knob Fully Clockwise ILS knob Fully Clockwise

ENG CONT switch PRI (Guard Down)
UHF backup radio function BOTH
UHF backup Channel As briefed

THROTTLE Verify freedom of motion then OFF

SPEEDBRAKE FORWARD DOGFIGHT switch CENTRE

#### **COCKPIT CHECK – LEFT AUXILIARY CONSOLE**

Rev: 1107 BMS 4 32

ALT GEAR handle IN

CMDS switches All OFF SYMBOLOGY Power knob OFF

STORE CONFIG switch As required

LANDING/TAXI light switch
LG HANDLE
GD JETT ENABLE switch
BRAKE CHANNEL switch
HOOK switch
UP

Canopy switch As desired

#### **COCKPIT CHECK - INSTRUMENT PANEL**

ROLL switch ATT HOLD PITCH switch A/P OFF MASTER ARM switch **OFF** LASER ARM switch OFF RF switch **NORM** FUEL QTY SEL knob NORM EXT FUEL TRANS switch **NORM** INSTR MODE knob As desired

#### **COCKPIT CHECK - RIGHT AUXILIARY CONSOLE**

Clock SET

#### **COCKPIT CHECK - RIGHT CONSOLE**

SNSR PWR switches All OFF HUD control panel SET

NUCLEAR CONSENT switch OFF (Guard Down)

Zeroize switch OFF

Interior LIGHTING knobs As desired

VOICE MESSAGE switch VOICE MESSAGE

TEMP knob AUTO
AIR SOURCE knob NORM
AVIONICS POWER switches All OFF
INS knob OFF

ANTI ICE switch AUTO/ON
IFF ANT SEL switch NORM

UHF ANT SEL NORM
Oxygen System Check