02-3 Device Trees

A systematic way to describe hardware

Much taken from:

http://learn.adafruit.com/introduction-to-the-beaglebone-black-device-tree

Device Tree - Overview

- A way to describe hardware in a system
- Example: how the UART interfaces with the system
 - which pins
 - how they should be muxed
 - the device to enable
 - which driver to use

History

- Under the 3.2 kernel
 - Huge influx of ARM systems in the past few years
 - ARM board files described how each board worked
 - a lot of confusion and conflicts in the Linux kernel surrounding the ARM components
- Under the 3.8 kernel
 - Any new ARM boards use the flattened device tree

Device Tree and Overlays

- The device tree is a file (or files) that describe at boot time all the hardware
- Problem: Embedded systems often add hardware at run time (i.e. capes)
- Solution: Device Tree Overlays and cape manager

gpio Example Overlay

- See Handout
- Example is a tree structure of nodes and properties (http://devicetree.org/Device Tree Usage)
- Start with

* Copyright (C) 2012 Texas Instruments Incorporated - http://www.ti.com

* This program is free software; you can redistribute it and/or modify * it under the terms of the GNU General Purpose License Version 2 as

* published by the Free Software Foundation

* Modified by Derek Molloy for the example on www.derekmolloy.ie * that maps GPIO pins for the example

Walk Through - 1

/plugin/;

· Version and plugin

/{

Root node

compatible = "ti,beaglebone", "ti,beaglebone-black";

- · describes which platforms the DT overlay works with
- most compatible -> least compatible
- Name all the platforms that you'd like to support, as it will fail to load in any platforms not mentioned.

Walk Through - 2

```
part-number = "DM-GPIO-Test";
    version = "00A0";
```

- Part number and version are further guards to ensure that the proper DT overlays are loaded.
- Also, as far as I can tell, the revision must be 00A0 on the BeagleBone Black.

Walk Through - 3

Not in your example

```
/* state the resources this cape uses */
exclusive-use =
    /* the pin header uses */
    "p9.24", /* uart1_txd */
    "p9.26", /* uart1_rxd */
    /* the hardware ip uses */
    "uart1";
```

 exclusive-use property allows overlays to describe what resources they need, and prevents any other overlays from using those resources.

Register values

beagle\$ exercises/node.js/findGPIO.js P9_12

• Use the Molloy P8/P9 tables to find the register values, or

```
gpio: 60,
mux: 'gpmc_ben1',
eeprom: 36,
key: 'P9_12',
muxRegOffset: '0x078',
options:
[ 'gpmc_ben1',
   'mi2_col',
   'NA',
   'mac2_dat3',
   'NA',
   'mcasp0_aclkr',
   'gpio1_28' ] }
```

{ name: 'GPIO1_28',

Register values

Register contents

• From the Molloy table

| | | GPIO Settings | | |
|--------------|--------------------|----------------------|-----------------------------------|---------------|
| Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2,1,0 |
| Slew Control | Receiver Active | Pullup/Pulldown | Enable Pullup/Pulldown | Mux Mode |
| 0 Fast | 0 Disable | O Pulldown select | 0 Enabled | 000 Mode 0 to |
| 1 Slow | 1 Enable | 1 Pullup select | 1 Disabled | 111 Mode 7 |
| | e a TNDHT SPTO(mov | (a7) 8v87 nulldown 8 | by17 mullion dw2f no mullion/down | |

e.g. INPUT GPIO(mode7) 0x07 pulldown, 0x17 pullup, 0x?f no pullup/down e.g. OUTPUT GPIO(mode7) 0x27 pulldown, 0x37 pullup, 0x?f no pullup/down

- \bullet Or from the Technical Reference Manual
- Section 9.2.2, page 747 (of 4161!)

| 91 | Freid | Yarue | Description |
|------|--------------|-------|---|
| 31-1 | Reserved . | 7.55 | Reserved, Read returns 1. |
| | BLEWCTRL | 3 | Detect befores facilet or olimes size. Fact Stor ⁽¹⁾ |
| | HAACTNE | 1 | Expel enable value for the Flat. Set to 5 for subput only. Set to 1 for equal or output. Securities disabled. Securities enabled. |
| * | PLALTYPESES. | 0 | Pod pung-pulation typ seector Polition seected Pulip seected |
| , | PLALLIDEN | 0 | File Pulluppulitivin endile Pulluppulitivin snatini Pulluppulitivin disatesi |
| 3-8 | MUNICIPALITY | | Pad functional signal max select |

```
Fragments - 2

    Enables gpio

fragment@1 {
    target = <&ocp>;
    __overlay__ {
        test_helper: helper {
            compatible = "bone-pinmux-helper";
            pinctrl-names = "default";
            pinctrl-0 = <&pinctrl_test>;
            status = "okay";
        };
   };
};
```

```
Firmware
• DT Overlays live in /lib/firmware
beagle$ ls /lib/firmware
                            bone pwm P8 46-00A0.dtbo
                            bone_pwm_P9_14-00A0.dts-
bone_pwm_P9_14-00A0.dtbo
BB-ADC-00A0.dtbo
BB-ADC-00A0.dts
BB-BONE-AUDI-01-00A0.dtbo
                            bone_pwm_P9_14-00A0.dts
BB-BONE-AUDI-01-00A0.dts
                            bone_pwm_P9_16-00A0.dtbo
BB-BONE-BACON-00A0.dtbo
                            bone_pwm_P9_16-00A0.dts
BB-BONE-PRU-01-00A0.dtbo
                            cape-bone-adafruit-lcd-00A0.dtbo
BB-BONE-PRU-01-00A0.dts
                            cape-bone-adafruit-lcd-00A0.dts
BB-I2C1-00A0.dts
                            cape-bone-pinmux-test-00A0.dtbo
BB-SPI0-00A0.dtbo
                            cape-bone-tester-00A0.dts
BB-SPI1-00A0.dtbo
                            cape-bone-weather-00A0.dts
```

Listing Overlays

- beagle\$ **export** SLOTS=/sys/devices/bone_capemgr.*/slots
- See what's loaded

```
beagle$ cat $SLOTS
```

0: 54:PF---1: 55:PF---2: 56:PF---

3: 57:PF---

4: ff:P-O-L Bone-LT-eMMC-2G,00A0,Texas Instrument,BB-BONE-EMMC-2G

5: ff:P-O-L Bone-Black-HDMI,00A0,Texas Instrument,BB-BONELT-HDMI

Compiling and Loading Overlays

• Compile with

beagle\$ dtc -O dtb -o DM-GPIO-Test-00A0.dtbo -b 0 -@ DM-GPIO-Test.dts

Compiling the overlay from .dts to .dtbo

• Or

beagle\$./build

Compiling the overlay from .dts to .dtbo

Install

beagle\$ cp DM-GPIO-Test-00A0.dtbo /lib/firmware beagle\$ echo DM-GPIO-Test > \$SLOTS

Verify Overlay

• Check to be sure it worked

beagle\$ cat \$SLOTS

- 0: 54:PF---
- 1: 55:PF---
- 3: 57:PF---
- 4: ff:P-O-L Bone-LT-eMMC-2G.00A0.Texas Instrument.BB-BONE-EMMC-2G
- 5: ff:P-O-L Bone-Black-HDMI,00A0,Texas Instrument,BB-BONELT-HDMI
- 7: ff:P-O-L Override Board Name,00A0,Override Manuf,DM-GPIO-Test
- Remove with

beagle\$ echo -7 > \$SLOTS

Making it persistent

You have to run the command...

beagle\$ echo DM-GPIO-Test > \$SLOTS

- ...everytime you boot
- · However you can make it automatically run at boot time with

beagle\$ mount /dev/mmcblk0p1 /media/BEAGLEBONE/

• This 'mounts' the FAT partition of the eMMC at /media/BEAGLEBONE

beagle\$ ls /media/BEAGLEBONE/

App ID.txt MLO.orig autorun.inf u-boot.img.orig LICENSE.txt README.md u-boot.img Docs uEnv.txt Drivers MLO START.htm u-boot.img.new uEnv.txt.orig

Edit the file uEnv.txt and add

capemgr.extra_override=DM-GPIO-Test-00A0 capemgr.enable_partn=DM-GPIO-Test