MC68040 User's Manual Errata

by: Microcontroller Division

This errata document describes corrections to the *MC68040 User's Manual*, order number MC68040UM. For convenience, the addenda items are grouped by revision. Please check our website at http://freescale.com for the latest updates.

The current version available of the MC68040 User's Manual is Revision 1.



1 Errata for Revision 1

Table 1. MC68040UM Rev. 1 Errata

Location		Description								
N/A	This errata is in reference to MC68040UM and PCN 11910. As described in PCN 11910, Freescale Semiconductor announced a change of specification on some parts in the MC68040 family. The previous minimum operating frequency for the MC68040 family was 20 MHz. The new specification for MC68040RC40A, MC68040FE40A, MC68040RC33A and MC68040FE33A will be as follows:									
		20 MHz	25 MHz	33 MHz	40 MHz	Min	Max	Units		
	MC68040RC25A MC68040FE25A	<	>			20	25	MHz		
	MC68040RC33A MC68040FE33A		<	<>		25	33	MHz		
	MC68040RC40A MC68040FE40A		<>		25	40	MHz			
	20 MHz to 25 MHz). There are no changes	related to w	vafer fabrica	DRC25A and MC68040FE25A (fer fabrication or assembly; the c tion for the affected devices.						

2 Revision History

Table 2 provides a revision history for this document.

Table 2. Revision History Table

Rev. Number	Substantive Changes	Date of Release
0	Initial release.	03/2006

Freescale Semiconductor 3

How to Reach Us:

Home Page:

www.freescale.com

F-mail·

support@freescale.com

USA/Europe or Locations Not Listed:

Freescale Semiconductor Technical Information Center, CH370 1300 N. Alma School Road Chandler, Arizona 85224 +1-800-521-6274 or +1-480-768-2130 support@freescale.com

Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH Technical Information Center Schatzbogen 7 81829 Muenchen, Germany +44 1296 380 456 (English) +46 8 52200080 (English) +49 89 92103 559 (German) +33 1 69 35 48 48 (French) support@freescale.com

Japan:

Freescale Semiconductor Japan Ltd. Headquarters ARCO Tower 15F 1-8-1, Shimo-Meguro, Meguro-ku, Tokyo 153-0064, Japan 0120 191014 or +81 3 5437 9125 support.japan@freescale.com

Asia/Pacific:

Freescale Semiconductor Hong Kong Ltd.
Technical Information Center
2 Dai King Street
Tai Po Industrial Estate
Tai Po, N.T., Hong Kong
+800 2666 8080
support.asia@freescale.com

For Literature Requests Only:

Freescale Semiconductor Literature Distribution Center P.O. Box 5405
Denver, Colorado 80217
1-800-441-2447 or 303-675-2140

Fax: 303-675-2150

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.



Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.© Freescale Semiconductor, Inc. 2005. All rights reserved.

MC68040UMAD2 Rev. 0 03/2006