DOME CONTROLLER

UP	84	Random Happy Sound
DOWN	79	Reset - Silent
LEFT	80	Reset - Chatty
RIGHT	85	Random Holo Twitch
O + UP		ARM - RESERVE
O + DOWN		ARM - RESERVE
O + LEFT		ARM - RESERVE
O + RIGHT	102	Body Door
X + UP		
X + DOWN	92	Front Holo Center
X + LEFT	104	Scanning
X + RIGHT	105	Alarm
L1 + UP	88	Front Holo Up
L1 + DOWN	91	Front Holo Down
L1 + LEFT	89	Front Holo Left
L1 + RIGHT	90	Front Holo Right
PS + UP	26	Volume Up
PS + DOWN	27	Volume Down
PS + LEFT	29	Volume Mid
PS + RIGHT	28	Volume Max
PS + X		
PS + O		
L1 + L3		Not Functional
L2 + X		
L2 + O		

FOOT CONTROLLER

UP	84	Random Happy Sound
DOWN	106	Random Angry Sound
LEFT	93	Random Scared Sound
RIGHT	94	Random Sad Sound
O + UP	2	Scream (Extreme Scared)
O + DOWN		
O + LEFT	9	Leia
O + RIGHT	7	Short Circuit
X + UP	81	Yes (Extreme Happy)
X + DOWN	82	No (Extreme Angry)
X + LEFT	108	Extreme Sad Sound
X + RIGHT	96	Love
L1 + UP	107	Cantina
L1 + DOWN	97	Jedi Theme
L1 + LEFT	83	Imperial March
L1 + RIGHT	10	Disco
PS + UP	100	Brightness Up
PS + DOWN	98	Brightness Down
PS + LEFT	99	Brightness Mid
PS + RIGHT	101	Brightness Max
PS + X		Stick Disable
PS + O		Stick Enable
L1 + L3		Toggle Drive Power
L2 + X		Dome Automation Off
L2 + O		Dome Automation Off