PicoTerm Quick Reference

Nov 3, 2026 · @Gene

PicoTerm 0.1 is a CoCo 3 terminal for the Pocket Pico: 1200 baud, 8 data bits, no parity, 1 stop bit, 80 columns. Nothing to set up.

Starting PicoTerm

The SD card in the CoCo SDC holds `PICOTERM.DSK`. Plug in the cable's wall adapter (the red LED in the case lights), then plug the 3.5 mm plug into the Pico and power the Pico up. Then type these two lines on the CoCo, pressing ENTER after each:

```
DRIVE 0,"PICOTERM.DSK"
RUN"PICOTERM"
```

PicoTerm wakes up the Pico by itself. Look for "The Pocket Pico is answering. Ready." and then the Pico's `cmd:` prompt. PicoTerm's own messages show in yellow; text from the Pico shows in white.

Shutting down: unplug the 3.5 mm plug from the Pico first, then the wall adapter.

Keys

The CoCo keyboard has no Ctrl-C key, no backspace and no `|` or `~`, so PicoTerm maps them to these keys. Press **F1** any time to see a short version on screen.

CoCo key	What it does
BREAK	Ctrl-C (back to the `cmd:` prompt)
CLEAR	Clear the screen
CTRL + letter	Control key (CTRL+Z = Ctrl-Z)
LEFT arrow	Backspace
SHIFT+0	Caps lock on/off (starts on)
F1	Help on screen
SHIFT+F1	Wake up the Pocket Pico again

CoCo key	What it does
F2	Quit to BASIC (press Y to confirm, any other key to stay)

Special characters, typed with CTRL plus a key:

CTRL +	1	3	7	8	9	,	-	.	/
Types	|	~	^	[	]	{	_	}	\ (backslash)

The CoCo's font shows `^` as an up arrow and `_` as a left arrow on screen. The Pico still gets the right characters.

If the Pico doesn't answer

PicoTerm says "No answer from the Pocket Pico" after about 9 seconds. Check these in order, then press **SHIFT+F1** to try again:

1. The Pico is powered on and the 3.5 mm plug is all the way in.
2. The cable's wall adapter is plugged in and the red LED in the case is on.
3. The Pico's jack speed is 1200. Connect the Pico to the PC by USB, open PuTTY, type `ABAUD` at `cmd:`. If it doesn't say 1200, see below.
4. Still no answer: unplug the 3.5 mm plug from the Pico and clip its tip to its ring (not the sleeve). Type in PicoTerm. If the letters show on screen, the cable and the CoCo are fine and the problem is on the Pico side.

Setting the jack speed back to 1200 (in PuTTY over USB, at `cmd:`):

1. `TXDELAY` and note the number it shows (call it n).
2. `ABAUD 1200`
3. `TXDELAY` n+1, then `TXDELAY` n. Each one saves the settings to flash ("Saving Ram Data to Flash").
4. `RESTART`. It should show `TTL Serial= 1200, 8, 1, None`.

The TXDELAY change matters: ABAUD by itself is not saved and goes back to 115200 at the next power-up. Never use `RESET`; it erases all the Pico's settings.