

Notes and Tips

From the Engineering Department

General notes:

1. Filter aid(s) such as alum are generally not required. Consult manufacture before use.
2. Clean and repack the recirculation pump and/or check the seal and overhaul the motor at least once a year.
3. Establish definite periods for using the vacuum cleaner and skimmer in removing leaves and other foreign matter from the pool.
 - 3.1. Do not allow nails, pins or other metal articles to remain in the pool for any length of time, as a rust stain will mar the finish.
 - 3.2. If the pool is empty for any reason, do not allow any walking on the floor, as stains and marks will result.
4. Brush walls and the floor of the pool frequently.
5. Filter(s) requires the pump strainer(s) to be cleaned regularly to eliminate the pump operating without water.
 - 5.1. Leaves become waterlogged, sink to the bottom of the pool, are sucked into the strainer and clog it. This causes the pump to run dry, overheating the motor and damaging the seal.

If you have a sand filter:

1. Only use grade no. 20, or 16/20 filter sand.
2. Periodically check the filter media and remove any accumulation of pine needles, grass cuttings or the like. This type of material may enter the tank through the overdrain distributor and become trapped therein.
3. If an amount of fine sand or similar material has accumulated in the bottom of a new pool prior to start-up, it is recommended that the pool be vacuumed to waste.
4. Pressure sand filter(s) are equipped with an automatic air relief valve to expel all air from the tank interior. Air relief valve should be inspected periodically to insure proper operations.

If you have a regenerative filter:

1. Only use a premium grade of Perlite or DE for filtration media.
2. Do not use flocculant agents as this can damage the filter elements.

Specific notes for your filter can be found in the filter instruction portion of this manual.