

# Winterizing

## Pressure Filter

Follow the suggested procedures below:

1. Backwash the filter thoroughly.
2. Close the main drain and return valves. Open backwash valve (gravity drain line assumed). Open all valves, which are a part of the filter face piping.
3. Drain all water from the filter tank and piping by opening the tank drain valve (except 6800 series; follow specific instructions).
4. Remove the manway cover (indoor installations only), gauges, and flowmeter and store in a dry place.
5. Check sand bed in filter, clean if necessary.
6. Check filter tank for damages (if necessary).
7. Remove strainer lid and basket. (Loosen lid and remove basket on outdoor installations).
8. For longest service life, recirculating pump and motor should be in a dry area during shutdown, remove and store as required.