

INSTALLATION GUIDE

5° & 10° End of Panel Clamping Ballasted Roof Racking System



INCLUDED PARTS



























INSTALLER PROVIDED PARTS






FAST AND EASY ASSEMBLY


INSTALLATION




Snap chalk lines for the north and east or west edges per plan.


Place the North end of the first *End-of-Row Support* along your chalk lines in either the North-East or North-West corner of the array. The *End-of-Row Support* has an extra 1/4-20 stud for the *WEEBL-6.7 lug* as shown in diagram 2A.






Add (I) *Mid Row Support* using (2) *Center Braces* to establish the spacing between them. Secure the *Center Braces* using (4) of the provided *10-32 Stainless Steel KEPS nuts*; torque nuts to 28 in-lbs. Continue the row by adding another *Mid Row Support*, (2) *Center Braces* and (4) nuts. Repeat until only one more support is required to finish the row, that last support will be an *End-of-Row Support*. If there is a break in the row, use an *End-of-Row Support* on both sides of the opening.






4


Add ballast into the *End-of-Row Supports* and the *Mid Row Supports* as required. Ballast to be placed inside the supports as shown in diagram 4A.





Begin building the next row south, as in steps 2 through 4, using the *Row-to-Row Spacer* as required establishing the location of the row. Number and location of spacers determined by engineering drawing. Attach each *Row-to-Row Spacer* using two of the *10-32 x 1/2 Stainless Steel Hex Cap Screw* tightening each to 28 in•lbs of torque.








At the end of every row and at breaks within a row, install a *WEEBL-6.7 lug* with the stainless flat washer, split lock washer and nut provided with *WEEBL-6.7 lug* as shown in the figure 6A. Torque *¼-20 nut* to 10 ft•lbs. Run a copper equipment grounding conductor to each lug from row to row and between *End-of-Row Supports* at breaks in rows and torque bolt to 7 ft•lbs.

IMPORTANT: WEEBL 6.7 rated for one 14 AWG to 6 AWG or two 10 AWG, two 12 AWG.


NOTE: Equipment grounding conductor size and quantity must be based on local and National Electrical Codes (NEC). Article 690, 250.





Place the *End Grounding Clips* on the threaded studs located on the *End-of-Row Supports*. Make sure the clips are oriented like shown in diagram 7A for proper grounding of the solar panel to the rack.


NOTE: The End Grounding Clips are sharp, handle with care to avoid injury.






Place the *Mid Grounding Clips* on the threaded studs located on the *Mid Row Supports*. Make sure the clips are oriented like shown in diagram 8A for proper grounding of the solar panel.

NOTE: The Mid Grounding Clips are sharp, handle with care to avoid injury.




9

Install solar panels on to the racking system making sure that the sharp upward pointing teeth of the *End Grounding Clip* and the *Mid Grounding Clip* are under the edge of the panel.




10

After installing the solar panels, place the *End Clamp* on the *End Grounding Clip* located on the *End-of-Row Support*. Add the *5/16-18 Stainless Steel KEPS Nuts* and tighten to 13 ft-lbs.




11

After installing the *End Clamps*, place (2) of the *Mid Clamps* on the 5/16-18 studs located on the *Mid Row Supports*. Add the *5/16-18 Stainless Steel KEPS Nut* and tighten to 13 ft•lbs. Repeat step 10 at end of row.



12

Add the *Deflector* and (4) *10-32 Stainless Steel KEPS Nuts* to all modules. Torque nuts to 28 in•lbs.



SAFETY INFORMATION

NOTICE

- Solar Mounting Solutions ballasted flat roof PV racking system is designed to be used with PV modules that have been certified and listed to UL 1703.
- A minimum of one ballast block per support is required, unless instructed otherwise by engineering layout.
- Stainless steel can seize. Apply anti-seize compound, avoid spinning on at a high rate of speed, and keep hardware out of the sun before installation.
- NOTE: The End Grounding Clips and Mid Grounding Clips are sharp, handle with care to avoid injury.

FIRE SAFETY

- This assembly is to be mounted over a fire resistant roof covering rated for the application.
- Consult your local authority for guidelines and requirements for building or structural fire safety.
- Roof constructions and installations may affect fire safety of a building: improper installation may create hazards in the event of a fire.

GROUNDING

• For grounding and bonding requirements of completed system please refer to regional and national safety and electricity standards.