

For each issue, follow the steps in order. If the issue is not resolved after completing all steps, inform the customer that a human agent will follow up within 24 hours. Do not improvise beyond the steps listed.

Laptops — TechCare Pro X15

Device Will Not Turn On

1. Hold the power button for 10 seconds to perform a hard reset.
2. Connect the charging cable and confirm the charging indicator light comes on.
3. Try a different power outlet or USB-C charging cable.
4. If the device still does not turn on after 15 minutes of charging, the battery may need replacement. Advise the customer to contact support for a repair or replacement assessment.

Screen Is Black or Unresponsive

1. Hold the power button and volume-down button simultaneously for 10 seconds.
2. Wait 30 seconds, then press the power button once to restart.
3. If the screen remains black but the device appears on, connect to an external monitor using the HDMI port to check if the display hardware is at fault.
4. If none of these steps resolve the issue, advise the customer that a hardware fault may be present and a technician assessment is required.

Wi-Fi Not Connecting

1. Toggle Wi-Fi off and on in system settings.
2. Forget the network and reconnect by entering the password again.
3. Restart the laptop and attempt to reconnect.
4. Check whether other devices on the same network are connecting successfully. If not, the issue is likely with the router, not the device.
5. If only this device cannot connect, reset network settings by going to Settings > Network > Reset Network Configuration.

Laptop Running Slowly

1. Restart the device.
2. Check that available storage is above 10% of total capacity. Low storage causes significant slowdowns.
3. Close unused applications running in the background.
4. Check for and install any pending software updates.
5. If the issue persists after updates, a factory reset may be required. Advise the customer to back up their data first.

Tablets — TechCare Tab Pro 12

Device Will Not Turn On

1. Hold the power button for 10 seconds.
2. Connect the charging cable. The tablet requires at least 5 minutes of charge before it can power on from a fully depleted battery.

3. Try a different USB-C cable or charger.
4. If still unresponsive after 20 minutes of charging, the battery may be faulty. Advise the customer to contact support.

Touchscreen Not Responding

1. Restart the device by holding the power button for 10 seconds.
2. Ensure the screen is clean and dry. Moisture or dirt can interfere with touch sensitivity.
3. Remove any screen protector temporarily to check if it is interfering with the display.
4. Go to Settings > Display > Touch Sensitivity and ensure it is set to Standard or High.
5. If the screen remains unresponsive in specific areas, a hardware fault is likely. Advise the customer to contact support for a replacement assessment.

Apps Crashing or Freezing

1. Close the affected app completely and reopen it.
2. Check for app updates in the TechCare App Store.
3. Clear the app cache by going to Settings > Apps > [App Name] > Clear Cache.
4. If the issue affects multiple apps, restart the device.
5. If the problem continues, a factory reset may be required after backing up data.

Wireless Accessories — TechCare Wireless Buds Pro

Buds Not Pairing with Device

1. Ensure the buds are in their charging case for 10 seconds, then remove them. This resets the pairing mode.
2. On the customer's phone or device, go to Bluetooth settings and delete any existing TechCare Buds entries.
3. Open the charging case lid. The buds should automatically enter pairing mode — the LED will flash white.
4. Select TechCare Wireless Buds Pro from the Bluetooth device list.
5. If pairing still fails, reset the buds by holding the button inside the case for 10 seconds until the LED flashes red then white.

No Audio or Low Volume

1. Check the volume on the connected device is turned up.
2. Clean the ear tips gently — debris can block the speaker mesh and reduce audio quality.
3. Disconnect and reconnect the buds via Bluetooth.
4. If one bud has no audio, place both back in the case for 30 seconds, then re-pair.
5. Check the TechCare app (if installed) for audio balance settings.

Buds Not Charging

1. Clean the charging contacts on both the buds and the case with a dry cotton bud.
2. Ensure the charging case itself has charge — connect it to a power source and check the LED indicator.
3. Try a different USB-C cable for charging the case.
4. If the case charges but the buds do not, the buds may have a hardware fault. Advise the customer to contact support.

Wireless Accessories — TechCare SmartWatch S3

Watch Will Not Turn On

1. Place the watch on its magnetic charging dock for at least 10 minutes.
2. Confirm the charging dock LED is green, indicating the watch is receiving charge.
3. Press and hold the side button for 10 seconds.
4. If the watch still does not respond, try a different power adapter for the charging dock.
5. If none of these steps work, the battery may need replacement. Advise the customer to contact support.

Watch Not Syncing with Phone

1. Ensure Bluetooth is enabled on the customer's phone.
2. Open the TechCare Watch app and check that the watch is listed as connected.
3. Force-close the app, reopen it, and attempt to sync again.
4. If the watch is not appearing in the app, remove the watch from Bluetooth settings on the phone and re-pair it by holding the watch side button for 5 seconds.
5. Ensure both the phone and the watch have the latest software updates installed.

Notifications Not Appearing on Watch

1. In the TechCare Watch app, go to Notifications > Manage and confirm the relevant apps are toggled on.
2. Check the phone's notification settings to ensure the apps have permission to send notifications.
3. Disable Do Not Disturb mode on both the phone and the watch.
4. Restart both the watch and the phone.

Home Accessories — TechCare SmartHub 4K

SmartHub Not Connecting to Wi-Fi

1. Ensure the router is working and other devices can connect to it.
2. Confirm the customer is using a 2.4GHz network — the SmartHub 4K does not support 5GHz.
3. Press the reset button on the back of the hub for 5 seconds until the LED flashes.
4. Open the TechCare Home app and follow the setup process again to reconnect.
5. If the hub still cannot connect, try moving it closer to the router during setup.

SmartHub Not Responding to Voice Commands

1. Check that the microphone is not muted — the LED ring will be red when muted. Press the mute button to unmute.
2. Ensure the hub is connected to the internet by checking the app.
3. Restart the hub by unplugging it for 10 seconds and plugging it back in.
4. Check for firmware updates in the TechCare Home app under Device Settings.

General Guidance for All Products

- If a customer's issue is not listed above, inform them that a human agent will follow up within 24 hours and take note of their contact details.
- Do not attempt to diagnose hardware faults beyond the steps listed. If steps are exhausted, escalate.
- Warranty queries, returns, and replacement requests are handled by a different team and are outside the scope of this agent.