

POWER SUPPLY SERVICE

PSU-1200 supplies power to all internal components.

Disconnect all cables from PSU-1200 before removal.

Replacement PSU-1200 units must match the original wattage rating.

STORAGE SERVICE

SSD-1410 is the primary boot drive and contains the operating system.

HDD-1420 is used for bulk storage and does not affect SSD-1410.