



WIND
F75

3 IN 1 HOT-SWAPPABLE
RGB GASKET
MECHANICAL KEYBOARD

English

한국어

Português

Español

Deutsch

Italian

Japan

Русский язык

ประเทศไทย

France

Україна

Indonesia

Türkiye



Function and indicator



① Capslock indicator

② Type-C

③ Toggle switch (left 2.4G wired/
OFF right BT)

④ USB receiver

⑤ Charging indicator

⑥ Multifunctional roller

Stylish design, 80 key layout, Gasket structure, delicate and soft touch.

Keycaps and mechanical switches are pluggable. The users can also purchase various brands of switches and personalized keycaps on the market for free DIY.

The keyboard material is solid and the buttons are responsive.

Two stage tripod with concealed independent storage receiver.

The user-friendly design of the keyboard, combined with the Fn key, adds a series of commonly used shortcut function buttons.

Keyboard return rate: wired mode 1000Hz, 2.4G mode 1000Hz, BT mode 125Hz.

The BT/2.4G/wired mode of the keyboard supports full key and no impact.

Specifications

- Number of keys: 80 keys
- Product size: 322.7 (L)X143.2 (W) x43.1 (H) +1mm
- Product weight:1023g (including wire/receiver)
- Changing voltage/current: DC 5V/≤700mA
- Rated voltage: DC 3.7V
- Battery life: about 17.5 hours (default lighting effect)about 266,5 hours (turn off all lights)
- Battery capacity: 4000mAh
- Charging interface: Type-C
- Computer System Requirements:Windows WIN XP, WIN7,WIN8, WIN10(Driver may be required under Win95 and Win98 systems)

Standard version shortcut key descriptions

(you have to switch to the corresponding mode FN+`~/1/2/3 in the upper left corner to be able to long press on the code)

Fn+	ESC	`~	1	2	3
Combined functions	Restore the default	2.4G	BT 1#	BT 2#	BT 3#
Fn+	Q	W	E	V	Wheel button
Combined functions	Android	Windows	Mac	Light effect switching	Light effect switching
Fn+	TAB	↑	↓	←	→
Combined functions	Colour switching	Brightness+	Brightness-	Speed-	Speed+
Fn+	WIN-L	U	I	O	DEL
Combined functions	Lock WIN	PRTSC	SCRLK	PAUSE	INS
Fn+	END	Left shift			Light effect of indicator
Combined functions	HOME	Light effect of indicator			

FN+Q=Android system (Q button red light flashes for 3s), F area single press function and F area FN combination function.

Key	F1	F2	F3	F4	F5	F6
Single press	Screen Brightness-	Screen Brightness+	conversion window	Return to Desktop	Brightness-	Brightness+
Fn combination	F1	F2	F3	F4	F5	F6
Key	F7	F8	F9	F10	F11	F12
Single press	previous song	Play/Pause	next song	Mute	Volume-	Volume+
Fn combination	F7	F8	F9	F10	F11	F12

FN+W=Windows system (W key red light flashes for 3s), F area single press function and F area FN combination function.

Key	F1	F2	F3	F4	F5	F6
Single press	F1	F2	F3	F4	F5	F6
Fn combination	Home page	Email	conversion window	Open Explorer	Brightness-	Brightness+
Key	F7	F8	F9	F10	F11	F12
Single press	F7	F8	F9	F10	F11	F12
Fn combination	previous	Play/Pause	next song	Mute	Volume-	Volume+

FN+E=Mac system (E button red light flashes for 3s), F zone single press function and F zone FN combination function.

Key	F1	F2	F3	F4	F5	F6
Single press	Screen brightness-	Screen brightness+	conversion window	Return to Desktop	Brightness-	Brightness+
Fn combination	F1	F2	F3	F4	F5	F6
Key	F7	F8	F9	F10	F11	F12
Single press	previous	Play/Pause	next song	Mute	Volume-	Volume+
Fn combination	F7	F8	F9	F10	F11	F12

Operating instructions

2.4G mode: the upper left switch is dialled to 2.4G mode, the cyan light of the '˜ key blinks slowly, and then press FN+‘˜ key for 3 seconds to enter the code pairing state, then plug in the receiver to finish the code pairing, the cyan light of the '˜ key is on for 2s, the 2.4G connection is successful. The factory default has been pairing code.

BT Mode: Top left switch toggle to Bluetooth mode BLE5.0/BLE3.0 (device name AULA-F75 3.0 KB/AULA-F75 5.0 KB), can connect 3 devices:

FN+1=BT 1, the blue indicator light under the key is flashing fast, back to the connection is flashing slowly, the blue light is on for 2s when connected.

FN+2=BT 2, the blue indicator light under the key is fast flashing, back to connect slow flashing, connect to blue light 2s.

FN+3=BT 3, the blue light under the key is flashing fast, back to connect the slow flash, connect the blue light 2s.

Wired mode: Top left switch to centre position = wired mode, white light on "4" button lights up for 2s.

Fn+Esc long press for 3 seconds = Restore default. The original connected BT device save will not be cleared.

Fn+ \=Light effect mode.

Fn+↑=Brightness+ Fn+↓=Brightness- Fn+←=Speed- Fn+→=Speed+.

CAPS indicator flashing when adjusting to maximum speed or brightness.

FN+Q=Android, FN+W=Windows, FN+E=Mac.(In the Winodws system, if switching to Android/MAC system mode, F1-F12 is the multimedia button function)

Fn+Tab=Toggle light effect colour.

Fn+WIN-L=Lock/open left WIN window key (Lock WIN indicator light is always on when locking WIN, under WIN system).

After switching to Mac system, WIN-L/ALT-L position is swapped (without locking WIN).

FN+B=battery level. The red light will turn on when battery is less than 30%. When the battery is low, the light effect will be turned off. If the battery level is greater than 30%, the green light will turn on. (This function is invalid in wired or charging mode)

Multifunctional roller button

Dual mode switching: Long press the button to switch between game/office modes.

Game mode (WIN key&CAPS key, green light flashing 3 times).

Short press the key to switch between 17 light effects.

Rotate the knob clockwise (increase the brightness of the light). When adjusted to maximum brightness, the CAPS indicator light flashes.

Rotate the knob counterclockwise (the brightness of the light decreases). The CAPS indicator light flashes when the minimum brightness is adjusted.

Office mode (WIN key&CAPS key, blue light flashing 3 times)

Short press knob=multimedia function (mute)

Rotate the knob clockwise=multimedia function (volume up)

Rotate the knob counterclockwise=multimedia function (volume decrease)