

RFID Punch Clock System

User Guide



Rares Covaci
Jeremy E Edwards
Jesse Owens
Blake Truong

Introduction

Welcome to the user manual for the RFID/NFC Punch Clock System. This system is designed to provide real-time data logging and remote access capabilities, making it a versatile tool for various business and personal settings.

Getting Started

Before you start using the system, ensure you unpackaged and have the following components:

- RFID Reading Unit
- USB Type B Power Cable
- 5V DC “Wall Wart” Power Converter
- MicroSD Card
- RFID Card

System Setup

1. **RFID Reading Unit:** Connect the power cable into the back of the unit and into the power supply.
2. **SD Card:** Insert the Micro SD card into the rear of the unit above the power cable.
3. **GPS:** Place unit near an external wall or preferably in the window with clear line of sight to the southern sky. Display will read No GPS Fix until acquiring a GPS signal lock.

Operation

1. **Power On:** Power on the system. The LCD should display a welcome message.
2. **Clock In/Out:** To clock in or out, bring your RFID/NFC tag close to the RFID reader. The system will log the time and display a confirmation message on the LCD.
3. **Data Access:** The system logs data in real-time on the SD card. To read the data, remove the SD card and insert into any SD card reader.

Troubleshooting

1. **Why is my system not displaying any information?**

Ensure the unit is plugged in with appropriate USB Type B cable and into the provided 5V power supply.

2. **Why does my unit display no GPS Fix?**

Upon powering up the unit, ensure the unit is placed in a south facing window with clear line of sight to the sky. The GPS will work best if there are no obstructions such as trees

or walls interfering with a GPS signal. The unit should acquire a GPS signal within 15 minutes.

3. **Why is my system not displaying the correct date and time?**

Ensure the unit has acquired a GPS fix to update date and time to the correct values.

4. **Why is my system not reading my card?**

Ensure you are using a compatible RFID card. This system will work with any S50 RFID cards.

5. **Why is my system not writing to my microSD card?**

This unit will only accept microSD cards formatted to the FAT16 or FAT32 filesystem. Ensure your microSD card has a storage capacity greater than 64 MB and is formatted correctly using a personal computer with a microSD reader.

Safety and Maintenance

Ensure the system is kept in a dry and dust-free environment. Regularly check the connections and update the system software as needed.

Conclusion

The RFID/NFC Punch Clock System is a powerful tool that offers a wide range of applications. With proper setup and maintenance, it will serve as a reliable and efficient solution for your needs.

Appendix

Appendix A – Rear Panel of RFID Unit

