TODO add ICSP port
remove matrix reset pin
increase speaker impedance
use +/- speaker pins 1N4001 vcc 8 → +5V VCC (PCINTO/CLKO/ICP1)PB0 PBO(MOSI/DI/SDA/AINO/OCOA/OC1A/AREF/PCINTO) VCC (PCINT1/OC1A)PB1 PB1(MISO/DO/AIN1/OCOB/OC1A/PCINT1) (PCINT2/OC1B/SS)PB2 PB2(SCK/USCK/SCL/TO/INTO/ADC1/PCINT2) PB3(XTAL1/CLKI/OC1B/ADC3/PCINT3) AVCC (PCINT3/OC2A/MOSI)PB3 (PCINT4/MISO)PB4 MISO PB4(XTAL2/CLKO/OC1B/ADC2/PCINT4) (AUDIO ATTINY_RESET GND 4 GND (PCINT5/SCK)PB5 PB5(RESET/dW/ADCO/PCINT5) 20 AREF (PCINT6/XTAL1/TOSC1)PB6 ATTINY85 - S Custom_Library:SOIC - 8_Wide (PCINT7/XTAL2/TOSC2)PB7 (PCINT8/ADC0)PC0 (PCINT9/ADC1)PC1 (PCINT10/ADC2)PC2 (PCINT11/ADC3)PC3 26× (PCINT12/SDA/ADC4)PC4 ×19 (PCINT13/SCL/ADC5)PC5 ADC6 22 ADC7 (PCINT14/RESET)PC6 (PCINT16/RXD)PD0 (PCINT17/TXD)PD1 (PCINT18/INTO)PD2 (PCINT19/OC2B/INT1)PD3 (PCINT20/XCK/TO)PD4 (PCINT21/OCOB/T1)PD5 GND (PCINT22/OCOA/AINO)PD6 (PCINT23/AIN1)PD7 ATMEGA328P-A Custom_Library:TQFP-32 PROGRAMMER Custom_Library:Pin_Header_01x06_Staggered MATRIX Custom_Library:Hirose_DF3A-5P-2DSA H1 BOM PLUG HOUSING H2 BOM PLUG HOUSING Created by Thomas Seary, Nov. 2017 ENTER = blue ENC_B = yellow ENC_A = red Sheet: / DOWN = green RIGHT = gray LEFT = brown File: Tetris_Controller.sch Title: Tetris Controller Date: 2019-12-10 Rev: v1 KiCad E.D.A. kicad (2015-08-26 BZR 6129, Git 2e41367)-product ld: 1/1