

Building Envelope Specification

07 21 00 THERMAL INSULATION

Provide compatible insulation, air barrier, flashing, sealant, and attachment systems that maintain continuous control layers. Confirm substrates are dry, sound, and within manufacturer temperature limits.

- Protect exposed insulation from ultraviolet degradation and weather intrusion.
- Do not bridge drainage paths with sealant or foam.

07 27 00 AIR BARRIERS

Detail continuity at roof edges, window openings, service penetrations, and transitions to retained construction. Use approved transition membrane where dissimilar materials meet.

- Perform adhesion checks on representative substrates before full installation.
- Repair punctures with patches extending beyond the damaged area on all sides.

07 60 00 FLASHING AND SHEET METAL

Fabricate flashings with hemmed edges and positive drainage. Coordinate with roofing, cladding, and door frame interfaces before fabrication release.

- Allow movement without tearing weatherproofing membranes.
- Keep fasteners out of horizontal water collection surfaces where avoidable.

07 92 00 JOINT SEALANTS

Use backer rod sized to control joint geometry and primer where required. Tool sealant to concave profile without voids or bond-breaker contamination.

- Test representative joints after cure for adhesion and continuity.
- Color selection follows approved finish control sample.