

How to Edit Master Settings for the Laser Cutter

- The following directions allow you to save .las files with custom settings. It will also become the initial settings for manual control upon load up so beware.
- Ctrl+P > Setup > More Settings > UCP Settings page should pop up
 - Here you can actually edit the Mode and Color Order
- For some reason, the mode (Vect, Rast, etc) is finicky. You can only change the mode in the master settings. The last modes saved in the master settings become the default in UCP. They CANNOT be changed unless you edit the master settings (as far as I know).
- The order of the colors can be changed in the master settings only. However, once you select a different material or load in a different .las file, it will revert back to the original order (I don't know why).
 - All other settings like speed/power can be adjusted at any time. They are also able to be overridden by selecting a material or loading in a different .las file.

	Can Edit in Manual Control?	Overridden by Material or Load?
Speed/Power/PPI	Yes	Yes
Mode (Rast, Vect)	No	No
Color Order	No	Yes