JP2 open by default. 3xAA: bridge JP2, omit U2 (never both).

#FLG01

#FLG02

JP2

#FLG03

3xAA_BYPASS

J5

U2

D1

1N5819

U2 = HW-553 boost (0.9–5V in, 5V out). Footprint is a PLACEHOLDER until the drawing arrives.

J5 pin1 = BAT+ (big + on silk). Check holder lead polarity before soldering.

Battery sense: 100k/100k divider, 1–3 cells read safely (max 2.4V at GP29).

JP1 default 1–2 bridged: DISP_VCC = VSYS (5V). Cut 1–2, bridge 2–3 for 3V3.

JP1

#FLG04

DS1

U1

RP2040-Zero

Buttons to GND, RP2040 internal pull-ups. J4 expansion header not populated (DNP).

J4

EXPANSION (DNP)

Sheet: /	
File: haven-badge.kicad_sch	
Title:	
Size: A4	Date:
KiCad E.D.A. 10.0.4	**Rev:** Id: 1/1