

CT-200 Controller Manual — Version 1

Document revision: V1.0

1. Installation

The CT-200 controller must be installed on a stable surface with adequate clearance around the ventilation openings. Connect the controller to the approved power supply before connecting external accessories.

For Version 1, leave at least 50 mm of clearance around the ventilation openings.

2. Initial Setup

After power-on, wait for the status indicator to complete its startup sequence. Open the configuration interface and confirm the controller identifier before continuing.

3. Network Configuration

For Version 1, configure the controller with a static IPv4 address before saving the network settings.

4. Safety Checks

Before normal operation, verify that the enclosure is secure, cables are seated correctly, and no warning indicator is active. Do not operate the controller if the power connection or enclosure shows visible damage.

5. Troubleshooting

If the controller does not start, disconnect power, inspect the connections, and retry after confirming the approved supply.

If the status indicator remains in a warning state, record the displayed code and consult the service procedure.