Telematics — user guide

Fleet management platform: live vehicle tracking, trip history, alerts, reports, fuel, driver working time and tachograph. This guide covers the web portal for company users (dispatcher, fleet manager, administrator).

1. Signing in and navigation

Signing in. Open the portal address, enter your **Email** and **Password**, and click **Sign in**. On first sign-in the system asks you to set a new password. If you forgot your password, choose **Reset your password** — a verification code will be sent by email.

The main screen has three parts:

- **Sidebar** (left) — menu split into the *Fleet*, *Insights* and *Admin* groups. The **Collapse** button at the bottom shrinks the sidebar to icons only; next to it is the light/dark mode switch.
- **Search** (top) — type a registration number or a driver's name to jump straight to that vehicle or driver.
- **Alerts bell and user menu** (top right) — unread alerts, **Profile**, **Settings**, **Sign out**.

> The menu items you see depend on your role. If a screen you need is missing, ask your company administrator to extend your role.

2. Fleet — day-to-day work

Screen	Purpose
Dashboard	Live fleet status, mileage over recent days, fuel consumption, latest alerts, expiring documents and the **Needs attention** list (e.g. devices silent for ≥ 24 h).
Live map	Current positions of all vehicles.
Timeline	Replay the history of a single vehicle on a selected day.
Geofencing	Define zones (geofences) used in alerts and reports.
Alerts	Alert inbox and rule configuration.
Routes	Plan truck routes with road tolls and a corridor.
Vehicles / Drivers / Fleets	Records: technical data, driver assignments, grouping vehicles into fleets.
Devices	GPS trackers installed in vehicles.
Tachograph	DDD file archive and remote data download.
Share links	Public vehicle tracking links for customers.

Live map

1. Filter vehicles with the **Search plate…** field or status filters. You can hide non-matching vehicles or just highlight matching ones.
2. Click a vehicle to open its details panel: speed, odometer, last activity, driver working time, fuel level, trailer telemetry.
3. From the panel you can **follow the vehicle** (the map keeps it centred), open its history on the **Timeline**, **Open in Google Maps**, or calculate a **Quick ETA** to a chosen place.
4. The layers button switches the base map and shows extra layers (e.g. geofences, company bases).

Timeline

Select a vehicle and a day. Drag the day scrubber to see the vehicle's position and parameters at that moment, plus alerts near the cursor. If the nearest reading is too old, parameters are hidden so outdated data is not shown as current.

Geofencing

Click **Add geofence**, search for an address or pick a point on the map (anchor), then choose:

- **circle** — enter a radius,
- **custom area** — draw a polygon (up to 100 vertices; double-click or Enter finishes drawing).

Routes

Plan route → select a vehicle, a time window and waypoints, then calculate the route. The map shows the path, corridor, road tolls and the driver's rest plan. On the **Notifications** tab, enable the **Corridor alert** — the system reports when the vehicle leaves the planned route (no separate rule in Alerts needed).

Share links

Create a **New Share Link** for a vehicle or fleet, give it a **Label** and a validity period (max. 30 days). The recipient sees position, speed and last fix time without signing in. A link can be **revoked** at any time.

3. Alerts

The **Alerts** screen has three tabs:

- **Inbox** — event list with filters. Alert details show the event timeline, map location, vehicle, driver, trigger and recovery conditions.
- **Rules** — rules created by your company.
- **System rules** — predefined rules.

Creating a rule: click **Create alert rule** and choose a type:

1. **Telemetry conditions** — e.g. speed, fuel level, temperature; combine conditions with AND/OR.
2. **No GPS signal** — alert after a set time without a report from the device.
3. **Geofence** — entering or leaving a zone.

Set the name and priority, vehicle types and mute period. Instead of filling in the form manually, you can describe the rule in plain language to the **AI Assistant**, which fills in the fields for you. Email recipients for rules are set in **Settings → Notifications**.

4. Insights — reports and fuel

Reports

Choose a report type, a date range and vehicles, drivers or fleets, then run the report. Main types:

Report	Contents
Route on map	GPS track coloured by speed, with stop markers.
Drives, stops and parking	Full day chronology: driving, stop (ignition on), parking (ignition off).
Daily summary / Fleet report	Distance, speed, odometer and fuel — for one vehicle or the whole fleet.
Fleet comparison	Distance, fuel consumption and data coverage across fleets.
Vehicle exploitation	GPS vs CAN distance, fuel, engine hours, RPM.
Driver working time, violations	See section 5.
Geofencing / Alerts	Time spent in zones; number of alerts per vehicle.
Report builder	Custom report built manually or with a natural-language prompt.

Results can be exported (e.g. CSV, PDF). Before exporting, the table can be adjusted in the **Edit before export** window. The **Automatic email delivery** icon schedules the report to run periodically and emails the CSV to you.

Fuel and Transactions

- **Fuel** — daily consumption in litres, average l/100 km, vehicle ranking. Vehicle details show driving segments, a tank level chart (refuels, drops) and fuel card purchases.
- **Transactions** — import of fuel card transactions. Connect a provider account, then assign cards or individual transactions to vehicles.

5. Driver working time

The system calculates working time against EU and Polish limits using DDD files (driver card, vehicle tachograph) and live telematics data. Live values are **estimates** — DDD data is final.

“Working time” panel on the map. Click a vehicle on the **Live map** and open **Working time**. You will see:

- a recommendation: **May drive now**, **Stop required** or **Verification required** (uncertain data),
- **Remaining limits**: time until the 45 min break, daily, weekly and fortnightly driving, deadlines for daily and weekly rest (e.g. “used 6:20 / 9:00”),
- a 14-day **Work chart** (driving, work, availability, rest) with border crossings; select a fragment to read the hours.

Quick ETA warns when the travel time exceeds the driver's available working time.

Reports (on the **Reports** screen):

- **Driver working time timeline** — day-by-day chart with activities, limits, violations (red underline), crew driving, rest places and a forecast for dispatchers. Click a segment for details; drag across the chart to measure time.
- **Driver working time** — totals of driving, work, rest and breaks for multiple drivers.

- **Fleet violations** — list of violations (continuous driving, daily/weekly driving and work time, night work, rests, data gaps) with severity (critical, warning, unverified). A violation can be marked as **Acknowledged** or **Justified**.

Configuration. The driver record must contain a tachograph card number. In **Settings → Driver limits** the administrator sets the night window start, the settlement period and confirms that work outside the vehicle is accounted for (required for a final recommendation).

6. Tachograph

The **Tachograph** screen has tabs:

- **DDD files** — archive of files downloaded from tachographs and driver cards, with period coverage and missing intervals.
- **Downloads** — remote download: click **New DDD download**, select a vehicle and date range. Optionally enter up to 5 email addresses to receive the files. The job status updates live (authenticating → downloading → completed).
- **Settings** — default download intervals for vehicles and fleets, and the driver card download interval (as required by regulations).

7. Administration

- **Users** — inviting users (email with a temporary password), disabling accounts, assigning roles and fleets.
- **Roles** — permission sets (e.g. map view only, reports, administration). A user sees only the screens their role allows.
- **Settings**:
- **Organization** — company name, tax ID (NIP), address;
- **Localization** — time zone, units and currency;
- **Driver limits** — working time settlement parameters (see section 5);
- **Map bases** — named company locations shown on the map;
- **Notifications** — channels and email recipients for alert rules.

8. Troubleshooting

Problem	What to do
Vehicle position is not updating	Check the **Needs attention** list on the Dashboard: the device may have stopped reporting (no power or coverage). Report it to the service team.
No fuel data	The vehicle needs a day with driving and a supported fuel counter; readings older than 24 h are marked as stale.
“No access to this page”	Your role does not include this screen — contact your company administrator.
Forgot password	On the sign-in screen choose **Reset your password**.
Wrong times in reports	Check the time zone in **Settings → Localization**.