
Preconditioning Kit Manual

Electroniq Buttons Boutique*
(Dated: October 12, 2026)

This manual covers basic use and frequently asked questions for the manual preconditioning kit.

I. WHICH CARS CAN USE THIS?

The kit is designed to work on most 2021-2024 Ioniq 5s, 2023-2025 Ioniq 6s, and 2021-2024 EV6s. We have tested on Ioniq 5s from three different markets, as well as one Ioniq 6 and one EV6. Contact us if you're interested in using the kit on a different car. The kit will only work if you have a battery heater. To assess that, please check for the 'Battery Conditioning Mode' menu in 'EV → EV Settings' (see Fig. 1a) on your car's head unit (center screen) (see Fig. 1b).



(a) (b)

Figure 1. (a) How to find the EV settings menu: on the main screen, hit the 'EV' icon; then, in the left-hand menu that appears, hit 'EV Settings'. (b) 'Battery Conditioning Mode' screen.

If you do not have this screen, you should not buy this kit. Please contact a dealership or knowledgeable owners in your country to evaluate whether it is possible to install this feature on your car with additional steps. For US, Canada or Norway, feel free to contact us at support@electroniqbuttons.com and we'll be happy to help you evaluate this with a bit of information about your car.

If instead of 'Battery Conditioning Mode' as shown in Figure 1b, you have 'Winter Mode', your car just needs a firmware update from a dealership. Find the relevant technical service bulletin for your country regarding this update and head to your nearest competent dealership. After completion of this step and confirmation of the 'Battery Conditioning Mode' menu replacing 'Winter Mode', you can buy this kit.

II. BASIC KIT SETUP

Start with the installation guides

A. Which firmware?

Your kit shipped with either our first stable firmware, or our EB 0.1.0, or EB 0.1.13, depending on when it shipped. This manual describes the latest release. Check for a newer version and update it (section III) if you want the features described below.

* support@electroniqbuttons.com

III. FIRMWARE UPDATE

We are rapidly releasing firmware updates, so check https://github.com/L1Z3/wicant-i-precondition/releases/ for the latest and follow these instructions: https://meatpihq.github.io/wican-fw/config/firmware-update/ to update your WiCAN.

A. Which binary is mine?

Every release publishes two builds, and you must use the one that matches your hardware:

1. `wican-fw_obd_...bin` is for the stock WiCAN ("WiCAN original", the WiCAN-OBD-C3). It uses an ESP32-C3 and has one CAN interface, which is all that parallel mode needs.
2. `wican-fw_custom_...bin` is for our customized WiCAN (the WiCAN-EB-S3). It uses an ESP32-S3 and has two CAN interfaces, and is capable of man-in-the-middle mode. The hardware is capable of CAN-FD, but firmware support isn't released yet.

The release notes label these two assets "WiCAN original" and "custom WiCAN". Flashing will error out if you try to flash the wrong one, and you can try again. Beta kits ship with a stock WiCAN and therefore take the `_obd_` build.

B. Before you update

Two cautions that come with the release instructions:

1. If MQTT is enabled, disable it before uploading the firmware.
2. An update may reset your device configuration. Save a backup first with "System → Download Configuration", so that you can restore your button mapping and modes afterwards.

IV. USER INTERFACE

We are rapidly developing the user interface, so check back here often! This documentation describes the latest beta interface. If there are features here not available on your WiCAN and you want them, update it!

To configure the manual preconditioning behavior, connect to the WiCAN WiFi and visit the WiCAN configuration page at http://192.168.80.1. The third tab, called "Buttons", shown in Figure 2a allows for configuration of the manual preconditioning button and any other custom buttons that are added later.


The first option, "Select Vehicle", tells the WiCAN which car it is in. It defaults to "Auto (not detected yet)" and changes itself once the WiCAN has seen enough CAN traffic to identify the car; you can also set it by hand to "Ioniq 5", "EV6" or "Ioniq 6". This setting only changes how the activation button list below is filtered, not how preconditioning behaves, so set it by hand if the automatic detection has not recognized your car.

The second option, "Preconditioning Mode", selects how preconditioning is managed after it is requested:

1. "Once" (default): after triggering a single preconditioning cycle, preconditioning will stop.
2. "Continuous": the BMS will automatically re-heat the battery if the temperature drops again, until the car is powered off.
3. "Persistent": like "Continuous", but the WiCAN remembers that preconditioning is enabled even through car on-off cycles, so it will automatically re-activate whenever you start the car.

The third option, "Preconditioning Activation Button", lets you choose which button triggers preconditioning. The list is filtered down to the buttons that exist on the selected car:

1. Disabled
2. Star Button (Steering Wheel) – Default
3. Star Button (Ioniq 5/6 Climate Bar)



(a)

Figure 2. Screenshot of "Buttons" page in WiCAN http configuration.

4. Tuner Press (Ioniq 5/6 Climate Bar)
5. Volume Press (Ioniq 5/6 Climate Bar)
6. Setup (EV6 Climate Bar)

More options are available with the customized WiCAN in man-in-the-middle mode. With "Disabled", no button will trigger preconditioning. This may be desirable when taking your car into a dealership for service to avoid confusing dealership service technicians. The "press" options refer to pressing in those buttons, as opposed to turning or pushing up or down. If none of these options work, you can check the "Show extra button options" checkbox to enable the less common buttons, and "Show buttons for all vehicles" to ignore the car filter. If the button you have selected is not one that exists on the car the WiCAN thinks it is in, a warning appears below the list; the firmware does not check this for you, and such a button will simply never trigger preconditioning. The additional options are:

a) Mode (Steering Wheel)
b) Speak (Steering Wheel)
c) Call (Steering Wheel)
d) Volume Press (Steering Wheel)
e) Volume Up (Steering Wheel)
f) Volume Down (Steering Wheel)

g) Skip Up (Steering Wheel)
h) Skip Down (Steering Wheel)
i) OK (Ioniq 5/EV6 Steering Wheel)
j) Map (Ioniq 5/6 Climate Bar)
k) Nav (Ioniq 5/6 Climate Bar)
l) Media (Ioniq 5/6 Climate Bar)
m) Tuner Up (Ioniq 5/6 Climate Bar)
n) Tuner Down (Ioniq 5/6 Climate Bar)

Pick the button that works for you! We hope to offer physical buttons soon.

The fourth option, "Preconditioning Press Type", lets you choose whether the activation button triggers on a short press or a long press. With "Short Press", preconditioning triggers when you press and release the button within one second. With "Long Press (hold 1s)", you need to hold the button for at least one second; this can help avoid accidental triggering while driving.

The fifth option, "Toggle Preconditioning Remotely", is a button that starts or stops preconditioning from this web page, so you do not have to reach for anything in the car. Its label switches between starting and stopping preconditioning, and the "Status" readings refresh shortly after you press it. You have to be connected to the WiCAN to use it, and, outside "Persistent" mode, preconditioning still ends when the car is powered off.

The sixth option, "Track Popup Text", sets the text that the WiCAN sends to the driver's display when it emulates the track-selection popup, and the "Show Popup" button beside it displays that text in the car immediately as a test. This allows other people in your household to get your attention if you're sitting in your car playing with it. The field is limited to 50 characters.

The seventh option, "CAN Connection Mode", is only shown when the WiCAN is connected to two CAN busses (the customized WiCAN in man-in-the-middle mode). With "MITM (forward between buses)", frames are forwarded between the two busses so the head unit and the rest of the car keep working normally, and preconditioning requests can be intercepted. With "Parallel (no forwarding)", no frames are forwarded. See the harness modes guide for more detail on MITM vs. parallel.

The first tab, "Status", shown in Figure 3a, is a read-only view of what the WiCAN can currently see. It reports the high-voltage battery temperature (minimum and maximum across the battery), which is a convenient way to check whether the conditions for preconditioning are met (see below), together with the battery state of charge, the battery voltage, and whether the car is powered on. "Preconditioning Requested" and "Preconditioning Active" report the state of the preconditioning session, and the "Check status" button refreshes the readings. The temperature can be shown in either °C or °F with the selector beside it; the same choice is used for the messages the WiCAN displays in the car.

To activate preconditioning manually, just press the activation button you've chosen. You should immediately see a countdown in meters/yards on your cluster that hijacks the distance-to-destination indicator. If you have cruise control on, it blocks the most obvious display of the distance-to-destination indicator. Use the pages button on the steering wheel to navigate to the cluster page that shows navigation instructions. Preconditioning starts when this countdown reaches zero. If the countdown resets, that means something unexpected happened and it's retrying.


The WiCAN also reports what it is doing as text messages on the cluster, accompanied by a short beep. If preconditioning cannot start, the message says which of the conditions below blocked it, quoting both the value it read and the limit it has to beat. In "Continuous" or "Persistent" mode it likewise tells you when it is waiting for the state of charge to recover or when it is holding the battery at temperature. If you shift the car into utility mode, preconditioning stops and says so.

When preconditioning activates, you'll see the standard popup saying, 'Battery preconditioning activated for optimal DC charging', shown in Figure 4a. You'll also get a snowflake or red coil icon over the battery symbol in the lower lefthand corner of the cluster, shown in Figure 4b.

If preconditioning never activates, confirm that the built-in conditions for activation are met:

1. Battery temperature must be less than 21 C/70 F
2. State of charge must be higher than 20 %
3. 'Battery Conditioning Mode' screen is present in 'EV Settings' menu (see section I)
4. The car must not be in utility mode

Unfortunately, these are limits that are built into battery management unit firmware or the hardware of the car that we cannot change with this kit. The WiCAN names the condition that blocked the start in the message it displays on the cluster, so you do not have to guess which one it was.



(a)

Figure 3. Screenshot of the "Status" page in WiCAN http configuration, including the high-voltage battery state of charge and temperature readouts and the preconditioning status. The status fields populate once the WiCAN begins talking to your car.


V. POWER USAGE

This kit runs on your car's 12V bus, which means it can draw from your car's 12V battery. It's worth discussing a few points related to this:

1. How much power does it use?
2. Will it kill the 12V?
3. MITM vs. parallel



(a)



(b)

Figure 4. (a) Screenshot of the pop-up indicating successful activation of battery preconditioning. (b) Example screenshot of the coil icon overlaid on the battery symbol in the lower left corner of the instrument cluster.

A. How much power does it use?

We measured power draw with car off (12.7V) for several microcontrollers in several states. The "normal use" WiCAN tests were performed without any http requests and without a BLE connection via CarScanner or similar. These tests were performed on the selectable CAN harness where no OBD requests are possible to our knowledge at present, so the microcontrollers capable of standard OBD (WiCAN, vLinker MC+) likely used less power than when actively polling OBD parameters on the normal OBD port.

1. WiCAN original running v4.20_eb0.1.1-beta19

1. Normal use: 30 mA
2. http page use: up to 34 mA
3. booting: up to 36 mA
4. CAN monitor: up to 38 mA
5. Sleep: <1 mA

2. WiCAN custom first rev running v4.20_eb0.1.1-beta19

1. Normal MITM use: 40 mA
2. Normal parallel use: 34 mA
3. booting: up to 48 mA

3. WiCAN Pro running v4.50

1. Normal use: 50 mA

4. Comma white panda running last animatronic_panda build

1. Normal use: 32 mA

5. vLinker MC+

1. Normal use (no connection): 15-18 mA
2. CarScanner connected via BLE: 20-25 mA, up to 60mA spikes

B. Will it kill the 12V?

The WiCAN has a power saving mode available, called sleep mode, where almost everything shuts down and it draws very little power. If you are concerned about your 12V, we encourage you to enable this feature, which can be found in the WiCAN interface at http://192.168.80.1 in the tab 'Power Saving'. "Sleep Mode" offers three choices:

1. "Low-Voltage Sleep": the WiCAN sleeps once the 12V battery falls below the "Sleep Voltage" threshold, and wakes when the voltage rises above it again.
2. "Car Power-Aware Sleep": the same voltage threshold, but the WiCAN will not sleep while the car looks like it is on, and wakes as soon as it does. How the WiCAN can tell that the car is on depends on your hardware: only the customized WiCAN has a car-on sense pin; otherwise the WiCAN relies on seeing the car's power-status message on CAN. If neither signal reaches it, this mode behaves like low-voltage sleep. Note also that the WiCAN disables its CAN buses while asleep, so it can no longer see the car wake up; in that state it falls back to waking on the battery voltage crossing the threshold.
3. "Disable": no sleep at all.

"Sleep After" sets how long the condition must hold before the WiCAN actually sleeps. See more documentation here: https://meatpihq.github.io/wican-fw/config/sleep-mode.

Over 7 days with a fresh 60Ah 12V battery, the customized WiCAN's typical power usage, 40 mA, would consume $40\text{mA} * 24\text{hours/day} * 7\text{days} = 6.7Ah$, which is about 10% of the 12V state of charge. Unlocked and off, a 2022 Canadian Preferred AWD Ioniq 5 with no aftermarket loads draws about 1.75 A (1750 mA). After ECUs quiet down 5 minutes after locking the car, the draw is still 0.75 A (750 mA). (The car has a further "sleep" mode after 7 days of inactivity; this draw hasn't been measured here.) So, a customized WiCAN in MITM mode and not in sleep mode increases draw over the first 7 days of inactivity by 5%.

C. MITM vs. Parallel

If the preconditioning kit harness is in MITM mode and your WiCAN goes to sleep, Hyundai/Kia app requests will not go through. A longer-term feature on our task list is to add a partial sleep that will allow CAN forwarding but disable WiFi. If the harness is in MITM mode and you want to use Hyundai/Kia app requests, we recommend setting the sleep-mode voltage threshold low, such as 12.3V (well below the resting voltage of a healthy 12V battery), so that the WiCAN stays awake during normal operation.

VI. FREQUENTLY ASKED QUESTIONS

Q: How do I install it?

A: See the installation guides. If this looks too complicated, ask your nearest teenager or car audio shop for help!

Q: Why does my backup camera, car app, or other center screen feature not work after installation?

A: Check the harness modes guide. If you have a WiCAN original or no device plugged into the OBD port, the harness must be in parallel mode. If you have a customized WiCAN, the harness should be in MITM mode.

Q: Does this make my car easier to steal?

A: Not likely, but the installation is designed to be difficult to see for multiple reasons, including security. We highly recommend changing your WiCAN password.

Q: Will this void my warranty?

A: Check your country's warranty and consumer protection law. In the US, the Magnusson-Moss Warranty Act offers strong consumer protections. Automaker threats about aftermarket parts "voiding warranties" in many cases do not hold up in court. (This is not legal advice.) At the same time, diagnosis of problems by an automotive technician is challenging, and we highly recommend removal of aftermarket parts and accessories that could make diagnosis more complicated. For example, if you are encountering head unit or USB port problems, it is a good idea to de-install this kit before taking your car into a dealership to avoid complications with diagnosis.

Q: What is the recommended configuration of the kit for taking my car into the dealership for basic service?

A: We recommend that you unplug your WiCAN and ensure that your harness is in parallel mode.

Q: What if I want to build this myself?

A: Do it! Everything we've done is open-source. Feel free to use the wiring harness diagram to build something yourself. The connectors are available on AliExpress. However, if you make a contribution to public knowledge in the form of a pull request to the DBC file or something else, rebates are available that will bring the net cost down to competitive-with-DIY pricing with a lot less labor.

Q: Why can't this be a software update?

A: It could be. We have our guesses as to why Hyundai/Kia hasn't included this in a navigation update. If you know how to hack your head unit and have found the CAN interface functions, you are welcome to add a manual preconditioning button to your head unit. However, distribution of hacked firmware is not possible at this time, so an aftermarket "update" would be difficult to make widely available.

Q: Can I implement this on my Comma device?

A: We have tested this and don't believe it works. There appears to be no forwarding of preconditioning messages from the A or E CAN busses the Comma sits on to the M or G busses the BMU sits on.

Q: Will this kill my ICCU?

A: No.

Q: Can I use the built-in navigation while using this kit?

A: With the beta version, this is not possible. This will be fixed with the customized WiCAN.

Q: Will a navigation update affect my ability to use the kit?

A: It's highly unlikely, as the kit doesn't depend on communication with the head unit. A battery management unit update could (for instance, the update that enabled preconditioning retroactively on early Ioniq 5s), but we believe those must be done by dealerships. However, we can't promise with 100% certainty that a navigation update will not affect the functionality of the kit. In the off chance that this does happen, let us know and we will do our best to update logic to restore manual preconditioning functionality.

Q: Why the countdown? Why can't you just start preconditioning immediately upon button press?

A: The battery management unit (the ECU inside the battery that contains the BMS) has a built-in 60-second timeout after the initial preconditioning request. If the request stops before the 60-second timeout passes, preconditioning won't start. So we've tried to make this 60-second wait obvious and clear to the user.

Q: Will you build me a new button?

A: Maybe! Email us at requests@electroniqbuttons.com with your requests.

Q: Your business is called 'Electroniq Buttons Boutique'. Where are the physical buttons?

A: We are working on making physical buttons available. Roy has a tested prototype shown in his Ironiq repository.