

# How to Start Your Aventro Car

Starting your Aventro car is a simple process, but exact procedures may vary slightly depending on the model, fuel type, and technology (conventional, electric, or hybrid). Below is a general step-by-step guide for Aventro Petrol, Diesel, Hybrid, and Electric cars.

---

## For All Aventro Models

### 1. Ensure Safety First

- Sit in the driver's seat and fasten your seatbelt.
  - Ensure the gear lever is in 'P' (Park, for automatic) or 'N' (Neutral, for manual).
  - Press the brake pedal (and the clutch for manual transmission).
- 

## A. Petrol & Diesel Models

### With Standard Key Ignition

#### 1. Insert the Key:

- Insert the car key into the ignition slot (usually on the right of the steering column).

#### 2. Turn the Key:

- Turn the key clockwise to the "ON" position (dashboard lights turn on).
- Continue turning to the "START" position. Release when the engine starts.

### With Push-Button Start

#### 1. Ensure Key Fob is Inside the Car:

- The key fob should be in your pocket or bag within the vehicle.

#### 2. Press the Start/Stop Button:

- Press and hold the brake pedal.
  - Press the "Start/Stop" button. The engine will start.
- 

## B. Electric Models

### 1. Key Fob Present

- Ensure the key fob is inside the vehicle.

### 2. Press Brake Pedal

- Firmly press and hold the brake pedal.

- 3. Press Start Button**
  - Press the “Start/Stop” button. Indicator lights and systems will activate.
- 4. Ready Indicator**
  - Wait for the ‘READY’ signal/light on the dashboard. The car is now ready to drive silently.

---

## C. Hybrid Models

- 1. Key Fob Present**
  - Make sure the key fob is with you, inside the car.
- 2. Press Brake Pedal**
  - Press and hold the brake pedal.
- 3. Press Start Button**
  - Press the “Start/Stop” button.
  - The car may start silently in EV mode or with a slight engine sound in engine mode. Watch for ‘READY’ signal on the dashboard.

---

## Additional Tips

- For all models, ensure all warning lights turn off after starting.
  - Do not press the accelerator while starting.
  - For electric/hybrid, if ‘READY’ does not appear, try restarting.
- 

If you’re unsure or the car doesn’t start, refer to your Aventro user manual or contact the nearest Aventro Service Center.

---