
## **OPC 40082-2 Instance for umati Demonstrator**

The namespace for the instances is manufacturer specific, e.g. http://samplemanufacturer.org/umati opc40082-2 sample instance/

Table 2 shows the complete structure of the instance needed for the umati demonstrator. The demonstrator requires, that all mandatory elements of the *HRD\_InterfaceType* are existent, even if there are not displayed in the dashboard. If the value of a variable a not displayed, is can be filled with a static dummy value (e.g. empty string). All displayed values are highlighted in **light-blue**.

Important: In OPC 40082-2 it is defined, that the instance of the *HRD\_InterfaceType* is located under the Object *DeviceSet*. For umati it is necessary to add it under the Machines folder defined by OPC UA for machinery. In practice it is not necessary to create a new instance. It is sufficient to have an *Organizes Reference* from the *Machines* folder to the instance located under DeviceSet



In addition, OPC 40082-2 uses the *MachineInformationType* defined in OPC 40083. For participation in the umati demonstrator it is necessary to create in parallel an instance of the *MachineIdentificationType* defined in OPC UA for Machinery.

Table 1 – Namespaces used in this document

NamespaceURI	Namespace Index	Example
http://opcfoundation.org/UA/	0	0:NodeVersion
http://opcfoundation.org/UA/PlasticsRubber/HotRunner/	1	Default namespace of OPC 40082-2 → no prefix used, e.g. HRD_InterfaceType
http://opcfoundation.org/UA/DI/	2	2:DeviceClass
http://opcfoundation.org/UA/PlasticsRubber/GeneralTypes/	3	3:MachineInformationType
http://opcfoundation.org/UA/Machinery	4	4:MachineIdentificationType

Table 2 - Sample instance of HRD\_InterfaceType

BrowseName	Туре	Example Value	Remarks
Objects			
→ Machines			
→ HRD_ <manufacturer>_<serialnumber></serialnumber></manufacturer>	HRD_InterfaceType		
→ 2:Identification	4:MachineIdentificationType		1)
<ul> <li>2:ProductInstanceUri</li> </ul>		"http://samplemanufacturer.com/ HRD1234"	2)
<ul><li>2:Manufacturer</li></ul>	0:LocalizedText	"Sample Manufacturer"	
<ul><li>2:Model</li></ul>	0:LocalizedText	"HRD 3000"	3)
<ul><li>2:SerialNumber</li></ul>	0:String	"1234"	
<ul><li>2:DeviceClass</li></ul>	0:String	"Hot Runner Device"	
<ul><li>4:Location</li></ul>	0:String	"K 14 F42/N 51.260407 E 6.744588"	3), 4)
→ Identification	3:IdentificationType		
<ul><li>2:DeviceClass</li></ul>	0:String	"Hot Runner Device"	
<ul> <li>2:Manufacturer</li> </ul>	0:LocalizedText	"Sample Manufacturer"	
<ul><li>2:Model</li></ul>	0:LocalizedText	"HRD 3000"	
<ul><li>2:SerialNumber</li></ul>	0:String	"1234"	
	3:MachineConfigurationType		2)
- 3:UserMachineName	0:String	"My HRD"	2)
<ul><li>3:LocationName</li></ul>	0:String	"K 14 F42/N 51.260407 E 6.744588"	2)
<ul><li>3:TimeZoneOffset</li></ul>	0:TimeZoneDataType	offset: 0 daylightSavingInOffset: true	2)
→ Operation	OperationType		
- ActiveErrors	3:ClassifiedActiveErrorDataType	empty array / NULL	2)
- ActiveEntris - ActiveSetValues	0:MultiStateValueDiscreteType	0	2)
DeviceMappingNumber	0:UInt32	1	2)
DeviceMappingNumber     EnablePower	0:Boolean	true	2)
HighestAlarmSeverity	0:UInt16	0	2)
ReactionOnDisconnect	0:MultiStateValueDiscreteType	0	2)
SessionNameForReaction     OnDisconnect	0:String	"MySession"	2)
→ Zones	ZonesType		0)
- 0:NodeVersion	0:String	"1"	2)
→ Zone_1	ZoneType		0)
- HighestAlarmSeverity	0:UInt16	0	2)
→ Controller	ControllerType	0 ( 0) 0055 1 005 0015501)	2)
- ActualType	ControllerTypeEnumeration	0 (= CLOSED_LOOP_CONTROL)	2)
- ActualValueActive	0:Boolean	true	2)
- SetValueActive	0:Boolean	true	2)
<ul><li>SetValueType</li></ul>	0:MultiStateValueDiscreteType	0	2)
	3:ControlledParameterType		
<ul><li>ActiveSetValue</li></ul>	0:MultiStateValueDiscreteType	0	2)
<ul><li>ActualValue</li></ul>	0:AnalogItemType → 0:Double	168.4	
– EURange	0:Range	Low: 0 High: 200	
<ul> <li>EngineeringUnits</li> </ul>	0:EUInformation	namespaceUri: "http://www.opcfoundation.org/UA/ units/un/cefact" unitld: 4408652 displayName: "°C" description: "degree Celsius"	

- 1) Not included in OPC 40084-2 HRD\_InterfaceType. To be added in the instance
- This variable is mandatory in the model but will not be displayed in the demonstrator Not mandatory in OPC UA for Machinery but for this model and will be displayed in the demonstrator
- 4) See <a href="https://showcase.umati.org/Dashboard.html#location-of-fair-machine-and-software-icons-on-the-dashboard">https://showcase.umati.org/Dashboard.html#location-of-fair-machine-and-software-icons-on-the-dashboard</a> for rules for filling the location.