Navigation map

VibeWare floppy on cold boot. Then connect, read stats and respond to Codex.

01 Connect

No Wi-Fi profile → Pair Wi-Fi

Scan the device QR in the provisioning app. Cancel opens the installer QR. Failed attempts offer Retry.

Saved Wi-Fi → Reconnect

Cody tries the saved network. If offline, choose Network setup or Later.

Wi-Fi ready → Connect Codex

New link shows a pairing code. Enter it in Codex. A saved link waits for the paired PC.

Manage a saved link

Connections → Connect Codex → Keep pairing, Pair again or Forget. Forget asks for confirmation.

Connected or Later → Dashboard

Later keeps the saved association.

02 Dashboard and Options

Left and right cycle enabled pages. Device stays available.

01 **Device**	02 Reset
03 Codex limits	04 Today
05 Last 7 days	06 Token activity
07 Credits	08 Codex account
09 Context	10 About

About right → Scan for more info QR. Left → About.

BOOT short press → Options

Connections	Open Setup
Display	Brightness, auto-rotate, orientation
Behavior	Dictation, shake, sounds, usage
Codex stats	Open first enabled statistics page
Visible screens	Show or hide pages on Cody

Back or Done returns through the current menu.

The outer ring shows valid weekly allowance on awake pages.

03 Notifications and voice

Question → Choose → Review

Send to the recipient. Wait for confirmation before Reply sent. Retry appears when available. Back or Done leaves the event.

Reply ready / Approval needed

Read the reply or make the approval decision in Codex on the PC.

PR and check notices

Read status or open View failures when offered. Back or Done returns.

Device → Record voice

Use Record voice or double-tap the dashboard center. Needs Dictation and a paired LAN link. Tap Send or Cancel while listening.

Authenticated diagnostics show system status. Done returns to the prior route.

PWR and standby

Short press toggles standby and wake. Hold for three seconds to request power off.

Authenticated event wake

New events wake ordinary standby. Sounds and quiet hours govern cues. Offline standby wakes manually.

Lateral arrows

Arrows fade after 10 s idle. Touch or shake reveals them. Shake returns to Reset or the first enabled statistics page.