TAXI

ENGINGE START	
Strobes ("NAV LTS")	
Avionic (Toggle Switches) XPDR, Horizon, Master Radio: 3x ON Transponder on device to STBY/GND	
Altimeter	
. g	

HeadlightsON
Engine Rev IDLE
Release parking brake and brake manually.
Perform brake check on first movement!
Taxi always with walking pace and ONLY
according to required clearances!

BEFORE TAKE-OFF
Parking brake
until oil temp. min. 50°C. Run-up Check

TAKE-OFF / DEPARTURE
For Line-Up: Headlights

CRUISE	
Flaps	
Powersetting: Normal Cruise: 4750 to 5000 RPM	
Normal Cruise: 4750 to 5000 RPM Fast Cruise: up to max. 5300 RPM	
CAUTION: High fuel consumption from 5000 RPM on! Check engine instruments regularly	

SHUT-DOWN	
At Parkingposition:	
ThrottleIDLE	
Parking Brake SET	
HeadlightsOFF	
XPDR, Radio, Horizon OFF	
TrimNEUTRAL	
Ignition (via key)OFF	
After Engine has STOPPED:	
Strobes ("NAV LTS")OFF	
FlapsFULLY EXTENDED	
Step-on protection! Check first, then:	
MASTER OFF	
Life-saving Eq. (Chute) SECURED	
Ignition keyREMOVED	
Put key into middle compartment.	
When getting out:	
ALL Flip-Switches 0FF!	
Parking Brake AS REQUIRED	
Will the A/C be moved?	
Parking Brake: released	
Parking over night? Outside?	
Parking Brake: SET	
Controls: SECURED	
(Arrest stick w/ Harness!)	
Wheel Chocks?	
A/C tied down?	
A/C covered? (Tarpaulin)	
·	