Heathkit SB-110 / SB-110A 6 m Transceiver — Restoration Plan

Rev. 2 — checked against the original Heath SB-110A manual

October 2026

Contents

1. Source documents **2**

2. Transceiver at a glance **2**
2.1 Specifications (manual pp. 121–125) . . . 2
2.2 Power requirements and the supply (pp. 86–87, 109, 123) . . . 3
2.2.1 HP-23A supply (checked against the HP-23A manual, 595-924-01, ©1968) . . . 4
2.2.2 PS-23 supply (checked against the PS-23 manual, 595-2314, ©1979) . . . 7
2.3 Tube and semiconductor complement (pp. 124–125, circuit description) . . . 9
2.4 Frequency scheme (p. 127, Figs. 2-11, 2-18) . . . 10
2.5 SB-110 vs. SB-110A . . . 10

3. What fails, ranked **10**
3.1 Service bulletin SB-110-1 (Nov 3, 1969) . . . 10
3.2 Capacitors . . . 11
3.3 Resistors . . . 12
3.4 Tubes, by risk . . . 12
3.5 LMO . . . 13
3.6 Relays: the manual differs from family practice . . . 13
3.7 Mechanical and grounding . . . 13

4. Restoration plan **13**
4.1 Phase 0: Assess cold . . . 13
4.2 Phase 1: Supply . . . 14
4.3 Phase 2: Clean . . . 14
4.4 Phase 3: Recap and resistor survey . . . 14
4.5 Phase 4: Initial test (p. 88) . . . 14
4.6 Phase 5: Alignment (manual pp. 89–94) . . . 15
4.7 Phase 6: Operating setup (pp. 105–108) . . . 17

5. Troubleshooting quick reference (chart pp. 111–120) **17**

6. Special crystals (pp. 95–96) **18**

7. Tips and tricks **18**

8. Maintenance schedule **19**

9. Parts sources **19**

10. Sources **19**

11. Rev. 2 change log (manual review) **19**

Safety (manual p. 88). “Lethal voltages are present both above and below the chassis.” The finals run at about +700 V DC (the HP-23A’s HV pin is marked +820 V unloaded). Heath says to connect a lead from a good earth ground to the ground bolt on the rear of the chassis, and to all test equipment. Use well-insulated tools. Short the hot end of every supply filter capacitor to chassis before working inside (p. 110). Transmit only into a **50 Ω non-reactive dummy load rated for 100 W; Heath says do not use light bulbs** (p. 89). **Never operate without an 8 Ω speaker or headphones connected** (p. 88).

About the sources. Rev. 2 is checked against **Heath manual 595-1145-01, *Assembly Manual, 6-Meter SSB Transceiver Model SB-110A*** (©1966, printed 4-17-70). Page numbers are the manual’s **printed** page numbers. Items still marked **[family]** are SB-line practice the manual does not cover.

1. Source documents

Document	Use
Heath SB-110A Assembly Manual 595-1145-01 (archive.org K6KJN; ManualsLib #895692; Dan’s scan)	Primary reference: parts lists (pp. 3–4, 18–21), preliminary checks and resistance chart (pp. 81–84), power supply connections (pp. 86–87), initial test (p. 88), alignment (pp. 89–94), special crystals (pp. 95–96), operation (pp. 105–109), troubleshooting (pp. 110–120), specifications (pp. 121–125), circuit description (pp. 127–146), voltage and resistance charts (Figs. 1-13, 1-14), replacement parts list (p. 151+).
SB-110 service bulletin **SB-110-1** (Nov 1969), Heath list (Mar 1998)	The only SB-110 bulletin on record.
Heath list SB-110/110A threads (1997–2012)	Model identification, field symptoms.
SB-100/101/102 and HW-101 bulletins; W5RKL SB-10x guide	**[family]** practice where the manual is silent.
HP-23A AC Power Supply assembly manual 595-924-01 (©1968), owner-supplied	HP-23A section checked against it (Rev. 2.2, §2.2.1).
PS-23 AC Power Supply manual 595-2314 (©1979), owner-supplied	Supply section checked against it (Rev. 2.1, §2.2.2).

2. Transceiver at a glance

2.1 Specifications (manual pp. 121–125)

Item	Value
Coverage	**49.5–54.0 MHz in 500 kHz segments; 50.0–52.0 MHz with the supplied crystals**
Sensitivity	**0.1 µV for 10 dB (S+N)/N**
Selectivity	2.1 kHz at −6 dB, 5 kHz max at −60 dB
Image / IF rejection	50 dB or better

Item	Value
Spurious	All below 0.1 µV equivalent, except 51.250 MHz (below 0.3 µV)
AGC	Audio varies < 12 dB for 50 dB input change (0.5–150 µV)
Audio	1 W; 8 Ω speaker; 600 Ω+ headphones
Input power	180 W PEP SSB; 150 W CW
Output power	**100 W PEP SSB; 90 W CW** (into 50 Ω non-reactive)
Carrier / unwanted sideband suppression	55 dB / 55 dB (at 1000 Hz and above)
Distortion products	30 dB below rated PEP
ALC	10 dB or better at 30 µA of final grid current
CW sidetone	About 800 Hz, internally switched to the speaker
Keying	Grid-block; VOX operated from the keyed tone
Stability	< 100 Hz/hr after 20 min warm-up; < 100 Hz for ±10% supply change
Dial accuracy	**Within 400 Hz on all segments after calibrating at the nearest 100 kHz point**; visual within 200 Hz; backlash ≤ 50 Hz
IFs	8.395–8.895 MHz (receiver 1st IF / transmitter 2nd IF); 3.395 MHz (receiver 2nd IF / transmitter 1st IF)
Size / weight	14-7/8 × 6-5/8 × 13-3/8 in.; 17 lb

Rev. 1 quoted "0.1 µV for 15 dB" and "noise figure ≤ 3 dB" from secondary sources. Neither appears in the manual.

2.2 Power requirements and the supply (pp. 86–87, 109, 123)

Rail	Requirement	11-pin power plug CC
HV	**+700 V DC @ 250 mA**, 1% max ripple	Pin 4 (HP-23A marked +820 V; HP-13A +800 V)
LV B+	**+250 V DC @ 100 mA**, 0.05% max ripple	Pin 3
Bias	**−115 V DC @ 10 mA**, 0.5% max ripple	Pin 1 (supply delivers about −130 V)
Filaments	**12.6 V AC/DC @ 4.355 A**	Pins 6 (hot), 2 (ground)
Ground	—	Pin 7 (B−, C+)
Power switch	Function switch AC loop	Pins 9–10
Linear amp relay	N.O. contacts	Pins 5 and 11

Answer to the Rev. 1 open question. The manual says the HP-23A's low-voltage circuit must be wired with its **alternate connection for the +250 V output** (p. 87; the same caution appears for the HP-13A on p. 86). **Do not use the 300 V setting the HW-101 and SB-102 need.** With the SB-110A's power cable, the HP-23A's own BIAS control is inoperative; bias is set by the transceiver's **BIAS ADJ** (Section K). The HP-23A manual explains why: the cable takes the fixed −130 V from pin 1, and the HP-23A's BIAS ADJUST only feeds pin 11 (§2.2.1). On an HP-23A, "+250 V" means the AC OFF switch **left (275 VDC no-load)**. With the **HP-13A** (mobile), turn the supply's Bias control **fully clockwise** (maximum bias) first (p. 86), then set 50 mA with the transceiver (p. 109).

Mobile warnings (p. 109). Vehicle charging voltage must not exceed **14.5 V**. LV B+ from the supply must not exceed **290 V**. Exceeding either shortens component life and causes inoperative VOX and instability. Troubleshooting items 15E and 35E both point here.

There is **no fuse in the transceiver.** Protection is in the supply: an HP-23A circuit breaker (65-17; rating not printed), a PS-23 2.92 A circuit breaker, or the HP-13A's in-line fuse holder (Fig. 1-3).

2.2.1 HP-23A supply (checked against the HP-23A manual, 595-924-01, ©1968)

Page numbers are the HP-23A manual's printed pages.

How the HP-23A works:

- **The front-panel AC OFF switch is also the B+ selector** (DPDT, 61-12). **Right = 350 VDC** (high tap), **left = 275 VDC** (low tap), **center = OFF** (p. 14). Plate and filament voltages switch together.
  - The field "300/OFF/250" labels are the **loaded** values of the same two taps.
  - With remote switching wired (pins 9–10 to the equipment's switch), the panel switch still selects B+, and the equipment's switch turns the supply on and off.
  - The switch is easy to bump into OFF, or through it to the other tap.
- **Two bias outputs** (pp. 13, 16, 17):
  - **fixed −130 V** (−100 V at 20 mA) on **pin 1**;
  - **adjustable −40 to −80 V** (1 mA max) on **pin 11**, set by BIAS ADJUST R9.

  When the cable is made up, its green wire goes to pin 1 *or* pin 11 (p. 12). These transceivers take the **fixed −130 V on pin 1** and set final bias with their own BIAS control. **That is why the rig manuals call the HP-23A's BIAS control inoperative: R9 only feeds pin 11.**
- **Filaments:** 12.6 VAC @ 5.5 A on **pin 6**, or 6.3 VAC @ 11 A on pin 8. The cable's red wire goes to one or the other (p. 12). These rigs use **pin 6 (12.6 V)**.
- **Primary protection is a circuit breaker** (65-17; the manual doesn't give its rating), not a fuse. Line: 120/240 VAC, 50/60 Hz, 350 W max (p. 16).
- The line cord (89-19) is listed without a conductor count. **[field]** Fit an 18/3 grounded cord.
- The HP-23A manual doesn't name specific transceivers. It says connection instructions come with the Heath equipment (p. 13).

SB-110A: switch LEFT (275 VDC). The SB-110A needs **+250 V @ 100 mA** (p. 123), which is exactly the HP-23A's low tap under load (250 V @ 100 mA). The SB-110A manual (p. 87) calls this the HP-23A's "alternate connection for the +250 V output." In this HP-23A manual printing the low tap is chosen with the **front-panel switch, not by rewiring**, so set it to the **left (275 VDC)** position. **Never use the right (350 VDC) position with the SB-110A.** The HW-101 and SB-102 use that position, and 350 V no-load also exceeds the SB-110A's ≤ 290 V B+ limit (p. 109). If one HP-23A is shared between an SB-110A and an HW-101 or SB-102, label the switch, because the same lever is also the power switch. Make up the cable per **Fig. 1-4**, with **green on pin 1** (fixed −130 V, which covers the −115 V @ 10 mA need) and **red on pin 6** (12.6 V). The SB-110A's own plug table above is the **transceiver end**: its pins 5 and 11 are linear-amp relay contacts, while on the HP-23A's supply-end socket pin 11 is the adjustable bias.

Specifications (p. 16):

Output	No load	Loaded	Ripple / duty
HV (pin 4)	820 V	700 V @ 250 mA (62.5 µF effective)	< 1% @ 250 mA; continuous to 150 mA, 50% @ 300 mA
LV high tap, switch **right** (pin 3)	350 V	300 V @ 150 mA (with 100 mA on HV)	< 0.05%; continuous to 175 mA
LV low tap, switch **left** (pin 3)	275 V	250 V @ 100 mA (with 100 mA on HV)	< 0.05%; continuous to 175 mA

Output	No load	Loaded	Ripple / duty
Fixed bias (pin 1)	−130 V	−100 V @ 20 mA	—
Adjustable bias (pin 11)	−40 to −80 V	1 mA max	—
Filament (pin 6 / pin 8)	—	12.6 VAC @ 5.5 A / 6.3 VAC @ 11 A	—

Supply-end socket pinout (schematic; cable wiring p. 12; Table 1 p. 13):

Pin	Cable wire	Function
1	Green (fixed option)	−130 V fixed bias
2	Black	Filament common
3	Orange	LV +350 V or +275 V (no load), per the switch
4	Yellow	HV +820 V (no load)
5	—	No connection
6	Red (12 V option)	12.6 VAC filament
7	White	Ground
8	Red (6 V option)	6.3 VAC filament
9, 10	Brown, blue	AC switch loop in the equipment. If the equipment can't switch AC, **jumper pins 9–10 at the plug** and leave brown and blue unconnected (p. 12).
11	Green (adjustable option)	−40 to −80 V adjustable bias

Recap list, with the HP-23A manual's values (parts list p. 3; price list p. 19; schematic; circuit description p. 17):

Ref	Manual value (Heath p/n)	Function	Notes
C1, C2	125 µF tab-mount (25-34)	HV full-wave voltage doubler, from about 282 VAC	Replace together. The voltage rating isn't in the parts list; **[field]** use 500 V (the PS-23 rates the same position 500 V), or 150 µF 500 V.
C3, C4	125 µF tab-mount (25-34)	LV half-wave doubler from the 125/95 VAC taps; C4 is also the pi-filter input	Same as C1/C2.
C5	40 µF (25-36)	LV pi-filter output, with choke **L1 6 H** (46-22)	**[field]** 450 V. An open C5 causes a CW tone and relay chatter (HW-101-73).
C6, C7	**20 µF** (25-19)	Bias filter, with R7	**Negative supply: the + lead goes to ground.** Rating not printed; **[field]** 160 V+. *(PS-23 and Latta's field list: 40 µF.)*
R1–R4	100 kΩ 2 W (1-24-2)	HV bleeders / equalizers across C1, C2	Drift high (field: ~150 kΩ).

Ref	Manual value (Heath p/n)	Function	Notes
R5	100 kΩ 2 W	LV bleeder	—
R7	1 kΩ 2 W (1-15-2)	Bias filter series	Chart: no bias → D7, R7, R8 or R9.
R8, R10	10 kΩ 1 W (1-9-1)	Limit the BIAS ADJUST range	*(The PS-23's R8 is a 27 kΩ bias bleeder; the HP-23A has R8/R9/R10 instead.)*
R9	10 kΩ tab-mount control (10-57)	BIAS ADJUST (pin 11 only)	Pin 11 resistance changes with its setting.
D1–D7	Silicon diode (57-27)	D1–D4 HV doubler; D5, D6 LV; D7 bias half-wave	Type not named in the HP-23A manual (field: 1N2071). **[field]** 1N4007.
Breaker	65-17	Primary	Opens on reset → short in the transformer, rectifier/filter or load, or overload.

Initial test (pp. 12–13). Do this **before** the first power-on and before the equipment connector is fitted.

1. Ohmmeter on R × 1: find the lead polarity. About **10 Ω** between terminal strip **J** lugs 3 (−) and 4 (+). Put the correct lead on socket **pin 7**.
2. Switch to R × 10k. Expect:
   - **pin 1 ≥ 22 kΩ**;
   - **pins 3 and 4 ≥ 75 kΩ** (the needle creeps up as the caps charge);
   - **pin 7 = 0 Ω**;
   - **pin 11 = 10–20 kΩ**, varying with BIAS ADJUST;
   - pins 2, 5, 6, 8, 9 and 10 infinite.

Troubleshooting chart (p. 15):

Difficulty	Possible cause
Completely dead	Breaker open, switch, pin 9/10 wiring, the equipment's remote switch, transformer
Breaker opens when reset	Short in transformer windings, rectifier/filter, or the equipment; overload
No HV	D1–D4; pin 4 wiring; transformer
No LV	D5/D6 open; L1 open; pin 3 wiring; switch; diode or filter-cap polarity reversed
No bias	D7 open; R7, R8 or R9 open; pin 1/11 wiring
HV half with no load, lower under load	D1, D2, D3 or D4 open
LV half	D5 or D6 open
All outputs half	Primary wired for 240 V on a 120 V line

Caution (p. 13). The outputs are lethal, and the big capacitors keep their charge.

- Let the bleeders discharge the caps. The manual allows shorting the cap lugs to chassis with a screwdriver blade; a **bleeder stick (resistor to ground)** is gentler.
- Stand on dry insulating material and keep one hand behind your back.
- **Never work on the supply with the line cord plugged in.**
- The manual's voltages are no-load readings with an 11 MΩ VTVM (p. 14).

2.2.2 PS-23 supply (checked against the PS-23 manual, 595-2314, ©1979)

The PS-23 is the later (1979) kit supply in the HP-23 family. Page numbers are the PS-23 manual's printed pages.

How the PS-23 differs from the HP-23/HP-23A:

- **There is no front-panel B+ switch.** The low-voltage tap is chosen by an internal jumper at assembly: **350 VDC wiring** (Detail 5B, p. 10) or **275 VDC wiring** (Detail 5C, p. 11). On the schematic (illustration booklet p. 4) the brown transformer lead feeds 350 VDC and the brown-yellow lead feeds 275 VDC.
- **There is no bias control.** The PS-23 gives a fixed **−130 V** with no load (−100 V at 20 mA); bias is set on the transceiver.
- **A 2.92 A circuit breaker** (65-17) replaces the fuse. Primary current goes through the breaker and through pins 9–10, the AC switch in the equipment (p. 21).
- A **3-wire grounded line cord** is standard; the green wire goes to chassis lug F (p. 13).
- The output cable is a captive 8-wire cable with an 11-pin plug. The connector for the far end comes with the equipment (p. 17).

SB-110A: LV tap. Needs **+250 V @ 100 mA**, so the PS-23 must have the **275 VDC wiring** (Detail 5C: brown wire from strip C lug 2 to capacitor K lug 4). That matches the SB-110A manual's +250 V instruction (p. 87). A PS-23 previously wired for an HW-101 or SB-102 must be **rewired** to 275 VDC first. The SB-110A mobile limit of ≤ 290 V on LV B+ also implies the low tap. Bias: the PS-23's fixed −130 V (−100 V at 20 mA) covers the SB-110A's −115 V @ 10 mA need, and BIAS ADJ in the transceiver sets 50 mA.

Specifications (p. 20):

Output	No load	Loaded	Duty
HV	820 V	700 V @ 250 mA (62.5 µF effective; < 1% ripple)	Continuous to 150 mA; 50% at 300 mA
LV high tap (350 VDC wiring)	350 V	300 V @ 150 mA (with 100 mA on HV)	Continuous to 175 mA
LV low tap (275 VDC wiring)	275 V	250 V @ 100 mA (with 100 mA on HV)	Continuous to 175 mA
Fixed bias	−130 V	−100 V @ 20 mA	—
Filament	—	12.6 VAC @ 5.5 A	—
Line	120/240 VAC, 50/60 Hz, 350 W		

Output pinout (schematic; Table 1, p. 17; Detail 7F, p. 14):

Pin	Cable wire	Function
1	Green	−130 V fixed bias
2	Black	Filament common
3	Orange	LV +350 V or +275 V (no load)
4	Yellow	HV +820 V (no load)
6	Red	12.6 VAC filament
7	White	Ground

Pin	Cable wire	Function
9, 10	Brown, blue	AC switch loop in the equipment. If the equipment has no AC switching, jumper pins 9–10 at the plug and leave brown and blue unconnected (p. 14).
5, 8, 11	—	No connection

Recap list, with the PS-23 manual's values (parts list p. 3; schematic; circuit description p. 21):

Ref	Manual value	Function	Notes
C1, C2	125 µF 500 V (25-265 can)	HV voltage doubler	Replace both together; field practice is 150 µF 500 V.
C3, C4	125 µF 500 V (25-265 can)	LV half-wave doubler; C4 is also the pi-filter input	Same type of can as C1/C2.
C5	40 µF 450 V (25-36)	LV pi-filter output (with choke L1, 6 H)	An open C5 causes a CW tone and relay chatter (HW-101-73).
C6, C7	40 µF 150 V (25-20)	Bias filter	**Negative supply: the + lead goes to the ground lug** (p. 12).
R1–R4	100 kΩ 2 W	HV bleeders / equalizers across C1, C2	Drift high (field: ~150 kΩ); metal film 2 W.
R5	100 kΩ 2 W	LV bleeder	—
R7	1000 Ω 2 W	Bias filter series	Chart: no bias → D7, R7 or R8.
R8	27 kΩ 1 W	Bias bleeder	Field practice uprates to 2 W.
D1–D7	1N2071 (57-27)	D1–D4 HV doubler (two per leg); D5, D6 LV; D7 bias	1N4007 is the usual replacement.
L1	46-56, 6 H	LV filter choke	Chart: no LV → D5/D6, L1.
Breaker	2.92 A (65-17)	Primary protection	Opens on reset → transformer, rectifier/filter or load short.

Initial test (p. 15). Use a VTVM or VOM; a solid-state ohmmeter won't turn the diodes on.

- Find the meter polarity on R × 1 (about 10 Ω between strip H lugs 3 and 4). Put the correct lead on ground and switch to R × 10k.
- Socket readings: **pin 1 ≥ 22 kΩ; pins 3 and 4 ≥ 75 kΩ** (they rise slowly as the caps charge); **pin 7 = 0 Ω**; all others infinite.

Troubleshooting shortcuts (p. 19):

- **HV only half the normal value** → D1–D4 or C1/C2.
- **LV only half** → D5/D6.
- **All outputs half** → primary wired for 240 V on a 120 V line.
- **Dead** → breaker, the pins 9–10 loop, or the equipment's switch.

Caution (p. 17). The outputs are lethal and the large capacitors hold their charge. The manual allows shorting the cap lugs to chassis with a screwdriver blade. A **bleeder stick (resistor to ground)** is gentler on the caps and terminals. Work with one hand, on an insulating surface.

2.3 Tube and semiconductor complement (pp. 124–125, circuit description)

V	Tube	Function
V1	6DS4 nuvistor	Receiver RF amplifier
V2	6DS4 nuvistor	Receiver 1st mixer
V3	6EA8	A: receiver 2nd mixer · B: crystal oscillator (Y6, AUX T / XTAL modes)
V4	6AZ8	A: 1st IF amp (receive **and** transmit) · B: VOX amplifier
V5	6AZ8 **(painted tip, 411-218; must go in V5)**	A: 2nd IF amp · B: VOX relay amplifier
V6	6EB8	A: 2nd audio preamp · B: audio output
V7	6EA8	A: heterodyne crystal oscillator · B: heterodyne oscillator amplifier
V8	12AT7	A: USB carrier generator (Y7) · B: LSB carrier generator (Y8)
V9	6AZ8	A: CW carrier generator (Y9) · B: transmitter isolation amplifier
V10	6EA8	A: microphone amp / 800 Hz CW tone oscillator · B: cathode follower
V11	6EA8	A: 100 kHz crystal calibrator (Y10) · B: transmitter 1st mixer
V12	6CB6	Transmitter 2nd mixer
V13	12BY7	Driver
V14, V15	**6146**	Finals (parallel, class AB1)
V16	0A2	+150 V regulator (must glow violet/orange at turn-on)
V17	**6BZ6**	LMO (inside the LMO; replace only with the same brand)
Q1	2N2712	Receiver 1st audio preamplifier

Diodes (p. 125).

Qty	Type (Heath p/n)	Use
6	1N2079 silicon rectifier (57-29, 750 mA 100 PIV)	VOX (SR52), anti-trip (SR50/SR51), ALC (SR150/SR151), DC blocking
3	GE S187 silicon (56-28)	Noise limiter (SD50/SD51), AGC (SD52)
10	1N191 germanium (56-26)	Balanced modulator (GD220–GD223), product detector (GD200–GD203), AGC (GD50), RF sampling (GD140)

Qty	Type (Heath p/n)	Use
1	1N4166A 15 V zener (56-25)	Cathode reference for relay amp V5B

2.4 Frequency scheme (p. 127, Figs. 2-11, 2-18)

- **LMO** tunes 5.0–5.5 MHz. It is shifted 2.8 kHz between USB and LSB by an internal shifter, so the dial reads the suppressed-carrier frequency in both modes.
- **Heterodyne crystals** (Y1–Y4, chassis, 2 × 2 under a retaining plate):

Segment	Crystal	Position
50.0	41.605 MHz	Y1
50.5	42.105 MHz	Y2
51.0	42.605 MHz	Y3
51.5	43.105 MHz	Y4

- **Carrier crystals: Y7 3393.6 kHz = USB**, **Y8 3396.4 kHz = LSB**, **Y9 3394.4 kHz = CW**. The CW carrier sits 800 Hz above the USB carrier, which allows cross-mode USB/CW contacts.
- **Y10** is the 100 kHz calibrator. **Y6** (receiver RF board, “XTAL FREQ ADJ” trimmer) is the optional fixed-frequency crystal for AUX T/XTAL operation.
- The heterodyne amplifier V7B feeds a stock **half-wave harmonic filter** (C77 22 pF / C78 150 pF, labelled “Harmonic filter” in Fig. 3-8). This is factory, not a mod.

2.5 SB-110 vs. SB-110A

The manual confirms the SB-110A layout:

- **V7** (heterodyne oscillator) is on the **chassis** with its own shield (p. 88).
- **Y1–Y4** sit in **sockets on the chassis under a crystal retaining plate** with a knurled nut (p. 85).
- The **Carrier Generator board 85-152** holds V6, V8, V9 and V10 (Fig. 1-5).

On the earlier **SB-110**, V7 was on the carrier generator board and the four crystals sat in a single row (Heath list, 2003). The SB-110 manual and its numbering may differ from what follows; this plan follows the SB-110A.

3. What fails, ranked

3.1 Service bulletin SB-110-1 (Nov 3, 1969)

Item	Detail
Symptom (SB-110)	Audio oscillation on CW with sidetone fully up; hand-capacitance effects; audio output tube overheats; a 20 µF electrolytic seems intermittent.
Cause	DC from the VOX amp plate reaches the audio output grid through a **3.3 MΩ resistor (R49)**, the sidetone control and a second 3.3 MΩ, putting about +3 V on the grid.

Item	Detail
Fix	Replace R49 with a **500 pF ceramic disc** (21-13).
SB-110A status (manual-verified)	**Already incorporated.** In the SB-110A the sidetone feed from the V4B plate is **capacitor-coupled through C48, 500 pF** (Fig. 2-2), and the SB-110A manual uses different part numbers (there is no R49/C658 in this circuit). **An SB-110A needs no change.** On an early **SB-110**, check for the bulletin fix.

A **hot 6EB8 (V6) or audio oscillation** on an SB-110A therefore points elsewhere. The troubleshooting chart (item 9, p. 112) lists R68 (22 kΩ 2 W) open or wrong, **C67 shorted or installed backwards**, V6, Q1, and relay DE contacts 2–3. Also check that the tube shields are fitted: the manual warns the IF and audio sections **may oscillate without tube shields** (p. 88).

3.2 Capacitors

Electrolytics. The kit has only **five**, all on circuit boards (pp. 4, 151). The chassis list has none.

Ref (from schematic figures)	Value	Where / role	Replace with
C68	**20 µF** (25-135)	Audio output B+ decoupling, with R68 22 kΩ 2 W	22 µF **≥ 350 V**
C63	**100 µF** (25-117)	V6A cathode bypass (with R62 5.6 kΩ)	100 µF ≥ 25 V
C67	10 µF	V6B (audio output) cathode bypass (R67 100 Ω)	10 µF ≥ 50 V; **check polarity** (chart 9D)
C102	10 µF	V10A mic amp cathode bypass (R102 1 kΩ)	10 µF ≥ 50 V
C210	10 µF	Q1 emitter bypass (R215 5.6 kΩ)	10 µF ≥ 25 V

The manual's parts lists give **no voltage ratings**, and they couldn't be read on the scanned schematic. The ratings above are chosen by circuit position; confirm on the board before ordering. *Rev. 1 also told you to replace a "bias-filter electrolytic on the −115 V line." There isn't one in the transceiver; bias filtering is in the supply.*

Other capacitors worth testing:

Part	Why
.1 µF and **.2 µF resin** caps (27-47, 27-34): e.g. C59 VOX delay, C230/C157/C158 AGC and ALC time constants, C106/C108/C109 audio	Leakage or drift changes VOX hold, AGC decay and ALC. Chart items 37 and 40 name C155–C158.
1 pF and 2.2 pF **phenolic** caps (28-2, 28-1)	Same failure mode as in the SB-301 (open, or drifted).
C47, C66 (anti-trip)	Chart item 39D.

Part	Why
C80–C86, C90–C92 (carrier oscillators)	Chart items 28–29: wrong value → no carrier.
C70/C73/C77/C78 (heterodyne oscillator)	Chart item 32F.
.005 µF 1.4 kV discs (21-72)	Line/HV bypass; replace with modern HV-rated parts.

3.3 Resistors

Survey all resistors with one lead lifted; replace any more than 10% out of tolerance. Manual-named suspects:

Ref	Value	Symptom if wrong (chart item)
R160	(+150 V regulator feed)	No, high or low regulated B+ (5–7)
R68	22 kΩ 2 W	No audio (9C)
R42, R43, R44, R52, R53, R54, R230, R231	S-meter bridge	S-meter backwards, inoperative or won't zero (17F)
R40, R41, R42, R43, R230	1st IF	No first-IF output (24F)
R125, R127	10 k / 15 kΩ (bias divider with BIAS ADJ)	Bias won't shift to operating level (19F)
R95–R98, R223, R224	Isolation amp	No output from V9B (25C)
R81–R83 / R91, R92	Carrier oscillators	No carrier injection (28C, 29E)
R190–R192	LMO shift	LMO won't shift with mode (31C)
R51, R232, R233	AGC (5.6 MΩ decay)	Slow recovery after transmit (37B)
R56, R57, R65	Anti-trip	ATG has no effect (39C)
R132 6800 Ω 1 W, **R151** 100 Ω 1 W	Driver and final screen feeds at AU	No driver or final output (21C, 20C)
R140 10 kΩ 2 W; 33 kΩ 2 W (RF board); 22 kΩ 2 W; 2000 Ω 10 W	Power resistors	Heat-stressed; check value and discoloration

3.4 Tubes, by risk

1. **6EB8 (V6):** hot running; audio faults (§3.1).
2. **6146 pair (V14/V15):**
   - The manual specifies the **6146** (411-75) and **does not mention the 6146B**.
   - After replacing the finals, **repeat the neutralizing procedure** (p. 85).
   - **[family]** HW-101 bulletins -18/-49 report RF-choke heating and high-band neutralizing trouble with some 6146Bs. If you fit Bs, neutralize carefully and watch RFC6.
3. **6DS4 nuvistors (V1, V2):** scarce. Install with the heat sinks, wide locating tab into the wide socket opening (p. 85).
4. **6AZ8 (V4, V5, V9):**
   - **V5 must be the painted-tip 6AZ8** (411-218) (p. 85).
   - Replacing V4 or V5 means rechecking S-meter zero and T2/T3 (p. 85).
   - If the T5 null or 50 mA reading can't be obtained, **swap V9 and V4** (p. 92).
5. **6BZ6 LMO tube (V17):** "replace with tube from the same manufacturer" (pp. 110, 117).
6. **0A2 (V16):** must glow at turn-on; if not, switch off (p. 88).

Do not pull tubes or pilot lamps with power applied. With a 12 V supply the filaments are series-parallel, and removing one can destroy others (p. 110).

3.5 LMO

- **Manual:** "At no time should the LMO be opened or the warranty will be voided" (p. 110). If the LMO is proven faulty after the chart 30 checks, Heath said to return the complete unit for replacement (p. 117).
- **[family], restorer practice:** for a jumpy dial or stiff tuning, the TRW-style service applies (rotor-to-frame braid; regrease the worm and anti-backlash gear; open one side only; never rotate the capacitor shaft with the stops loose). Do this only if needed, and expect to recalibrate.
- **Shift problems:** LMO frequency not shifting with mode → R190/R191/R192, MODE wafer MS1R, 30-lug strip segments (chart 31).

3.6 Relays: the manual differs from family practice

> **Manual (p. 110):** clean relay contacts **with a burnishing tool only**. "**DO NOT TRY TO USE PAPER, FINGER NAIL BOARDS OR LIQUID CONTACT CLEANERS.**" Compressed air often removes foreign matter.

This overrides the paper-strip method used on the SB-10x/HW-101. Relay-related chart items:

- 8, 18 (DE contacts 16–18), 9H (2–3), 19B (1–2), 24C (4–5), 40C (4–5).
- 20D (antenna relay contacts 1–2).
- 42 (a short between DE 17–18 makes the plate meter read backwards).

3.7 Mechanical and grounding

- **Instability** (receive item 15, transmit item 36): circuit-board mounting screws loose or **lockwashers missing between board and chassis** (lockwashers go against the foil side; p. 110); preselector or driver tuning-cap hardware loose; neutralization off; supply voltage too high; defective feedthroughs AP–AU.
- Switch wafers: many chart items are reversed leads at MS1R, MS2F, FS1R and BS1R–BS3R. Photograph before any rework.
- **Dial drive** (100-450 assembly): spiral follower, zero-set pulley, drive-shaft bushing. Check that the nylon spiral follower is engaged before calibrating (p. 94).
- Preset positions for every internal control are on p. 82. Use them if a previous owner has "tweaked" the rig.

4. Restoration plan

4.1 Phase 0: Assess cold

- Identify SB-110 vs. SB-110A (§2.5) and note the blue/white ID label (production series, p. 98).
- Photograph everything. Note mods and non-stock tubes. **Check that V5 is the painted-tip 6AZ8.**
- Pull and label tubes (nuvistors with their heat sinks). Test them.
- Check heterodyne crystals Y1–Y4 against §2.4, and any Y6 crystal.
- **Run the manual's resistance checks (pp. 82–84)** with both 6146s removed, at the 11-pin plug CC, using the switch and relay states in the chart. Key readings, ±20%:

Pin	Condition	Expected
1 (bias)	OFF/USB, relay NE	32 kΩ (12–34 kΩ across switch states)
3 (LV)	Relay NE / E	65 kΩ / 18 kΩ
4 (HV)	—	∞ (≈ 6 Ω with a 6146 anode lead shorted to chassis)
6 (FIL)	Pilot lamp socket out / in	~20 Ω / ~10 Ω (meter dependent)
2, 7	—	0
5, 8, 11	—	∞
9–10	OFF / PTT	∞ / 0

- Fig. 1-14 (fold-out) gives the full tube-socket resistance chart.

4.2 Phase 1: Supply

- Recap and test the HP-23A/HP-23, PS-23 or HP-13A.
  - **HP-23A** values are verified (§2.2.1): C1–C4 125 µF; C5 40 µF; **bias C6/C7 20 µF** (reverse polarity); R1–R5 100 kΩ 2 W; R7 1 kΩ 2 W; R8/R10 10 kΩ 1 W with the R9 BIAS ADJUST; D1–D7 silicon (57-27). Voltage ratings aren't printed; use the PS-23's ratings as a guide. Run the HP-23A socket resistance check (pp. 12–13).
  - **PS-23** values are verified (§2.2.2): C1–C4 125 µF 500 V → 150 µF 500 V; C5 40 µF 450 V → 47 µF 450 V; bias C6/C7 40 µF 150 V → 47 µF 160 V+ (reverse polarity); R1–R5 100 kΩ 2 W; R7 1 kΩ 2 W; R8 27 kΩ 1 W; D1–D7 1N2071 → 1N4007; grounded cord (standard on the PS-23).
- **Set the low-voltage section for +250 V** (p. 87). On an HP-23A that means the AC OFF switch **left (275 VDC)**. On a PS-23 it means the **275 VDC wiring** (Detail 5C); rewire it if the supply came from an HW-101 or SB-102.
- Bring it up on a variac with resistive loads.
- Make up the 8-conductor power cable exactly per Fig. 1-4 (HP-23A) or Fig. 1-3 (HP-13A).

4.3 Phase 2: Clean

- Vacuum and brush; use cleaner on swabs.
- DeoxIT the rotary switches and pots (not the relays; §3.6).
- Keep solvents off the dial and meter plastics and the panel lettering.

4.4 Phase 3: Recap and resistor survey

1. Replace the five electrolytics (§3.2), observing polarity.
2. Test or replace the resin caps in the VOX, AGC, ALC and audio circuits; replace the phenolic caps.
3. Resistor survey (§3.3).
4. Burnish relay contacts if dirty (§3.6).
5. Check every board's mounting screws and lockwashers.

4.5 Phase 4: Initial test (p. 88)

1. Set the controls per p. 81 (FUNCTION OFF, MODE USB, OSC MODE LMO, MIC/CW fully CCW, METER PLATE, etc.).
2. Connect the supply, an 8 Ω speaker and an earth ground.
3. FUNCTION → PTT: the pilot lamps light at once and the tubes glow in a few seconds. **V16 (0A2) must glow violet/orange.** Switch off immediately if a relay pulls in or anything overheats.

4. With an 11 MΩ VTVM, check feedthrough **AT ≈ −125 V DC** and **AU ≈ +250 V DC** (Fig. 1-6).
5. Install all tube shields (p. 88; V16 has none).
6. Compare with the **voltage chart, Fig. 1-13** (11 MΩ VTVM, ±10–20%).

4.6 Phase 5: Alignment (manual pp. 89–94)

Equipment: an **11 MΩ VTVM**, a **50 Ω non-reactive 100 W dummy load**, and a receiver that can hear **WWV** (2.5/5/10/15 MHz) or a broadcast station on a multiple of 100 kHz. Lay the chassis on its right side. Put a tape flag on the alignment tool. Fit the **47 Ω load plug** in ANT RF OUT for the receiver steps. **Do not transmit until told to** (p. 89).

Receiver: heterodyne oscillator (Section G).

1. VTVM negative lead to **TP** (the free lead of the 100 kΩ resistor in Section H); range for −1.5 to −3 V. FUNCTION PTT; warm up 1–2 min.
2. Band 50.0: peak **L6**, then turn its slug ¼ turn CCW. Peak **L10** (about **−2 V**).
3. Repeat for 50.5 (**L7** then ¼ CCW; **L11**), 51.0 (**L8**; **L12**) and 51.5 (**L9**; **L13**).
4. The −2 V reading varies slightly with PRESELECTOR. Unusually high or low readings mean trouble (see chart 32).

Receiver: IF and RF (Sections G, H).

1. Band 50.0; VTVM on AC across the speaker. Peak **T3**, then **T2**. Where there are two slug peaks, **use the one nearest the circuit board** (p. 90).
2. Temporarily jumper **4–5** on the foil side of the RF board (85-114-1). This removes B+ from the RF stage for the L2 step.
3. FUNCTION CAL. Set the dial to 50.10 (BAND 50.0, upper dial at 1, circular dial at 0). Rock the dial ±20 kHz: you'll find two signals about 10 kHz apart. Set the dial midway and adjust **CAL ADJ** (Section M) until a signal is heard there.
4. PRESELECTOR at 10 o'clock: peak **L4**, **L3**, **L1**.
5. **L2 (RF neutralizing coil):** adjust for a **minimum** (null) of signal leak-through. Re-peak L4, L3, L1.
6. FUNCTION OFF. Tape over L2's hole. Remove the jumper and install the **33 kΩ 2 W** resistor on the RF board.
7. FUNCTION CAL: re-peak T3, T2, L4, L3, L1.
8. **Do not readjust L2 later.** It can only be set with B+ removed from the RF stage (p. 90).

S-meter (p. 90). FUNCTION PTT.

1. METER PLATE: adjust **S-METER "0" ADJ** (Section M) for zero.
2. METER ALC: adjust **ALC METER ADJ** (Section G) for zero.
3. Repeat until neither position deflects.

Transmitter alignment (pp. 91–93). In the factory sequence the driver and final screen feeds (the **6800 Ω 1 W** and **100 Ω 1 W** resistors at AU) are left unsoldered until neutralizing is done. **To re-neutralize a built unit, temporarily lift those leads exactly as described.**

1. **Driver and mixer coils:**
   - Tack the 6800 Ω lead from AL8 to AU (temporary).
   - VTVM at **AL2**, ≥ −150 V range. PTT: about **−125 V**. TUNE: both relays energize and the reading drops to about 0 V.
   - DRIVER at 10 o'clock; MIC/CW fully CW. Peak **L14, L15, L16**; repeat until no further increase.
   - Peak **T5** (Section J; preset, ≤ ½ turn).
2. **Bias preset:**
   - Move the VTVM to **AT**, MODE LSB, PTT: about **−125 V**. TUNE (BIAS ADJ fully CCW): about **−45 V**.
   - With MIC/CW fully CW, peak L16, L15, L14 again: about **−60 to −70 V**.

- **OSC MODE → AUX T: the reading must drop to about −45 V.** If it doesn't, L14–L16 are tuned to the heterodyne oscillator output instead of the mixer product. Turn all three slugs at least **5 full turns CCW**, return to LMO, and repeat from the start of this group (p. 91).

3. **Final neutralizing (cold):**
   - Remove the 47 Ω load. METER REL PWR; FINAL LOAD fully CW; REL PWR ADJ fully CW.
   - Peak **FINAL** tune (about half scale).
   - Adjust **FINAL NEUT** (Section A, underside; use the trimmer tool made per Fig. 1-6) for a **minimum** meter reading.
   - MIC/CW fully CCW. Adjust **BIAS ADJ** (Section K) for **−50 V** on the VTVM.
4. **Driver neutralizing:**
   - MODE LSB, OFF; disconnect the VTVM.
   - Remove the 6800 Ω lead from AU. Solder the 100 Ω 1 W lead from AF3 to AU **permanently**.
   - PTT, METER PLATE, TUNE: the meter should read **50 mA static plate current**; adjust BIAS ADJ if not.
   - METER REL PWR, MIC/CW fully CW, FINAL LOAD at 50 Ω. Peak FINAL (about 1–2 S-units).
   - Adjust **DRIVER NEUT** (Section L) for a **minimum** meter indication.
   - MIC/CW CCW, MODE LSB, OFF. **Reconnect the 6800 Ω to AU permanently.**
5. **Carrier isolation null (T5):**
   - Connect the 50 Ω, 100 W dummy load to RF OUT.
   - PTT, MIC/CW fully CCW, TUNE. Adjust **T5** for a **null** (≤ ½ turn), then turn the slug **clockwise to the second null and leave it there**.
   - METER PLATE should read **50 mA**. If you can't get the null or 50 mA, **swap V9 and V4**. A tube change means rechecking T2/T3 and the S-meter zero.
6. **Tune-up into the load:**
   - REL PWR METER ADJ mid-range. MIC/CW at 11 o'clock: plate current rises slightly.
   - Peak with **DRIVER** for maximum plate current, keeping it **< 250 mA** with MIC/CW. Dip with **FINAL**.
   - Advance MIC/CW while re-peaking DRIVER and re-dipping until the plate current reads **250 mA**.
   - With a true 50 Ω load, LOADING can stay at its preset. Otherwise: METER REL PWR, set REL PWR ADJ for half scale, then adjust FINAL tune and load for maximum, **never exceeding 250 mA**.
   - MIC/CW fully CCW; MODE USB; REL PWR METER ADJ fully CW.
7. **Carrier null (p. 93):**
   - Ground MIC connector NF lug 2 to energize the relays. METER REL PWR: about 1–2 S-units.
   - Alternate **CARRIER NULL ADJ** and **CARRIER BAL ADJ** (Section J) to a null, until the meter reads 0.
   - For better suppression, listen on an external receiver at **50.1 or 8.5 MHz** with its BFO on. Null in USB, then switch to LSB and compromise with CARRIER NULL ADJ so the carrier is equal on both sidebands.
   - If CARRIER BAL ADJ ends at **minimum capacity**, move it from **position A to B** on the carrier generator board.
   - If CARRIER NULL ADJ ends at an **extreme**, **interchange R220 and R222**.
   - Afterwards recheck the **50 mA** static plate current. Remove the NF lug 2 jumper.
8. **Crystal calibrator (pp. 93–94):**
   - Wrap the external receiver's antenna wire one or two turns around the **orange shielded cable at point 5 on the receiver RF board**.
   - Transceiver AF GAIN fully CCW, FUNCTION CAL. Tune the external receiver to **WWV** (or a broadcast station on a multiple of 100 kHz).
   - Adjust **CAL ADJ** (Section M) for zero beat, best during WWV's unmodulated periods.

Use S-meter pulsation if the receiver has one.
    - Toggle FUNCTION VOX ↔ CAL: the S-meter should stay steady.
    - Precision matters: the 6 m dial uses the **500th harmonic**, so **a 20 Hz error at 100 kHz becomes a 10 kHz dial error at 50 MHz** (p. 94).
    - Spurious 100 kHz signals can appear. Find the real one by its strength, or by the heterodyne-crystal "chirp" when you switch BAND away and back.
9. **LMO shifter (p. 94):**
    - Dial at 50.10, CAL, **LSB**: zero-beat the calibrator and peak PRESELECTOR.
    - Switch to **USB without touching the dial**. Adjust the **LMO FREQUENCY SHIFTER** (top of the LMO) for exact zero beat. Recheck LSB and repeat as needed.
10. **Dial calibration (p. 94):**
    - Zero-beat at 50.10 and center the zero-set line in the window.
    - Remove the tuning knob. Hold the LMO drive shaft with a screwdriver through the escutcheon hole. Loosen the circular-dial setscrew, set **0** under the zero-set line and retighten.
    - Confirm the nylon spiral follower is engaged. Refit the knob.

4.7 Phase 6: Operating setup (pp. 105–108)

- **Every time you tune up** (steps 1–13, p. 106):
    - TUNE should read **50 mA**.
    - MIC/CW to 100–150 mA, dip FINAL; peak DRIVER (≤ 250 mA); advance to **250 mA** loaded; peak REL PWR with LOAD and FINAL.
    - Set MIC/CW **just below saturation**. Going beyond saturation causes a time lag on transmit-to-receive changeover.
    - Re-tune DRIVER, FINAL and LOAD after any big frequency change.
- **SSB:** METER ALC; MIC/CW so voice peaks reach about **S3**, never beyond the top of the ALC (S8) region.
- **VOX / ATG / DELAY** are on the front of the final shield, under the cover. Set VOX just high enough, ATG just high enough to stop the speaker tripping the relays, and DELAY to hold between words.
- **CW:** the transmitted signal is **800 Hz above the dial reading**. Set VOX so the relays close on key-down, DELAY to hold between characters, and SIDETONE LEVEL to taste.
- Most 6 m SSB was USB when the manual was written (p. 105).
- The manual warns not to run voice on 50.0–50.1 MHz, reflecting band rules at the time (p. 106).

5. Troubleshooting quick reference (chart pp. 111–120)

Symptom	First checks (chart item)
No regulated +150 V	V16 0A2, R160, V16 socket wiring (5–7)
No audio	R68, C67, V6, Q1, T4, relay DE 2–3 (9)
Hum only, no signal or noise	RFC1, product detector GD200–203, carrier injection, T3, V5A, noise limiter SD50/51 (12)
Noise but no signal	T2, filter Y5, LMO injection at V3A, V4A, V3A, T1, heterodyne injection at V2, V1/V2 6DS4s, RL2 contacts (13)
Receiver oscillates or birdies	**L2 misaligned**, loose preselector/board hardware, missing lockwashers, bad antenna SWR, supply too high (15)
Sidebands reversed	**Y7/Y8 swapped**, Y9 swapped (16)
S-meter backwards or won't zero	Meter leads, DE 14–15, S/ALC zero, R42–R44, R52–R54, R230/231, V4A/V5A (17)

Symptom	First checks (chart item)
Bias won’t shift on transmit	DE 1–2, R125, R127, BIAS ADJ (19)
No final output	HV missing, RFC6, R151, RL2/AE, bias, V14/V15 (20)
No driver output	RFC4, R132, bias, L14–L16, V13 (21)
No output in USB/LSB only	Balanced modulator GD220–223, RFC2/3, CARRIER BAL/NULL, MIC cabling, V10 (26)
No output in TUNE/CW only	Y9, C90–C92, R91/R92, V9A (28)
LMO won’t shift with mode	R190–R192, MS1R, 30-lug strip (31)
No heterodyne injection	Y1–Y4, oscillator board orientation, BS1R–BS3R, C70/C73/C77/C78, V7 (32)
VOX won’t trip / always tripped	V4B, SR52, zener, ATG; SR50/51, B+ too high (34, 35)
Transmitter unstable	Neutralization, driver-cap hardware, board lockwashers, feedthroughs AP–AU, L14–L16 (36)
Slow receive recovery	MIC/CW too high; R51, R232, R233; RF GAIN/AGC wiring (37)
ALC ineffective	SR150/151, C155–C158, DE 4–5, MS2F, neutralization, L16 (40)
Plate meter backwards, ALC pinned, audio oscillation	**Short between relay DE contacts 17–18** (42)

6. Special crystals (pp. 95–96)

- **Extra 500 kHz segments:**

Segment	Crystal
49.5–50.0 MHz (MARS)	41.105 MHz
52.0–52.5	43.605 MHz
52.5–53.0	44.105 MHz
53.0–53.5	44.605 MHz
53.5–54.0	45.105 MHz

After changing a crystal, realign its heterodyne oscillator and amplifier coils. - **Heterodyne crystal spec:** 3rd overtone, ±0.003%, HC-6/U, 0.050 in. pins on 0.486 in. spacing, CL 23.2 pF, C0 ≤ 5 pF, Rs ≤ 30 Ω, 10 mW drive. - **Fixed-frequency Y6 (AUX T: transmit on Y6, receive on the LMO; XTAL: both on Y6):** fundamental, ±0.01%, HC-6/U, CL 15 pF, C0 ≤ 7 pF, Rs ≤ 25 Ω, 2 mW. - USB: f = (f_MARS − f_het) − 3.3936 MHz. LSB: f = (f_MARS − f_het) − 3.3964 MHz. - Example for 49.980 MHz on the 41.605 crystal: 4.9814 MHz (USB), 4.9786 MHz (LSB). - Trim with XTAL FREQ ADJ. Below 50.0 MHz, Y6 operation is limited to about 25 kHz by the T1/T6 couplers; beyond that, use the 41.105 MHz heterodyne crystal.

7. Tips and tricks

- Spares: 6DS4 ×2 (hardest to find), a 6146 pair, 6EB8, 6EA8, 6AZ8 (plus a painted-tip one for V5), 12BY7, 6BZ6 of the original LMO brand, 0A2, #47 ×2, #53 ×1.
- Never pull tubes or lamps hot (§3.4).
- Keep the internal controls’ preset positions (p. 82) on file.
- Mobile antennas: keep SWR low. Loading is more critical on 6 m mobile antennas (p. 109).

8. Maintenance schedule

Interval	Task
Each session	20–30 min warm-up; calibrator zero-set at the nearest 100 kHz point.
6 months	Exercise switches and pots; S-meter and ALC zero (p. 90).
Yearly	Static plate current (50 mA); carrier null; receive check on the calibrator; inspect relays (burnish only if needed).
2–3 years	Neutralization check (cold method, §4.6); board screws and lockwashers; calibrator vs. WWV.
5 years	Tube test (nuvistors, finals, 6EB8 first); supply voltages (+250 / +700 / −115).
~15–20 years	Re-check the five electrolytics and the supply capacitors.

9. Parts sources

- Mouser / Digi-Key: electrolytics, film caps, resistors.
- HP-23 rebuild kits.
- Nuvistors: specialty tube dealers; test before buying.
- Heathkit-Radios and heathkit (groups.io): SB-110 parts units, crystals, dial parts.

10. Sources

- Heath, *Assembly Manual, 6-Meter SSB Transceiver Model SB-110A*, 595-1145-01 (1966; printed 4-17-70).
- Heath list (puck.nether.net): SB-110 service bulletins (Mar 1998); “SB110 Question to Owners” (Jun 2003); “SB-110 VFO’s” (Apr 2012); “SB-110A Question – 6146Bs” (Feb 2003); SB-110A oscillation (Oct 1997); low drive (Feb 1999).
- Heath, *Heathkit Assembly Manual, AC Power Supply Model HP-23A*, 595-924-01 (©1968).
- Heath, *Heathkit Manual for the AC Power Supply Model PS-23*, 595-2314 (©1979).
- **[family]** HW-101/SB-10x service bulletins; W5RKL SB-10x guide; Latta HP-23 restoration.

11. Rev. 2 change log (manual review)

Item	Rev. 1	Rev. 2 (per manual)
HP-23 B+	Open question: 250 vs. 300 V	**+250 V**: wire the HP-23A low-voltage section for +250 V (p. 87); HP-23A bias control inoperative, BIAS ADJ in the transceiver
Sensitivity / NF	0.1 µV for 15 dB; NF ≤ 3 dB	**0.1 µV for 10 dB (S+N)/N**; no NF spec (p. 121)
Heterodyne crystals	42.105, 42.605, 43.105 and one more MHz	**41.605 / 42.105 / 42.605 / 43.105 MHz** = Y1–Y4 for 50.0–51.5 (Fig. 2-11)

Item	Rev. 1	Rev. 2 (per manual)
Carrier crystals	Listed without sideband	**Y7 3393.6 = USB, Y8 3396.4 = LSB, Y9 3394.4 = CW**
Tube table	Partial, “verify”	Full V1–V17 + Q1 with functions; LMO tube is a **6BZ6 (V17)**; V5 must be the painted-tip 6AZ8
SB-110-1	“Check whether present; replace C658”	**Built into the SB-110A** (C48 500 pF coupling); bulletin applies to early SB-110s only
Electrolytics	“Several 10, 20, 100 µF + bias filter”	**Exactly five** (C63 100, C68 20, C67/C102/C210 10 µF); **no bias-filter electrolytic** in the transceiver; ratings not printed in the manual
Pilot lamps / fuse	#47 and #53	#47 ×2, #53 ×1; **no fuse in the transceiver** (in the supply)
Relay cleaning	Paper strip **[family]**	**Burnishing tool only; no paper or liquid cleaners** (p. 110)
Bias	“About 50 mA idle **[family]**”	**50 mA static plate current** in TUNE (pp. 92, 106, 136); −50 V at the VTVM during alignment
Neutralizing	SB-100-2 alternate method **[family]**	Manual’s cold method: finals and driver neutralized with their screen feeds (100 Ω / 6800 Ω at AU) lifted; repeat after any 6146 change
Alignment	Pending	Full sequence with TP ≈ −2 V, L1–L16, T2/T3/T5, **L2 null with RF B+ removed**, AUX T −45 V check, carrier BAL A/B and R220/R222 swap
Calibrator on 6 m	“Use counter or HF zero beat”	Zero-beat against WWV on an external receiver; 20 Hz error = 10 kHz on the dial
LMO shifter	“Zero beat USB, adjust in LSB”	**Zero beat in LSB, adjust the shifter in USB** (p. 94)
Heterodyne “harmonic filtering”	Possible owner mod	**Stock** half-wave harmonic filter (C77/C78)
Max plate current	—	**250 mA** tune-up limit; MIC/CW just below saturation
Mobile	—	HP-13A bias fully CW; alternator ≤ 14.5 V; LV B+ ≤ 290 V
6146B	List question	Manual specifies 6146 only; no 6146B guidance

Item	Rev. 1	Rev. 2 (per manual)
Supply (Rev. 2.1)	HP-23A only, **[family]** recap	Added the PS-23 section (now §2.2.2), checked against the **PS-23 manual**: **275 VDC internal wiring gives +250 V** for the SB-110A (no switch), fixed −130 V bias, 2.92 A breaker, verified recap table, pinout, initial resistance test, troubleshooting.
Supply (Rev. 2.2)	HP-23A described from the SB-110A manual only; recap from the PS-23 and **[family]**	Added §2.2.1, checked against the **HP-23A manual** (595-924-01). The AC OFF switch is the B+ selector: **left = 275 VDC no-load = 250 V @ 100 mA**, which is the SB-110A's "+250 V"; right = 350 VDC, never used with the SB-110A. In this printing the tap is chosen by switch, not by rewiring. Fixed −130 V bias on pin 1 and adjustable −40 to −80 V on pin 11 (R9), which explains why the HP-23A BIAS control is inoperative. Supply-end pinout (pin 11 = adjustable bias, unlike the SB-110A plug's relay pin). **The HP-23A has a circuit breaker, not a fuse** (Rev. 2 said "HP-23A fuse"). Recap table: **C6/C7 are 20 µF** (40 µF in the PS-23), R8/R10 10 kΩ 1 W. Initial resistance test; troubleshooting chart. Capacitor voltage ratings and the breaker rating are not printed in the HP-23A manual.

Not readable or not in the manual: electrolytic voltage ratings (not in the parts lists, and illegible on the scanned schematic); which socket takes the #53 lamp vs. the #47s; the value of R160.