STOP

Set up Arduino before uploading.

Use a USB-C **data** cable.

01 Install megaTinyCore

Scan the QR for the Boards Manager URL. Install **megaTinyCore** by Spence Konde.

LED LIBRARY INCLUDED

02 Choose these settings

BOARD	ATtiny412/402/212/202 **without Optiboot**
CLOCK	20 MHz internal
BOD VOLTAGE	**4.2V (20 MHz or less)**
PROGRAMMER	SerialUPDI – 230400 baud

03 Upload the example

Open **LED_example.ino**. Choose **Sketch → Upload Using Programmer**.

POWER: use side **VCC + GND**—never the 5V pin. Recommended maximum: **20 V**.

FULL GUIDE + EXAMPLE CODE

github.com/user-will/cursedPCB

ARDUINO IDE: ARDUINO.CC

CURSED PCB ATTINY412 / SETUP

STOP

Set up Arduino before uploading.

Use a USB-C **data** cable.

01 Install megaTinyCore

Scan the QR for the Boards Manager URL. Install **megaTinyCore** by Spence Konde.

LED LIBRARY INCLUDED

02 Choose these settings

BOARD ATtiny412/402/212/202 **without Optiboot**

CLOCK 20 MHz internal

BOD VOLTAGE **4.2V (20 MHz or less)**

PROGRAMMER SerialUPDI – 230400 baud

03 Upload the example

Open **LED_example.ino**. Choose **Sketch → Upload Using Programmer**.

POWER: use side **VCC + GND**—never the 5V pin. Recommended maximum: **20 V**.

FULL GUIDE + EXAMPLE CODE

github.com/user-will/cursedPCB

ARDUINO IDE: ARDUINO.CC

CURSED PCB ATTINY412 / SETUP

STOP

Set up Arduino before uploading.

Use a USB-C **data** cable.

01 Install megaTinyCore

Scan the QR for the Boards Manager URL. Install **megaTinyCore** by Spence Konde.

LED LIBRARY INCLUDED

02 Choose these settings

BOARD ATtiny412/402/212/202 **without Optiboot**

CLOCK 20 MHz internal

BOD VOLTAGE **4.2V (20 MHz or less)**

PROGRAMMER SerialUPDI – 230400 baud

03 Upload the example

Open **LED_example.ino**. Choose **Sketch → Upload Using Programmer**.

POWER: use side **VCC + GND**—never the 5V pin. Recommended maximum: **20 V**.

FULL GUIDE + EXAMPLE CODE

github.com/user-will/cursedPCB

ARDUINO IDE: ARDUINO.CC

CURSED PCB ATTINY412 / SETUP

STOP

Set up Arduino before uploading.

Use a USB-C **data** cable.

01 Install megaTinyCore

Scan the QR for the Boards Manager URL. Install **megaTinyCore** by Spence Konde.

LED LIBRARY INCLUDED

02 Choose these settings

BOARD ATtiny412/402/212/202 **without Optiboot**

CLOCK 20 MHz internal

BOD VOLTAGE **4.2V (20 MHz or less)**

PROGRAMMER SerialUPDI – 230400 baud

03 Upload the example

Open **LED_example.ino**. Choose **Sketch → Upload Using Programmer**.

POWER: use side **VCC + GND**—never the 5V pin. Recommended maximum: **20 V**.

FULL GUIDE + EXAMPLE CODE

github.com/user-will/cursedPCB

ARDUINO IDE: ARDUINO.CC

CURSED PCB ATTINY412 / SETUP

STOP

Set up Arduino before uploading.

Use a USB-C **data** cable.

01 Install megaTinyCore

Scan the QR for the Boards Manager URL. Install **megaTinyCore** by Spence Konde.

LED LIBRARY INCLUDED

02 Choose these settings

BOARD ATtiny412/402/212/202 **without Optiboot**

CLOCK 20 MHz internal

BOD VOLTAGE **4.2V (20 MHz or less)**

PROGRAMMER SerialUPDI – 230400 baud

03 Upload the example

Open **LED_example.ino**. Choose **Sketch → Upload Using Programmer**.

POWER: use side **VCC + GND**—never the 5V pin. Recommended maximum: **20 V**.

FULL GUIDE + EXAMPLE CODE

github.com/user-will/cursedPCB

ARDUINO IDE: ARDUINO.CC

CURSED PCB ATTINY412 / SETUP

STOP

Set up Arduino before uploading.

Use a USB-C **data** cable.

01 Install megaTinyCore

Scan the QR for the Boards Manager URL. Install **megaTinyCore** by Spence Konde.

LED LIBRARY INCLUDED

02 Choose these settings

BOARD ATtiny412/402/212/202 **without Optiboot**

CLOCK 20 MHz internal

BOD VOLTAGE **4.2V (20 MHz or less)**

PROGRAMMER SerialUPDI – 230400 baud

03 Upload the example

Open **LED_example.ino**. Choose **Sketch → Upload Using Programmer**.

POWER: use side **VCC + GND**—never the 5V pin. Recommended maximum: **20 V**.

FULL GUIDE + EXAMPLE CODE

github.com/user-will/cursedPCB

ARDUINO IDE: ARDUINO.CC

CURSED PCB ATTINY412 / SETUP

STOP

Set up Arduino before uploading.

Use a USB-C **data** cable.

01 Install megaTinyCore

Scan the QR for the Boards Manager URL. Install **megaTinyCore** by Spence Konde.

LED LIBRARY INCLUDED

02 Choose these settings

BOARD ATtiny412/402/212/202 **without Optiboot**

CLOCK 20 MHz internal

BOD VOLTAGE **4.2V (20 MHz or less)**

PROGRAMMER SerialUPDI – 230400 baud

03 Upload the example

Open **LED_example.ino**. Choose **Sketch → Upload Using Programmer**.

POWER: use side **VCC + GND**—never the 5V pin. Recommended maximum: **20 V**.

FULL GUIDE + EXAMPLE CODE

github.com/user-will/cursedPCB

ARDUINO IDE: ARDUINO.CC

CURSED PCB ATTINY412 / SETUP

STOP

Set up Arduino before uploading.

Use a USB-C **data** cable.

01 Install megaTinyCore

Scan the QR for the Boards Manager URL. Install **megaTinyCore** by Spence Konde.

LED LIBRARY INCLUDED

02 Choose these settings

BOARD ATtiny412/402/212/202 **without Optiboot**

CLOCK 20 MHz internal

BOD VOLTAGE **4.2V (20 MHz or less)**

PROGRAMMER SerialUPDI – 230400 baud

03 Upload the example

Open **LED_example.ino**. Choose **Sketch → Upload Using Programmer**.

POWER: use side **VCC + GND**—never the 5V pin. Recommended maximum: **20 V**.

FULL GUIDE + EXAMPLE CODE

github.com/user-will/cursedPCB

ARDUINO IDE: ARDUINO.CC