



Set up Arduino before uploading.

Use a USB-C **data** cable.

01 Install megaTinyCore

Scan the QR for the Boards Manager URL. Install **megaTinyCore** by Spence Konde.

LED LIBRARY INCLUDED

02 Choose these settings

BOARD	ATtiny412/402/212/202 without Optiboot
CLOCK	20 MHz internal
BOD VOLTAGE	4.2V (20 MHz or less)
PROGRAMMER	SerialUPDI – 230400 baud

03 Upload the example

Open **LED_example.ino**. Choose **Sketch → Upload Using Programmer**.

POWER: use side **VCC + GND**—never the 5V pin. Recommended maximum: 20 V.



FULL GUIDE + EXAMPLE CODE

[github.com/user-will/
cursedPCB](https://github.com/user-will/cursedPCB)

ARDUINO IDE: ARDUINO.CC