STOP

Set up Arduino before uploading.

Use a USB-C **data** cable.

01 Install megaTinyCore

Arduino IDE → Preferences → **Additional Boards Manager URLs:**

```
http://drazzy.com/
package_drazzy.com_index.json
```

Boards Manager: install **megaTinyCore** by Spence Konde.
LED library included.

02 Choose these settings

BOARD	ATtiny412/402/212/202 **without Optiboot**
CLOCK	20 MHz internal
BOD VOLTAGE	**4.2V (20 MHz or less)**
PROGRAMMER	SerialUPDI – 230400 baud

03 Upload the example

Open **LED_example.ino**. Choose **Sketch → Upload Using Programmer**.

Power the board using the side **VCC** pin with up to **20V**. Supplying raw voltage to the **5V** pin may cause damage.

FULL GUIDE + EXAMPLE CODE
github.com/user-will/cursedPCB

Reil