



Set up Arduino before uploading.

This is not a standard Arduino board. Use a USB-C **data** cable.

01 Install megaTinyCore

Arduino IDE → Preferences → Additional Boards Manager URLs:

```
http://drazzy.com/  
package_drazzy.com_index.json
```

Then open Boards Manager, search **megaTinyCore**, and install the newest version by Spence Konde.

LED LIBRARY INCLUDED — no separate download needed.

megaTinyCore automatically installs the required **tinyNeoPixel_Static** library.

02 Connect + choose settings

BOARD	ATtiny412/402/212/202 without Optiboot
CLOCK	20 MHz internal
BOD VOLTAGE	4.2V (20 MHz or less)
PROGRAMMER	SerialUPDI - 230400 baud

03 Upload the example

Open **LED_example.ino**. Choose **Sketch → Upload Using Programmer**—not the regular Upload command.

FULL GUIDE + EXAMPLE CODE
github.com/user-will/cursedPCB →