

PW-2200 electric pressure washer: care and parts

Specifications

- Maximum pressure: 2,200 PSI.
- Water flow: 6.4 litres per minute.
- Electric motor: 1,800 W. Plug into an outdoor outlet with a GFCI (ground-fault) protection.
- High-pressure hose: 8 m.

Before each use

Connect the garden hose and turn the water on fully before you start the motor.

Check the hose and the trigger gun for leaks.

Using it safely

Never run the pressure washer for more than 2 minutes with the trigger released: the pump overheats.

Never point the spray at people, animals or electrical outlets.

Use only detergents sold for pressure washers.

Winter storage

Drain all water from the pump and hoses before temperatures fall below 0 °C.

Store it indoors, above 0 °C. Frost damage is not covered by the warranty.

Troubleshooting

- Pressure pulses up and down: clean the inlet filter and check that the water tap is fully open.
- Motor hums but does not start: release the trigger, wait 2 minutes, try again.

Parts and part numbers

Part	Part number	Notes
Pump kit	PK-2200-07	fits the PW-2200 only
Nozzle set (0°, 15°, 25°, 40° and soap)	NZ-415	fits the PW-2200 and PW-2400
High-pressure hose, 8 m	HS-2208	
Trigger gun	TG-22	
O-ring kit	OR-12	

Warranty

See the Larkfield warranty policy for the warranty periods of pressure washers and their parts.