

PvAttrEnumSet

Set the value of an enumeration attribute.

Prototype

Parameters

Camera Handle to open camera.

Name Attribute name.

Value The enumeration value (a null terminated string).

Return Value

tPvErr type error code. Typical error codes for this function:

ePvErrSuccess Function successful.

ePvErrOutOfRange The value is not a member of the current enumeration

set.

ePvErrForbidden The attribute cannot be set at this time.

ePvErrNotFound The attribute does not exist.

ePvErrWrongType The attribute is not an enumeration type.