

ESC Connector Pinout Reference Table

This table was redrawn from the supplied ESC connector image to improve readability. Verify row 5 of the 2 x 8 connector against the original ESC manual if exact wording is required.

ESC Connector Pinout Table

2 × 8 Connector			
Port	Function definition	Code	Voltage
1	throttle power		5V
2	throttle GND		0V
3	throttle signal		0~5V
4	3 gear	PA0	0~5V
5	repair/safe boost	PC15	0~5V
6	P gear	PC14	0~5V
7	Line output	PB9	0~5V
8	high brake	PB5	0~12V
9	electric door lock		40V~B+
10	UART-TX		0~5V
11	UART-RX		0~5V
12	R gear	PA11	0~5V
13	1 gear	PB2	0~5V
14	GND		0V
15	S gear	PB3	0~5V
16	low brake	PB4	0~5V

2 × 3 Connector		
Port	Function definition	Voltage
1	hall signal A	0~5V
2	hall signal B	0~5V
3	hall signal C	0~5V
4	hall power	5V
5	motor temp signal	0~5V

2 × 4 Connector			
Port	Function definition	Code	Voltage
1	GND		0V
2	JTCK		0~5V
3	SWD		0~5V
4	5V input		0~5V
5	anti-theft power		B+
6	anti-theft electric door lock		40V~B+
7	push signal		0V~B+
8	anti-theft signal	PA12	0~5V

Note: This table was redrawn manually from the supplied low-resolution image. Row 5 of the 2×8 connector is interpreted as "repair/safe boost"; please verify against the original ESC manual if exact wording is required.