## VP-45: SUPERUSER (pg 1 of 2)

Time: N/A

Purpose: To allow any protected parameter to be edited

## **CAUTION!**

DO NOT Edit System Rev. Parameter 1.1.

- 1. Verify that display date is correct.
  - SYSTEM
  - DATE
  - EXIT
  - EXIT
- 2. Determine Superuser Access Code Number for today.

3. Enter Superuser:

## **CAUTION!**

DO NOT give access numbers to the customer!

- (decimal key)
- Enter Access Code.
- (decimal key)
  [(SUPER) is displayed beside READY.]

**VP-45:** Superuser

- 4. Perform edits as required.
- 5. Exit Superuser:
  - a. Repeat step #3.b. Wait approximately 1 minute.
- 6. Return to READY menu.

Verification Procedures
 LCx<sup>®</sup> Analyzer Service Manual (Text P/N 47278-102)

Superuser Codes chart

Chapter Manual
Contents Contents

CD Main Screen Index

5 - 85

VP-45: Superuser (pg 2 of 2)

## **Superuser Codes**

Instructions: Select the code that corresponds to the day of the month.

Enter the code using the numeric keypad.

Format: Use this format: .nnnn. Example: On March 29, enter .2988.

Day	Code								
1	7121	7	1210	13	0424	19	3511	25	2935
2	4103	8	5030	14	6109	20	0112	26	8614
3	1222	9	1706	15	7220	21	1999	27	7387
4	6211	10	6971	16	0612	22	7230	28	1020
5	9171	11	5121	17	0224	23	3624	29	2988
6	0924	12	0706	18	9001	24	4784	30	2328
								31	8421

5	Verification Procedures	VP-45: Superuser	5 - 86
	LCx® Analyzer Service Manual (Text P/N 47278-102)		

Chapter	Manual	CD Main	Index	
Contents	Contents	Screen		